

AN11153

DMX512/RDM slave using LPC111x

Rev. 1 — 1 February 2012

Application note

Document information

Info	Content
Keywords	LPC1110FD20; LPC1111FDH20; LPC1111FHN33; LPC1112FD20; LPC1112FDH20; LPC1112FDH28; LPC1112FHN33; LPC1112FHI33; LPC1113FHN33; LPC1113FBD48; LPC1114FDH28; LPC1114FN28; LPC1114FHN33; LPC1114FHI33; LPC1114FBD48; LPC1115FBD48; LPC111x, ARM, Cortex M0, DMX, DMX512, RDM, Architectural Lighting, Entertainment Lighting
Abstract	This application note describes the use of the NXP LPC111x Cortex M0 microcontroller to create an RDM enabled DMX512 Slave.



Revision history

Rev	Date	Description
1	20120201	Initial version.

Contact information

For more information, please visit: <http://www.nxp.com>

For sales office addresses, please send an email to: salesaddresses@nxp.com

1. Document purpose

The purpose of this document is to explain the NXP DMX512/RDM slave demoboard design. Both hardware and software are described in detail.

This document is intended for technical persons, such as system architects and hardware/software engineers, interested in designing/developing a DMX512 slave using an NXP microcontroller.

2. Introduction

The DMX512 slave or DMX512 receiver is an example implementation for an RDM enabled DMX512 device built around the NXP LPC111x Cortex M0 microcontroller. The DMX512 slave features four DMX controllable LEDs, a red heartbeat LED, a green traffic LED, DIP switches for selecting the DMX start address, a 5-position joystick, and an optional LCD. The UART and the 16-bit timer/counters of the LPC111x MCU are the main hardware blocks needed to implement the DMX512 slave. The I²C hardware block is used to interface with the (optional) LCD functionality.

References in this document to DMX512 refer to DMX512-A, since both hardware and software are designed using the latest standard^[1].

The software can be built with

- LPCXpresso v4.1.0_190, and
- IAR Embedded Workbench for ARM v6.20.4.



Fig 1. DMX512 slave

3. DMX512 slave hardware

3.1 Physical layer

The schematic of the physical DMX layer is depicted in Fig 2.




Fig 2. DMX512 physical layer

The DMX bus connects to DATA+ and DATA- of DMX-IN and DMX-OUT. DMX-IN is a 5-pole male XLR receptacle. DMX-OUT is a 5-pole female XLR receptacle. A 3-pin spare connector (not mounted) is available for other form factors. IC3 is an RS-485/RS422 transceiver, providing 15 kV ESD protection.

The physical layer is electrically isolated from the DMX bus. The RX, TX and DIR signals from the microcontroller are optically isolated with high-speed optocouplers, and the supply for the optocouplers and bus transceiver are provided via the isolated DC/DC convertor (DC1). During startup the IO pins of the micro are high, and FET Q2 is used as an inverter to switch the DIR of IC3 to receive mode to avoid unwanted driving of the DMX bus.

3.2 Microcontroller

The schematic of the microcontroller is depicted in Fig 3.




Fig 3. Microcontroller on DMX512 slave

The system is built around NXP's new LPC1114 device, which is a Cortex-M0 running at frequencies of up to 50 MHz. Included are 32 kB on-chip flash, 8 kB SRAM, SSP, I²C, UART, ADC, etc.

Debugging and flashing connection is provided by means of header SWD, which complies with the 10-pin SWD standard as supported by many flash and software tools.

The RESET button can be used to reset the microcontroller.
 A 4-channel DIP switch is added to support diversity.
 Two LEDs are provided, one red and one green.

3.3 User interface

The schematic of the user interface is depicted in [Fig 4](#).




Fig 4. User interface on DMX512 slave

The I²C alpha-numeric, 2x16 character LCD display is used to give feedback to the user. User commands can be entered with 5-way navigation switch S2.

3.4 LED interface and local LED feedback

The DMX512 slave board delivers four PWM signals to an external light source (e.g., LED) on the LEDS_OUT plug.




Fig 5. RGBW LED PWM output

The red, green, blue and white PWM signals are also connected to four corresponding on-board LEDs. The LEDs are placed in a circle, close to each other. When a diffuser is attached (not provided), the colors can be combined to form a single color. If the local feedback is not desired, it can be disabled with jumper LEDES_ENABLE.

3.5 Extension interface

The DMX512 slave board also has an extension plug with system power, ground, I²C bus and RESET signal.




Fig 6. I²C extension plug

3.6 System power

The schematic of the power supply is depicted in [Fig 7](#).




Fig 7. Power circuit of DMX512 slave

A standard USB-mini-B plug is used to connect the 5 V system power. The ON LED illuminates when USB power is provided.

Note: IC2 (SA57000-33D) is pin-compatible with the LP3985IM5-3.3 device.

3.7 Board layout

The layout of the board (5.95" x 3.75") is shown in [Fig 8](#).




Fig 8. Board layout of DMX512 slave

On the left are the DMX-OUT and DMX-IN receptacles. On the top-left is the (not mounted) DMX extension plug. The left part of the board is electrically isolated from the right part on the division line through the middle of the optocouplers and the DC/DC convertor.

The LCD display is at the top; below left are the two LEDs and below right is the navigation switch.

In the circle are the four PWM-controlled LEDs, and to the right are the DIP switches and the microcontroller. At the bottom right are the RESET switch and the SWD interface.

At the bottom are the USB power plug, the PWM LEDs outputs and the extension plug.

Table 1. DMX512 slave parts list

Part	Value	Device	Package	Farnell	Description
RESET	B3S1000	B3S1000	B3XS	177807	6.2 mm x 6.5 mm TACT Switch (SMD)
Q2	BSH105	BSH105	SOT23	1758066	N-channel enhancement mode MOS transistor
D11	BTHQ21605V-COG-FSRE-I2C	BTHQ21605V-COG-FSRE-I2C	LCD_I2C	1220409	Batron I2C LCD Module, alphanumeric, 2X16
C10	100n	C0805	P0805		Capacitor
C13	100n	C0805	P0805		Capacitor
C14	100n	C0805	P0805		Capacitor
C15	100n	C0805	P0805		Capacitor
C19	100n	C0805	P0805		Capacitor
C20	100n	C0805	P0805		Capacitor
C21	100n	C0805	P0805		Capacitor
C24	100n	C0805	P0805		Capacitor
C25	100n	C0805	P0805		Capacitor
C5	100n	C0805	P0805		Capacitor
C9	100n	C0805	P0805		Capacitor
C17	180n	C0805	P0805		Capacitor
C16	1u	C0805	P0805		Capacitor
C18	1u	C0805	P0805		Capacitor
C22	220n	C0805	P0805		Capacitor
C23	220n	C0805	P0805		Capacitor
C7	220n	C0805	P0805		Capacitor
C3	22p	C0805	P0805		Capacitor
C4	22p	C0805	P0805		Capacitor
C6	2u2	C0805	P0805		Capacitor
C8	2u2	C0805	P0805		Capacitor
C1	4u7	C0805	P0805		Capacitor
C11	4u7	C0805	P0805		Capacitor
C12	4u7	C0805	P0805		Capacitor
C2	4u7	C0805	P0805		Capacitor
Q1	AKER-C3E-12MHz	CRYSTAL4	XTAL4	1640974	Crystal, 2.5 mm x 3 mm
DIR	FOD060L	FOD060L	SOIC08	1228309	Fairchild Opto Coupler, 3V3, high-speed, 10 Mbit/s
RX	FOD060L	FOD060L	SOIC08	1228309	Fairchild Opto Coupler, 3V3, high-speed, 10 Mbit/s
TX	FOD060L	FOD060L	SOIC08	1228309	Fairchild Opto Coupler, 3V3, high-speed, 10 Mbit/s
SWD	FTSH-105-DV	FTSH-105-DV	127_2R10_SMT	1767036	Samtec connector, 10-way

Part	Value	Device	Package	Farnell	Description
LEDS_ENABLE	JP1E	JP1E	JP1		JUMPER
L1	BLM18AG601S	L0603	P0603		Inductor
L2	BLM18AG601S	L0603	P0603		Inductor
L3	BLM18AG601S	L0603	P0603		Inductor
IC1	LPC1114FBD48/301	LPC1113/14-LQFP48	LQFP48	1786289	NXP Semiconductors, Cortex-M0 MCU, 32-bit
L4	10uH	L-USL1812	L1812	1174073	INDUCTOR, American symbol
S1	MCDHN-4F-T-V	MCDHN-4F-T-V	DIP4	1605479	DIP Switch SMD, 4-way
DMX-OUT	NC5FAH	NC5FAH	NC5FAH	8020418	Neutrik Audio Connector XLR SERIES
DMX-IN	NC5MAH	NC5MAH	NC5MAH	8020396	Neutrik Audio Connector XLR SERIES
DC1	NKE0303SC	NME	NME	1175765	DC-DC CONVERTER
W	OVS-0801 (W)	OVS-0801(W)	CHIPLED_0805	1716764	Chip LED 0805
B	OVS-0803 (B)	OVS-0803(B)	CHIPLED_0805	1716765	Chip LED 0805
ON	OVS-0803 (B)	OVS-0803(B)	CHIPLED_0805	1716765	Chip LED 0805
G	OVS-0804 (G)	OVS-0804(G)	CHIPLED_0805	1716766	Chip LED 0805
LED2	OVS-0804 (G)	OVS-0804(G)	CHIPLED_0805	1716766	Chip LED 0805
LED1	OVS-0808 (R)	OVS-0808(R)	CHIPLED_0805	1716768	Chip LED 0805
R	OVS-0808 (R)	OVS-0808(R)	CHIPLED_0805	1716768	Chip LED 0805
EXT	nc	PINHD-1X5	1X05		PIN HEADER
LEDS_OUT	nc	PINHD-1X6	1X06		PIN HEADER
R22	100E	R0805	P0805		Resistor
R15	10k	R0805	P0805		Resistor
R16	10k	R0805	P0805		Resistor
R17	10k	R0805	P0805		Resistor
R18	10k	R0805	P0805		Resistor
R20	10k	R0805	P0805		Resistor
R21	10k	R0805	P0805		Resistor
R5	10k	R0805	P0805		Resistor
R6	10k	R0805	P0805		Resistor
R8	150E	R0805	P0805		Resistor
R1	1k	R0805	P0805		Resistor
R2	1k	R0805	P0805		Resistor
R35	1k5	R0805	P0805		Resistor
R10	390E	R0805	P0805		Resistor
R14	390E	R0805	P0805		Resistor
R7	390E	R0805	P0805		Resistor
R9	390E	R0805	P0805		Resistor
R11	3k3	R0805	P0805		Resistor
R12	3k3	R0805	P0805		Resistor

Part	Value	Device	Package	Farnell	Description
R13	3k3	R0805	P0805		Resistor
R23	3k3	R0805	P0805		Resistor
R19	47k	R0805	P0805		Resistor
R3	560E	R0805	P0805		Resistor
R4	560E	R0805	P0805		Resistor
IC2	SA57000-33D	SA57000-33D	SOT23-5	1826832	CapFREE 150 mA, low-noise, low-drop regulator
S2	SKQUDBE010	SKQUDBE010	JOYSTICK	1435776	Joystick, 4-directions with center push, SKQU
IC3	SP3075EEN-L	SP3075EEN-L	SO08	9386688	RS-485/RS422 transceivers
TP1	TPSPAD1-13	TPSPAD1-13	P1-13		TEST PIN
TP2	TPSPAD1-13	TPSPAD1-13	P1-13		TEST PIN
X5	USB-MB-SMD	USB-MB-SMD	USB-MB-SMD	1654060	MINI USB-B connector
DMX	nc	W237-103	W237-103		WAGO SCREW CLAMP

4. DMX512 slave software

This section first describes the software architecture and the main software execution flow. The second part of this section explains the software structure in more detail.

4.1 Architecture

The software of the DMX512 slave has a modular architecture, meaning that each hardware block has its own software driver. To keep the memory footprint of the firmware as small as possible, the software running on the DMX512 slave does not incorporate a Real Time Operating System. The software is written in the “C” programming language. Functionality can be easily enabled or disabled before building the software, such as support of the local LCD and support of RDM (see [Section 4.9](#)), in order to get a smaller flash memory footprint. When RDM support is enabled, bidirectional communication will be used between the DMX512 master and the DMX512 slave. [Fig 9](#) shows the architectural block diagram.




Fig 9. Software architecture of DMX512 slave

4.2 Main software execution flow

[Fig 10](#) shows the flowchart of the DMX512 slave software. The DMX slave init is described in [Section 4.4](#). The following described actions are repeated until the DMX512 slave is powered down or reset.

The main loop starts with reading a DMX512 packet from the DMX transmission line. This is done by calling the function `Uart_RecvDmxSlotValues()`. This read action times out after one second, being the maximum time between two successive DMX512 packets, when no data is received. This timeout could be caused by the DMX512 master being powered down or disconnected from the DMX transmission line, the DMX512 slave being disconnected from the DMX transmission line, the transmission line being broken, or a hardware conflict on the DMX transmission line.

When a timeout occurs the four DMX controlled LEDs are turned OFF, and the text “No packets from DMX512 master” is shown on the LCD. This text is removed from the LCD as soon as a DMX512 NULL START packet is received.

When the read action is successful the GREEN traffic LED is toggled. The traffic LED is an indication of how many DMX512 packets are received per second: slow blinking means low traffic; fast blinking means high traffic; no blinking means no traffic or the receiving circuit of DMX512 slave is broken. Then the DMX512 start code (also called slot 0, or the first byte of the packet) is checked to be a NULL START code (hexadecimal 0x00), the Alternate START code 23 (hexadecimal 0x17) indicating an ASCII Text packet, or the START code 204 (hexadecimal 0xCC) indicating a RDM packet. The received slot data from the NULL START code packet is used to drive the four DMX controllable LEDs (dimnable from 0 % to 100 %).

When no new data is received for one or more of the DMX controlled LEDs, because the DMX transmission didn't include these slots, these LEDs are turned OFF. When none of the four DMX controllable LEDs is addressed with a NULL START code packet, the text “Not addressed by DMX512 master” is shown on the LCD. If the example software is built without RDM support, the position of the DIP switches is read again, to determine which DMX slots (channels) the DMX512 slave will listen to; the DMX512 slave does not need a power down/up or reset to let it listen to other DMX slots.

When an ASCII text packet is received, the first 32 characters of this message are displayed on the LCD. When an RDM packet is received, it will only be handled when it is addressed to this DMX512 slave, or when it is a broadcast message (see [Section 4.3](#) for more details).

The last action in the main loop is triggering the WatchDog Timer (WDT). If the WDT isn't triggered for six seconds (this should never happen because of the one second read timeout), the DMX512 slave will be reset, resulting in the start message being shown on the LCD.




Fig 10. Flowchart of DMX512 slave software

4.3 RDM

The Remote Device Management (RDM) protocol^[3] permits intelligent bidirectional communication between a DMX512 master and a DMX512 slave. RDM enables DMX device discovery (when connected to the DMX transmission line) plus management and control of the DMX device. Examples of RDM messages (control packets) are: change (set) DMX start address, get DMX device state info (e.g., lamp burning hours, power cycles, etc), RDM device self test, etc. This DMX512 slave illustrates the mandatory RDM messages. Extension of the supported RDM messages is very easy with our example software implementation.

RDM has only six command classes (see [Table 2](#)) in which the RDM packets can be grouped.

Table 2. RDM command class defines

RDM command classes	Value
DISCOVERY_COMMAND	0x10
DISCOVERY_COMMAND_RESPONSE	0x11
GET_COMMAND	0x20
GET_COMMAND_RESPONSE	0x21
SET_COMMAND	0x30
SET_COMMAND_RESPONSE	0x31

[Table 3](#) shows the implemented RDM packets and the command class to which they belong.

Table 3. Implemented RDM packets

Discovery class	Get class	Set class	RDM PID	Value
•			DISC_UNIQUE_BRANCH	0x0001
•			DISC_MUTE	0x0002
•			DISC_UN_MUTE	0x0003
	•		DEVICE_INFO	0x0060
	•		SOFTWARE_VERSION_LABEL	0x00C0
	•	•	DMX_START_ADDRESS	0x00F0
	•	•	IDENTIFY_DEVICE	0x1000

Each RDM device has a 48-bit unique device ID or UID; the most significant 16-bits are reserved for the manufacturer ID. Example software described in this manual uses the NXP RDM manufacturer ID hexadecimal 0x3B10, given by the following formula:

$$\#define MAN_ID ((32*32*('N'-'@')) + (32*('X'-'@')) + ('P'-'@'))$$

Any NXP customer that wants to create an RDM enabled DMX device should apply for (and use) its own manufacturer ID at PLASA^[4].

4.3.1 Device discovery

For the DMX512 master to be able to send RDM packets to specific RDM devices, the DMX512 master must first discover the UIDs of the RDM devices connected to the DMX transmission line. This is done by the discovery process, driven by the DMX512 master or a host (PC) that controls the DMX512 master. This discovery process makes use of a binary search mechanism to search over the total 48-bit address range. An RDM device should only handle an RDM packet when this packet is addressed to this RDM device (its own UID), or when it is a broadcast message. The RDM device shall only send a response packet to the DMX512 master when the RDM packet was addressed to its own UID, or when its UID was in the lower bound and upper bound UID range of the DISC_UNIQUE_BRANCH RDM packet. Responding on the DISC_UNIQUE_BRANCH RDM packet is the only time that collisions might take place on the DMX transmission line. When an RDM device is uniquely identified during the discovery process, it is muted by sending a DISC_MUTE RDM packet to this RDM device; this keeps it from interfering with the discovery process (sending back responses to the DMX512 master) when the search for other RDM devices is continued. For a full discovery, the discovery process will start by un-muting all RDM devices by sending a DISC_UN_MUTE RDM broadcast message. An RDM broadcast message is identified by the 48-bit destination UID having the hexadecimal value 0xFFFFFFFFFFFF.

After the discovery process has finished, the DMX512 master can get the device info, software version label, DMX start address, and identify state of the DMX512 slave. Furthermore, the DMX512 master can assign another DMX start address to the DMX512 slave, and it can ask the slave to identify itself. The new DMX start address is not permanently stored in some NVM, meaning that after a power cycle or reset the DMX512 slave will have its default DMX address as defined by the setting of the DIP switches. When the DMX512 slave receives the RDM packet IDENTIFY_DEVICE with parameter IDENTIFY_ON, it will turn ON the four DMX controllable LEDs (100 %) and the text “**You found me ☺**” is shown on the LCD. After receiving the RDM packet IDENTIFY_DEVICE with parameter IDENTIFY_OFF, the four DMX controllable LEDs will be turned OFF, and the LCD is cleared. Disconnecting the DMX512 slave from the DMX transmission line while its identify state is IDENTIFY_ON will NOT turn OFF the four LEDs and the identify text is NOT removed from the LCD.

For more info on Remote Device Management see [Reference \[3\]](#).

4.4 Initialization sequence

When the LPC111x microcontroller starts up (as a result of the DMX512 slave being powered), the stack pointer is loaded with the value from address 0:3, and the program counter is loaded with the value from address 4:7 (the address of the reset handler). This will result in the calling of main().

The function main() implements an infinite loop which receives data from the DMX transmission line, drives the LEDs, and the (optional) LCD. Before the infinite loop is entered the function SystemInit() is called, which sets up the main PLL that is used to set the proper CPU clock, as configured by LPC_CORE_CLOCKSPEED_HZ in 'app_config.h'. Function SystemInit() comes with CMSIS.

After calling SystemInit() the function bsp_init() is called. This function sets up the system tick counter to 1000 ticks per second; it enables the HW blocks GPIO / I2C / CT16B0 / CT16B1 / CT32B0 / UART / WDT; it configures the LPC pins for controlling the LEDs / dip switches / UART pins / I2C pins / etc.; and it initializes the PWM counter_timer driver, DMX UART driver, I2C driver, LCD driver and WDT driver. Then init_globals() is

called which reads out the DIP switches and determines the DMX start address of the DMX512 slave. The four DIP switches are used to select 1 of 16 DMX slot ranges. Each range covers (512 / 16 =) 32 slots; the last four slots are used to address the four DMX controllable LEDs.

Table 4. Dip switch translation into DMX512 slave address

Dip switch setting	DMX512 slave address (and slot usage)
0	DMX slave address = 29 This means: Slot[29] = Red LED Slot[30] = Green LED Slot[31] = Blue LED Slot[32] = White LED
x	DMX slave address = (x * 32) + 29 This means: Slot[(x*32)+29] = Red LED Slot[(x*32)+30] = Green LED Slot[(x*32)+31] = Blue LED Slot[(x*32)+32] = White LED
15	DMX slave address = 509 This means: Slot[509] = Red LED Slot[510] = Green LED Slot[511] = Blue LED Slot[512] = White LED

When built with RDM support, this DMX address can be changed via RDM. After calling `init_globals()` the DMX controlled LEDs are switched ON so that the user can check that they are working; in addition, the text “**NXP LPC1114 DMX512 slave**” is shown on the LCD. After this the main loop is entered.

4.5 DMX UART driver

The UART driver is specially written for receiving/transmitting DMX/RDM packets from/to the DMX transmission line. A DMX packet always starts with a “Break” (the only exception being the response on a `DISC_UNIQUE_BRANCH` packet), TX line being low for at least 92 micro seconds, followed by a “Mark”, TX line being high for at least 12 micro seconds. See [Reference \[1\]](#) for more detailed information on DMX timing. This sequence indicates the start of the DMX packet. The bytes following the synchronization header have the structure of one start bit, eight data bits, no parity bits, and two stop bits, making it a total of 11 bits per data byte. The first byte is the start byte (or slot 0) and is followed by up to 512 bytes (slot 1 up till slot 512). The slots are also referred to as channels, so a maximum of 512 channels can be driven by the DMX packet (slot 0 is used for the type of packet indication). Slot 1 is channel 1, slot 2 is channel 2, up to 512. The transmission speed is fixed at 250 kbit/s (+/- 2 %).

The UART driver is initialized by the BSP. Since the communication settings (baud rate, parity, etc) are fixed for DMX, the function `Uart_Init()` does not have parameters for this in its arguments list. Function `Uart_Init()` takes care for initializing the variables used within the UART driver, initializes the UART hardware block, claims a milliseconds counter (to be used for timeout purposes) via the BSP, and enables the UART receive data IRQ. The UART driver uses double buffering (two internal byte arrays of 513 bytes each) for

receiving slot 0 up till slot 512 from the DMX transmission line. When one buffer is filled with received slot values, a pointer to this buffer is passed back to the DMX512 slave application while continuing to receive and store new slot values in the other buffer. The next time a buffer is full, a pointer to this buffer is passed back to the DMX512 slave application, preventing any unnecessary data copies.

The received slot values are stored in the buffers by the UART interrupt handler. In the case of a NULL START packet the application can select the channels from these buffers in which it is interested (depending on its DMX address), for dimming the LEDs. In the case of an ASCII text packet, the buffer holds the complete text packet (maximum 510 characters including the terminating zero). In the case of an RDM packet, the buffer holds the complete RDM packet.

4.6 PWM counter/timer driver

The DMX512 slave uses two 16-bit counter/timers to drive the four RGBW LEDs; each counter/timer drives two LEDs using three of the four available match registers per CT to create a Pulse Width Modulation signal to steer the LEDs.

For CT16B0, the output of match register 0 is used for driving the RED LED (PWM mode); the output of match register 1 is used for driving the GREEN LED (PWM mode); and match register 3 is used for setting the frequency for the RED and GREEN LEDs.

For CT16B1, the output of match register 0 is used for driving the BLUE LED (PWM mode); the output of match register 1 is used for driving the WHITE LED (PWM mode); and match register 3 is used for setting the frequency for the BLUE and WHITE LEDs. The PWM frequency of all four LEDs is taken from the same define PWM_FREQ with a value of 733 Hz.

The counter/timer driver exports three functions; only two are used in the DMX512 slave software. The BSP calls the function Timer_PWM_Init() for the hardware blocks CT16B0 and CT16B1. This initialization function programs the registers of the requested counter/timer and sets an initial pulse width duty cycle of 50 %.

The second function used in this counter/timer driver is Timer_PWM_Set_Duty_Cycle(), which is called from the main loop when a NULL START packet is received. A linear transformation is used from slot value into duty cycle, so a slot value of 0 corresponds with a duty cycle of 0 %, a slot value of 5 corresponds with a duty cycle of 2 %, and a slot value of 250 up to 255 corresponds with a duty cycle of 100 %.

4.7 Interrupts

The LPC111x microcontroller has four interrupt priority levels, where 0 is the highest and 3 the lowest priority level. [Table 5](#) shows the interrupts that are handled by the software, the interrupt priority of each interrupt, and between brackets the actual interrupt priority level.

Table 5. Used interrupts and assigned priorities in DMX512 slave software

Interrupt	Priority	Description
I2C_IRQn	Highest (1)	Generated by the I2C HW block. Used for writing text to the LCD panel.
UART_IRQn	Middle (2)	Generated by the UART HW block. Used for transmitting/receiving data to/from the DMX transmission line.
TickHandler	Lowest (3)	Generated by the systick timer. Used for implementing software timers.

The TickHandler is called every millisecond to increment millisecond counters that are used by the application. After each second the TickHandler toggles the RED heartbeat LED. The millisecond counters overflow after 2^32 milliseconds (1193 hours = 49 days).

4.8 Software source code files

The software tree holding the source code files of the DMX512 slave is shown in [Fig 11](#). All DMX512 slave source code is contained in the directory LPC111xSlave. The files “.cproject” and “.project” are LPCXpresso project files; the files LPC111xDMXslave.*” are IAR EWARM project files.




Fig 11. Software tree of DMX512 slave

This directory also contains a “CMSIS” directory containing the CMSIS source code, and all the source files of [Fig 12](#) in the directory “src”, which is the source code that forms the heart of the DMX512 slave.

A brief description of these source code files is shown in [Table 6](#).

Table 6. Source code file description

File name	Description
app_config.h	Configures the DMX512 slave application
bsp.c	This file implements the “board support package”, software functions specific for this MCU and the electronics (LEDs/switches/etc) on the PCB
bsp.h	Header file describing the exported functions by bsp.c
cr_startup_lpc111x.c	This file contains the Reset vector and exception vector table (needed for the LPCXpresso build only)
i2c.c	Software driver for the I2C hardware block
i2c.h	Header file describing the exported functions by i2c.c
lcd.c	Software driver for the LCD mounted on the DMX512 slave PCB
lcd.h	Header file describing the exported functions by lcd.c
main.c	This file contains the application entry point, main loop and RDM packet handling
main.h	Header file describing the exported functions by main.c
manual_ctrl.c	Implements joystick support for stand-alone RGB controller functionality
manual_ctrl.h	Header file describing the exported functions by manual_ctrl.h
startup_armcm0.s	Assembly file containing the Reset vector and exception vector table (needed for the IAR build only)
timer_pwm.c	SW driver for the counter/timer hardware blocks, using PWM to dim the RGB LEDs
timer_pwm.h	Header file describing the exported functions by timer_pwm.c
uart.c	Software driver for the UART hardware block especially for DMX512 packet RTX
uart.h	Header file describing the exported functions by uart.c
wdt.c	Software driver for the WDT hardware block
wdt.h	Header file describing the exported functions by wdt.c




Fig 12. DMX512 slave source code files

4.9 Building the software

The software tree includes project files for LPCXpresso v4.1.0_190. When using LPCXpresso for building the DMX512 slave, use workspace location <your install path>\DMX512 and import existing project <your install path>DMX512\LPC111xSlave and make sure to uncheck the checkbox "Copy projects into workspace".

The software tree also includes project files for the IAR Embedded Workbench for ARM v6.20.4.

When the IAR workbench is installed, the project can be opened by double clicking the file 'LPC111xDMXslave.eww'.

The software can be configured via the source file 'app_config.h' which contains several global software defines that are explained in [Table 7](#) DMX512 slave configuration options.

Table 7. DMX512 slave configuration options

Define	Description
LPC_CORE_CLOCKSPEED_HZ	Sets the CPU clock.
SUPPORT_RDM_OVER_DMX512	Must be enabled when the DMX512 slave must support Remote Device Management
SUPPORT_I2C_BUS	Must be enabled when text output on the LCD is required.
SUPPORT_I2C_MASTER_MODE	Must be enabled when text output on the LCD is required. The LPC111x is I2C master, the LCD is I2C slave.
SUPPORT_MANUAL_CONTROL	Must be enabled when software support for the joystick is wanted. This software shows how to use the DMX512 slave as a stand-alone RGB controller.

By default the CPU clock is configured at 48 MHz, being a multiple of 12 MHz.

A DEBUG build doesn't optimize the executable image, which makes it possible to debug the software. A RELEASE build is optimized for size, which reduces the flash memory footprint significantly.

[Table 8](#) shows the firmware sizes (in bytes) of a RELEASE build of the DMX512 slave for a DMX512 only build, a DMX512 build with RDM support, and a full featured build.

Table 8. DMX512 slave firmware sizes

Firmware sizes for DMX512 slave (Release build)	IAR EWARM v6.20.4		LPCXpresso v4.1.0_190	
	Flash [Bytes]	RAM [Bytes]	Flash [Bytes]	RAM [Bytes]
DMX512	3344 + 48	1435	3988	12 + 1108
DMX512+RDM	4876 + 48	1529	5668	12 + 1196
DMX512+RDM+ joystick	7800 + 164	1617	9208	48 + 1248

4.10 Summary

It has been tested/verified that the firmware currently implemented on the DMX512 slave (as described in the previous paragraphs) also runs on 12 MHz, and that even at this CPU speed it can handle the maximum DMX512 bus load (512+1 slots at 44 Hz). This means that there are still enough CPU cycles available to add extra functionality to the DMX512 slave.

5. Document management

5.1 Abbreviations

Table 9. Abbreviations

Acronym	Description
BSP	Board Support Package
CMSIS	Cortex Microcontroller Software Interface Standard
CPU	Central Processing Unit
CT	Counter Timer
GPIO	General Purpose Input/Output
HW	Hardware
IRQ	Interrupt Request
I2C	Inter Integrated Circuit
LCD	Liquid Crystal Display
LED	Light Emitting Diode
MCU	Micro Controller Unit
NVM	Non Volatile Memory
PC	Personal Computer
PCB	Printed Circuit Board
PLASA	The lead international membership body for those who supply technologies and services to the event, entertainment and installation industries
PLL	Phase Locked Loop
PWM	Pulse Width Modulation
RDM	Remote Device Management
RGB	Red Green Blue
RTX	Receive and Transmit
SW	Software
UART	Universal Asynchronous Receiver/Transmitter
UID	Unique device ID
WDT	Watchdog Timer

5.2 Referenced documents

Table 10. Referenced documents

Doc Title	Version	Author	Issue Date
[1] ANSI E1.11 - Asynchronous Serial Data Transmission Standard for Controlling Lighting Equipment and Accessories	2008	ESTA	20081204
[2] UM10398 - LPC111x/LPC11Cxx User manual	Rev. 4	NXP	20110304
[3] ANSI E1.20 - Remote Device Management Over DMX512 Networks	2010	PLASA	20110104
[4] PLASA manufacturer ID's http://tsp.plasa.org/tsp/working_groups/CP/mfctrlDs.php			

6. Appendix A: Testing the DMX512 slave

6.1 USB power

Action	Power the DMX512 slave (disconnected from DMX512 bus) via the USB connector X5.
Result	<p>The BLUE ON LED (just above the USB connector) must light up continuously.</p> <p>The LPC1114 must start to run the firmware resulting in:</p> <ul style="list-style-type: none"> • Turning on GREEN LED2. • For one second the LEDS R (RED), G (GREEN), B (BLUE), W (WHITE) will light up (only when the LEDS ENABLE jumper is placed) and the LCD must display the text "NXP LPC1114 DMX512 slave". • After one second the LCD must display the text "No packets from DMX512 master" and the RED LED1 starts to blink with a 1 Hz frequency

6.2 DMX512 input

Action	Connect DMX512 slave to DMX512 bus which carries 512 slots of data.
Result	<p>The GREEN LED2 blinks with the refresh rate of the DMX512 packets on the bus.</p> <p>The LEDS R (RED), G (GREEN), B (BLUE), W (WHITE) will light up depending on the received data values of the slots assigned to these LEDS (DMX start address).</p> <p>The LCD is blank.</p>

6.3 DMX512 output

Action	Connect DMX512 slave to DMX512 bus and do an RDM discovery.
Result	Each DMX512 slave should be discovered via bi-directional RDM packets.

6.4 Reset button

Action	Press the reset button while the board is powered (and keep it pressed).
Result	<p>The BLUE ON LED (just above the USB connector) stays on.</p> <p>The RED LED1 stops blinking and doesn't light up.</p> <p>The GREEN LED2 turns off.</p> <p>Any text on the LCD keeps being displayed.</p>

Action	Release the reset button.
Result	<p>The LPC1114 must start to run the firmware resulting in the GREEN LED2 to turn on.</p> <p>For one second the LEDS R (RED), G (GREEN), B (BLUE), W (WHITE) will light up (only when the LEDS ENABLE jumper is placed) and the LCD must display the text "NXP LPC1114 DMX512 slave".</p> <p>After one second the LCD must display the text "No packets from DMX512 master" and the RED LED1 starts to blink with a 1 Hz frequency.</p>

6.5 Joystick

Action	Press the joystick (center switch) while the board is powered, and keep it pressed for 1 second.
Result	The LCD must display the text: MANUAL CONTROL 1 Go The RED LED1 keeps blinking with a 1 Hz frequency

Action	Use the UP / DOWN / LEFT / RIGHT / center switches of the joystick while the board is powered and while in MANUAL CONTROL (see previous action).
Result	With the joystick the user can navigate through the following menu (visible on the LCD display): MANUAL CONTROL 1 Go 2 Set colors 3 Version info 4 Quit 1.1 Mode 1 1.2 Speed 10 1.3 Dim 100 1.4 Quit 2.1 Color 1 2.2 Hue 0 2.3 Sat 100 2.4 Bright 100 2.5 Quit

7. Appendix B: Flashing the DMX512 Slave


When using IAR Embedded Workbench for ARM v6.20.4 and a j-link JTAG / SWD +SWO probe, the firmware can be easily flashed in the LPC1114/301 of the DMX512 slave.

The IAR project also generates a binary file that can be flashed in the DMX512 slave using a LPC-Link and LPCXpresso v4.1.0_190.

The steps for Windows7 are:

Step 1) Booting LPC-Link 'boot_LPC-link.bat'

Step 2) Running the flash programming utility 'flash_DMXslave.bat'



```

C:\Windows\system32\cmd.exe
Microsoft Windows [Version 6.1.7601]
Copyright (c) 2009 Microsoft Corporation. All rights reserved.

C:\Users\nlv10675>cd \npx\lighting\DMX512_RDM_SDK_v1.0\LPC111xSlave\bin
C:\npx\lighting\DMX512_RDM_SDK_v1.0\LPC111xSlave\bin>boot_LPC-link.bat
C:\npx\lighting\DMX512_RDM_SDK_v1.0\LPC111xSlave\bin>C:\npx\LPCXpresso_4.1.0_190\lpcxpresso\bin\Scripts\bootLPCXpresso.cmd hid
Booting LPC-Link with LPCXpressoHS.enc
Press any key to continue . . .
C:\npx\lighting\DMX512_RDM_SDK_v1.0\LPC111xSlave\bin>flash_DMXslave.bat
C:\npx\lighting\DMX512_RDM_SDK_v1.0\LPC111xSlave\bin>C:\npx\LPCXpresso_4.1.0_190\lpcxpresso\bin\crt_emu_lpc11_13_nxp -wire=hid -pLPC1114/301 -flash-load-exec=LPC111xDMXslave.bin -load-base=0x0
Ni: LPCXpresso Debug Driver v4.0 (Sep 21 2011 20:05:54)
Hc: Looked for chip XML file in C:/npx/LPCXpresso_4.1.0_190/lpcxpresso/bin/LPC1114/301.xml
Hc: Looked for vendor directory XML file in C:/npx/LPCXpresso_4.1.0_190/lpcxpresso/bin/nxp_directory.xml
Hc: Found generic directory XML file in C:/npx/LPCXpresso_4.1.0_190/lpcxpresso/bin/crt_directory.xml
Hc: Emu(0): Conn&Reset. DpID: BB11477. Info: T1S6RGRIA
Hc: SWD Frequency: 3000 KHz. RTCK: False. Vector catch: False.
Hc: Packet delay: 0 Poll delay: 0.
Hc: NXP: LPC1114/301 Part ID: 0x0444102B
Cr:v Registered license, download limit of 128K
Nt: Loading binary file 'LPC111xDMXslave.bin' at location 00000000
Hc: nSRST assert (if available)
Hc: Executing in user flash.
Hc: nSRST assert (if available)
Hc: Executing in user flash.

C:\npx\lighting\DMX512_RDM_SDK_v1.0\LPC111xSlave\bin>

```

Fig 13. Flashing the DMX512 slave

For help with the command line flash programming tool using Linux, go to:

<http://support.code-red-tech.com/CodeRedWiki/CommandLineFlashProgramming>

8. Legal information

8.1 Definitions

Draft — The document is a draft version only. The content is still under internal review and subject to formal approval, which may result in modifications or additions. NXP Semiconductors does not give any representations or warranties as to the accuracy or completeness of information included herein and shall have no liability for the consequences of use of such information.

8.2 Disclaimers

Limited warranty and liability — Information in this document is believed to be accurate and reliable. However, NXP Semiconductors does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information. NXP Semiconductors takes no responsibility for the content in this document if provided by an information source outside of NXP Semiconductors.

In no event shall NXP Semiconductors be liable for any indirect, incidental, punitive, special or consequential damages (including - without limitation - lost profits, lost savings, business interruption, costs related to the removal or replacement of any products or rework charges) whether or not such damages are based on tort (including negligence), warranty, breach of contract or any other legal theory.

Notwithstanding any damages that customer might incur for any reason whatsoever, NXP Semiconductors' aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms and conditions of commercial sale of NXP Semiconductors.

Right to make changes — NXP Semiconductors reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

Suitability for use — NXP Semiconductors products are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of an NXP Semiconductors product can reasonably be expected to result in personal injury, death or severe property or environmental damage. NXP Semiconductors and its suppliers accept no liability for inclusion and/or use of NXP Semiconductors products in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

Applications — Applications that are described herein for any of these products are for illustrative purposes only. NXP Semiconductors makes no representation or warranty that such applications will be suitable for the specified use without further testing or modification.

Customers are responsible for the design and operation of their applications and products using NXP Semiconductors products, and NXP

Semiconductors accepts no liability for any assistance with applications or customer product design. It is customer's sole responsibility to determine whether the NXP Semiconductors product is suitable and fit for the customer's applications and products planned, as well as for the planned application and use of customer's third party customer(s). Customers should provide appropriate design and operating safeguards to minimize the risks associated with their applications and products.

NXP Semiconductors does not accept any liability related to any default, damage, costs or problem which is based on any weakness or default in the customer's applications or products, or the application or use by customer's third party customer(s). Customer is responsible for doing all necessary testing for the customer's applications and products using NXP Semiconductors products in order to avoid a default of the applications and the products or of the application or use by customer's third party customer(s). NXP does not accept any liability in this respect.

Export control — This document as well as the item(s) described herein may be subject to export control regulations. Export might require a prior authorization from competent authorities.

Evaluation products — This product is provided on an "as is" and "with all faults" basis for evaluation purposes only. NXP Semiconductors, its affiliates and their suppliers expressly disclaim all warranties, whether express, implied or statutory, including but not limited to the implied warranties of non-infringement, merchantability and fitness for a particular purpose. The entire risk as to the quality, or arising out of the use or performance, of this product remains with customer.

In no event shall NXP Semiconductors, its affiliates or their suppliers be liable to customer for any special, indirect, consequential, punitive or incidental damages (including without limitation damages for loss of business, business interruption, loss of use, loss of data or information, and the like) arising out the use of or inability to use the product, whether or not based on tort (including negligence), strict liability, breach of contract, breach of warranty or any other theory, even if advised of the possibility of such damages.

Notwithstanding any damages that customer might incur for any reason whatsoever (including without limitation, all damages referenced above and all direct or general damages), the entire liability of NXP Semiconductors, its affiliates and their suppliers and customer's exclusive remedy for all of the foregoing shall be limited to actual damages incurred by customer based on reasonable reliance up to the greater of the amount actually paid by customer for the product or five dollars (US\$5.00). The foregoing limitations, exclusions and disclaimers shall apply to the maximum extent permitted by applicable law, even if any remedy fails of its essential purpose.

8.3 Trademarks

Notice: All referenced brands, product names, service names and trademarks are property of their respective owners.

9. List of figures

Fig 1.	DMX512 slave.....	3
Fig 2.	DMX512 physical layer	4
Fig 3.	Microcontroller on DMX512 slave	5
Fig 4.	User interface on DMX512 slave	6
Fig 5.	RGBW LED PWM output	6
Fig 6.	I ² C extension plug	7
Fig 7.	Power circuit of DMX512 slave	7
Fig 8.	Board layout of DMX512 slave.....	8
Fig 9.	Software architecture of DMX512 slave	12
Fig 10.	Flowchart of DMX512 slave software.....	14
Fig 11.	Software tree of DMX512 slave	19
Fig 12.	DMX512 slave source code files.....	21
Fig 13.	Flashing the DMX512 slave	27

10. List of tables

Table 1.	DMX512 slave parts list	9
Table 2.	RDM command class defines	15
Table 3.	Implemented RDM packets	15
Table 4.	Dip switch translation into DMX512 slave address	17
Table 5.	Used interrupts and assigned priorities in DMX512 slave software	19
Table 6.	Source code file description	20
Table 7.	DMX512 slave configuration options.....	22
Table 8.	DMX512 slave firmware sizes	22
Table 9.	Abbreviations	23
Table 10.	Referenced documents	24

11. Contents

1.	Document purpose	3
2.	Introduction	3
3.	DMX512 slave hardware	4
3.1	Physical layer	4
3.2	Microcontroller	5
3.3	User interface	6
3.4	LED interface and local LED feedback	6
3.5	Extension interface	7
3.6	System power	7
3.7	Board layout	8
4.	DMX512 slave software	12
4.1	Architecture	12
4.2	Main software execution flow	12
4.3	RDM	15
4.3.1	Device discovery	16
4.4	Initialization sequence	16
4.5	DMX UART driver	17
4.6	PWM counter/timer driver.....	18
4.7	Interrupts	18
4.8	Software source code files	19
4.9	Building the software	21
4.10	Summary.....	22
5.	Document management	23
5.1	Abbreviations	23
5.2	Referenced documents	24
6.	Appendix A: Testing the DMX512 slave	25
6.1	USB power	25
6.2	DMX512 input	25
6.3	DMX512 output	25
6.4	Reset button.....	25
6.5	Joystick	26
7.	Appendix B: Flashing the DMX512 Slave	27
8.	Legal information	28
8.1	Definitions	28
8.2	Disclaimers.....	28
8.3	Trademarks	28
9.	List of figures	29
10.	List of tables	30
11.	Contents	31

Please be aware that important notices concerning this document and the product(s) described herein, have been included in the section 'Legal information'.
