# Q90R2 R-GAGE® Radar Sensor Product Manual



Original Instructions p/n: 240867 Rev. B 03-Oct-24 © Banner Engineering Corp. All rights reserved.

# Contents

### **Chapter 1 Product Description**

Models	. 4
Overview	. 5
Features and Indicators	. 6
Banner Measurement Sensor Software	. 6

## **Chapter 2 Installation Instructions**

Sensor Orientation
Wiring
Mount the Device

### **Chapter 3 Getting Started**

Install the Software	9
Connect to the Sensor	9
Software Overview	10

### **Chapter 4 Banner Measurement Sensor Workspace**

Navigation Toolbar	1	11
Live Sensor Data	1	11
2D Scatter Tab	1	11
Spectrum Tab	1	12
Summary Pane	1	13
Sensor Settings Pane	1	13
General Tab	1	13
Discrete 1 Tab	1	14
Discrete 2 Tab	1	14
Analog Tab	1	15
Live Sensor Data Controls	1	16
Using Measurement Hold Example	1	17

### Chapter 5 Configuring a Sensor

Banner Measurement Sensor Software	
IO-Link Interface	
Remote Input	
Remote Teach	20
Remote Setup	20
Set the Signal Strength Threshold	
Set the Speed	22
Target Selection Mode	22
Set the Shape of the Detection Area	23
Reset the Sensor to Factory Defaults	
Factory Default Settings	

### **Chapter 6 Specifications**

FCC Part 15 Class A for Intentional Radiators	26
Industry Canada Statement for Intentional Radiators.	27
ISED Compliance Aircraft Warning	. 27
Dimensions	27
Ream Patterns	28
Beam r auchio	20

### **Chapter 7 Accessories**

Configuration Tool	29
Cordsets	29
Brackets	30
IO-Link Masters	31

### **Chapter 8 Product Support**

Update the Software	2
Supporting Documentation	3
Repairs	3
Contact Us	3

Banner Engineering Corp. Software Copyright Notice	. 33
Banner Engineering Corp Limited Warranty	. 33

#### **Chapter Contents**

Models	. 4
Overview	. 5
Features and Indicators	. 6
Banner Measurement Sensor Software	. 6

# Chapter 1

# **Product Description**



#### · FMCW radar detects moving and stationary objects

- · Adjustable sensing field—ignores objects beyond setpoint
- Easy setup and configuration using the Banner Measurement Sensor Software
- Sensing functions are immune to wind, fog, steam, and temperature changes and resistant to rain and snow
- · Compact, rugged IP69K housing withstands harsh environments
- · Highly configurable field of view enables precision positioning and control
- · Reliable detection across a broad vertical and horizontal field of view
- Customize advanced parameters such as window shape and target setpoints to each application

#### WARNING:

- · Do not use this device for personnel protection
- Using this device for personnel protection could result in serious injury or death.
- This device does not include the self-checking redundant circuitry necessary to allow its use in
  personnel safety applications. A device failure or malfunction can cause either an energized (on)
  or de-energized (off) output condition.

#### WARNING:

- · N'utilisez pas ce dispositif pour la protection du personnel.
- L'utilisation de ce dispositif pour la protection du personnel pourrait entraîner des blessures graves ou mortelles.
- Ce dispositif n'est pas équipé du circuit redondant d'autodiagnostic nécessaire pour être utilisé dans des applications de protection du personnel. Une panne ou un dysfonctionnement du dispositif peut entraîner l'activation ou la désactivation de la sortie.

**IMPORTANT:** To satisfy RF exposure requirements, this device and its antenna must operate with a separation distance of at least 20 cm (7.9 in) from all persons.

## Models

#### 60 GHz Models

Models	Detection Range	Supply Voltage	Telecom Approved	Output
Q90R2-12040-6KDQ	0.15 m to 20 m (0.5 ft to 65.6 ft)	10 V DC to 30 V DC	US, Canada, Europe, Australia, New Zealand	Dual discrete (NPN/PNP, PFM, and IO-Link)
Q90R2-12040-6KIQ				Analog current (4 mA to 20 mA, 1 NPN/PNP discrete, and IO-Link)
Continued on page 5				

03-Oct-24

Continued	from	page 4
Continucu	nom	page +

Models	Detection Range	Supply Voltage	Telecom Approved	Output
Q90R2-12040-6KUQ		12 V DC to 30 V DC		Analog voltage (0 V to 10 V or 0.5 V to 4.5 V, 1 NPN/ PNP discrete, and IO-Link)

# Overview

The Q90R2 is an industrial radar sensor that uses high-frequency radio waves from its internal antenna to detect and measure distance to objects in its field of view.

The Q90R2 detects a wide variety of materials including metal, liquids, or organic materials. Use the supplied software, IO-Link, or a remote input wire to configure the sensor to sense objects within a specified distance or area while ignoring objects beyond this distance or area (background suppression). Or configure the sensor to indicate the presence or absence of objects at a specific (or "taught") distance or range of distances (retroreflective).



D0 (m)	D1 (m)	D2 (m)
0	0.15	20

#### Sensing Field of View: 120 degrees × 40 degrees



See "Beam Patterns" on page 28 for details.

# Features and Indicators

		LED	Color	Description
0	1	Power	Green	Power ON
1 2	2	Signal Strength	Green	Signal strength indication
	3	Output 1	Amber	Target is within the taught analog span or discrete output status
3 00 0	4	Output 2	Amber	Discrete output status

# Banner Measurement Sensor Software

Use the Banner Measurement Sensor software to:

- Quickly configure the sensor
  - · Easily monitor device status via the software
  - Visualize the application in real-time
  - · Make adjustments to sensor settings on the fly

For more information, visit www.bannerengineering.com/us/en/products/sensors/software/banner-measurement-sensor-software.html.



Sensor Orientation	apter Contents
	sor Orientation7
Wiring	ing7
Mount the Device	unt the Device

# Chapter 2 Installation Instructions

# Sensor Orientation

Correct sensor-to-object orientation is important to ensure proper sensing.

Minimize the tilt angle of a target relative to the sensor. The target should be tilted less than half of the beam angle.



T= Target Angle, BA=Beam Angle

# Wiring

Quick disconnect wiring diagrams are functionally identical.





\* Push-Pull output. User-configurable PNP/NPN setting.





\* Push-Pull output. User-configurable PNP/NPN setting.

Continued on page 8

#### Continued from page 7



**NOTE:** Banner recommends that the shield wire (quick-disconnect cordsets only) be connected to earth ground or DC common. Shielded cordsets are recommended for all quick-disconnect models.

## Mount the Device

- 1. If a bracket is needed, mount the device onto the bracket.
- 2. Mount the device (or the device and the bracket) to the machine or equipment at the desired location. Do not tighten the mounting screws at this time.
- 3. Check the device alignment.
- 4. Tighten the mounting screws to secure the device (or the device and the bracket) in the aligned position.

Chapter Contents	
Install the Software	)
Connect to the Sensor	)
Software Overview	)

# Chapter 3

# **Getting Started**

Power up the sensor, and verify the green power LED is on.

# Install the Software

**IMPORTANT:** Administrative rights are required to install the Banner Measurement Sensor software.

- 1. Download the latest version of the software from www.bannerengineering.com/us/en/products/sensors/software/ banner-measurement-sensor-software.html.
- 2. Navigate to and open the downloaded file.
- 3. Click Install to begin the installation process.
- 4. Depending on your system settings, a popup window may appear prompting to allow the Banner Measurement Sensor software to make changes to your computer. Click Yes.
- 5. Click Close to exit the installer.

## Connect to the Sensor



- A = Pro Converter Cable (MQDC-506-USB) B = Splitter (CSB-M1251FM1251M) C = PC running Banner Measurement Sensor software D = Q90R2
- E = Power Supply (PSW-24-1 or PSD-24-4) F = Optional 5-Pin to 5-Pin Double-Ended Cordset (ex. MQDEC3-515SS)
- 1. Connect the sensor to the splitter cable from the PRO-KIT. See "Configuration Tool" on page 29.
- 2. Connect the external power and Pro Converter cable to the splitter cable.
- 3. Connect the Pro Converter cable to the PC.
- 4. Open the Banner Measurement Sensor Software.
- 5. Go to Sensor > Connect on the Navigation toolbar. The Connection screen displays.
- 6. Select the correct Sensor Model and Com Port for the sensor.

#### 7. Click Connect.

The **Connection** screen closes and the sensor data displays.

## Software Overview

Easy setup and configuration using the Banner Measurement Sensor software and Pro Converter Cable.



Banner Measurement Sensor Software

- 1. Navigation toolbar—Use this toolbar to connect to the sensor, to save or load a configuration, or to reset to factory defaults
- 2. Live Sensor Data—

2D Scatter tab: Shows the location of targets detected within the active sensing range, as well as options to select which data displays on the 2D Scatter tab

Spectrum tab: Shows the signal strength versus distance for the connected sensor (not shown)

- 3. Summary pane—Displays the distance to the target, the velocity, the angle, the signal strength, and the output status
- 4. Sensor Settings pane—Set the sensor parameters in this pane
- 5. Status bar—Shows whether the sensor is connected, if a software update is available, and if the sensor data is being recorded to a file
- 6. Live Sensor Data controls—Use these controls to record, freeze, and play real-time sensor data, and to refresh the sensor connection

#### **Chapter Contents**

Navigation Toolbar	11
Live Sensor Data	11
Summary Pane	13
Sensor Settings Pane	13
Live Sensor Data Controls	16
Using Measurement Hold Example	17



## Banner Measurement Sensor Workspace

## **Navigation Toolbar**

Use this toolbar to connect to the sensor, to save or load a configuration, or to reset to factory defaults.

#### From the File menu, the following options are available:

#### Load Configuration

Load a configuration to the connected sensor. Use this option to set up multiple sensors with the same parameters.

#### **Save Configuration**

Save a configuration to a desired location for future use.

#### **Reset Frequently Used Settings**

Resets the software settings without changing the configuration of the attached sensor.

#### Exit

Exit the Banner Measurement Sensor software.

#### From the Sensor menu, the following options are available:

#### Connect

Connect to the sensor.

#### Disconnect

Disconnect from the sensor.

#### **Factory Reset**

Select to perform a factory reset on the sensor. All custom parameters will be lost

#### From the Help menu, the following option is available:

#### About

Select to view the software version number, the copyright notice, and the warranty.

# Live Sensor Data

### 2D Scatter Tab

The **2D Scatter** tab displays the live target information within the horizontal active sensing area. This includes the primary target, static targets, and dynamic targets.

The discrete detection areas are visualized. Adjust them by clicking and dragging on the switch point lines of the detection area. The active sensing range correspond to the color of each output window and are hidden by default.

Use **Distance Max** to adjust the range and field of view displayed on the **2D Scatter** tab.

Legend -- Use the legend to select which data appears on the graph:

#### **Primary Target**

Represents the location of the target inside the switch point window.

#### Discrete 1/Discrete 2

The defined area for which the output state changes when a target is detected.

#### Analog

The range the analog signal represents. Available on analog models. Varies by output model.

#### Switch Point Lines

Displays the switch point extents.

#### **Hysteresis Lines**

Displays the hysteresis. If a range-angle window is configured, the hysteresis is defined and displayed corresponding to the beam angle. If a rectangular window is defined, the hysteresis is defined and displayed corresponding to the X and Y dimension.

#### Active Sen Windows

Defines the area in which the sensor is actively detecting and evaluating targets. It is based on the output window and threshold that have been defined.

#### **Static Targets**

Targets within the Active Sensing Range with no velocity.

#### **Dynamic Targets**

Targets within the Active Sensing Range with velocity toward or away from the origin (the sensor).

### Spectrum Tab

The **Spectrum** tab displays the live distance and amplitude signal from the connected radar sensor. The signal strength threshold, switch point, and hysteresis are also plotted. Use these signals to evaluate targets to determine where the signal strength threshold and switch point should be configured for reliable detection.

Use the Y-Axis Max and the X-Axis Max to adjust the range displayed on the plot.

Legend -- Use the legend to select which data appears on the graph.

#### Signal

Displays the strength of the signal over distance.

## Signal Threshold

Displays the signal strength threshold.

#### **Primary Target**

Represents the signal strength and location of the nearest or strongest target inside the switch point.

#### Discrete 1 Window/Discrete 2 Window

The range for the discrete output.

Varies by output model.

#### Analog 1 Window

The range of the analog output Varies by output model.

#### Switch Point Lines

Displays the switch point distance.

#### **Hysteresis Lines**

Displays the hysteresis distance.

# Summary Pane

The Summary pane (blue shaded area) displays Distance, Velocity, Angle, Signal Strength, and Output Status.

#### State

Displays whether the output is ON or OFF, and the analog output value (analog models only).

#### Distance

Displays the distance to the target, in meters.

#### Velocity

Displays the velocity of the target relative to the sensor, in meters per second.

#### Angle

Displays the angle of the target relative to the sensor, in degrees.

#### Strength

Displays the amount of excess gain of the signal received from the target. The excess gain is relative to the minimum detection threshold (Signal Strength Threshold = 1).

# Sensor Settings Pane

#### Set parameters for the sensor.

Click **Read** to read the current parameters of the connected sensor. Click **Write** to write the parameters to the sensor. Yellow highlight on a parameter's value indicates changes that have not yet been written to the sensor.

### General Tab

The following are the parameters on the General tab on the Sensor Settings pane.

#### **Response Speed**

Choose the response speed of the sensor (Slow, Medium, Fast).

#### **Detection Area**

Set the shape of the detection area. Choose Radial or Rectangular.

#### Target Filters

Signal Strength Threshold: Choose the threshold for the minimum amount of signal needed to activate the output.

Minimum Active Sensing Range: Sensor ignores anything from the face of the sensor to this defined range.

Maximum Active Sensing Range: Sensor ignores anything past this defined range.

Velocity Filter—Allows further thresholds to be defined based on the velocity of targets and their direction of movement relative to the sensor:

All Targets—Targets with any velocity (or no velocity) are detected within the defined detection area.

**Dynamic Targets Only**—Only targets with a component of velocity in the radial direction, either towards or away from the sensor, are detected.

Approaching Targets Only—Only targets moving toward the sensor (targets with a negative velocity) are detected with the defined detection area.

**Receding Targets Only**—Only targets moving away from the sensor (targets with a positive velocity) are detected with the defined detection area.

Custom—Allows the user to define a custom threshold based on velocity switch points.

#### **Advanced Target**

#### **Detection Sensitivity:**

**Standard**—Balanced thresholds for accurate detection of targets and prevention of false detection. **High**—Reduced thresholds for higher likelihood of target detection, especially for targets with a low signal strength.

**Measurement Hold**: A rate of change filter to smooth the output and reduce chatter. For more information, see "Using Measurement Hold Example" on page 17.

**Distance Increase Hold Time**: The period of time the sensor holds its last measurement and output status if the measurement changes more than the configured max distance increase. Available when **Measurement Hold** is set to enabled.

**Maximum Distance Increase**: The allowed limit the measurement can increase, or move farther away from the sensor, before initiating the **Measurement Hold**. Setting this to zero disables it. Available when **Measurement Hold** is set to enabled.

**Distance Decrease Hold Time**: The period of time the sensor holds its last measurement and output status if the measurement changes more than the configured max distance decrease. Available when **Measurement Hold** is set to enabled.

**Maximum Distance Decrease**: The allowed limit the measurement can decrease, or move closer to the sensor, before initiating the **Measurement Hold**. Setting this to zero disables it. Available when **Measurement Hold** is set to enabled.

#### Sensor Polarity

Define the output and remote input signal type.

#### Sensor Lockout

Remote Input (Gray Wire): Enable or disable the remote input wire.

#### Indication

Enable or disable the **Status LEDs** on the sensor.

### Discrete 1 Tab

The following are the parameters on the **Discrete 1** tab on the **Sensor Settings** pane.

#### **Output Mode**

#### Select Switch Point or Window.

**Switch Point**: The distance at which the switch point threshold is placed. **Window**: Define two distance set points to create window limits.

#### **Detection Area Settings**

#### Target Mode: Select Nearest Target or Strongest Target.

**Nearest Target**: Output responds to the nearest target that is over the signal strength threshold. **Strongest Target**: Output responds to the target with the highest signal strength that is over the signal strength threshold.

Switch Points: Define the area in which the target will be detected and measured. Switch points are defined according to the detection area (Radial or Rectangular).

#### **Output Settings**

NO/NC: Select Normally Open or Normally Closed from the list. On Delay: Set an on delay in milliseconds. The maximum time is 60,000 ms. Off Delay: Set an off delay in milliseconds. The maximum time is 60,000 ms.

#### **Response Time**

Shows the On and Off response times. This information is view only.

### Discrete 2 Tab

The following are the parameters on the **Discrete 2** tab on the **Sensor Settings** pane. This tab is available for dual discrete models.

#### Output Mode

Select Switch Point, Window, Complementary, or Pulse Pro/PFM.

Switch Point: Set a single switch point for the output to change.

Window: Define two setpoints to create window limits.

Complementary: Output 2 will be the opposite of Output 1.

**Pulse Pro/PFM**: Pulse Pro/PFM output to interface with Banner lights or a PLC with Pulse Frequency Modulated (PFM) inputs.

#### **Detection Area Settings**

#### Target Mode: Select Nearest Target or Strongest Target.

**Nearest Target**: Output responds to the nearest target that is over the signal strength threshold. **Strongest Target**: Output responds to the target with the highest signal strength that is over the signal strength threshold.

Min/Max: Define the area in which the target velocity will be measured. Available when Pulse Pro/PFM Settings is set to Velocity.

Velocity Switch Points: Define the minimum and maximum velocities which will correspond to the PFM minimum and maximum. Available when Pulse Pro/PFM Settings is set to Velocity

#### Output Settings

Available when Output Mode is set to Switch Point or Window.

NO/NC: Select Normally Open or Normally Closed from the list.

On Delay: Set an on delay in milliseconds. The maximum time is 60,000 ms.

Off Delay: Set an off delay in milliseconds. The maximum time is 60,000 ms.

#### **Response Time**

Calculates the total response time, taking into account the general response speed and on or off delays.

#### Pulse Pro/PFM Settings

Available when Output Mode is set to Pulse Pro/PFM.

The Q90R2 can generate pulses whose frequency are proportional to the sensor's measured distance or velocity, thereby providing a method for representing an analog signal with only a discrete counter. The sensing range or velocity range (defined in Detection Area Settings) of the sensor is scaled from 100 Hz to 600 Hz. 100 Hz equals the near range limit, and 600 Hz equals the far range limit. An output of 50 Hz or 650 Hz (user defined in the software) represents a loss of signal condition where there is no target or the target is out of range. This output can be tied directly to a number of Banner lights for visual feedback without the need for a controller.

**100 Hz:** Define the near sensing range limit of the Pulse Pro range.

**600 Hz**: Define the far sensing range limit of the Pulse Pro range.

Loss-of-Signal: Sets the value used by the sensor during a loss of signal. When a signal is restored, measurement resumes.

Hold last value—The Discrete 2 Output holds the last value indefinitely during a loss of signal.

50 Hz—The Discrete 2 Output switches to this value 2 seconds after a loss of signal.

650 Hz—The Discrete 2 Output switches to this value 2 seconds after a loss of signal.

### Analog Tab

The following are the parameters on the Analog tab on the Sensor Settings pane. This tab is available for analog models.



The analog current output tracks slightly beyond each window limit (from 3.8 mA to 20.2 mA)



The analog current output tracks slightly beyond the upper window limit (up to 10.2 V)

Slope—Voltage-Sourcing Models, 0.5 V to 4.5 V





#### **Detection Area Settings**

Range: Select 0V-10V or 0.5V-4.5V. Available for analog voltage models.

#### Target Mode: Select Nearest Target or Strongest Target.

**Nearest Target**: Output responds to the nearest target that is over the signal strength threshold.

Strongest Target: Output responds to the target with the highest signal strength that is over the signal strength threshold.

**Distance**: Use either the sliders or the fields to define the sensing limits in meters. Available when the **Detection Area** is set to **Radial** on the **General** tab.

Beam Angle: Use either the sliders or the fields to define the sensing angle switch points. Available when the Detection Area is set to Radial on the General tab.

Y/X: Use either the sliders or the fields to define the sensing area in meters. Available when the **Detection Area** is set to **Rectangular** on the **General** tab.

Velocity: Use either the sliders or the fields to define the velocity. Available when **Measurement** is set to **Velocity**. **Measurement**: Select **Distance (Radial)/Distance (Y)** or **Velocity**.

#### Output

**Loss-of-Signal**: Sets the Analog Output value used by the sensor during a loss of signal. When a signal is restored, measurement resumes.

Hold Last Value—The Analog Output holds the last value indefinitely during a loss of signal.

**3.5 mA** (analog current models) or **0 V** (analog voltage models)—The Analog Output switches to this value 2 seconds after a loss of signal.

**20.5 mA** (analog current models) **10.5 V** or **5 V** (analog voltage models, depending on the analog range settings)— The Analog Output switches to this value 2 seconds after a loss of signal.

**Averaging**: Use this menu to set the number of measurements that are averaged together for the analog output. Increasing the averaging improves repeatability but increases the total response speed. The default is 1. The filter can be set to 1, 2, 4, 8, 16, 32, 64, or 128. The total response time is shown under Response Time.

#### **Response Time**

Calculates the total response time, taking into account the general response speed and averaging.

Analog

	Analog Output Filter Setting								
Response Speed	1	2	4	8	16	32	64	128	
	Analog Output Spec (ms)								
Fast	4	8	16	32	64	128	256	512	
Medium	40	80	160	320	640	1280	2560	5120	
Slow	200	400	800	1600	3200	6400	12,800	25,600	

# Live Sensor Data Controls

After connecting to the sensor, data sampling begins automatically (but not recording).

To stop data sampling, click **Stop**.

To restart data sampling, click Play. This only samples data from the sensor and displays it on the plot; it does not record the data to a log file.

To record data to a log file, click **Record**. The log file selection prompt displays. Save the log file as desired. The log file format is .csv.

If communication to the sensor is lost, click C Refresh Device Connection to reconnect.

# Using Measurement Hold Example



Measurement Hold (The hold time is set to 1 second)

- A The Max Distance Change threshold (red lines) adapts based on the previous Raw Measurement sample (blue lines) as long as that sample was within the previous thresholds.
- The temporary distance spike in the Raw Measurement (blue lines) is filtered out because the distance increase
   was outside of the Max Distance Change (red lines). The Output Measurement (green lines) will hold its last measurement.

The Raw Measurement change (blue lines) is greater than the Max Distance Change (red lines) so the Output Measurement (green lines) holds its previous value while the Raw Measurement is beyond the Max Distance Change. After the 1 second Hold Time expires, the Output Measurement and Max Distance Change thresholds

The Raw Measurement (blue lines) drops down to a value below the Max Distance Change (red lines) so the Output Measurement (green lines) holds its value for the Hold Time. After the 1 second Hold Time expires, the

D Output Measurement (green lines) holds its value for the Hold Time. After the T second Hold Time expires, the Output Measurement and Max Distance Change thresholds are updated based on the next Raw Measurement value.

are updated based on the next Raw Measurement value.

С

**Chapter Contents** 

Banner Measurement Sensor Software	. 18 . 18
Remote Input	. 18
Reset the Sensor to Factory Defaults	. 23
Factory Default Settings	. 24
, , , , , , , , , , , , , , , , , , ,	

Chapter 5

# Configuring a Sensor

# Banner Measurement Sensor Software

Use the Banner Measurement Sensor software and PRO-KIT to set up the R-GAGE sensor.

For more information visit www.bannerengineering.com/us/en/products/sensors/software/banner-measurement-sensor-software.html.

# **IO-Link Interface**

IO-Link is a point-to-point communication link between a master device and sensor. Use IO-Link to parameterize sensors and transmit process data automatically.

For the latest IO-Link protocol and specifications, see www.io-link.com.

Each IO-Link device has an IODD (IO Device Description) file that contains information about the manufacturer, article number, functionality etc. This information can be easily read and processed by the user. Each device can be unambiguously identified via the IODD as well as via an internal device ID. Download the Q90R2's IO-Link IODD package (p/n 241455 for dual discrete models and p/n 241635 for analog models) from Banner Engineering's website at www.bannerengineering.com.

Banner has also developed Add On Instruction (AOI) files to simplify ease-of-use between the Q90R2, multiple third-party vendors' IO-Link masters, and the Logix Designer software package for Rockwell Automation PLCs. Three types of AOI files for Rockwell Allen-Bradley PLCs are listed below. These files and more information can be found at www.bannerengineering.com.

**Process Data AOIs**—These files can be used alone, without the need for any other IO-Link AOIs. The job of a Process Data AOI is to intelligently parse out the Process Data word(s) in separate pieces of information. All that is required to make use of this AOI is an EtherNet/IP connection to the IO-Link Master and knowledge of where the Process Data registers are located for each port.

**Parameter Data AOIs**—These files require the use of an associated IO-Link Master AOI. The job of a Parameter Data AOI, when working in conjunction with the IO-Link Master AOI, is to provide quasi-realtime read/write access to all IO-Link parameter data in the sensor. Each Parameter Data AOI is specific to a given sensor or device.

**IO-Link Master AOIs**—These files require the use of one or more associated Parameter Data AOIs. The job of an IO-Link Master AOI is to translate the desired IO-Link read/write requests, made by the Parameter Data AOI, into the format a specific IO-Link Master requires. Each IO-Link Master AOI is customized for a given brand of IO-Link Master.

Add and configure the relevant Banner IO-Link Master AOI in your ladder logic program first; then add and configure Banner IO-Link Device AOIs as desired, linking them to the Master AOI as shown in the relevant AOI documentation.

## **Remote Input**

Use the remote input to program the sensor remotely.

The remote input provides limited programming options and is Active High. This can be configured for Active Low in the Banner Measurement Sensor software by changing the **Sensor Polarity**. For Active High, connect the gray input wire to V+ (10 V DC to 30 V DC), with a remote switch connected between the wire and V+. For Active Low, connect the gray input wire to ground (0 V DC) with a remote switch connected between the wire and ground.

The remote input wire is disabled by default. Pulse the remote input wire 10 times or use the Banner Measurement Sensor software to enable the feature. After enabling the remote input feature, pulse the remote input according to the diagram and the instructions provided in this manual. Remote teach can also be performed using the button on the Pro Converter Cable.

The length of the individual programming pulses is equal to the value T: 0.04 seconds  $\leq T \leq 0.8$  seconds.

Exit remote programming modes by setting the remote input Low for longer than 2 seconds or by waiting for 60 seconds.



**NOTE:** If a factory reset is performed through the Banner Measurement Sensor Software, the remote input wire becomes disabled (factory default setting). If the sensor is returned to factory defaults by using the remote input wire, the input wire remains enabled and the rest of the settings are restored to factory defaults.

### Remote Teach

Use the following procedure to teach the first and second switch points.

- 1. Pulse the remote input once. The green Power LED flashes and all other LEDs are off.
- 2. Present the first point.
- 3. Teach the switch point.

Action	Result
Teach either Output 1 or Output 2: Output 1: Single-pulse the remote input. Output 2: Double-pulse the remote input.	Teach AcceptedThe green Power LED is off, the amber LED of the output being taught flashes while the amber LED of the output not being taught is off. The Green Signal Strength LED indicates signal strength.Teach Not AcceptedThe Amber output LED continues to flash, the green Signal Strength LED indicates signal strength. All other LEDs are off.Retry teaching the first point.

- 4. Present the second point.
- 5. Teach the switch point.

Action	Result
	The green Power LED turns on.
	Teach Accepted
	The sensor returns to run mode.
Single-pulse the remote input.	Teach Not Accepted
	The green Power LED remains off, the amber LED of the output being taught continues to flash while the amber LED of the output not being taught is off.
	Retry teaching the second point.

### Remote Setup

Use Remote Setup to set the output mode to normally open or normally closed, change the analog slope, or set the teach mode.

While in remote set up, pulsing the remote wire once configures output 1. For analog models, the slope of the output changes. For discrete output, output 1 and output 2 options are identical.

Changing the Output Mode using remote input affects both the output configuration (normally open versus normally closed) and the Teach mode. The output configuration change takes effect immediately and can be used to change the output between normally open and normally closed or the analog slope without changing the switch point distance. The change in Teach mode does not immediately change the switch point location, but will affect the behavior of the next remote Teach.

### Analog Teach Modes

The default is to teach two separate points. The first taught point is the analog output minimum: 4 mA (current models) or 0 V (voltage models). The second taught point is the analog output maximum: 20 mA (current models) or 4.5 V or 10 V (voltage models, depending on analog output settings).

The analog output will have a positive slope with distance when the first taught point is closer to the sensor than the second taught point. When the first taught point is farther away than the second taught point, the analog output will have a negative slope.

If the two taught points are within 100 mm or less, the sensor views them as the same point. It considers that point as the 20 mA/4.5 V/10 V spot and sets the 4 mA/0 V spot at 150 mm. If a taught point is within the dead zone, the sensor sets that point at 150 mm.

#### **Discrete Teach Modes**

Teaching two separate points creates a window around that range.

Background Teach—Teaching the same point twice (points within 100 mm of each other) sets the switch point 200 mm in front of the taught point.

Object Teach—Teaching the same point twice (points within 100 mm of each other) sets the switch point 100 mm behind the taught point.

Window Teach—Teaching the same point twice (points within 100 mm of each other) sets a window ±50 mm on either side of the taught point, for a total window size of 100 mm.

#### Set the Remote Field of View

Use this setting to change the size of the detection area. The settings correspond to the detection area shape, either radial or rectangular.

- 1. Pulse the remote input twice. The green power LED flashes slowly.
- 2. Access Remote Field of View Setup.

Action	Result	
Select either Output 1 or Output 2: Output 1: Pulse the remote input three times. Output 2: Pulse the remote input four times.	The Green power LED continues to flash slowly.	

3. Select the desired field of view.

Action			Result	
Pulses		TEACH Mode		
1		Radial: ± 50 Degrees Rectangular (X) ± 15 m		
2		Radial: $\pm$ 40 Degrees Rectangular (X) $\pm$ 10 m	The field of view is set and the green	
3		Radial: $\pm$ 30 Degrees Rectangular (X) $\pm$ 5 m	number of pluses, pauses, and then flashes equal to the number of pulses a second time. Then the sensor exits	
4		Radial: ± 20 Degrees Rectangular (X) ± 3.5 m	remote teach and returns to run mode.	
5		Radial: ± 10 Degrees Rectangular (X) ± 1.75 m		

## Set the Signal Strength Threshold

Use the following procedure to configure the signal strength threshold.

1. Access Signal Strength Threshold.

Action	Result
Triple-pulse the remote input.	The green power LED flashes slowly.

#### 2. Select the desired signal threshold.

Action			Popult
Pulses		TEACH Mode	Result
1		Signal Strength Threshold = 1	
2		Signal Strength Threshold = 2	
3		Signal Strength Threshold = 5	
4		Signal Strength Threshold = 10	The signal threshold is set and the green power LED flashes equal to the number of pluses, pauses, and then flashes equal to the surplus of the set of the surplus to the surplus of the set of the se
5		Signal Strength Threshold = 25	pulses a second time. Then the sensor exits remote teach and returns to run mode.
6		Signal Strength Threshold = 50	
7		Signal Strength Threshold = 100	
8		Signal Strength Threshold = 200	

## Set the Speed

Use Speed Selection to set the speed of the sensor.

1. Access Speed Selection.

Action	Result
Four-pulse the remote input.	The green power LED flashes slowly.

2. Select the desired speed.

Action			Popult
Pulses		TEACH Mode	Result
1		Speed = Fast	
2		Speed = Medium	The speed is set and the power LED flashes equ to the number of pluses, pauses, and then flashe equal to the number of pulses a second time. Th sensor exits remote teach and returns to run
3		Speed = Slow	mode.

## **Target Selection Mode**

Use Target Selection to set the target that the output sees.

1. Access Target Selection mode.

Action	Result
Five-pulse the remote input.	The green power LED flashes slowly.

2. Select the desired target.

Action Pulses			Beeutt
		TEACH Mode	Result
1		Nearest Target—Output responds to the nearest target that is over the signal strength threshold.	The signal threshold is set and the green power LED flashes equal to the number of pluses,
2		Strongest Target—Output responds to the target with the highest signal strength that is over the signal strength threshold.	pauses, and then flashes equal to the number of pulses a second time. Then the sensor exits remote teach and returns to run mode.

## Set the Shape of the Detection Area

Use this setting to switch between detection area shapes radial and rectangular.

1. Access Detection Area selection

Action	Result
Pulse the remote input seven times.	The green power LED flashes slowly.

2. Select the desired detection area.

Action			Popult
Pulses		TEACH Mode	Result
1		Radial	The detection area shape is set and the green power LED flashes equal to the number of pluses, pauses, and
2		Rectangular	then flashes equal to the number of pulses a second time. Then the sensor exits remote teach and returns to run mode.

# Reset the Sensor to Factory Defaults

Reset the sensor to factory default settings using one of two methods.

**NOTE:** If a factory reset is performed through the Banner Measurement Sensor software, the remote input wire becomes disabled (factory default setting). If the sensor is returned to factory default settings by using the remote input wire, the input wire remains enabled and the rest of the settings are restored to factory defaults.

To reset using the Banner Measurement Sensor software, go to **Sensor > Factory Reset**. The sensor indicators flash once, the sensor is reset back to the factory default settings, and a confirmation message displays.

To reset using the remote input, eight-pulse the remote input to apply the factory default settings.

# Factory Default Settings

#### General Tab Default Settings

Setting	Factory Default
Response Speed	Medium
Detection Area	Radial
Signal Strength Threshold	1.0
Minimum Active Sensing Range	0 m
Maximum Active Sensing Range	21.0 m
Velocity Filter	All Targets
Detection Sensitivity	Standard
Measurement Hold	Disabled
Remote Input Wire	PNP (Active High)
Remote Input	Disabled
Status LEDs	Enabled

Analog Tab Default Settings

Setting	Factory Default
Range	4 mA to 20 mA (0 V to 10 V)
4mA/0.5V/0V Point	0.15 m (0.49 ft)
20mA/0.5V/10V Point	20.0 m (65.6 ft)
Loss of Signal	3.5 mA (0 V)
Averaging	1× (no averaging)

Discrete 1 & 2 Tabs Default Settings

Setting	Factory Default
Output Mode	Switch Point
Target Mode	Nearest Target
Distance Switch Point	20.0 m
Beam Angle Switch Point 1	-60 degrees
Beam Angle Switch Point 2	60 degrees
NO/NC	Normally Open
On Delay	0 ms
Off Delay	500 ms
On Response Time	132 ms
Off Response Time	632 ms

#### **Chapter Contents**

FCC Part 15 Class A for Intentional Radiators	26
Industry Canada Statement for Intentional Radiators	27
ISED Compliance Aircraft Warning	27
Dimensions	27
Beam Patterns	28

# Chapter 6

# **Specifications**

Response Speed	Fast	Medium	Slow
Response Time	50 ms	150 ms	250 ms
Maximum Velocity	± 9 m/s	± 9 m/s	± 4.5 m/s
Velocity Resolution	0.5 m/s	0.25 m/s	0.15 m/s

#### **Operating Principle**

Frequency-modulated continuous-wave (FMCW) radar

#### Operating Frequency

60 GHz to 61.5 GHz

#### Transmitting Power

< 20 dBm (E.I.R.P)

#### Field of View

Horizontal: ±60° Vertical: ±20°

#### Distance

0.15 m to 20 m (0.5 ft to 65.6 ft)

#### **Distance Resolution**

0.2 m

## >200mm, ±10 mm

### Distance Repeatability

10 mm

telocity Linearity ±0.01 m/s

## Velocity Repeatability

0.03 m/s

#### Supply Voltage (Vcc)

Analog Voltage models: 12 V DC to 30 V DC Analog Current and Dual Discrete models: 10 V DC to 30 V DC

Use only with a suitable Class 2 power supply (UL) or Limited Power Supply (CE)

#### Power and Current Consumption, exclusive of load

Power Consumption: < 2.4 W

Current Consumption: <100 mA at 24 V DC

#### Supply Protection Circuitry

Protected against reverse polarity and transient overvoltages

#### Delay at Power-up

< 2 s

#### **Output Configuration**

Analog Outputs:

#### Current models

Discrete Output (Black Wire): IO-Link, push/pull output, configurable PNP or NPN output Analog output (White Wire): 4 mA to 20 mA

#### Voltage models

Discrete Output (Black Wire): IO-Link, push/pull output, configurable PNP or NPN output Analog output (White Wire): Configurable 0 V to 10 V or 0.5 V to 4.5 V

#### · Dual Discrete models

Discrete Output 1 (Black Wire): IO-Link, push/pull output, configurable PNP or NPN output Discrete Output 2 (White Wire): Configurable PNP or NPN, or Pulse Frequency Modulated (PFM) output

#### **Output Protection**

Protected against output short-circuit

#### Remote Input

Allowable Input Voltage Range: 0 to Vsupply

Active High (internal weak pull-down): High state > (Vsupply - 2.25 V) at 2 mA maximum

Active Low (internal weak pull-up): Low state < 2.25 V at 2 mA maximum

#### Indicators

Power LED: Green, power on

Signal Strength LED:

Green Flash: Weak signal Green Solid: 4x threshold **Output LEDs:** Amber, target within taught analog span/ discrete output status

#### Construction

Housing: Aluminum

Window: Polycarbonate

#### Connections

Integral M12 quick disconnect Models with a quick disconnect require a mating cordset

#### Vibration and Mechanical Shock

All models meet MIL-STD-202G, Method 201A (Vibration: 10 Hz to 60 Hz, 0.06 inch (1.52 mm) double amplitude, 2 hours each along X, Y and Z axes) requirements. Also meets IEC 60947-5-2 (Shock: 30G 11 ms duration, half sine wave) requirements. Method 213B conditions H&I. Shock: 75G with device operating; 100G for non-operation

#### **Operating Temperature**

-40 °C to +65 °C (-40 °F to +149 °F)

#### **Temperature Effect**

<±10 mm from -40 °C to +65 °C (-40 °F to +149 °F)</p>

#### Environmental Rating

IP67 per IEC60529 IEC IP69K per BS/ISO 20653:2013

#### Country of Origin

USA

Certifications



IND. CONT. EQ. E526767



Banner Engineering BV Park Lane, Culliganlaan 2F bus 3 1831 Diegem, BELGIUM



Turck Banner Ere Ere Blenheim Court Wickford, Essex SS11 8YT GREAT BRITAIN Turck Banner LTD Blenheim House



**⊘ IO**-Link<sup>®</sup>

ETSI EN 305 550 V2.1.0 ETSI EN 305 550-1 V.1.2.1 ETSI EN 305 550-2 V.1.2.1 FCC ID: UE3Q90R2-6 IC: 7044A-Q90R26 Install where not accessible by unauthorized personnel. The device shall only be accessible for adjustment, programming, or maintenance. The device was evaluated for IK08 impact energy in accordance with IEC 62262.

#### **Output Ratings**

Analog Outputs:

- Current Output (Q90R...-I.. models): 1 kΩ maximum load resistance at 24 V; maximum load resistance = [(Vcc - 4.5)/ 0.02 Ω]

**Advanced Capabilities** 

· Voltage Output (Q90R....-.U.. models): 2.5 kΩ minimum load resistance

· Current rating = 50 mA maximum each

Black wire specifications per configuration		
IO-Link Push/Pull	Output High	≥ Vsupply - 2.5 V
	Output Low	≤ 2.5 V
PNP	Output High	≥ Vsupply - 2.5 V
	Output Low	$\leq$ 1V (loads $\leq$ 1 Meg $\Omega$ )
NPN	Output High	≥ Vsupply - 2.5 V
	Output Low	≤ 2.5 V

White wire specifications per configuration			
	Output High	≥ Vsupply - 2.5 V	
FINE	Output Low	$\leq$ 2.5 V (loads $\leq$ 70 k $\Omega$ )	
NPN	Output High	≥ Vsupply - 2.5 V	
	Output Low	≤ 2.5 V	

# FCC Part 15 Class A for Intentional Radiators

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses,

and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

(Part 15.21) Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

# Industry Canada Statement for Intentional Radiators This device contains licence-exempt transmitters(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt

RSS(s). Operation is subject to the following two conditions:

- 1. This device may not cause interference.
- 2. This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil contient des émetteurs/récepteurs exemptés de licence conformes à la norme Innovation, Sciences, et Développement économique Canada. L'exploitation est autorisée aux deux conditions suivantes:

- 1. L'appareil ne doit pas produire de brouillage
- 2. L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

# ISED Compliance Aircraft Warning

Devices used on aircraft are permitted under the following conditions:

- 1. Except as allowed in J.2(b), devices are only to be used when the aircraft is on the ground.
- 2. Devices used in-flight are subject to the following restrictions:
  - a. they shall be used within closed, exclusive on-board, communication networks within the aircraft
  - b. they shall not be used in wireless avionics intra-communication (WAIC) applications where external structural sensors or external cameras are mounted on the outside of the aircraft structure
  - c. they shall not be used on aircraft equipped with a body/fuselage that provides little or no RF attenuation except when installed on unmanned air vehicles (UAVs) and complying with J.2(d)
  - d. devices operating in the 59.3-71.0 GHz band shall not be used except if they meet all of the following conditions: i, they are FDS
    - ii. they are installed within personal portable electronic devices
    - iii. they comply with the relevant requirements in J.3.2(a), J.3.2(b) and J.3.2(c)

## **Dimensions**

All measurements are listed in millimeters [inches], unless noted otherwise. The measurements provided are subject to change.







# **Beam Patterns**

The beam pattern of the radar sensor is dependent on the radar cross section (RCS) of the target.

The beam pattern graphs represent Standard Mode and are guides for representative object detection capabilities based on different-sized radar cross sections and corresponding example real-world targets. Use the following charts as a starting point in application setup. Note that applications vary.

- Use the Beam Width versus Distance chart to understand where corresponding objects can be detected. Adjusting the signal strength threshold also affects the beam pattern when the target is constant.
- Use the Beam Width versus Degrees chart to help determine how much the target can tilt from 90 degrees while still maintaining detection.

Unless otherwise specified, the following beam patterns are shown with Signal Strength Threshold = 1.

#### Horizontal



Typical beam pattern, in degrees, on representative targets



#### Vertical

Typical beam pattern, in millimeters, on representative targets



Typical beam pattern, in degrees, on representative targets



#### **Chapter Contents**

Configuration Tool	29
Cordsets	29
Brackets	30
IO-Link Masters	31

Chapter 7

# Accessories

# **Configuration Tool**

#### PRO-KIT

#### Includes:

- Pro Converter Cable (MQDC-506-USB)
- Splitter (CSB-M1251FM1251M)
- Power Supply (PSW-24-1)



## Cordsets

5-Pin Threaded M12 Cordsets with Shield—Single Ended				
Model	Length	Style	Dimensions	Pinout (Female)
MQDEC2-506	2 m (6.56 ft)	Straight	44 Typ. M12 x 1 Ø 14.5	
MQDEC2-506RA	2 m (6.56 ft)	Right-Angle	32 Typ. [1.26"] 30 Typ. [1.18"] w12 x 1 w 14.5 [0.57"]	4 5 1 = Brown 2 = White 3 = Blue 4 = Black 5 = Gray



5-Pin M12 Female to M12 Male Flat Junction Splitter Cordsets				
Model	Trunk (Male)	Branches (Female)	Pinout (Male)	Pinout (Female)
CSB-M1251M1251B	0.3 m (0.98 ft)	0.3 m (0.98 ft)		$\begin{array}{c}1\\0\\0\\4\end{array}$
M12 x 1	3 x o5.9	0 14.5 M12 x 1 43.5 Typ M12 x 1 x 2	1 = Brown 2 = White 3 = Blue	4 = Black 5 = Gray

**NOTE:** The splitter in the PRO-KIT has two male and one female connectors. The CSB-M1251M1251B splitter has one male and two female connectors. Use the CSB-M1251M1251B to connect the sensor to power and a one of the Banner Pro lights with the Pulse Pro output.

# Brackets

#### SMBAMSQ90R

- Adjustable mounting bracket
- 14-Gauge 304 stainless steel
- M6 × 1 mounting hardware included

#### SMBRAQ90R

- Right-angle mounting bracket
- 14-Gauge 304 stainless steel
- M6 × 1 mounting hardware included

#### SMBMAG3

- 3.2 inch diameter magnet with 95 lbs pull force
- Use with LMBWLC90PT, SMBAMS70AS, SMBAMSQ90R bracket
- Hardware for mounting to bracket included



6X Ø6.3

NOTE: Use SMBMAG3 with SMBAMSQ90R.

# **IO-Link Masters**

DXMR110-8K Series Controller IO-Link Master

- Two female M12 D-Code Ethernet connectors for daisy chaining and communication to a higher-level control system
- Eight female M12 connections for IO-Link master connections
- One male M12 connection for incoming power, one female M12 connection for daisy chaining power
- Product documentation (p/n 233120)





Model	Pinout (Male)	Pinout (Female)
<ul> <li>R45C-2K-MQ 2-Port IO-Link Master/Modbus Converter</li> <li>Connects two IO-Link devices and provides access via Modbus RTU interface</li> <li>5-pin M12 male quick-disconnect connector</li> <li>Two 4-pin M12 female quick-disconnect connectors</li> </ul>	2 + 4 3 + 5 1 = Brown 2 = White 3 = Blue 4 = Black 5 = Gray	1 = Brown $2 = White$ $3 = Blue$ $4 = Black$

Model		Pinout (Male)	Pinout (Female)
<ul> <li>R90C-4K-MQ 4-Port IO-Link Master/Modbus Convertor</li> <li>Connects four IO-Link devices and provides access via Modbus RTU interface</li> <li>5-pin M12 male quick-disconnect connector</li> <li>Four 4-pin M12 female quick-disconnect connectors</li> </ul>	0000 M	2 + 4 3 + 5 1 = Brown 2 = White 3 = Blue 4 = Black 5 = Gray	1 = Brown $2 = White$ $3 = Blue$ $4 = Black$

**Chapter Contents** 

Update the Software	. 32
Supporting Documentation	. 33
Repairs	. 33
Contact Us	. 33
Banner Engineering Corp. Software Copyright Notice	. 33
Banner Engineering Corp Limited Warranty	. 33

## Update the Software

Use this procedure to update the Banner Measurement Sensor software.

The Banner Measurement Sensor software automatically looks for updated software versions. The symbol in the lower right corner indicates that a software update is available.

	Software Update Available	
	Connected(Q130RA-9076-AFQ)	
. Click 📕 in the lower right corner of the	software.	
The Banner Measurement Sensor soft	ware update screen displays.	
Ban	ner Measurement Sensor Software Update S	Screen
😭 Bann	er Measurement Sensor Software Update	×
The curro The new To Upgra Measure will be d	ent version running is: 3.0.0.0 version is: 4.0.0.1706 ade, choose the Upgrade button below. If you do, 8 ment Sensor Software will close immediately and a ownloaded to the Desktop.	Banner an installer

2. Click Upgrade to begin the process.

The Banner Measurement Sensor software closes and an installer (BannerMeasurementSensorSoftwareInstaller.exe) downloads to the desktop.

**NOTE:** If changes have not been written to the sensor, the system asks whether you want to exit the program. Click **No** to stop the update process and return to the software. Write the changes to the sensor, then return to step 1, above, to update the software.

- 3. Navigate to and open the file BannerMeasurementSensorSoftwareInstaller.exe.
- 4. Depending on your system settings, a popup window may appear prompting to allow Banner Measurement Sensor software to make changes to your computer. Click **Yes**.
- 5. Click **Close** to exit the installer.

The software update is complete.

# **Supporting Documentation**

The following documentation is available at www.bannerengineering.com.

Part number	Document Name
241456	IO-Link Data Reference Guide: Q90R2 60 GHz
241455	Q90R2 Discrete IODD File
B_51900763	Q90R2 KD Discrete IO-Link AOI File
241634	IO-Link Data Reference Guide: Q90R2 Analog 60 GHz
241635	Q90R2 Analog IODD File
B_51915602	Q90R2 KD Analog IO-Link AOI Files

## Repairs

Contact Banner Engineering for troubleshooting of this device. **Do not attempt any repairs to this Banner device; it contains no field-replaceable parts or components.** If the device, device part, or device component is determined to be defective by a Banner Applications Engineer, they will advise you of Banner's RMA (Return Merchandise Authorization) procedure.

**IMPORTANT:** If instructed to return the device, pack it with care. Damage that occurs in return shipping is not covered by warranty.

You may be asked to provide the configuration file and the data log file (.cfg) to aid in troubleshooting.

# Contact Us

Banner Engineering Corp. headquarters is located at: 9714 Tenth Avenue North | Plymouth, MN 55441, USA | Phone: + 1 888 373 6767

For worldwide locations and local representatives, visit www.bannerengineering.com.

# Banner Engineering Corp. Software Copyright Notice

© Banner Engineering Corp., All Rights Reserved.

https://www.bannerengineering.com/us/en/company/terms-and-conditions.html

Disclaimer of Warranties. This software is provided "AS-IS." To the maximum extent permitted by applicable law, Banner, it affiliates, and its channel partners disclaim all warranties, expressed or implied, including any warranty that the software is fit for a particular purpose, title, merchantability, data loss, noninterference with or non-infringement of any intellectual property rights, or the accuracy, reliability, quality or content in or linked to the services. Banner and its affiliates and channel partners do not warrant that the services are secure, free from bugs, viruses, interruption, errors, theft or destruction. If the exclusions for implied warranties do not apply to you, any implied warranties are limited to 60 days from the date of first use of this software.

Limitation of Liability and Indemnity. Banner, its affiliates and channel partners are not liable for indirect, special, incidental, punitive or consequential damages, damages relating to corruption, security, loss or theft of data, viruses, spyware, loss of business, revenue, profits, or investment, or use of software or hardware that does not meet Banner minimum systems requirements. The above limitations apply even if Banner and its affiliates and channel partners have been advised of the possibility of such damages. This Agreement sets forth the entire liability of Banner, its affiliates and your exclusive remedy with respect to the software use.

# Banner Engineering Corp Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

#### THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSS OF PROFITS, OR ANY

## INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product is identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to: www.bannerengineering.com.

For patent information, see www.bannerengineering.com/patents.



G

<u>LinkedIn</u>

X (formerly Twitter)

<u>Facebook</u>



# **Mouser Electronics**

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

**Banner Engineering:** 

Q90R2-12040-6KDQ