

Anaren Integrated Radio

AIR BoosterPack User's Manual

A2530R24A A2530E24A

Release Date 11/2/12



Anaren Integrated Radio

THIS PAGE LEFT INTENTIONALLY BLANK

USER'S MANUAL

AIR BoosterPack

Contents

1.	AIR Bo	osterPack Overview	5
	1.1. Ove	rview	5
	1.2. Kit (Contents	6
2.	Getting	Started with the AIR BoosterPack	7
	2.1. Har	dware Installation	9
	2.1.1.	AIR BoosterPack with MSP430 LaunchPad	9
	2.1.2.	AIR BoosterPack with Stellaris LaunchPad	11
	2.2. USE	3 Driver Installation	13
	2.3. Prog	gramming the Demo Application on Stellaris	17
	2.4. IMP	PORTANT: Required Radio Setup	19
	2.5. Usir	ng the Demo Application	20
	2.6. AIR	A2530 Wiki	20
3.	AIR Bo	osterPack Hardware	21
	3.1. Elec	trical Characteristics	21
	3.1.1.	Absolute Maximum Ratings	21
	3.1.2.	Recommended Operating Conditions	21
	3.2. Fun	ctional Description	22
	3.2.1.	A2530 Radio Module (U6)	23
	3.2.2.	MCU & Socket (U5)	23
	3.2.3.	Sensors	23
	3.2.4.	Serial EEPROM (U1)	24
	3.2.5.	LED Indicators	24
	3.2.6.	Switches	25
	3.2.7.	Jumpers	
	3.2.8.	Connectors	
	3.3. Sche	ematics	35
	3.4. PCE	3 Layout	
	3.5. Bill	ot Materials (BOM)	41



Anaren Integrated Radio

THIS PAGE LEFT INTENTIONALLY BLANK

1. AIR BoosterPack Overview

1.1. Overview

The AIR BoosterPack is a low-power wireless transceiver extension module for use with the Texas Instruments MSP-EXP430G2 and EK-LM4F120XL LaunchPad development kits. The BoosterPack is available in various configurations, each of which contains an AIR radio module with integrated antenna. See Table 1 for a listing of the supported BoosterPacks and their operating bands. The included AIR BoosterPack software applications demonstrate example sensor networks, as well as providing basic examples for communicating with the radio module.

Model	Operating Band	Range Extender
A2530R24A	2400-2483.5MHz ISM Band (FCC/IC, ETSI)	No
A2530E24A	2400-2483.5MHz ISM Band (FCC/IC, ETSI)	Yes

Table 1 - AIR	BoosterPack	Models
---------------	-------------	--------



Figure 1 - AIR BoosterPack with MSP430 LaunchPad



Anaren Integrated Radio

AIR BoosterPack Hardware Features:

- 2.7V to 3.6 V operation (2.2V min when RGB Light Sensor power disabled)
- Low power consumption
- SPI interface to Radio Module
- IR Temperature Sensor (TI TMP006)
- RGB Light Sensor (TAOS TCS3414)
- EEPROM (16K x 8)
- Analog Current Monitor
- Tri-Color LED with PWM control
- Accessible Test Points for all MCU ports plus four Radio Module ports
- 8 DIP Switches for board configuration and user input
- 20-pin DIP socket for operation with or without MSP430 microcontroller (MCU removed when used with the Stellaris LaunchPad)
- ROHS compliant
- See AIR Module Users Manual for radio specific features

AIR BoosterPack Software Features:

- Texas Instruments ZNP protocol
- Mesh network topology with one Coordinator, one or more Routers, and one or more End Points

1.2. Kit Contents

The AIR BoosterPack kit includes the following:

- Three AIR BoosterPacks (each with MSP430G2553 device preinstalled and preloaded with a sample program)
- One AA battery pack with On/Off switch and JST style connector
- Quick Start Guide for use with MSP430 LaunchPad
- Quick Start Guide for use with Stellaris LaunchPad
- Regulatory Guide
- CD containing AIR BoosterPack demo applications, USB UART device drivers, board design files, and supporting documentation



Anaren Integrated Radio

2. Getting Started with the AIR BoosterPack

The following sections describe the necessary steps to get the AIR BoosterPack hardware and software up and running with the LaunchPad.



Figure 2 - AIR BoosterPack Overview

- 1) AIR Radio Module (U6).
- 2) Radio GPIO Test Points (J5).
- 3) Radio GPIO DIP Switches (S4).
- 4) J2 Test Point Solder Jumpers.
- 5) Sensor/LED DIP Switches (S3).
- 6 MCU (MSP430) Reset Pushbutton Switch (S1). Duplicate of S1 on MSP430 LaunchPad.
- 7 Yellow LED (D3).
- 8) Green LED (D2). Duplicate of LED2 on MSP430 LaunchPad.
- **9)** Red LED (D1). Duplicate of LED1 on MSP430 LaunchPad.
- 10 Pushbutton Switch (S2). Duplicate of S2 on MSP430 LaunchPad.
- (11) J1 Test Point Solder Jumpers.



Anaren Integrated Radio

- (12) IR Temperature Sensor (U1).
- (13) RGB Light Sensor (U2).
- (14) 128Kb (16K x 8) Serial EEPROM (U1).
- (15) RGB LED (D4).
- 16) J1 LaunchPad Connector.
- (17) J1 Test Points.
- (18) Current Sense Amplifier (U4).
- (19) Current Sense Select Jumper (JP1).
- (20) Current Sense Disconnect Jumper (JP2).
- (21) 20-Pin DIP Socket + MSP430G2553 (U5).
- (22) SPI/I²C Test Points (J3).
- 23) J2 Test Points.
- (24) J2 LaunchPad Connector.
- (25) Optional Radio Reset Pushbutton Switch (S5).
- 26) Option Radio CC Debugger Header (J4).
- 27) Red LED (D8).
- 28) Yellow LED (D9).



Anaren Integrated Radio

2.1. Hardware Installation

2.1.1. AIR BoosterPack with MSP430 LaunchPad

The following steps need to be performed on each LaunchPad/BoosterPack:

- 1) If not already populated, solder both 10-pin male headers provided in the LaunchPad kit onto the LaunchPad's J1 and J2 breakout connections.
- 2) Configure UART jumper settings on the LaunchPad.
 - a. For LaunchPad Rev1.4 and earlier, remove jumpers TXD and RXD from J3 and install crossover jumpers (not included) onto the same group of pins to make the following connections:
 - i. Connect J3.3 to J3.6
 - ii. Connect J3.5 to J3.4
 - b. For LaunchPad Rev1.5 and later, change the orientation of the J3 TXD and RXD jumpers to use the HW UART.
- 3) Ensure the VCC jumper is populated on J3. Jumpers RST and TEST also need to be installed when programming the microcontroller or when debugging software.
- 4) Remove the existing MSP430 device on the LaunchPad as the BoosterPack comes with a microcontroller already installed. Alternatively, the provided microcontroller may be installed in the LaunchPad's socket. In either case, only one device should be installed at any given time. See Figure 4 and Figure 5 which show the two options for MSP430 location.
- 5) Install the AIR BoosterPack onto the LaunchPad board. Ensure the BoosterPack is oriented correctly. J1 of the BoosterPack must connect to J1 of the LaunchPad. The same is true for J2.



Figure 3 – Installed BoosterPack (MSP430 LaunchPad)



Anaren Integrated Radio



Figure 4 - Standard Installation (MSP430 on BoosterPack)



Figure 5 - Alternate Installation (MSP430 on LaunchPad)



Anaren Integrated Radio

2.1.2. AIR BoosterPack with Stellaris LaunchPad

The following steps need to be performed on each LaunchPad/BoosterPack:

- 1) Remove the provided MSP430 device on the BoosterPack.
- Install the AIR BoosterPack onto the LaunchPad board. Ensure the BoosterPack is oriented correctly. J1 of the BoosterPack must connect to J1 of the LaunchPad. The same is true for J2.



Figure 6 - Installed BoosterPack (Stellaris LaunchPad)

Optional:

The default BoosterPack configuration utilizes a software I²C controller (i.e. bit-banged) to maintain compatibility with both LaunchPad types (i.e. MSP430 and Stellaris). Since the Stellaris microcontroller supports using UART, SPI, and I²C at the same time (compared to the MSP430G2553 which only has two USCIs), the BoosterPack may be configured to use the hardware I²C controller instead of the bit-banged controller. The following steps need to be performed on each LaunchPad/BoosterPack:

- Install 10-pin connector (not included) at BoosterPack J1 Test Points location. This corresponds to the LaunchPad J3 connector (see Figure 7). The same can be done for BoosterPack J2 Test Points (LaunchPad J4), although this is optional. Only LaunchPad pins J3.3 and J3.4 are utilized by the BoosterPack. The remaining J3 and J4 LaunchPad signals are simply pass-thru.
- 2) Remove R9 and R10 from the LaunchPad. See Figure 8 for the location of these resistors.



Anaren Integrated Radio



Figure 7 – BoosterPack with Additional Connectors Installed



Figure 8 – Stellaris LaunchPad



Figure 9 - Installed BoosterPack (with Additional Connectors, Stellaris LaunchPad)



Anaren Integrated Radio

2.2. USB Driver Installation

System Requirements

- Microsoft Windows XP SP3 or later operating system (32-bit and 64-bit supported)
- CD drive

Many of the provided firmware examples require using a Virtual COM port via the LaunchPad's USB interface. If the necessary USB drivers have not already been installed on the PC/Laptop, follow one of the following procedures. Please note that the MSP430 and Stellaris LaunchPad boards each require different drivers.

1) Install drivers using the instructions provided with the LaunchPad kit.

– OR –

- Install drivers provided on the CD in the A2530 BoosterPack kit following the steps below. These drivers are the same as those provided by TI; Anaren has simply provided a GUI to install them.
 - a. Insert the BooserPack CD in the CD drive. The AIR A2530 BoosterPack Installation GUI should automatically start. If it does not, navigate to the CD drive using Windows Explorer and then double click the AutoRun.exe icon.

🌀 🗢 📕 « Local Disk	(C:) ► CD ROOT ►	✓ 4 Search CD ROOT	٩
Organize 👻 🖬 Open	New folder		≣ ▼ 🔟 🔞
☆ Favorites	Name	Date modified	Туре
📃 Desktop	Documentation	10/21/2012 3:10 PM	File folder
🚺 Downloads	Drivers	10/21/2012 3:10 PM	File folder
💠 Dropbox	🥼 Firmware	10/21/2012 3:10 PM	File folder
Recent Places	PCBDesignFiles	10/21/2012 3:10 PM	File folder
ivireless 🔋	💽 AutoRun.exe	10/19/2012 5:51 PM	Application
	Autorun.inf	10/18/2012 4:29 PM	Setup Information
🥃 Libraries			
Documents			
J Music			
Pictures			
Videos			•
AutoRun.exe D Application	ate modified: 10/19/2012 5:51 PM Size: 3.67 MB	Date created: 10/21/2012 3:10 PM	



Anaren Integrated Radio

b. Select which LaunchPad board will be used with the BoosterPack by clicking either the MSP430 button or Stellaris button.



c. Click on the "Install LaunchPad USB Driver" button.





Anaren Integrated Radio

When installing Stellaris drivers, a message will pop up indicating that later steps may warn about drivers not being signed. The installation may be cancelled at this point if you do not want to install unsigned drivers, however the USB Virtual COM will be unusable. Click OK to continue with the installation if you agree with installing unsigned drivers.



d. Click Next to continue the installation.





Anaren Integrated Radio

For Stellaris, Windows may provide a Security Warning due to the drivers not being signed. Click on "Install this driver software anyway" to continue installation. There may be up to three of these messages due to there being three separate drivers installed.



Click Finish when the installation is complete.





Anaren Integrated Radio

2.3. Programming the Demo Application on Stellaris

Follow these steps to load the "Simple Application" demo on each of the Stellaris LaunchPads.

- 1) Plug in one of the Stellaris LaunchPads to a USB port.
- 2) Run the Texas Instruments LM Flash Programmer utility available on the TI website.
- 3) In the Configuration tab, select "LM4F120 LaunchPad" from the Quick Set pull-down.

LM Flash Programmer - Build 1463	_ _ X
Configuration Program Flash Utilities Other Utilities	Help
Quick Set	
LM4F120 LaunchPad	<u> </u>
Interface	
ICDI (Eval Board)	
Speed (Hz): 2000000	
Clock Source	
Using the Selected Crystal Value: 16 MHz	-
C. Using the Specified Single Federal Source Units (UR):	_
Cosing the specified single Ended source value (Hz):	
TEXAS INSTRUME	INTS
Idle	



Anaren Integrated Radio

4) In the Program tab, browse to the "Firmware\FactoryDefault\Stellaris" folder on the BoosterPack CD and select "SimpleApplicationCoordinator.bin". Then click Program.

🛂 LM Flash Programmer - Build 1463	×
Configuration Program Flash Utilities Other Utilities	Help
Select .bin file	n Browse
Options	
Erase Method: © Erase Entire Flash - (faster) © Erase Necessary Pages - (slower)	
Veniy Arter Program Z Reset MCLI After Program	
Program Address Offset: 0x 0	
CRC32 - Device CPC32 -	
Calculate	
Program	Hardware Reset
🕂 Texas Instrum	IENTS
Idle	

- 5) Unplug the LaunchPad from the USB port.
- 6) Repeat steps 1 thru 5 above for the "SimpleApplicationRouter.bin" file.
- 7) Repeat steps 1 thru 5 above for the "SimpleApplicationEndDevice.bin" file.

Alternatively, the LaunchPads may be programmed using Code Composer Studio (CCS). The CCS projects are located in the "Firmware\ ZM Examples\CCS_Stellaris" folder on the BoosterPack CD.

Continue to section 2.4 for information on using the demo application.



Anaren Integrated Radio

2.4. IMPORTANT: Required Radio Setup

The AIR BoosterPack must be operated in accordance with local regulations. The firmware preloaded in the MSP430G2553 devices provided with the AIR BoosterPack kit (or loaded into the Stellaris devices as described in section 2.3) offers two radio operation options; FCC/IC for use in US/Canada (default) and ETSI for use in Europe. If your location is not covered by either FCC/IC or ETSI then you must check local regulatory codes for how to obtain permission to operate the modules prior to using them.

If covered under ETSI regulations, you must first change S4-1 to the OFF position as shown in Figure 10.



Figure 10 -BoosterPack Configured For Use in Europe (ETSI)



Anaren Integrated Radio

2.5. Using the Demo Application

The "Simple Application" demo is an example sensor network that passes measured data from the Router(s) and/or End Point(s) to the Coordinator.

All nodes configured as a Router periodically (about every 1.5 seconds) read the onboard IR Temperature sensor and transmit the value to the Coordinator. To change the sensor readings, simply place a warm (e.g. palm of your hand) or cold (e.g. soda can) object a few inches from the sensor. There is no need to have physical contact between the sensor and the object.

Similarly, all nodes configured as an End Point periodically (about every 3 seconds) read the onboard RGB Light sensor and transmit the value to the Coordinator. To change the sensor readings, shine a different color light at the sensor.

After applying power to the nodes they should start communicating within a minute. When communicating, each node blinks an LED.

- Coordinator flashes red LED D1
- Router RGB LED normally green, flashes blue
- End Point RGB LED normally OFF, flashes blue

The Coordinator displays the received data from the Router(s) and End Point(s) in two ways.

- 1) The data is sent out the UART. All messages received are displayed with details of the data transfer in addition to the actual measurements. The information may be viewed on a terminal emulator connected to the LaunchPad USB Virtual COM port. The port must be configured as 9600,8,N,1 for MSP430 and 115200,8,N,1 for Stellaris.
- 2) The measurements are displayed graphically via the onboard RGB LED (BoosterPack LED for MSP430, LaunchPad LED for Stellaris).
 - a. Router IR Temperature values are displayed as follows:
 - Blue = Cold
 - Green = Warm (room)
 - Red = Hot

To select this mode, press the S2 pushbutton (SW1 on the Stellaris LaunchPad) one time on the Coordinator. Red LED D8 should be OFF and yellow LED D9 should be ON.

b. The color of light detected by the EndPoint RGB Light Sensor is displayed. To select this mode, press the S2 pushbutton (SW1 on the Stellaris LaunchPad) a second time on the Coordinator. Red LED D8 should be ON and yellow LED D9 should be OFF.

2.6. AIR A2530 Wiki

Please visit the AIR A2530 Wiki (<u>http://www.anaren.com/air-wiki-zigbee</u>) on the Anaren website for details regarding the example applications, Module Interface Specification (i.e. API), and general Zigbee® information.



Anaren Integrated Radio

3. AIR BoosterPack Hardware

3.1. Electrical Characteristics

3.1.1. Absolute Maximum Ratings

Under no circumstances shall the absolute maximum ratings given in Table 2 be violated. Stress exceeding one or more of the limiting values may cause permanent damage to the device.



Caution!

ESD sensitive device. Precaution should be used when handling the device in order to prevent permanent damage.

Max	Unit	Conditio
Table	2 - Abs	solute Maximum Ratings

Parameter	Min	Max	Unit	Condition
Supply Voltage	-0.3	3.8	V	
Voltage On Any Digital Pin	-0.3	VDD + 0.3 max 3.8	V	
Input RF Level		+10	dBm	
Storage Temperature Range	-40	85	°C	
ESD		<2000	V	According to JEDEC STD 22, method A114, Human Body Model (HBM)
200		<500	V	According to JEDEC STD 22, C101C,Charged Device Model (CDM)

3.1.2. Recommended Operating Conditions

Table 3 - Recommended Operating Conditions

Parameter	Min	Max	Unit	Condition
Operating Supply Voltage	2.7	3.6	V	RGB Light Sensor powered
Operating Supply voltage	2.2	3.6	V	RGB Light Sensor disconnected
Operating Temperature	-40	85	°C	



Anaren Integrated Radio

3.2. Functional Description



Figure 11 – Hardware Block Diagram



Anaren Integrated Radio

3.2.1. A2530 Radio Module (U6)

The Anaren A2530 module is a 2.4GHz IEEE 802.15.4 compliant radio running the Texas Instruments ZNP protocol. For details regarding the radio module, refer to the A2530E24x and A2530R24x User's Manuals located on the CD provided in the BoosterPack kit.

3.2.2. MCU & Socket (U5)

The BoosterPack has a 20-pin DIP socket with a MSP430G2553 MCU pre-installed. This allows for operation of the BoosterPack while installed on a LaunchPad board or standalone. Please refer to the MSP430G2x53 datasheet and MSP430x2xx Family User's Guide on the TI website for further info regarding this device.

3.2.3. Sensors

RGB Light Sensor (U2)

The TAOS TCS3414 Digital Color Sensor (I²C) measures the color of ambient light and reports the measurements in 16-bit RGBC (Red/Green/Blue/Clear) format. Please refer to the TCS3414 datasheet on the TAOS website for further info regarding this device.

The I²C bus address of this device is 0x39.

IR Temperature Sensor (U3)

The Texas Instruments TMP006 Infrared Thermopile Sensor (I^2C) measures the temperate of an object without the need to make contact with the object (-40C to +125C operating range). Please refer to the TMP006 datasheet on the TI website for further info regarding this device.

Please note the BoosterPack itself is rated to +85C and should not be subjected to ambient temperatures above this limit.

The I²C bus address of this device is 0x40.

Current Sensor (U4)

The Texas Instruments INA216A2 Current Shunt Monitor (analog) amplifies the voltage across a current sense resistor with a gain of 50. Please refer to the INA216 datasheet on the TI website for further info regarding this device.

The sensor's analog output is routed to MSP430 pin P1.4 where it can be sampled using the MCU's internal ADC. The measured voltage can be used to calculate the current draw of the A2530 only or that of the entire board. The selection is made by setting jumper JP1 to the desired position (see section 3.2.7 for information on setting the jumper). To calculate current flowing through the 0.2 Ω sense resistor, simply divide the measured voltage by 10 (I_{shunt} = V_{shunt} / R_{shunt}, where R_{shunt} = 0.2 Ω and V_{shunt} = V_{meas} / 50).



Anaren Integrated Radio

3.2.4. Serial EEPROM (U1)

A 128Kbit (16K x 8) serial EEPROM is provided for applications that require storing data in nonvolatile memory. Please refer to the AT24C128C datasheet on the Atmel website for further info regarding this device.

The I²C bus address of this device is 0x50.

3.2.5. LED Indicators

Red LED (D1)

Duplicate of Red LED on MSP430 LaunchPad. Controlled by MSP430 P1.0 (J1.2) – active high.

Green LED (D2)

Duplicate of Green LED on MSP430 LaunchPad. Controlled by MSP430 P1.6 (J2.4) – active high. This LED is shared with the SPI MISO signal and is therefore unusable without modification to the SPI driver.

Yellow LED (D3)

Controlled by MSP430 P2.4 (J2.2) – active low. This LED is shared with the I^2C SCL signal and is only usable when not using I^2C .

Tri-Color LED (D4)

When using a MSP430 the Tri-Color LED can be pulse width modulated (PWM) to produce a wide range of colors. This capability is not available when the BoosterPack is used with a Stellaris LaunchPad due to lack of PWM capability on the chosen pins. In this situation, the Tri-Color LED on the Stellaris LaunchPad will need to be used instead for applications requiring multiple colors. The BoosterPack Tri-Color LED is controlled as follows:

Red Segment – MSP430 P2.1/TA1.1 (J1.9) – active low. Green Segment – MSP430 P2.5/TA1.2 (J2.3) – active low. Blue Segment – MSP430 P2.6/TA0.1 (J2.9) – active low.

A2530 Red LED (D8)

Controlled by A2530 P1.0 (GPIO3) – active high.

 A2530 Yellow LED (D9) Controlled by A2530 P0.6 (GPIO2) – active high.



Anaren Integrated Radio

Blue LEDs (D6, D7)

These LEDs (when populated) are always ON and are intended to produce a "cool" looking visual effect which is especially noticeable when the BoosterPacks are operated in a dark environment.



Figure 12 - BoosterPack with Blue LEDs Installed

3.2.6. Switches

- MCU Reset (S1) Duplicate of S1 reset pushbutton on MSP430 LaunchPad. Active low.
- MCU Control Input (S2)
 Duplicate of S2 user pushbutton on MSP430 LaunchPad. Active low.
- A2530 Reset (S5) Radio Module hardware reset. Active low.



Anaren Integrated Radio

Sensor/LED Power Control (S3)

These DIP switches are used to control power to specific devices on the BoosterPack board. The primary purpose is to provide a method for turning off unused devices to conserve power. For example, an application not using the Color Light Sensor would benefit from turning off position 3, since the light sensor is relatively power hungry. Another example would be an application that utilizes the LEDs but the user turns off positions 1 and 4 to reduce power consumption (no code change necessary).

The default state of all DIP switches is ON (closed).

Switch	Position	Signal Name	Description
			Power control for the on-board Red and Green LEDs (D1 and D2, respectively). Does not impact LEDs on the LaunchPad boards.
	1	D1,2_EN	ON (closed): Red and Green LEDs are enabled and may be turned on by driving their control signals high.
			OFF (open): Red and Green LEDs are disabled and cannot be turned on, regardless of the state of their control signals.
			Power control for the IR Temperature Sensor and EEPPROM on the I^2 C bus
	2	TEMP/ROM_EN	ON (closed): Power is applied to these devices.
S3			OFF (open): The devices are powered down.
			Power control for the I ² C RGB Light Sensor.
	3	LGT_EN	ON (closed): Power is applied to the device.
			OFF (open): The device is powered down.
			Power control for the on-board Yellow and Tri- Color LEDs (D3 and D4, respectively). Does not impact LEDs on the LaunchPad boards.
	4	D3,4_EN	ON (closed): Yellow and Tri-Color LEDs are enabled and may be turned on by driving their control signals low.
			OFF (open): Yellow and Tri-Color LEDs are disabled and cannot be turned on, regardless of the state of their control signals.

1 u o le 4 - Senson LED DIP Switch Settings (55)
--



Radio Module GPIO (S4)

These DIP switches are used to electrically isolate the LEDs and pull-down resistors from the A2530 GPIO signals for applications that require the GPIO but don't want the added load of the resistors and LEDs. Positions 1 and 2 (GPIO0 and GPIO1, respectively) may also be used as user input.

The default state of all DIP switches is ON (closed).

Switch	Position	Signal Name	Description
	1	GPIO0	Provides a method for changing the state of the A2530 GPIO input.ON (closed): Signal is pulled to GND through a 2KΩ Ohm resistor.
			OFF (open): Signal is floating.
	2	GPIO1	 Provides a method for changing the state of the A2530 GPIO input. ON (closed): Signal is pulled to GND through a 2KΩ Ohm resistor. OFF (open): Signal is floating.
S4	3	GPIO2	 A2530 Yellow LED connect/disconnect. ON (closed): Yellow LED is enabled and may be turned on by driving its control signal high. OFF (open): Yellow LED is disabled and cannot be turned on, regardless of the state of its control signal.
	4	GPIO3	 A2530 Red LED connect/disconnect. ON (closed): Red LED is enabled and may be turned on by driving its control signal high. OFF (open): Red LED is disabled and cannot be turned on, regardless of the state of its control signal.

Table 5 –	Radio	Module	GPIO	DIP	Switch	Settinos	(S4)
1 n o n o o -	manio	monnic	0110	$D\Pi$	Switch	Jungo	$(\mathbf{J}\mathbf{I})$



Anaren Integrated Radio

3.2.7. Jumpers

Current Sensor

The onboard Current Sensor can be configured to measure the current drawn by the A2530 radio module only or by the entire board. The current consumption of the radio module is always measured and the installed shunt determines which side of the current sense resistor the remainder of the board gets its power from. Therefore there must always be a shunt installed on JP1, otherwise only the radio module will be powered.

For applications that do not require current sensing and wish to utilize the MCU pin for another function, the Current Sensor's analog output can be disconnected from the rest of the board by removing the shunt from JP2.

Table 6 -	JP1	Jumper	Settings	(Current	Sensor	Select)
-----------	-----	--------	----------	----------	--------	---------

Jumper	Position	Description
	1	Current Sensor measures radio module only (default)
JPT	2	Current Sensor measures entire board

Table 7 - JP2 Jumper Settings (Current Sensor Enable)

Jumper	Position	Description
	Closed	Current Sensor analog output connected to MCU (default)
JPZ	Open	Current Sensor analog output disconnected from MCU

Radio Module Configuration

JP100 and JP101 control the operating mode of the A2530 radio module. Currently JP100 is reserved for future use while JP101 selects whether the electrical interface to the module is SPI or UART. Both of these are 3-terminal jumpers that can accommodate a 0603 resistor populated in one of two positions. The BoosterPack is shipped with a PCB trace making the default connection. To change to a different setting, this trace must be cut prior to soldering a resistor in the new position.

Table 8 -	JP100	Jumper	Settings	(CFG0)
-----------	-------	--------	----------	--------

Jumper	Position	Radio Signal Name	Description
	1	0500	Reserved (default)
JP100 2 CFG0	CrGU	Reserved	

Table 9 - JP101	Jumper Settings	(CFG1)
-----------------	-----------------	--------

Jumper	Position	Radio Signal Name	Description
	1		Radio uses SPI interface (default)
JFIUI	2 CFG1	CrGT	Radio uses UART interface



Anaren Integrated Radio

Radio Module Pin Mapping

The AIR BoosterPack board provides the ability to remap several of the radio module's I/O pins to different MCU pins. JP102, JP105, and JP108 consist of one or more 0603 SMT pads which allow a zero Ohm resistor to be soldered in place to select the desired jumper position. The default signal routing is determined by a small trace between one set of pads. To change jumper positions, this trace needs to be cut and a zero Ohm resistor soldered in the new position.

JP102, in conjunction with R100, selects whether the radio module's reset signal is generated by MCU pin P2.5 or P2.7. This allows applications requiring a crystal on the MCU to use a different pin for radio module reset, at the expense of giving up the use of the Green segment of the Tri-Color LED.

SRDY is a required signal when using a secondary MCU with the A2530 radio module, there JP105 should not be modified.

JP108 can be used to select whether MRDY is tied to MODULE_SS or uses its own MCU pin. Some applications may require MRDY to be isolated from MODULE_SS. In these cases, MRDY can be configured to use MCU pin P1.4 instead of P2.0, at the expense of giving up the use of the Current Sensor.

Jumper	Position	Radio Signal Name	MCU Signal Name	Description
10102	Closed	MDOT	P2.7	MRST connected to MCU pin P2.7 (default)
JP 102	Open	IVIRGI	/MRST	MRST disconnected from MCU pin P2.7

Table 10 – JP102 Jumper Settings

Table 11 – JP105 Jumper Settings

Jumper	Position	Radio Signal Name	MCU Signal Name	Description
	Closed	SDDA	P2.2/	SRDY connected to MCU pin P2.2 (default)
JF 105	Open	SKUT	SRDY	SRDY disconnected from MCU pin P2.2

Table 12 – JP108 Jumper Settings

Jumper	Position	Radio Signal Name	MCU Signal Name	Description
	1		P2.0/ MODULE_SS	MRDY connected to MCU pin P2.0 (default)
JP108	2	MRDY	P1.4/ CUR/ MRDY/ EXT_CSN	MRDY connected to MCU pin P1.4



Anaren Integrated Radio

I²C Pin Mapping

The example application preloaded in the MSP430 uses a software I^2C controller on port pins P2.3 and P2.4. For Stellaris applications utilizing a hardware I^2C controller, JP106 and JP107 may be used to free up these two pins for other purposes. Both of these are 2-terminal jumpers that can accommodate a 0603 resistor. The BoosterPack is shipped with a PCB trace making the connection by default. To break the connection, this trace must be cut.

Jumper	Position	LaunchPad Signal Name	MSP430 Signal Name	Description
10106	Closed	P2.3/	8DA	MSP430 P2.3 connected to J2-1 (default)
JP106	Open	SDA	SDA	MSP430 P2.3 disconnected from J2-1

Table 13 - JP106 Jumper Settings (SDA)

|--|

Jumper	Position	LaunchPad Signal Name	MSP430 Signal Name	Description
JP107	Closed	P2.4/	SCL	MSP430 P2.4 connected to J2-2 (default)
	Open	LED3		MSP430 P2.4 disconnected from J2-2

Miscellaneous

JP103 and JP104 are small solder jumpers intended for test purposes only. Do not bridge the gap at these locations as the I²C signals (SCL, SDA) would be shorted directly to GND, preventing normal operation of the I²C bus.

Jumper	Position	Radio Signal Name	MCU Signal Name	Description
10102	Closed	троо	SD4	Reserved
JP 103	Open	1823	SDA	Reserved (default)

Table 15 - JP103 Jumper Settings

Table 16 - JP104 Jumper Settings

Jumper	Position	Radio Signal Name	MCU Signal Name	Description	
	Closed	TD01	50	Reserved	
JP 104	Open	IPZI	SUL	Reserved (default)	



Anaren Integrated Radio

3.2.8. Connectors

• J1 – LaunchPad J1 Interface

Pin	Signal Name	I/O	Description
J1-1	LP_VCC	I	Supply voltage
		0	LaunchPad Red LED Control – active high
11-2		0	(onboard MSP430)
J1-2	FI.0/LEDI	1	Red LED control – active high
		1	(external LaunchPad MCU)
		1	UART receive data
.11-3	P1 1/RXD	1	(onboard MSP430)
010		-	Not Connected
			(external LaunchPad MCU)
		0	UART transmit data
.11-4	P1 2/TXD		(onboard MSP430)
01.1	11.2,17,0	-	Not Connected
			(external LaunchPad MCU)
J1-5	P1.3/S2	1/0	Pushbutton Switch connected in parallel with S2 on
	1 110,02	., O	MSP430 LaunchPad – active low
	P1 4/CUR/MRDY/EXT_CS		Not Used
J1-6		0	(onboard MSP430)
			Current Sensor analog signal
			(external LaunchPad MCU)
		0	Not used
J1-7	P1.5/SCLK		(Onboard MSP430)
			Radio Module SPI Clock
			(external LaurenPau WCO)
		0	(ophoard MSP430)
J1-8	P2.0/MODULE_SS		(Ulibualu MSF430) Radio Modulo Slavo Soloct - activo low
		Ι	(external LaunchPad MCII)
			Not Used
		0	(onboard MSP430)
J1-9	P2.1/LED4		RGB red I ED control – active low
		I	(external LaunchPad MCU)
			Not Used
			(onboard MSP430)
J1-10	P2.2/SRDY	0	Radio Module Slave Ready – active high
			(external LaunchPad MCU)

Table 17 –	J1 Lau	nchPad	Connector	Pinout
------------	--------	--------	-----------	--------



Page 31 of 45

Anaren Integrated Radio

J2 – LaunchPad J2 Interface

Pin	Signal Name	I/O	Description
			Not used
J2-1		1/0	(onboard MSP430)
J2-1	P2.3/5DA	1/0	I ² C Data
			(external LaunchPad MCU)
		0	I ² C Clock output
10.0		0	(onboard MSP430)
JZ-2	P2.4/SOL/LEDS	Not Used I/O Iono I/O I ² C Data (external LaunchPad MCU) I ² C Clock output (onboard MSP430) I I ² C Clock input (external LaunchPad MCU) O Not Used (onboard MSP430) I RGB green LED control – active low (external LaunchPad MCU) O Not Used (onboard MSP430) I RGB green LED control – active low (external LaunchPad MCU) O LaunchPad Green LED Control – active high (onboard MSP430) O Radio Module SPI Data Output (external LaunchPad MCU) I Green LED control – active high (external LaunchPad MCU) I Green LED control – active high (onboard MSP430) I Radio Module SPI Data Input (external LaunchPad MCU) I/O Reset / Spy-Bi-Wire Data (onboard MSP430) I/O Reset / Spy-Bi-Wire Data (onboard MSP430) I Test / Spy-Bi-Wire Clock (onboard MSP430) I Test / Spy-Bi-Wire Clock (onboard MSP430) I Radio Module Reset – active low (external LaunchPad MCU) O Not Connected (external LaunchPad MCU) O Not Used (onboard MSP430) I Radio Module Reset – active low (external LaunchPad MCU)	I ² C Clock input
			(external LaunchPad MCU)
		0	Not Used
10.0		0	(onboard MSP430)
JZ-3	F2.3/LED3	1	RGB green LED control – active low
		I	(external LaunchPad MCU)
		0	LaunchPad Green LED Control – active high
		0	(onboard MSP430)
12.4		0	Radio Module SPI Data Output
J2-4	F1.0/WIGO/LEDZ	0	(external LaunchPad MCU)
			Green LED control – active high
			(external LaunchPad MCU)
		0	SPI MOSI
12-5	P1 7/MOSI		(onboard MSP430)
02-0	11.7/10001	1	Radio Module SPI Data Input
			(external LaunchPad MCU)
		1/0	Reset / Spy-Bi-Wire Data
.12-6	RST/S1	"0	(onboard MSP430)
02.0		_	Not Connected
		I/O I/O I/C Data (external LaunchPad MCU) I/C Clock output O I/C Clock input (onboard MSP430) I I I/C Clock input (external LaunchPad MCU) O Not Used (onboard MSP430) I I/C Clock input (external LaunchPad MCU) O Not Used (onboard MSP430) I RGB green LED control – active low (external LaunchPad MCU) O Radio Module SPI Data Output (external LaunchPad MCU) O Radio Module SPI Data Output (external LaunchPad MCU) O SPI MOSI (onboard MSP430) I Reset / Spy-Bi-Wire Data (onboard MSP430) I Reset / Spy-Bi-Wire Data (onboard MSP430) I Test / Spy-Bi-Wire Data (onboard MSP430) I Test / Spy-Bi-Wire Clock (onboard MSP430) I Test / Spy-Bi-Wire Clock (onboard MSP430) Not Connected (external LaunchPad MCU) <td>(external LaunchPad MCU)</td>	(external LaunchPad MCU)
		1	Test / Spy-Bi-Wire Clock
.12-7	TEST		(onboard MSP430)
•= ·		-	Not Connected
			(external LaunchPad MCU)
J2-8		0	Not Used
	P2.7/MRST		(onboard MSP430)
			Radio Module Reset – active low
			(external LaunchPad MCU)
.12-9		0	Not Used
	P2.6/LED6	Ľ.	(onboard MSP430)
		Ι	RGB blue LED control – active low
			(external LaunchPad MCU)
J2-10	GND	-	Ground reference

Table 18 - J2 LaunchPad Connector Pinout



Anaren Integrated Radio

• J3 – External Device Interface

0.1" pitch thru-hole footprint which provides a single location for connecting external devices (e.g. sensors) to the BoosterPack via SPI and/or I²C.

It is also possible to connect an external MCU acting as SPI/I²C master to this port, provided the LaunchPad/BoosterPack MCU is removed or configured as SPI/I²C slave device (e.g. to drive LEDs or monitor pushbuttons). Firmware examples for using the LaunchPad/BoosterPack MCU as a slave device are not provided.

Please note that the shunt must be removed from JP2 when using an external SPI slave device (see section \Box for more details).

Pin	Signal Name	I/O	Description
J3-1	GND	-	Ground reference
J3-2	P1.4/CUR/MRDY/EXT_CS	0	Chip Select output to external SPI slave – active low
J3-3	VDD	0	Supply voltage to external device(s)
		\circ	MOSI output to external SPI slave
13-4		0	(MCU on LaunchPad or BoosterPack)
00-4	1 1.7/10001	1	MOSI input from external SPI master
		'	(external MCU connected via J3)
		0	Clock output to external I ² C slave(s)
.13-5	SCI	Ŭ	(MCU on LaunchPad or BoosterPack)
000	002	1	Clock input from external I ² C master
		•	(external MCU connected via J3)
		0	MISO output to external SPI master
J3-6	P1.6/MISO/LED2		(external MCU connected via J3)
00-0			MISO input from external SPI slave
			(MCU on LaunchPad or BoosterPack)
J3-7	SDA	I/O	I ² C Data
		0	SCLK output to external SPI slave
J3-8	P1.5/SCLK	-	(MCU on LaunchPad or BoosterPack)
		- Ground reference CS O Chip Select output to external SPI slave – act O Supply voltage to external device(s) O MOSI output to external SPI slave (MCU on LaunchPad or BoosterPack) I MOSI input from external SPI master (external MCU connected via J3) O Clock output to external I ² C slave(s) (MCU on LaunchPad or BoosterPack) I Clock input from external I ² C master (external MCU connected via J3) O MISO output to external SPI master (external MCU connected via J3) O MISO output to external SPI master (external MCU connected via J3) I MISO input from external SPI slave (MCU on LaunchPad or BoosterPack) I/O I ² C Data O SCLK output to external SPI slave (MCU on LaunchPad or BoosterPack) I SCLK input from external SPI master (external MCU connected via J3) - Ground reference O Not Used (MCU on LaunchPad or BoosterPack) I Radio Module Chip Select input from external master (external MCU connected via J3) O Radio Module Slave Ready output I Not Used (MCU on LaunchPad or BoosterPack) I Radio Module Slave Ready output O Not Used (MCU on LaunchPad	SCLK input from external SPI master
10.0		- Ground reference 3 O Chip Select output to external SPI slave – active 0 Supply voltage to external device(s) 0 MOSI output to external SPI slave 0 MOSI output to external SPI slave 1 MOSI input from external SPI master (external MCU connected via J3) Clock output to external I ² C slave(s) 0 Clock input from external I ² C master (external MCU connected via J3) Clock input from external SPI master 1 Clock input from external SPI master (external MCU connected via J3) MISO output to external SPI master 0 MISO output from external SPI master (external MCU connected via J3) MISO input from external SPI slave 1 MISO input from external SPI slave (MCU on LaunchPad or BoosterPack) I/O 1/O I ² C Data 0 SCLK output to external SPI master (external MCU connected via J3) - 1 SCLK input from external SPI master (MCU on LaunchPad or BoosterPack) Radio Module Chip Select input from external S 1 SCLK input from external SPI master (external MCU connected via J3)	(external MCU connected via J3)
J3-9	GND	-	Ground reference
		0	Not Used
		O Chip Select output to external SPI slave – active low O Supply voltage to external device(s) O MOSI output to external SPI slave (MCU on LaunchPad or BoosterPack) MOSI input from external SPI master (external MCU connected via J3) Clock output to external I ² C slave(s) (MCU on LaunchPad or BoosterPack) Clock output to external I ² C master (external MCU connected via J3) Clock input from external I ² C master (external MCU connected via J3) MISO output to external SPI master (external MCU connected via J3) MISO output to external SPI master (external MCU connected via J3) MISO input from external SPI slave (MCU on LaunchPad or BoosterPack) MISO I/O I ² C Data O SCLK output to external SPI slave (MCU on LaunchPad or BoosterPack) I I SCLK input from external SPI master (external MCU connected via J3) Ground reference O Not Used (MCU on LaunchPad or BoosterPack) Radio Module Chip Select input from external SPI I master (external MCU connected via J3) O O Radio Module Chip Select input from external SPI	
J3-10	P2.0/MODULE_SS		Radio Module Chip Select input from external SPI
		I	master
	0000		(external MCU connected via J3)
J3-11	SRDY	0	Radio Module Slave Ready output
		0	Not Used
J3-12	MRST	-	(MCU on LaunchPad or BoosterPack)
		1 Image: Internal Internation of the image: Internating the image: Internation of the image: Internation of t	Radio Module hardware reset – active low
			(external MCU connected via J3)

Table 19 - J3 External Device Connector Pinout



Anaren Integrated Radio

J4 – Radio Module Programming/Debugging Interface

0.05" pitch footprint for A2530 programming/debugging using a CC Debugger.

Pin	Signal Name	I/O	Description
J3-1	GND	-	Ground reference
J3-2	VDD	0	Supply voltage to debugger
J3-3	MODULE_DC		Radio Module Debug Clock
J3-4	MODULE_DD	I/O	Radio Module Debug Data
J3-5	-	-	
J3-6	-	-	
J3-7	MRST		Radio Module Hardware Reset – active low
J3-8	-	-	
J3-9	-	-	
J3-10	-	-	

Table 20 –	J4 A2530	Program/Debug	Connector	Pinout
------------	----------	---------------	-----------	--------

J5 – Radio Module GPIO Interface

0.1" pitch thru-hole footprint which provides access to the Radio Module's four GPIO signals. For applications requiring use of these pins, the LEDs and $2K\Omega$ pull-down resistors sharing the GPIO signals may be electrically isolated by turning off the S4 DIP switches (see Table 5 for more info regarding the DIP switches).

Table 21 -	J5 A2530	GPIO	Connector	Pinout
------------	----------	------	-----------	--------

Pin	Signal Name	I/O	Description
J3-1	GND	1	Ground reference
J3-2	VDD	0	Supply voltage
J3-3	GPIO1	I/O	Radio Module P0.1
J3-4	GPIO0	I/O	Radio Module P0.0
J3-5	GPIO3	I/O	Radio Module P1.0
J3-6	GPIO2	I/O	Radio Module P0.6

J101 – External Power Interface

2mm pitch shrouded header for connecting external power (e.g. from a battery) to the BoosterPack. The positive terminal has a series Schottky diode to prevent accidental battery charging in the event the BoosterPack is installed on a powered LaunchPad.

	Table 22 –	J101	External	Power	(Battery)	Connector	Pinout
--	------------	------	----------	-------	-----------	-----------	--------

Pin	Signal Name	I/O	Description
J101-1	GND	-	Ground reference
J101-2	VDD		Supply voltage



3.3. Schematics



Anaren Integrated Radio





Anaren Integrated Radio

3.4. PCB Layout



Figure 15 - PCB Layout Top Layer



Figure 16 - PCB Layout Inner Layer (GND Plane)



Anaren Integrated Radio



Figure 17 - PCB Layout Inner Layer (Split PWR Plane)



Figure 18 - PCB Layout Bottom Layer



Anaren Integrated Radio



Figure 19 - PCB Layout Top Silkscreen



Figure 20 - PCB Layout Bottom Silkscreen



Anaren Integrated Radio



Figure 21 - PCB Layout Bottom Layer Mirror Image



Figure 22 - PCB Layout Bottom Silkscreen Mirror Image



Anaren Integrated Radio

3.5. Bill of Materials (BOM)

Item	Ref Des	Qty	Description	Comment
1	C1,C2,C3,	5		
-	C4,C9	5	CAP CER 0.101 107 1078 X/10 0402	
2	C5,C6	2	CAP CER 1000PF 50V 5% NP0 0402	
3	C7,C8	2 NP	CAP CER 12PF 50V 5% NP0 0402	Not populated
4	C10	1	CAP CER 10UF 6.3V 20% X5R 0603	
5	D1,D8	2	LED 0402 RED SMD	
6	D2	1	LED 0402 GREEN SMD	
7	D3,D9	2	LED 0402 YELLOW SMD	
8	D4	1	LED RGB SQUARE CLEAR SMD	
9	D5	1	DIODE SCHOTTKY 500mA SMD	
10	D6 D7	2 NP	LED 0402 BLUE SMD	Not populated
10	20,21	2 11		APHHS1005QBC/D (or equivalent)
11	J1,J2	2	CONN SOCKET 10POS 2.54MM SINGLE ROW VERTICAL T/H	
12	J3	1 NP	CONN HEADER 12POS 2.54MM DUAL ROW VERTICAL T/H	Not populated
13	J4	1 NP	CONN HEADER 10POS 1.27MM DUAL ROW VERTICAL T/H SHROUDED	Not populated Samtec SHF-105-01-L-D-TH
				(or equivalent)
14	J5	1 NP	CONN HEADER 6POS 2.54MM DUAL ROW VERTICAL T/H	Not populated
15	J101	1	CONN HEADER 2POS 2MM RA T/H	
16	JP1 (HDR)	1	CONN HEADER 3POS 2MM SINGLE ROW VERTICAL T/H	
17	JP1 (SHUNT)	1	CONN SHUNT 2MM 2POS GOLD	
18	JP2 (HDR)	1	CONN HEADER 2POS 2MM SINGLE ROW VERTICAL T/H	
19	JP2 (SHUNT)	1	CONN SHUNT 2MM 2POS GOLD	
20	JP100, JP101, JP108	3 NP	JUMPER 3PAD SMD (RES 0.0 OHM 1/10W 0603 SMD)	Not populated
21	JP102, JP105, JP106, JP107	4 NP	JUMPER 2PAD SMD (RES 0.0 OHM 1/10W 0603 SMD)	Not populated

Table 23 - Bill of Material







Anaren Integrated Radio

Item	Ref Des	Qty	Description	Comment
22	R1,R15, R18	3	RES 47K OHM 1/10W 5% 0402 SMD	
23	R2,R5,R7, R8,R9, R10,R11, R12,R13, R14,R16, R17,R19, R20,R21	13/2 NP	RES 2K OHM 1/10W 5% 0402 SMD	R12,R13 not populated
24	R3,R6	2	RES 0.2 OHM 1/10W 1% 0603 SMD	
25	R4	1 NP	RES 0.0 OHM 1/10W 0402 SMD	Not populated
26	R100	1 NP	RES 0.0 OHM 1/10W 0603 SMD	Not populated
27	S1,S2,S5	2/1 NP	SWITCH TACT SPST NO SMD	S5 not populated Omron B3U-1000P (or equivalent)
28	S3,S4	2	SWITCH DIP 4POS 1.27MM SMD	
29	U1	1	IC EEPROM 128KBIT 400KHZ 8UDFN	Atmel AT24C128C-MAHM-T
30	U2	1	IC COLOR SENSOR DGTL PROGR 6-DFN	TAOS TCS3414FN
31	U3	1	IC SENSOR THERMOPILE 8DSBGA	Texas Instruments TMP006AIYZFT
32	U4	1	IC CURRENT SHUNT MONITOR 4DSBGA	Texas Instruments INA216A2YFFR
33	U5 (SKT)	1	IC SOCKET 20PIN	
34	U5 (IC)	1	IC MCU 16BIT 16KB FLASH 20PDIP	Texas Instruments MSP430G2553IN20
35	U6	1	RADIO MODULE A2530 SMD	Anaren A2530E24AZ1 or A2530R24AZ1
36	Y1	1 NP	CRYSTAL 32.768 KHZ 12.5PF SMD	Not populated Abracon ABS06-32.768KHZ-T (or equivalent)



Anaren Integrated Radio

HISTORY

Date	Author	Change Note No./Notes
11/2/12		Initial Draft



Anaren Integrated Radio

THIS PAGE LEFT INTENTIONALLY BLANK

Attach distributor contact information here

If you have additional questions, need samples, or would like a quote – please email the AIR team at <u>AIR@anaren.com</u>.

For a full list of our franchised distributors, please visit our website: <u>http://www.anaren.com/air/</u>



 $\left(\left(\left(AIR\right)\right)\right)$



Anaren Microwave, Inc.	Anaren Microwave (Europe), Inc.	Anaren Communication Suzhou Co. Ltd.
6635 Kirkville Road	12 Somerset House, Suite 16 & 17	No. 5 Chun Hui Road
East Syracuse, NY 13057	Hussar Court, Waterlooville	Wei Ting, Suzhou Industrial Park
Tel: +1 315 432 8909	Hampshire, England P07-7SG	Suzhou 215122, PR China
+1 800 411 6596	Tel: +44 2392 232392	Tel: +86 512 6287 6400
Fax: +1 315 432 8970	Fax: +44 2392 251369	Fax: +86 512 6274 9283

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Anaren: A2530E24A-LPZ