

ACT88760EVK-102.E2 User's Guide

Description

This document describes the characteristics and operation of the Qorvo ACT88760EVK-102.E2 evaluation kit (EVK). It provides setup and operation instructions, schematic, layout, BOM, and test data. This EVK demonstrates the ACT88760-102.E2T Active PMU power management IC. Other ACT88760-xxx options can be evaluated on this EVK by replacing the IC and any other necessary components.

Features

The EVK can be used as a standalone board if desired. However, to access the internal registers and to take full advantage of the IC's capability, the user must connect the EVK kit to a PC with Qorvo's USB-TO-I2C interface dongle and use the GUI software. The EVK provides full access to each converter's input and output voltage, as well as all the digital control signals. This gives the user the flexibility to configure the EVK to match their real system.

Note that the ACT88760EVK-102.E2 is specifically configured for the ACT88760-102.E2T.




Figure 1– EVK Picture

EVK Contents

The ACT88760EVK-102.E2 evaluation kit comes with the following items:

1. EVK assembly
2. USB-TO-I2C dongle
 - a. Dongle
 - b. Custom 4-pin connector that connects the USB-TO-I2C dongle to the EVK assembly.

Required Equipment

ACT88760EVK-102.E2

USB-TO-I2C Dongle

Power supply – 5V @ 8A for full power operation

Oscilloscope – >100MHz, >4 channels

Loads – Electronic or resistive. 8.0A minimum current capability.

Digital Multi-meters (DMM)

Windows compatible computer with spare USB port.

Hardware Setup




Figure 2 – EVK Setup

Quick Start

Hardware Setup

1. The EVK is configured to support the dual-phase Buck1 and Buck2 configuration, so R1 is installed on the PCB. R2 is removed because Buck3 and Buck4 operate as separate power supplies. R1 and R2 can be changed as needed depending on the specific CMI being evaluated.
2. Decide which voltage will power VIO. If the shorting jumper is not installed on J10, the ACT88760-102 powers VIO from an internal 1.8V rail. It is ok to choose a different VIO voltage by connecting a shorting jumper between J10-1(VIN) and J10-2(VIO), or between J10-2(VIO) and J10-3(LDO3), either before or after applying input power to the EVK. Note that applying a different input voltage to VIO may affect the EVK startup waveforms.
3. Connect a lab supply between J1-1(VIN) and J1-2(GND) to power VIN.
4. Connect a shorting jumper between J3-1 (VIN) and J3-2 (INL1) to use VIN to power LDO1.
5. Connect a shorting jumper between J5-1 (VIN) and J5-2 (INL2) to use VIN to power LDO2.
6. Connect a shorting jumper between J7-1 (VIN) and J7-2 (INL3) to use VIN to power LDO3.
7. Connect a shorting jumper between J4-1 (VIN) and J4-2 (INL4) to use VIN to power LDO4.
8. Connect a shorting jumper between J6-2 (INL5) and J6-3 (OUT7) to use OUT7 to power LDO5.
9. Connect a shorting jumper between J8-2 (INL6) and J8-3 (OUT5) to use OUT5 to power LDO6.
10. Connect a shorting jumper between J19-1(GPIO3) and J19-2(GND), connect a shorting jumper between J21-1(GPIO4) and J21-2(GND) to set Buck1/2/7 output VSET0.
11. Connect a shorting jumper between J14-1(VIO with a pull up resistor) and J14-2(GPIO6) to set GPIO6 high. GPIO6 is the PWREN pin to control system ON/OFF, enter/exit DPSLP for ACT88760-102.
12. Connect a shorting jumper between J23-1(VIO with a pull up resistor) and J23-2(GPIO9) to pull up GPIO9 to VIO. Note that D1 is not installed on the EVK.
13. Connect an appropriate load to each power supply output.
14. Apply a 5V input voltage to J1 and the outputs turn on automatically.

GUI Setup (optional)

1. Install the ACT88760 GUI.
2. Connect the USB-TO-I2C dongle to the computer via a USB cable.
3. Connect the USB-TO-I2C dongle to the EVK J34 connector. Refer to Figure 4 to ensure the correct polarity of the connection. As a guide, use the “Qorvo” logo or (“Active-Semi”) logo on the top of the dongle so the black wire is connected to the Dongle GND pin.




Figure 3 – USB-TO-I2C Dongle Connection

EVK Design Parameters

The ACT88760EVK-102.E2 is designed for a 5V input voltage. Table1 shows the Regulators’ output voltage and the current supply capability.

Table 1. EVK Design Parameters

Parameter	Description	Min	Typ	Max	Unit
VIN	Operation Input range of Power Supply	3	5	5.8	V
OUT1	Buck1 output voltage, (Buck 12, 2-phase)		0.8		V
OUT2	Buck2 output voltage, (Buck 12, 2-phase)		0.8		V
OUT3	Buck3 output voltage		1		V
OUT4	Buck4 output voltage		1.8		
OUT5	Buck5 output voltage		2.7		
OUT6	Buck6 output voltage		3.3		
OUT7	Buck7 output voltage		0.8		
LDO1	LDO1 output voltage		1.8		
LDO2	LDO2 output voltage		1.2		
LDO3	LDO3 output voltage		3.3		
LDO4	LDO4 output voltage		3.3		
LDO5	LDO5 output voltage, Load Switch from Buck7=0.8V		LSW		
LDO6	LDO6 output voltage, Load Switch from Buck5=1.1V		LSW		
Io_OUT1	Buck1 load current		4	4	A

Io_OUT2	Buck2 load current		4	4	A
Io_OUT3	Buck3 load current		3	3	A
Io_OUT4	Buck4 load current		3	3	A
Io_OUT5	Buck5 load current		2	2	A
Io_OUT6	Buck6 load current		2	2	A
Io_OUT7	Buck7 load current		4	4	A
Io_LDO1	LDO1 load current		0.8	0.8	A
Io_LDO2	LDO2 load current		0.8	0.8	A
Io_LDO3	LDO3 load current		0.2	0.4	A
Io_LDO4	LDO4 load current		0.2	0.4	A
Io_LDO5	LDO5 load current		0.2	0.4	A
Io_LDO6	LDO6 load current		0.2	0.4	A

EVK Operation

Turn ON

Apply the 5V input voltage.



2-Phase Parallel Mode

Buck1 and Buck2 work in 2-phase parallel mode in ACT88760-102.E2. In parallel mode operation they are combined into a single higher current 2-phase regulator to support up to 8A (10A peak) output currents. Buck3 and Buck4 also can be operated as a single 2-phase regulator to support output currents up to 6A (8A peak). Note that the ACT88760-102.E2 configures Buck3 and Buck4 as separate, single phase outputs.


PWREN

GPIO6 is used for the PWREN function. It is defined as an active high input. Connect GPIO6 to VIO using the shorting jumper on J24, apply VIN=5V, then all outputs automatically turn on with the programmed startup sequence. PWREN is then used to enter or exit DPSLP mode. Drive GPIO6 from high to low to enter DPSLP mode, and drive GPIO6 from low to high to exit DPSLP mode.

Test Result




CMI 102
Startup Sequence




4ms / div

CMI 102
Enable LDO5/6 by GPIO7




4ms / div

CMI 102
Enter SLEEP Mode by I2C




1ms / div

CMI 102
Enter SLEEP Mode by I2C




1ms / div


CMI 102
Exit SLEEP Mode by I2C




CMI 102
Exit SLEEP Mode by I2C




CMI 102
GPIO3/4 Control Buck1/2/7 DVS




CMI 102
GPIO3/4 Control Buck1/2/7 DVS




CMI 102
Enter and Exit DPSLP Mode by PWREN




CMI 102
Enter and Exit DPSLP Mode by PWREN




CMI 102
Buck1/2 Ripple and SW @8A Load




CMI 102
Buck3 Ripple and SW @3A Load




CMI 102
Buck5 Ripple and SW @2A Load




CMI 102
Buck7 Ripple and SW @4A Load




CMI 102
Buck1/2 Load Transient, 2A-6A




CMI 102
Buck3 Load Transient, 0.75A-2.25A



CMI 102
Buck5 Load Transient, 0.7A-1.5A



CMI 101
Buck7 Load Transient, 1A-3A



Schematic




Figure 4 – ACT88760EVK1-102 Schematic

Layout




Figure 5 – Layout Top Layer




Figure 6 – Layout GND Layer




Figure 7 – Layout AGND Layer




Figure 8 – Layout VIN Layer




Figure 9 – Layout Bottom Layer

Bill of Materials

Table 2 – BOM

Item	Designator	Quantity	Description	Manufacturer	Part Number
1	C1, C16, C20, C22, C25, C29, C32	7	Capacitor, Ceramic, 1uF, 0603	SAMSUNG	std
2	C2, C3, C8, C12, C15, C23, C30, C36	8	Capacitor, Ceramic, 10uF, 0603	Murata	std
3	C4, C5, C6, C9, C10, C11, C13, C14, C18, C19, C26, C27, C33, C34, C37, C38, C39	17	Capacitor, Ceramic, 22uF, 0603	Murata	std
4	C7	1	Capacitor, Ceramic, 100nF, 0603	Murata	std
5	C17, C21, C24, C28, C31, C35	6	Capacitor, Ceramic, 2.2uF, 0603	Murata	std
6	D2	1	Diode, Led, blue, 0603		
7	D1	0	Diode, Led, blue, 0603		
8	J1, J2, J9, J11, J17, J22, J29, J32	8	Connector, Screw Terminal, 3.50, 2P	Würth	691214110002S
9	J3, J4, J5, J6, J7, J8, J10, J13, J14, J23, J24	11	Header, Unshrouded, 2.54, Male, 3P	Würth	61300311121
10	J12, J15, J16, J18, J19, J20, J21, J25, J26, J27, J28, J30, J31	13	Header, Unshrouded, 2.54, Male, 2P	Würth	61300211121
11	J33	1	Header, Unshrouded, 1.27, Male, 6P	Würth	GRPB061VWVN-RC
12	J34	1	Header, Unshrouded, 2.54, Male, 4P	Würth	61300411121
13	L1, L2, L7	3	Inductor, 0.47uH, 4020	WURTH	744383560047HT
14	L3, L4, L5, L6	4	Inductor, 0.47uH, 2512	WURTH	744383240047
15	nPB	1	Switch, TSW, TE-1437565-0	std	std
16	R1	1	Resistor, 0R, 1206	Standard	Standard
17	R2	0	Resistor, 0R, 1206	Standard	Standard
18	R3, R4, R5, R6, R7, R8, R9, R10, R11, R12, R13	11	Resistor, 100k, 0603	Standard	Standard
19	TP1, TP3, TP5, TP7, TP9, TP11, TP13	7	TEST POINT PC MINI .040"D RED	KeyStone	5000
20	TP2, TP4, TP6, TP8, TP10, TP12, TP14	7	TEST POINT PC MINI .040"D BLK	KeyStone	5001
21	U1	1	IC, ACT88760	Qorvo	ACT88760-102.E2T

GUI Installation

1. You can find the ACT88760 GUI files on the Qorvo website. Save them on your computer.
2. Plug the USB-TO-I²C dongle into a free USB port.
3. Follow the instructions of “Qorvo's GUI and Dongle Driver Installation Rev1.1” in the “Driver” folder.
4. Double click on the ACT88760 GUI Rev1.2.exe to start the ACT88760 GUI.

Name	Date modified	Type	Size
Archive	9/4/2020 5:07 PM	File folder	
CodingMatrix	9/4/2020 5:07 PM	File folder	
Config	9/4/2020 5:07 PM	File folder	
Data	9/4/2020 9:06 AM	File folder	
DieLib	9/4/2020 5:07 PM	File folder	
Driver	9/4/2020 5:07 PM	File folder	
Function	9/4/2020 9:06 AM	File folder	
Note	9/4/2020 9:06 AM	File folder	
Script	9/4/2020 5:07 PM	File folder	
Temp	9/4/2020 5:07 PM	File folder	
TileLib	9/4/2020 5:07 PM	File folder	
ACT88760 ActiveCiPS GUI User's Guide-Rev0.2 20200821.pdf	9/4/2020 5:07 PM	Adobe Acrobat D...	322 KB
ACT88760 EVK GUI User's Guide-Rev0.2 20200727.pdf	9/4/2020 5:07 PM	Adobe Acrobat D...	626 KB
ACT88760 GUI Rev1.2.exe	9/4/2020 5:07 PM	Application	21,484 KB
Qorvo's GUI and Dongle Driver Installation Rev1.1.pdf	9/4/2020 5:07 PM	Adobe Acrobat D...	1,268 KB

Figure 9 – GUI Folder

GUI Overview

The GUI has 2 basic function buttons allocated in top-left of the Tool Bar which are Read and Write I2C. The GUI contains 2 setting modes: Configuration Mode and Regulator Mode. In Configuration Mode screen it displays each regulator's basic information on a single page, all the information is user configurable via the drop-down boxes. Regulator Mode allows the user to view and change the IC's advanced internal registers of each regulator.

Configuration Mode

Click the “Configuration” button in the left of the GUI screen to see the basic user programmable options. This display mode allows user to change some basic settings of each regulator (voltages, current...). User can use either the mouse scroll or the right-side scroll bar to navigate to other regulators. Using drop-boxes, left-click the small arrow next to the value, then a selection pop-up displays all possible options to choose from. Scroll up/down to find the target value and left-click to select it. After the required parameters are changed, click the “Write” button to transfer the changes from the GUI to the IC.




Figure 10 – GUI Configuration Mode

Regulator Mode

Click the “Regulator” button in the left of the GUI screen to see all available user programmable options. In the left side of the screen, click on the Tiles Selector to choose which regulator or LDO’s to show. There are two tabs for each tile, “Setting “and “Register”.

The “Settings” tab is easy to read and has drop down menus that show the available choices. The “Registers” tab shows the actual register values required to achieve a desired setting.




Figure 11 – GUI Setting Tab of Regulator Mode




Figure 13 – GUI Register Tab of Regulator Mode

Button Descriptions

Read: Clicking on this button reads the ACT88760 registers and displays them in the GUI. Note that this reads all registers. Active-Semi recommends reading registers each time the ACT88760 powers-up to acquire the initial register settings. Qorvo also recommends reading registers after making changes to them. Immediately reading the registers after a write confirms the changes were properly stored. This also updates the SYSTEM STATUS box to ensure that one of the changes did not generate a fault condition.



Figure 12 – Read Button

Write: Clicking on this button writes the GUI settings to the ACT88760's registers. All registers are written, regardless of whether or not they were changed.

Note: Remember that changes to the GUI settings are not transferred into the IC until the GUI's "Write" button is pressed.



Figure 15 – Write Button

Dongle Connection Status: The GUI also contains a dongle is connected status which indicates that Active-Semi's USB-TO-I2C dongle is connected to the USB port of the driver installed. The figure below shows the two possible indication status graphics.




Figure 136– Dongle Connection Status

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Qorvo:

[ACT88760EVK1-101](#)