




Products Crimped
AMPLI-BOND* and PLASTI-GRIP* Terminals
TERMINYL* Terminals and Splices
Pre-Insulated AMPOWER* Terminals
Pre-Insulated Nylon Heavy Duty Terminals
COPALUM* Sealed Terminals and Splices

Figure 1

1. INTRODUCTION

This instruction sheet covers application, inspection and maintenance procedures for Crimping Head 1752787-1 (see Figure 1). This crimping head uses interchangeable crimping dies and is used to crimp the products listed in the table above; for large wire sizes 8 thru 4/0 AWG.

Note: This instruction sheet provides general information for the insertion of dies and the crimping procedure. Always refer to the instructions packaged with specific die sets for specific crimping instructions and for compatible products, wire ranges, strip dimensions, and application procedures.

This crimping head is designed for use with Foot Hydraulic Pump PN 1583659-1, Hand Hydraulic Pump PN 1583661-1, or Electric Hydraulic Pumps; PN 1804700-1 (115 VAC) and PN 1804700-2 (220 VAC).

Warning: To avoid personal injury and potential damage to the crimp head, TE Connectivity (TE) requires the crimp head to operate at 9,800 to 10,200 PSI [676 to 703 bar]. TE recommends using 10,000 PSI [689 bar] TE Hydraulic Pumps as other manufacturers' pumps may apply insufficient pressure (resulting in an inadequate crimp) or excessive pressure (resulting in failure of the head). Additionally, the TE pump must be used to maintain CE certification; if using other manufacturers' pumps, the user is responsible for self-certification.



NOTE

Dimensions in this instruction sheet are in millimeters [with inches in brackets]. Illustrations and figures are for reference only and are not drawn to scale.

Reasons for reissue of this Instruction Sheet are provided in Section 8; REVISION SUMMARY

2. DESCRIPTION

Main components of the crimping head are: a yoke which houses the stationary die and retains the terminal assembly for crimping, a removable latch pin which allows pivoting of the yoke on the pivot pin (typically required for splice terminations), a cylinder which contains the head's hydraulic chamber, a piston (ram) which holds and controls the moving die, and a quick connect/disconnect coupler (cylinder half) which mates with the coupler on the hose or handle control to release or supply pressure.



DANGER

To avoid injury when using hydraulic crimping equipment, observe the following precautions:

- *DO NOT* modify the crimping equipment in any way.
- *USE ONLY* dies, terminals, and wire specified for the head.
- *DO NOT* perform repairs other than those specified in the instructional material supplied with the equipment.

3. CRIMPING HEAD INSTALLATION

Each crimping head is shipped with a coating of lubricating oil to prevent rust and corrosion. Wipe the oil off before installing the crimping head on the power unit. Note that the crimping head is shipped without oil inside the cylinder. To install crimping head, proceed as follows:



DANGER

Verify that hydraulic pressure to the hose or handle control is released and that power supply is disconnected from electric power unit, if applicable.

1. Thoroughly clean coupling area of handle control or hose assembly and crimping head (see Figure 1).
2. Remove protective dust caps from both quick connect/disconnect couplers.
3. Hold hose or handle control in vertical position to prevent oil spillage. Attach hose or handle control to coupling section on head. **THREAD PROPERLY AND TIGHTEN SECURELY.**



CAUTION

Oil flow must be unobstructed between power unit and crimping head. Verify that all couplers are fully mated and tightened.



NOTE

If crimping head must be removed after being in production, pressure must be released in the hydraulic system beforehand.

- *If using Electric Hydraulic Pumps; PN 1804700-1 (115 VAC) and PN 1804700-2 (220 VAC), disconnect power unit from power supply.*
- *If using Foot Hydraulic Pump PN 1583659-1, or Hand Hydraulic Pump PN 1583661-1, depress pressure release lever.*

4. DIE INSERTION AND REMOVAL (FIGURE 2)



DANGER

Use extreme care when operating power unit. DO NOT inadvertently actuate the tool when installing or changing dies. Personal injury could result.

4.1. Die Insertion



CAUTION

Verify that matched die set, terminal, and wire size are compatible.

1. Remove latch pin and open yoke on crimping head.
2. Loosen setscrew in yoke. Refer to die set instructions and insert stationary (upper) die which includes the nest area into well of yoke. Tighten setscrew.
3. Activate power unit to advance ram until setscrew is visible (about 12.7mm [.50 in.]). Loosen setscrew.
4. Insert moving (lower) die, which serves as the indenter, into ram well, making sure that moving die is properly oriented to mate with stationary die. Tighten setscrew.
5. Close yoke and secure with latch pin.
6. Slowly close dies to ensure proper alignment.

7. Complete the cycle and return the ram to the “DOWN” position.


CAUTION

Ensure latch pin is fully inserted or damage may occur to the yoke, dies, or latch pin.




Figure 2

4.2. Die Removal

1. Remove latch pin and open yoke.
2. Activate power unit to advance ram slightly to gain access to the ram setscrew which secures the moving die. Loosen the setscrew and remove the moving die.
3. Loosen setscrew in yoke and remove the stationary die.

5. CRIMPING PROCEDURE

The following crimping procedure provides general information. Refer to instructions packaged with individual die sets for specific products, wire sizes, strip dimensions, positioning of terminals and splices in the dies, and crimping procedures.


DANGER

To prevent personal injury when operating the power unit, exercise caution while holding terminals, splices or wire near crimping area.


CAUTION

Never operate the power unit without having a crimping head attached to the handle control or crimping head coupling.

1. Insert terminal or splice in the stationary (upper) die in accordance with instructions packaged with the dies. Verify the latch pin is secure before activating the power unit.
2. Slowly advance moving (lower) die with short, quick strokes until terminal or splice is secure.
3. Insert the stripped wire.
4. Cycle tool to complete crimp.
Remove crimped terminal or splice.


NOTE

If the splice or terminal sticks in the die after crimping, apply a rocking action to release it.

6. INSPECTION AND MAINTENANCE



DANGER

Verify hydraulic pressure is released and power supply is disconnected before following maintenance and inspection procedures; unless otherwise specified in the procedure.

Each crimping head is assembled and inspected before shipment. TE Connectivity recommends that the crimping head be inspected immediately upon its arrival at the facility of use, and at regularly scheduled intervals, to ensure the head has not been damaged during handling and use. Frequency of inspection depends upon the following: care, amount of use, and handling of the head; type and size of products crimped; degree of operator skill; and environmental conditions.

6.1. Cleaning

Remove accumulations of dirt and grease on the crimping head; especially in areas where dies are installed and terminals are crimped. Clean the entire head frequently with a clean, lint-free cloth.

6.2. Visual Inspection

Refer to Figure 3 and proceed as follows:

1. With hydraulic pressure released, inspect the assembled head for nicks, scratches, and cracks. Inspect for cracks especially at the corners of the yoke and around the top of the cylinder.




Figure 3

2. Inspect pivot pin holes and latch pin holes for wear. Replace parts, as needed.
3. Activate power unit. Raise ram to "UP" position. Inspect flat/round surfaces of ram for galling (fretting or wear by friction), cracks or oil leakage. Release pressure and verify that ram retracts smoothly.
4. If head shows evidence of galling, cracks, oil leakage, or rough cycling, return the crimping head to TE for repairs. Refer to Section 7, REPLACEMENT AND REPAIR.



NOTE

Once per year, or every 7,500 cycles (whichever comes first), the hydraulic head should be returned to TE for magnetic particle inspection. Additionally, inspect and service the head (as described in Figure 3) every month or 1,000 cycles; whichever comes first. Refer to Instruction Sheet [408-8909](#).

6.3. Crimping Head Check-Out Procedure

If the ram fails to return to the "DOWN" position after completion of a crimping cycle, the cause may be in the crimping head. To determine whether the trouble is in the crimping head or not, release pressure in the hydraulic system.

If the ram retracts, the trouble is not in the crimping head.


If ram does NOT retract, return the crimping head to TE for repairs. refer to Section 7; REPLACEMENT AND REPAIR.

7. REPLACEMENT AND REPAIR

Customer-replaceable parts are listed in Figure 4. A complete inventory should be stocked and controlled to prevent lost time when replacement of parts is necessary. Order parts through your TE representative or call 1-800-526-5142, or send a facsimile of your purchase order to 1-717-986-7605, or write, or return the entire tool for evaluation and repair, with a written description of the problem to:

CUSTOMER SERVICE (38-35)
TE CONNECTIVITY CORPORATION
P.O. BOX 3608
HARRISBURG, PA 17105-3608

Tools may also be returned for evaluation and repair. For tool repair service, contact a TE representative at 1-800-526-5136.



Item Number	Part Number	Description	Quantity Per Head
1	311470-1	Coupler, Quick-Disconnect, Cylinder Half	1
2	306209-8	Pin, Removable Latch	1
3	8-59558-5	Pin, Pivot	1
4	1-21045-1	Ring, Retaining	1
5	21061-9	Screw, Socket Set, Cone Point, 8-32 UNC x .250 in. Long	2
6	4-23147-7	Spring, Compression	1
7	1-21919-6	Pin, Dowel	1
8	4-21012-0	Screw, Socket Set, Flat Point, Self-Locking, 8-32 UNC x .250 in. Long	1
9	23150-3	Nipple, Hex	1

Figure 4

8. REVISION SUMMARY

Revisions to this instruction sheet include:

- Latest TE format, logo, and enterprise name
- Section 1: Added Warning
- Updated Electric Hydraulic Pump part numbers from 1583660-1 to 1804700-1 (115 VAC) and from 1583660-2 to 1804700-2 (220 VAC) in several places.
- Added paragraph 4.2. Die Removal.
- Updating of information in paragraph 6.3.

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[TE Connectivity:](#)

[1752787-1](#)