



***RI*Grunner**

for model

4010S



www.westmountainradio.com

1020 Spring City Drive
Waukesha, WI 53186
262-522-6503

sales@westmountainradio.com

©2012 West Mountain Radio, All rights reserved.
All trademarks are the property of their respective
owners.

Thank you for choosing the West Mountain Radio RIRunner 4010S. You will enjoy having a RIRunner with durable, standardized Powerpole® connections. Having proper DC distribution should make a long overdue improvement to the convenience and safety of your station. The RIRunner is a simple device, with obvious function. Think of a RIRunner as the 12 volt equivalent of a 120 VAC power panel in a house.

There are some considerations to think about. Please read these instructions carefully before setting up your RIRunner.

Choosing a mounting location

Pick a location that is close, or central to, most of your radios and accessories; especially those that draw large amounts of current. Locate your power source as close as possible to the RIRunner. Remember that every wire has resistance, longer wires have more resistance. More than a 10' run of #10 wire is not quite adequate to supply the RIRunner to full output without a significant voltage drop.

Install in a cool dry place with good ventilation. For example, do not put it on top of your amplifier or room heater, or cover it with something. It is recommended to not put it in the engine compartment of your car, or directly on the floor of a car; rain from open windows or snow covered boots may cause water damage.

Connecting your equipment

Recognizing that RIRunner comes standard with Powerpoles®, updating your cables that supply or use 12 volts DC with Powerpoles® will improve the convenience of quick connections and use of your equipment. Remember, Powerpoles® are genderless and the same connector arrangement works for both supply and load. Powerpoles® can be used to charge or power batteries, all using the same connectors.

Powerpoles® can be installed by soldering or crimping. Be sure to make good connections. For detailed Powerpole® connector installation tips see RIRunner support pages at <http://www.westmountainradio.com/content.php?page=supportrr>

IMPORTANT!! It is essential that assembly of the pairs is correct. Follow the amateur radio standard used by the RIRunner. **DO NOT PLUG IN** without verifying that **RED + PLUS** and **BLACK – MINUS** is correct.

The far left connector is labeled the DCIN and is supplied with a 40 amp fuse. The next connector is labeled “Master” and is always ON. The master outlet is where you would connect the radio or piece of equipment that you would like to automatically control the nine switched outlets. Plug in the equipment that you would like to be switched ON and OFF, into switched outlets 1-9, starting with the highest power connections to the left, and lower power drain units to the right.

Anderson Power Products® and Powerpole® is a registered trademark of Anderson Power Products, Inc.

Notice the supplied fuse ratings next to the connector. Typically 12V input amplifiers and 100 watt RF output transceivers should be to the left, VHF radios next, and smaller accessories to the right.

Multiple amplifiers and/or transceivers may be connected to the RIGrunner. There is a 40 amp maximum that would be exceeded if trying to transmit all connected units at once. Most radios and amplifiers draw less than 3 amps in receive, but require many more amps in transmit. Therefore, the limiting factor is total current draw while transmitting. To determine how many radios may be used to transmit at one time, consult the radio manual for power consumption specifications. In the event that the total current goes over the 40 amp maximum, a fuse will blow or make an undersized power supply unhappy. The RIGrunner and any equipment plugged into the RIGrunner should go unharmed.

Using the proper fuses

The RIGrunner 4010S comes supplied with a range of fuses installed. This assortment should be suitable for most stations, but can be changed easily. Every RIGrunner output is safe up to 40 amps, but the total allowable is also 40 amps. Note that the fuse on the Master outlet should be sized to the lowest value that is possible to adequately supply the equipment plugged into that outlet.

A fuse **MUST** have be in each position in use. **ANY ATTEMPT TO BYPASS OR SHORT ACROSS THE FUSES IS DANGEROUS AND VOIDS THE RIGRUNNER WARRANTY.** Since the maximum available automotive fuse is 40 amps, the RIGrunner will be protected as long as any value ATC/ATO fuse is installed. Choose the correct fuse for your equipment. Standard ATC/ATO automotive blade fuses are used. These fuses are available in 10 values ranging from 1 amp to 40 amps.

The DC input should have a fuse that is appropriate for the power supply rating. If using a smaller power supply, consider using a lower value fuse than the 40 amp value supplied. Ideally all of the outlets should have a fuse that is the next higher value above the maximum current draw of the unit on that fuse. If using a power cord with a fuse, match that value or go one or two values higher. Sizing each fuse for each unit is desirable, but not absolutely necessary. Having a higher value than the minimum will offer less protection for that unit, too low a value and the fuse will blow out prematurely.

Note that each fuse position has a LED blown fuse indicator that will conveniently light up if an output fuse is blown. There must be power to the RIGrunner and a load on the circuit that has the blown fuse for the blown fuse LED to light.

Automatic or Manual Power Switching

The RIGrunner 4010S has a unique, high performance and convenient power switching system. It uses an electronically controlled solid state FET switch designed to switch DC currents of up to 100 Amps. This FET switch is over current and over temperature protected. It should last indefinitely compared to a mechanical switch that suffers from arcing. The mechanical control switch in the RIGrunner carries none of the load.

The control switch has three positions: “OFF”, “AUTO” and ALL ON”. In the “OFF” position only the switched outlets are switched off. In the “AUTO” position the switched outlets will automatically turn on whenever an adequate load current is drawn from the, always on, “MASTER” outlet. In the “ALL ON” position all of the switched outlets will be on regardless of what is connected to the master outlet.

IMPORTANT: The fuse installed in the master outlet must be chosen correctly (a package of extra fuses is supplied)! The power consumption of the unit you would like to use to control the master outlet must be matched to the fuse. Select the lowest value fuse that will supply your unit. A higher value fuse than is needed will reduce the sensitivity of the automatic control circuit. Too high a value may render the automatic control inoperative. Use the table below to select the proper master outlet fuse and to determine if the power consumption of the unit you plan to use will provide positive control.

Master Fuse Amps	Sensitivity Amps (typ.)	Master control unit
40	.8 A	160 watt VHF amp
30	.6 A	
25	.5 A	100 watt transceiver
20	.4 A	
15	.3 A	
10	.2 A	30 watt VHF mobile
5	.1 A	QRP transceiver
1	.02	small station accessory

NOTE: The current sensing circuit is very sensitive, it measures current with no additional voltage drop on the master outlet compared to an unswitched RIGrunner outlet. We are actually using the master fuse as the current sensing element! We have done everything possible to avoid false triggering of the automatic turn on. RF and transient voltages should not falsely trigger our circuit. The circuit is designed for 13.8 VDC operation. Operation at voltages in excess of 15 Volts may cause improper operation. We are not responsible if your equipment is accidentally left on due to improper operation.

NOTE: If the master outlet fuse is blown or removed, that blown fuse LED will light and the 4010S switched outlets will turn on even if there is nothing plugged in to the master outlet. A good fuse of any value must be installed at all times.

WARNING: Do not adjust the internal calibration potentiometer, it is carefully set for proper operation.

West Mountain Radio does not know the power requirements of all radios and station accessories made. Consult the owners manual for your unit or actually measure the power consumption.

A West Mountain Radio **PWRcheck** is a handy way to easily measure Volts, Amps, Watts and Amp / hours all at the same time on one display.

A Red overvoltage indication is bad, DISCONNECT OR TURN OFF THE POWER SUPPLY IMMEDIATELY! Overheating or damage a radio or other equipment may occur. As supplied there is an audible alert, unlike other RIGrunners, on both undervoltage and overvoltage.

The audible alert may be configured for only undervoltage or only overvoltage, or may be disabled altogether. Simply place the P14 jumpers on under, over, both or none. Store the unused jumpers on a single pin to not lose them for later use.

NOTE: Because of the characteristics of the comparator chip it is normal for the undervoltage LED to glow very dimly with a normal or overvoltage indication. It is also normal for the LEDs to change intensity as it steps through 10 precision points or to flicker on the edge of these points. Two LEDs may be on or off exactly at the switchover point.

If there is a bad power source or power connection, the Yellow LED may flash or come on during transmit. This happens with most automobiles when running the starter motor. Check the power source and connections. It is possible for RF from a transmitter to cause an electronically regulated power supply to lose regulation and cause an overvoltage alert during transmit. The RIRunner is extensively RF bypassed and should minimize the possibility of this problem. In the case of an overvoltage condition during transmit, especially with a VHF high power amp, it is due to inadequate RF filtering on the DC lead of the VHF amplifier, or poor RF immunity of the power supply regulator circuit.

RIRunner Accessories

	<u>Order Sku#</u>
Fuse Assortment Low Value (8pcs) 3- 1A, 3- 5A & 2- 10A	#58537-1085
Fuse Assortment High Value (8pcs) 2 ea. of 15A, 20A, 30A, 40A	#58537-1086
Buss 10A ATC Circuit Breaker	#58537-1087
Buss 15A ATC Circuit Breaker	#58537-1088
Buss 20A ATC Circuit Breaker	#58537-1089
Buss 25A ATC Circuit Breaker	#58537-1090
Buss 30A ATC Circuit Breaker	#58537-1091
Powerpole® Extension Cable, 3 ft. #12 Red/Black Wire w/ powerpole ends	#58531-1082
Powerpole® Extension Cable, 6 ft. #12 Red/Black Wire w/ powerpole ends	#58531-1083
Powerpole® Extension Cable, 10 ft. #12 Red/Black Wire w/ powerpole ends	#58531-1084
15A. Powerpole® Connector-12 Pair	#58257-1093
30A. Powerpole® Connector-12 Pair	#58257-1095
45A. Powerpole® Connector-12 Pair	#58257-1099
Powerpole® Retention Clips - 12 Pack	#58257-1092
PowerLock - RIRunner Retainer Kit	#58512-1060
PWRcrimp Crimp Tool	#58568-1049

*To purchase or view other accessories available,
call or go online at:*

www.westmountainradio.com/shop

Additional Support and Operating Tips:

www.westmountainradio/supportrr.htm

www.westmountainradio/optipsrr.htm

RIGrunner Warranty

The RIGrunner is warranted against failure due to defects in workmanship or materials for one year after the date of purchase from West Mountain Radio or an authorized dealer. If purchased from an authorized dealer it must be returned with a copy of the original sales receipt or proof of purchase.

Warranty does not cover damage caused by abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation, alteration, lightning, or other incidence of excessive voltage or current. If failure occurs within this period, return the RIGrunner or accessory to West Mountain Radio at your shipping expense with a full explanation and necessary proof of purchase. The device or accessory will be repaired or replaced, at our option, without charge, and returned to you at our shipping expense. Repaired or replaced items are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the RIGrunner or accessory made after the expiration of the warranty period.

West Mountain Radio shall have no liability or responsibility to customer or any other person or entity with respect to any liability, loss, or damage caused directly or indirectly by use or performance of the products or arising out of any breach of this warranty, including, but not limited to, any damages resulting from inconvenience, loss of time, data, property, revenue, or profit, or any indirect, special incidental, or consequential damages, even if West Mountain Radio has been advised of such damages.

Except as provided herein, West Mountain Radio makes no express warranties and any implied warranties, including fitness for a particular purpose, are limited in duration to the stated duration provided herein.

Powerpole® Wiring Guide

Powerpole® Series Contact	Recommended Wire Gauge
15 A	20-16 AWG
30A	20-12 AWG
45A	14-10 AWG

***Additional Resources for Anderson Powerpoles®
go to: www.andersonpower.com***

***Details and a video demonstration for using PWRcrimp
Tool with powerpoles®, go to:
www.westmountainradio.com/crimptool***

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

CCS:

[58305-1032](#)