

RH850/F1KM-S1 Starter Kit V3

User Manual: Hardware

RENESAS MCU
RH850/F1KM-S1 Series

Y-ASK-RH850F1KM-S1-V3

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corp. without notice. Please review the latest information published by Renesas Electronics Corp. through various means, including the Renesas Electronics Corp. website (<http://www.renesas.com>).

For updates of this manual please check:

<https://www.renesas.com/document/mat/rh850f1km-s1-starter-kit-v3-user-manual-hardware>

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: "Standard", "High Quality", and "Specific". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as "Specific" without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is "Standard" unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.

"Specific": Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

Table of Contents

1.	Introduction	4
2.	Cautions	5
3.	Quick Start Information	6
3.1	Connector and jumper overview	6
3.1.1	Microcontroller assembled and Port Pin Interfaces	6
3.3	Board Overview RH850/F1KM-S1 [Y-ASK-RH850F1KM-S1-V3]	10
4.	Starter Kit Hardware	11
4.1	Starter Kit functions.....	11
4.1.1	RH850/F1KM-S1 Starter Kit.....	11
4.2	Functional Areas	12
4.2.1	Power Supply	13
4.2.2	LEDs	14
4.2.3	Digital Inputs for Low Power Sampler (LPS)	15
4.2.4	Pushbutton Switches.....	16
4.2.5	Analog Input - Potentiometer	16
4.2.6	Rotary Encoder with Pushbutton Switch	17
4.2.7	Serial Communication Interfaces	17
4.2.8	On-chip Debug and Flash Programming Connector	19
4.2.9	OLED Board (optional).....	20
5.	Development tools	21
5.1	E2 On-Chip Debug Emulator [RTE0T00020KCE00000R].....	21
5.2	PG-FP6 Programmer [RTE0T00001FWREA000R]	21
5.3	Development Software.....	21
6.	RH850/F1KM-S1 Starter Kit Example Software	22
6.1	Framework Description	22
6.2	Sample Software Classic.....	23
6.3	Start Up Test	24
6.4	Mode 1	24
6.5	Mode 2	25
6.6	StandBy	25
7.	Component Placement and Schematics	27
7.1	Component placement.....	27
7.2	Schematics	28
7.2.1	Y-ASK-RH850F1KM-S1-V3 Schematics (without Motor Control)	28
	Revision History	29

1. Introduction

The 'RH850/F1KM-S1 Starter Kit' serves as a simple and easy to use platform for evaluating the features and performance of Renesas Electronics' 32-bit RH850/F1KM-S1' microcontroller.

Features:

- Connections for on-chip debugging and flash memory programming
- Access to all microcontroller I/O pins
- User interaction through potentiometer, rotary switch, buttons and LEDs
- Serial interface connections for
 - 1x UART/USB
 - 1x LIN
 - 1x SENT
 - 2x CAN-FD
- Multiple power supply options by
 - RENESAS E2 On-Chip debugger (5V/200mA)
 - Provided 12V DC power supply via DC Jack

This document will describe the functionality provided by the Starter Kit and guide the user through its operation. For details regarding the operation of the microcontroller refer to the RH850/F1KM-S1 Hardware User Manual.

Renesas provides a SENT Extension Board “**Y-RH850-SENT-EXT-BRD-V2**” that comes with a sample software, which receives the SENT messages from a ZSSC4161D and gives feedback via the peripheral LEDs on the starter kit.

Please find below a short overview of the related Documents:

Table 1 Related documents

Description	DOC-Number
1. Hardware User Manual of RH850/F1KM-S1	R01UH0684EJxxxx
2. Datasheet of RH850/F1KM-S1	Included in above document
3. QSG for RH850/F1KM-S1 Starter Kit V3	D016351-11
4. RH850 Family SENT Application Board UM	R12UT0014EDxxxx
5. Renesas SENT App Note	R01AN3963ED0201

2. Cautions

1. Do not look into the LED beam!

Special care must be taken with the high power LEDs



2. When power supply of E2 On-Chip debugger is used please note that the maximum current provided by the debugger is limited to 200mA. Thus, an external power supply is required in case all functions on the Starter Kit are used to full extend.

3. Quick Start Information

3.1 Connector and jumper overview

3.1.1 Microcontroller assembled and Port Pin Interfaces

On the RH850/F1KM-S1 Starter Kit the following device is assembled:

R7F701684

As external clock supply of the microcontroller, a 16MHz crystal is mounted.

Each microcontroller I/O pin is connected to a pin header interface. The pin header interfaces allow easy probing of I/O pins and provide the ability to selectively connect the I/O pins to power, ground or other signals. Table 2 and Table 3 are showing the assignment of the pin header interface.

Table 2 J3 – J4 – Signal Assignment

J3				J4			
Pin	Function		Pin	Pin	Function		Pin
1	P10_3	P10_4	2	1	AP0_13	AP0_12	2
3	P10_5	P10_15	4	3	AP0_11	AP0_10	4
5	P11_0	P0_0	6	5	AP0_9	AP0_8	6
7	P0_1	P0_2	8	7	AP0_7	AP0_6	8
9	P0_3	P0_4	10	9	AP0_5	AP0_4	10
11	P0_5	P0_6	12	11	AP0_3	AP0_2	12
13	P0_11	P0_12	14	13	AP0_1	AP0_0	14
15	P0_13	P0_14	16	15	P9_0	P9_1	16
17	P8_2	P8_10	18	17	P9_2	P9_3	18
19	P8_11	P8_12	20	19	P9_4	P9_5	20
21	GND	VDD_5V	22	21	GND	VDD_5V	22

Table 3 J7 – J8 – Signal Assignment

J7				J8			
<i>Pin</i>	<i>Function</i>		<i>Pin</i>	<i>Pin</i>	<i>Function</i>		<i>Pin</i>
1	P9_6	P10_6	2	1	JP0_5	JP0_4	2
3	P10_7	P10_8	4	3	JP0_3	JP0_2	4
5	P10_9	P10_10	6	5	JP0_1	JP0_0	6
7	P10_11	P10_12	8	7	FLMD0	P0_10	8
9	P10_13	P10_14	10	9	P0_9	P0_8	10
11	P11_1	P11_2	12	11	P0_7	P8_3	12
13	P11_3	P11_4	14	13	P8_4	P8_5	14
15	P11_5	P11_6	16	15	P8_6	P8_7	16
17	P11_7	P10_0	18	17	P8_8	P8_9	18
19	P10_1	P10_2	20	19	AP0_15	AP0_14	20
21	GND	VDD_5V	22	21	GND	VDD_5V	22

Table 4. Jumper / Connector Settings Overview

Jumper	Description	Setting	Note
FB J1	RGB LED Connector	1 – 2	R: PWM feedback ↔ AP0_5
		3 – 4	G: PWM feedback ↔ AP0_6
		5 – 6	B: PWM feedback ↔ AP0_7
LED16 J2	Blue LED Circle to MCU connector	1 – 2	LA: SPI driver LE ↔ P8_10
		3 – 4	BL: SPI driver OE# ↔ P8_11
		5 – 6	MC: SPI driver CLK ↔ P11_3
		7 – 8	MO: SPI driver SDI ↔ P11_2
		9 – 10	MI: SPI driver SDO ↔ P11_4
ENC J5	Encoder to MCU connector	1 – 2	a: Encoder input 0 ↔ P10_9
		3 – 4	b: Encoder input 1 ↔ P10_10
		5 – 6	B: Encoder button ↔ P0_13
PWM J6	PWM output to RGB LED connector	1 – 2	R: PWM signal ↔ P11_7
		3 – 4	G: PWM signal ↔ P11_6
		5 – 6	B: PWM signal ↔ P11_5
J9	Interrupt Button to MCU connector	1 – 2	INT: Button ↔ P8_2
J10 LED	Indication LED to MCU Connector	1 – 2	LED18 ↔ P0_14
		3 – 4	LED17 ↔ P8_5
J11	Potentiometer to MCU Connector	1 – 2	POT1 ↔ AP0_4
		3 – 4	APO ↔ P0_1
J12	MCU power distribution	1 – 2	REG: REGVCC supply
		3 – 4	EVCC: EVCC/A0VREF supply
J14 UART	UART to USB connector	1 – 2	UART/USB TX ↔ P0_2
		3 – 4	UART/USB RX ↔ P0_3
		5 – 6	UART/USB EN ↔ AP0_9
J15	LIN Transceiver to MCU connector	1 – 2	LIN RX ↔ P0_7
		3 – 4	LIN TX ↔ P0_8
J19	SENT interface connector	1 – 2	SENT RX ↔ P9_0
		3 – 4	SENT SPCO ↔ P9_1
J20	CAN0/1 transceiver TX/RX to MCU connector	1 – 2	CAN0TX ↔ P10_7
		3 – 4	CAN0RX ↔ P10_6
		5 – 6	CAN1TX ↔ P0_10
		7 – 8	CAN1RX ↔ P0_9

J21	Digital LPS input to MCU connector	1 – 2	DIN ↔ P8_3
		3 – 4	SELDP0 ↔ P0_4
		5 – 6	SELDP1 ↔ P0_5
		7 – 8	SELDP2 ↔ P0_6
		9 – 10	DPO ↔ P0_0
J22	VBAT selector	1 – 2	12V ↔ 12V_IN
		2 – 3	5V ↔ 12V_IN

Note: Default jumper setting (Power Supply by E2 Debugger) is indicated by **bold font**.

3.3 Board Overview RH850/F1KM-S1 [Y-ASK-RH850F1KM-S1-V3]

The RH850/F1KM-S1 Version of the V3 Starter Kit (without Motor Control Part equipped) is shown in the figure below.




Figure 1. Starter Kit V3 top view RH850/F1KM-S1 without MC

4. Starter Kit Hardware

4.1 Starter Kit functions

4.1.1 RH850/F1KM-S1 Starter Kit




Figure 2. Functional overview

4.2 Functional Areas

The functional areas provide various circuits and components useful for interacting with the microcontroller's I/O:




Figure 3. Functional Areas

4.2.1 Power Supply

4.2.1.1 Power supply configuration

The Starter Kit provides two options for powering the board's integrated circuits. It is possible to supply the Starter Kit by using the E2 Debugger or by connecting the provided external 12 Volt power supply to the DC Jack.

With the default jumper setting (see Table 5) the Starter Kit is configured to be power supplied by the E2 Debugger.

The operation of the LIN interface is only possible by using the provided external 12 Volt power supply.

When the board is supplied **by the E2-Debugger**, use the following jumper setting:

Table 5 Jumper setting for power supply by E2-Debugger

Jumper	Description	Setting	Note
J22	VBAT selector	1-2, 12V – 12V_IN	open
		2-3, 5V – 12V_IN	closed

When the board is supplied **via the DC Jack**, please choose the following jumper settings:

Table 6. Jumper setting for power supply over DC Jack

Jumper	Description	Setting	Note
J22	VBAT selector	1-2, 12V – 12V_IN	closed
		2-3, 5V – 12V_IN	open

The power supply area includes a DC Jack type connector for providing external power supply to the Starter Kit and its components. The external supply is reversibly protected against overvoltage. Nevertheless, please always observe the right polarity and voltage.

Table 7. Power supply connector specification

Connector	Description	Input Voltage Range
DC Jack*	DC Power Jack ID=2.0mm, center positive	+10V to +15V

4.2.1.2 Power supply measurement

The current which is consumed by MCU can be measured by using J12. Please find below a description of the jumper.

RH850/F1KM-S1:**Table 8. RH850/F1KM-S1 MCU power measurement**

Jumper	Description	Pins	Note
J12	MCU power measurement	1-2	REGVCC power supply (5 V)
		3-4	EVCC, AV0REF power supply (5 V)

4.2.2 LEDs**4.2.2.1 RGB LED**

A RGB LED is provided to allow visual observation of microcontroller output port state and to show the functionality of the PWM Diagnostic Macro. The RGB LED, which is part of the Rotary Encoder, is driven by three N-channel transistors. Feedback for each RGB LED channel is connected to the A/D converter of the microcontroller to evaluate the LED drive state. The LED PWM signals are active high.

Please use the following jumper configuration to activate the full RGB LED functionality:

Table 9. White RGB Signals Configuration

Jumper	Description	Setting	Note
J1	RGB LED Connector	1-2	R_PWM feedback ↔ AP0_5
		3-4	G_PWM feedback ↔ AP0_6
		5-6	B_PWM feedback ↔ AP0_7
J6	PWM output to RGB LED connector	1-2	R_PWM signal ↔ P11_7
		3-4	G_PWM signal ↔ P11_6
		5-6	B_PWM signal ↔ P11_5

4.2.2.2 Green Indicator LEDs

Two green low power LEDs (LED1 and LED2) are provided to allow visual observation of microcontroller output port states. The LED signals are active high.

Table 10. Green Indicator LED Signals

Jumper	Setting	LED	Device Port
J10	1-2	LED18	P0_14
	3-4	LED17	P8_5

4.2.2.3 Blue Power Supply LEDs

The three indicator LEDs are showing which power supply voltages are available:

Table 11. Power Indicator LEDs

Name on board	Signal Name	Meaning
D16	VDD_12V	Microcontroller area powered by DC Jack
D17	VDD_5V	Microcontroller area powered by E2

4.2.2.4 Blue LED Circle

Sixteen blue LEDs are driven by the TLC5925, which can be controlled by the SPI command to change the output states.

Table 12. Blue LED Circle Signals

Jumper	Setting	Signal	Device Port
J2	1-2	LAT	P8_10
	3-4	BLNK	P8_11
	5-6	MCLK	P11_3
	7-8	MOSI	P11_2
	9-10	MISO	P11_4

4.2.3 Digital Inputs for Low Power Sampler (LPS)

Eight digital input signals, which are generated by a DIP switch array (S3), are provided to trigger the microcontroller's Low Power Sampler. The input signals are connected to the microcontroller via 8 to 1 Multiplexer (IC4). When the DIP switches (S3) are changed during low power mode (DeepSTOP mode), the microcontroller will wake up.

Please use the following jumper configuration to connect the DIP Switch and multiplexer to the microcontroller

Table 13. LPS Jumper Configuration

Jumper	Description	Setting	Note
J21	Digital LPS input to MCU connector	1 – 2	DIN ↔ P8_3
		3 – 4	SELDP0 ↔ P0_4
		5 – 6	SELDP1 ↔ P0_5
		7 – 8	SELDP2 ↔ P0_6
		9 – 10	DPO ↔ P0_0

4.2.4 Pushbutton Switches

Two pushbutton switches (S1 and S2) are provided to allow the switching of microcontroller input port states. Those switches are active low and normally open.

Table 14. Pushbutton Switch Signals

Switch	Device signal	Active Level	Inactive State
S1	P8_2 (INTP6)	low	open
S2	RESET	low	open

Please use the following jumper configuration to connect the interrupt pushbutton switch (S1) to the microcontroller.

Table 15. Interrupt Pushbutton Jumper Configuration

Jumper	Description	Setting	Note
J9	Interrupt pushbutton to MCU connector	1-2	Button ↔ P8_2

Additionally, a pushbutton is provided with the Rotary Encoder. For details, please refer to “Rotary Encoder with Pushbutton”.

4.2.5 Analog Input - Potentiometer

A potentiometer (POT1) is provided to generate an analog voltage, which can be delivered to the microcontroller's analog input pins.

By turning the potentiometer POT1, a voltage derived from the MCU output signal APO (P0_1) can be adjusted. The APO signal can be controlled by the Low Power Sampler (LPS) macro. If the LPS macro is not used, APO has to be set to high manually (use P0_1 as general purpose digital output).

Table 16. Analog Input Signal

Potentiometer	Analog Input MCU
POT1	AP0_4

Please use the following jumper configuration to connect the potentiometers to the microcontroller:

Table 17. Potentiometer Jumper Configuration

Jumper	Description	Setting	Note
J11	Potentiometer to MCU Connector	1-2	POT1 ↔ AP0_4
		3-4	POT1 supply ↔ APO

4.2.6 Rotary Encoder with Pushbutton Switch

An incremental Rotary Encoder (ENC1) is provided on the starter kit. The outputs *ENC1_a* and *ENC1_b* of the Rotary Encoder can be connected to the microcontroller internal encoder timer via jumpers. In addition, the Rotary Encoder (ENC1) incorporates a pushbutton switch *ENC1_Switch*, which can also be connected to a pin of the microcontroller via jumper. The switch is active low and normally open.

Table 18. Encoder Jumper Configuration

Jumper	Description	Setting	Note
J5	Encoder to MCU connector	1-2	P10_9 ↔ ENC1_a
		3-4	P10_10 ↔ ENC1_b
		5-6	P0_13 ↔ ENC1_Switch

4.2.7 Serial Communication Interfaces

4.2.7.1 SENT and LIN

Local Interconnect Network (LIN) transceiver (IC5) is supplied to provide a LIN interface. The transceiver can be connected to the microcontroller's LIN macro (RLIN21).

The DB9 connector CN5 is shared between the board's LIN and SENT interface. Renesas provides a SENT Extension Board "**Y-RH850-SENT-EXT-BRD-V2**" that can be connected to the DB9 connector and comes with a sample software, which receives the SENT messages from an Renesas ZSSC4161D.

Please close the following jumpers to connect the LIN transceiver to the microcontroller:

Table 19. LIN Transceiver Jumper Configuration

Jumper	Description	Setting	Note
J15	LIN Transceiver to MCU connector	1-2	LIN RX ↔ P0_7
		3-4	LIN TX ↔ P0_8

Please close the following jumpers to connect the SENT interface to the microcontroller:

Table 20. SENT Jumper Configuration

Jumper	Description	Setting	Note
J19	SENT interface connector	1-2	SENT SPCO ↔ P9_1
		3-4	SENT RX ↔ P9_0
		5-6	SENT PROG ↔ AP0_14

The serial interfaces are connected to the DB9 connector CN5 via DIP switch S5.

Only one interface can be used at a time. Please see the configuration for LIN in **Table 21** and for SENT in **Table 22**.

Table 21. Switch S5 configuration for LIN

Switch		Configuration	Signal	DB9 pin (CN5)
S5	1	on	LIN	7
	2	on	GND	3
	3	on	VBATF (12V DC)	9
	4	off	-	6
	5	off	-	8
	6	off	-	1

Table 22. Switch S5 configuration for SENT

Switch		Configuration	Signal	DB9 pin (CN5)
S5	1	off	-	7
	2	off	-	3
	3	off	-	9
	4	on	GND	6
	5	on	SENT_RX (SENT_SPCO)	8
	6	on/off*	VDD_5V	1

*Caution: If you want to connect your own sensor board, make sure not to exceed the maximum output current of the Port AP0_14! If you do, please don't use AP0_14 but turn on the 5th switch of the S5 dip switch.

Note: Please ensure that only one interface is configured for operation at the same time (either LIN or SENT) by using DIP switch S5.

4.2.7.2 UART/USB Interface

UART TO USB transceiver (U1) is supplied to provide a serial interface. The transceiver can be connected to the microcontroller's UART macro (RLIN30).

Please close the following jumpers to connect the UART/USB transceiver to the microcontroller:

Table 23. UART/USB Transceiver Jumper Configuration

Jumper	Description	Setting	Note
J14	UART to USB connector	1-2	UART/USB TX ↔ P0_2
		3-4	UART/USB RX ↔ P0_3
		5-6	UART/USB EN ↔ AP0_9

4.2.7.3 CAN Interfaces

Controller Area Network (CAN) transceivers (IC6 and IC8) are supplied to provide two CAN bus interfaces. Each transceiver can be connected to one of the microcontroller's CAN interfaces (CAN1, CAN4). The CAN bus interfaces are connected to the DB9 connectors CN6 and CN8. The CAN0/1 transceiver is enabled by default and able to transmit and receive data via the CANH and CANL bus lines. This receive-only mode can be used to test the connection of the bus medium. In silent mode it can still receive data from the bus, but the transmitter is disabled and therefore no data can be sent to the CAN bus. DIP switch S4 provides additional CAN bus interface configuration options including the ability to selectively interconnect CAN bus interfaces on-board.

The CAN transceiver support CAN and CAN-FD communication.

Please close the following jumpers to connect the CAN0 transceiver (IC6) and CAN1 transceiver (IC8) to the microcontroller:

Table 24. CAN0 and CAN1 Transceiver Jumper Configuration

Jumper	Description	Setting	Note
J20 (optional)	CAN0 transceiver TX/RX to MCU connector	1 – 2	CANTX0 ↔ P10_7 (CAN1TX)
		3 – 4	CANRX0 ↔ P10_6 (CAN1RX)
	CAN1 transceiver TX/RX to MCU connector	5 – 6	CANTX1 ↔ P0_10 (CAN4TX)
		7 – 8	CANRX1 ↔ P0_9 (CAN4RX)

The on-board CAN bus and the terminal resistors of each CAN channel can be activated by DIP switch S4.

Table 25. DIP Switch S4 - CAN Interfaces Signals

Transceiver	CAN channel	Switch	Note
IC6	CAN0	1	Enable termination resistor
IC8	CAN1	2	Enable termination resistor
All	All	3	Connect to on-board CAN bus
		4	Connect to on-board CAN bus

4.2.8 On-chip Debug and Flash Programming Connector

Connector CN1 is provided to allow the connection of microcontroller debug and flash programming tools. Connector CN1 is a 14 pin, 0.1" pin pitch connector. The pinout of this connector supports the Renesas E2 On-chip debug emulator and the Renesas PG-FP6 Flash Programmer. For more information about the E2, please see Chapter 5.1 *E2 On-Chip Debug Emulator* [RTE0T00020KCE00000R]. For more information about the PG-FP6, please see Chapter 5.2 *PG-FP6 Programmer* [RTE0T00001FWREA000R]

4.2.9 OLED Board (optional)

The Starter Kit offers a pin header to optionally connect an external display to the board. For example, following *OLED* Display is compatible to the connector:

<https://www.adafruit.com/product/326>

Table 26. OLED header (optional)

Connector	PCB	Display
1	GND	GND
2	5V	VIN
3	M_DISPLAY_3V3 (AP0_8)	3.3V
4		CS
5	M_DISPLAY_RESET2 (P8_6)	RST
6		DC
7	M_DISPLAY_SCL (P0_12)	SCL
8	M_DISPLAY_SDA (P0_11)	SDA

5. Development tools

5.1 E2 On-Chip Debug Emulator [RTE0T00020KCE00000R]

The *E2 On-Chip Debug Emulator* is a powerful debugging tool with flash programming functions which supports various Renesas microcontrollers.

Updates and User Manuals for this tool can be found on the Renesas website:

<http://www.renesas.com/e2>

5.2 PG-FP6 Programmer [RTE0T00001FWREA000R]

The PG-FP6 Programmer is an easy to use and fast Flash Programmer, which supports various Renesas microcontrollers.

Updates and User Manuals for this tool can be found on the Renesas website:

<http://www.renesas.com/pg-fp6>

5.3 Development Software

The following development software tools are included in the Starter Kit package:

- Green Hills MULTI IDE (90 days evaluation version)
- IAR Embedded Workbench for Renesas RH850 (128KB Kickstart version)
- iSYSTEM winIDEA with E2 support
- CS+ integrated development environment (Evaluation Version via download)
- Renesas Flash Programmer (RFP)
- Renesas Smart Configurator (SC)

More information about the usage of these software tools is shown in the Quick Start Guide which is also part of the Starter Kit package.

6. RH850/F1KM-S1 Starter Kit Example Software

The included demo software provides the following functions:

- Basic MCU Initialization
- PWM Generation for user LEDs and RGB LEDs
- PWM Diagnostic Function for RGB LEDs
- A/D-Converter for PWM-Diagnostics and Potentiometers
- Standby modes including Low Power Sampler (LPS)
- Push-Button Function
- Encoder Function
- CAN Frame Transmission
- LIN Frame Transmission
- UART/USB Transmission
- SENT Transmission
- SPI Transmission
- Operating System Timer
- Timer Array Unit J
- Timer Array Unit B

6.1 Framework Description

Renesas provides a software framework with its Starter Kits, so that the customer can easily access and use the modules of the controller. The Starter Kits are equipped with a lot of peripheral devices like encoder, potentiometer, LEDs, optional display, CAN-, LIN- and UART/USB-transceivers, buttons and. To use these modules, the Starter Kit contains software functions which allows an easy and fast use.

The framework is divided in 3 layers:




Figure 4. Framework Layers

In the layer peripherals you can find the source code related to the peripherals of the microcontroller. For example, you can find all related functions for the ports in the `r_port.c`. Only the functions defined in this source file should set or read the port registers.

In the modules layer, you can find modules like CAN-FD, which accesses not only the functions for the RS-CANFD peripheral of the MCU, but also for example the functions of the port peripheral. It can also contain a not controller specific module like "led". This module for example uses functions of the port-, timer- and pwmd peripheral to get the behavior of the led you want. The highest layer is the app layer which contains the actual application. For example, the sample application for the Starter Kit uses the lower layer modules to write to the display, turn on some LEDs and checks the transceivers of the Starter Kit.

It is intended that a higher layer should only access the lower layers and not the other way around.

6.2 Sample Software Classic

The software contains a test function executed at the start and two run modes.

For live documentation of the RH850 actions connect a USB-Port of your computer via a USB Cable to the USB connector "J18" of the board.

Note: Use a USB 1.0/2.0 Type A to mini-USB 1.0/2.0 mini-B computer cable and a baud-rate of 9600 Bd.




Figure 5. Software flow

6.3 Start Up Test

Once started, the clock will be initialized, and a start-up test is performed. During the test, the LEDs of the Blue LED Circle will successively be turned on and then turned off in the same pattern. Simultaneously the RGB LED will sweep through different colors and then turn off. Afterwards the RGB LED will light up in white for 500ms, as well as the whole Blue LED Circle. LED1 and LED2 will light during the whole test. The Serial Interfaces CAN, LIN and the RGB LED PWM feedback signals are checked. The result is printed out in the debugger and via UART/USB. Also, a Test Picture will be output on the Display. After this the SW continues with Mode 1.

6.4 Mode 1

LED1 and LED2 glow in different intensities depending on the potentiometer POT1 position. The converted analogue value of POT1 is used to update the duty cycle of the PWM module which drives these LEDs. The LEDs of the Blue LED Circle follow the Rotary Encoder ENC1. By pressing the Rotary Encoder Pushbutton, the color of the RGB LED is changed.

The load current through each of the RGB LEDs is evaluated by converting feedback/sense signal into digital values and applying conversion result upper / lower limit check function of ADC (PWM diagnostic function). In case the measured current is either too high or too low, a fault is assumed and in turn the PWM of the corresponding LED is switched OFF. By switching to Mode 2 the PWM output and diagnostic is started again.

A short push on pushbutton S1 will switch to Mode 2, holding it pressed for 3s or more will switch to DeepSTOP mode.

After 30s without user action, the microcontroller will enter DeepSTOP mode on its own.

Mode 1 is called in a 1ms cycle using the Operating System Timer.

6.5 Mode 2

LED1 and LED2 blink alternately and the LEDs of the Blue LED Circle run around the Rotary Encoder in a specific frequency. The frequency is determined by the analogue value of POT1 which is converted to a corresponding Timer Array Unit J interval time. After each interval, the duty cycle of the LEDs LED1 and LED2 is adjusted to generate the alternatively blinking pattern, as well as the positions of the Blue LED Circle. The number of blue LEDs which are circling can be increased/decreased by the Rotary Encoder ENC1.

The load current through each of the RGB LEDs is evaluated by converting feedback/sense signal into digital values and applying conversion result upper / lower limit check function of ADC (PWM diagnostic function). In case the measured current is either too high or too low, a fault is assumed and in turn the PWM of the corresponding LED is switched OFF. By switching to Mode 1 the PWM output and diagnostic is started again.

A short push on pushbutton S1 will switch to mode 1, holding it pressed for 3s or more will switch to DeepSTOP mode.

After 30s without user action, the microcontroller will enter DeepSTOP mode on its own.

Mode 2 is called in a 1ms cycle using the Operating System Timer.

6.6 StandBy

Entering standby mode will turn off all unnecessary functions and switch the controller into DeepSTOP for low power consumption. This is indicated by a 2s interval of LED2 generated by the Timer Array Unit J.

A wake-up can be performed by a short push the pushbutton S1, the Rotary Encoder Pushbutton, changing the configuration of the DIP switch S6 or turning potentiometer POT1 more than 25% of the actual state. DIP switch and POT1 related wake-up events are generated by using the Low Power Sampler triggered by Timer Array Unit J in a 500ms interval. Performing a wake-up will resume the last mode the SW was in before standby was entered.

7. Component Placement and Schematics

7.1 Component placement




Figure 6. Component Placement

Note: This component placement is related to the following release version of the PCB:
 "D01474754_06_V02"

7.2 Schematics

7.2.1 Y-ASK-RH850F1KM-S1-V3 Schematics (without Motor Control)




Figure 7. Schematics

Note: This Schematic is related to the following release version of the PCB: "D01474754_06_V02"

Revision History

RH850/F1KM-S1 Starter Kit V3 User Manual: Hardware
--

Rev.	Date	Description	
		Page	Summary
1.00	June 2018	—	First edition issued
1.01	November 2018	20, 24, 27, 34, 35	Schematics/component placement updated, Hall Sensor connection added, SENT description extended, Framework Description added
1.02	February 2019	—	Minor corrections
1.03	April 2019	23	Motor connector table corrected.
1.03	October 2019	15, 16	Max power supply current added.
1.10	January 2023	All	Deleted motor control description in this Manual and minor updates. Exchanged SENT Sensor references with new one.

RH850/F1KM-S1 Starter Kit V3 User Manual: Hardware

Publication Date: January 2023

Published by: Renesas Electronics



Renesas Electronics Corporation

SALES OFFICES

<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

Renesas Electronics America Inc.

2880 Scott Boulevard Santa Clara, CA 95050-2554, U.S.A.

Tel: +1-408-588-6000, Fax: +1-408-588-6130

Renesas Electronics Canada Limited

1101 Nicholson Road, Newmarket, Ontario L3Y 9C3, Canada

Tel: +1-905-898-5441, Fax: +1-905-898-3220

Renesas Electronics Europe Limited

Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K

Tel: +44-1628-585-100, Fax: +44-1628-585-900

Renesas Electronics Europe GmbH

Arcadiastrasse 10, 40472 Düsseldorf, Germany

Tel: +49-211-65030, Fax: +49-211-6503-1327

Renesas Electronics (China) Co., Ltd.

7th Floor, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100083, P.R.China

Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

Renesas Electronics (Shanghai) Co., Ltd.

Unit 204, 205, AZIA Center, No.1233 Lujiazui Ring Rd., Pudong District, Shanghai 200120, China

Tel: +86-21-5877-1818, Fax: +86-21-6887-7858 / -7898

Renesas Electronics Hong Kong Limited

Unit 1601-1613, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong

Tel: +852-2886-9318, Fax: +852 2886-9022/9044

Renesas Electronics Taiwan Co., Ltd.

7F, No. 363 Fu Shing North Road Taipei, Taiwan

Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

Renesas Electronics Singapore Pte. Ltd.

1 harbourFront Avenue, #06-10, Keppel Bay Tower, Singapore 098632

Tel: +65-6213-0200, Fax: +65-6278-8001

Renesas Electronics Malaysia Sdn.Bhd.

Unit 906, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia

Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

Renesas Electronics Korea Co., Ltd.

11F., Samik Lavied' or Bldg., 720-2 Yeoksam-Dong, Kangnam-Ku, Seoul 135-080, Korea

Tel: +82-2-558-3737, Fax: +82-2-558-5141

RH850/F1KM-S1 Starter Kit V3

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Renesas Electronics:](#)

[Y-ASK-RH850F1KM-S1-V3](#)