



Gesture Demonstrator Kit ezPyro™

- Prototype

For low cost, low power, non-contact mid IR gesture control

User Guide Version

1.2

Please note: the information contained in this document is **draft only** and subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. Pyreos Ltd, SMC, West Mains Road, Edinburgh EH9 3JF, UK. Tel: +441316507009, www.pyreos.com; © Copyright Pyreos Ltd 2017



1	Introduction	3
1.1	Kit requirements	3
2	Kit Contents.....	3
3	Getting started	4
3.1	Kit contents	4
3.2	Minimum system requirements	4
4	Installation	5
4.1	Install the Pyreos software	5
5	Installing the ST Microcontroller USB Driver	6
6	Installing .NET 4.5 framework.....	6
6.1	Connect the ezPyro demo kit.....	6
7	Running the Software	7
8	Gesture Detection Mode	14
8.1	General Gesture Detection	14
8.2	Gesture Trigger Threshold option.....	15
8.3	Gesture Detection Algorithm Peak Spread	16
9	Presence Detection Mode	16
9.1	Proximity Detection Algorithm Parameters.....	16

Please note: the information contained in this document is **draft only** and subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. Pyreos Ltd, SMC, West Mains Road, Edinburgh EH9 3JF, UK. Tel:+441316507009, www.pyreos.com; © Copyright Pyreos Ltd 2017



1 Introduction

This user guide describes the Pyreos Gesture evaluation kit for ezPyro™ gesture sensor. This includes the gesture kit with a lens (dPYEGE01) and the gesture kit without a lens (dPYEGE02).

1.1 Kit requirements

- Microsoft Windows PC (all versions supported currently)
- Local administrative rights to install device drivers
- Microsoft .net framework 4.0 (if not present it will be installed during software setup) □
1 free USB port

2 Kit Contents

1. Mini USB cable
2. EzPyro Gesture Software
3. EzPyro Gesture kit (dPYEGE02 shown)



Figure 1 ezPyro Gesture Demo Kit

Please note: the information contained in this document is **draft only** and subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. Pyreos Ltd, SMC, West Mains Road, Edinburgh EH9 3JF, UK. Tel: +441316507009, www.pyreos.com; © Copyright Pyreos Ltd 2017



3 Getting started

3.1 Kit contents

1. EzPyro - Prototype Flame Sensor Demonstrator Kit
2. MicroUSB-to-USB cable
3. Pyreos flame detection software (Setup file included in software package)
4. USB drive with software and documentation

3.2 Minimum system requirements

1. Microsoft® Windows PC (all versions supported currently)
2. 2 GB of RAM
3. 450 MB of available hard-disk space for installation, additional free space required for storing CSV files
4. 1024x768 display (1280 x 1024 recommended)
5. Local administrative rights to install device drivers
6. .NET Framework 4.5
7. 1 free USB port

Please note: the information contained in this document is **draft only** and subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. Pyreos Ltd, SMC, West Mains Road, Edinburgh EH9 3JF, UK. Tel: +441316507009, www.pyreos.com; © Copyright Pyreos Ltd 2017



4 Installation

4.1 Install the Pyreos software

From the software pack included with the kit, select the “setup.exe” file that has this icon. This will start the installation process.



Figure 2: Installer screen

Follow the on screen instructions and enter the information required.

As part of the installation process a check will take place to see if .NET Framework 4.5 is present. If not, the setup routine can be cancelled and the .NET framework 4.5 can be downloaded from Microsoft's website.

A driver is needed for the STM32F303K8T6 microcontroller. This is included in the software package.

Please note: the information contained in this document is **draft only** and subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. Pyreos Ltd, SMC, West Mains Road, Edinburgh EH9 3JF, UK. Tel:+441316507009, www.pyreos.com; © Copyright Pyreos Ltd 2017



5 Installing the ST Microcontroller USB Driver

The USB supplied contains a folder called “en.stsw-link009.zip”. Extract the files and run either the application “dpinst_amd64.exe” if you have a 64bit system or “dpinst_x86.exe” if you have a 32 bit system. This will install the USB driver for the ST microcontroller that is connected to the ezPyro board.

Once the driver has been installed the USB cable can be connected between the ezPyro Board and the computer.

Once connected the green light on the ezPyro board will be on constantly and the red light will flash (The microcontroller is the inverse of this, red is on constantly and green flashes).

6 Installing .NET 4.5 framework

If you do not have the .NET 4.5 framework installed on your computer then use the installer provided (“dotnetfx45_full_x86_x64”) in the software package.

6.1 Connect the ezPyro demo kit

1. Connect the USB cable to the kit and Windows PC


You may see a message suggesting you are required to install a device driver. Follow the on screen instructions and download a driver from Windows Update or install from the software package provided.



7 Running the Software

Double clicking on the .exe file will open the application.

This will open the window shown below:




To connect to the demo kit, select the Device -> Connect to Device

Please note: the information contained in this document is **draft only** and subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. Pyreos Ltd, SMC, West Mains Road, Edinburgh EH9 3JF, UK. Tel: +441316507009, www.pyreos.com; © Copyright Pyreos Ltd 2017



This will open a window with all available devices on COM ports.



Connect to the port that appears once the device is connected. This can be checked by disconnecting the device and refreshing the list. Re-connect and refresh the list then select the COM port that has appeared and click OK.

Once the device has been selected the software runs through a calibration sequence, whilst the calibration sequence is running the arrow that indicates a gesture direction will spin round and then vanish upon completion of the calibration. This is required when using the device without a method of stopping drafts from running across the device.

Please note: the information contained in this document is **draft only** and subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. Pyreos Ltd, SMC, West Mains Road, Edinburgh EH9 3JF, UK. Tel:+441316507009, www.pyreos.com; © Copyright Pyreos Ltd 2017



The main window contains the following sections:

Algorithm Tab


- Window showing current detection mode (The button for the active mode, gesture or presence is highlighted in blue). When an event occurs, the detected event will be shown with a direction icon,
- 4 scope windows which show the signals produced by each of the pixels in the sensor.
- A console which displays detected messages as well as any changes or errors and a simple setting window where the trigger threshold can be changed.

Please note: the information contained in this document is **draft only** and subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. Pyreos Ltd, SMC, West Mains Road, Edinburgh EH9 3JF, UK. Tel: +441316507009, www.pyreos.com; © Copyright Pyreos Ltd 2017



See section 5 for use of parameters.

Please note: the information contained in this document is **draft only** and subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. Pyreos Ltd, SMC, West Mains Road, Edinburgh EH9 3JF, UK. Tel: +441316507009, www.pyreos.com; © Copyright Pyreos Ltd 2017



ASIC Control Tab


The ASIC box gives the user access to the various parameters that can be controlled on the output of the ezPyro.

- Gain: The gains should all be set equal on every channel for gesture detection. They are allowed to be set independently simply to allow the user complete control over every aspect of the device that can be set. The gain is set by selecting a capacitor to be used in the charge amplifier within the device.
- High Pass Filter (HPF): The high pass filters should again be set equal for gesture detection.
- Transconductance: The transconductance gives the user the ability to set the time constant of the sensor and amplifier set-up.
- Low Pass Filter: The low pass filter used is common to all channels of the ezPyro.

Please note: the information contained in this document is **draft only** and subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. Pyreos Ltd, SMC, West Mains Road, Edinburgh EH9 3JF, UK. Tel: +441316507009, www.pyreos.com; © Copyright Pyreos Ltd 2017



- Sampling Period: This allows the sampling rate to be altered.




Wake-up Tab

The wake up box allows the setting of the wake up conditions for the device. The wake up only applies when the device is in sleep mode.

- The wake up works by requiring the signal to be within the range of threshold 1 and 2 or within threshold 3 and 4 for a certain number of samples.
- The number of samples required is in the top right box.
- The channel that is being used for the wake up condition is selected in the box above the 'apply' button.

For more detail on wake up conditions please refer to the ezPyro datasheet.

Please note: the information contained in this document is **draft only** and subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. Pyreos Ltd, SMC, West Mains Road, Edinburgh EH9 3JF, UK. Tel: +441316507009, www.pyreos.com; © Copyright Pyreos Ltd 2017



System Tab

The system box allows the user to set the orientation of the device to ensure directions of gesture are correctly displayed.


Please note: the information contained in this document is **draft only** and subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. Pyreos Ltd, SMC, West Mains Road, Edinburgh EH9 3JF, UK. Tel: +441316507009, www.pyreos.com; © Copyright Pyreos Ltd 2017



8 Gesture Detection Mode


8.1 General Gesture Detection

The initial settings for the orientation are as shown below.



The gestures will produce a distinct signal shape on each channel as can be seen below.

Please note: the information contained in this document is **draft only** and subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. Pyreos Ltd, SMC, West Mains Road, Edinburgh EH9 3JF, UK. Tel: +441316507009, www.pyreos.com; © Copyright Pyreos Ltd 2017



The faster the gesture, the closer together the peaks in the signals are. If the signal peaks are small (can be caused by the hand temperature being close to background temperature), it is recommended to reduce the sensitivity in the settings window as will be described later.

8.2 Gesture Trigger Threshold option

Setting the threshold for gestures to be lower will cause a greater chance of false gestures being registered caused by noise. And setting too high will make registering actual gestures less likely.

Please note: the information contained in this document is **draft only** and subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. Pyreos Ltd, SMC, West Mains Road, Edinburgh EH9 3JF, UK. Tel:+441316507009, www.pyreos.com; © Copyright Pyreos Ltd 2017




8.3 Gesture Detection Algorithm Peak Spread

- How far apart the peaks in signals can be before considered a gesture. The larger the value used, the more the system is affected by noise.
- Range : 1 to 400
- Typical : 12

9 Presence Detection Mode

A presence event is one that simply states that an object of higher temperature than the background radiation has come into or moved out of the FOV of the sensor.



9.1 Proximity Detection Algorithm Parameters

It is possible to modify the proximity detection algorithm parameters.

Please note: the information contained in this document is **draft only** and subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. Pyreos Ltd, SMC, West Mains Road, Edinburgh EH9 3JF, UK. Tel: +441316507009, www.pyreos.com; © Copyright Pyreos Ltd 2017



- **Window Size**
 - Window width in samples used to detect event.
Larger window allow slower gestures, smaller rejects them.
 - Range : 10 to 2000
 - Typical : 400
- **Detection Threshold**
 - How high the peak value has to be before recognised for gesture.
 - Range : 1 to 20
 - Typical : 3

The same ASIC, wake up and System settings are available within the presence section as in the gesture detection section.

Please note: the information contained in this document is **draft only** and subject to change without further notification. Pyreos reserves the right to alter the performance and any resulting specification. Pyreos may choose not to supply any engineering sample devices as a commercial product. No responsibility is accepted for any consequential loss incurred. Pyreos Ltd, SMC, West Mains Road, Edinburgh EH9 3JF, UK. Tel:+441316507009, www.pyreos.com; © Copyright Pyreos Ltd 2017

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Pyreos:

[dPYEGE01](#) [dPYEGE02](#)