

Product Document



User Guide

UG000416

TMF8x0x

EVM User Guide

TMF8x0x-EVM

v6-00 • 2023-Apr-27

Content Guide

1	Introduction	3	3.2	EVM GUI “Distance vs Time” Tab	14
1.1	EVM Kit Content	3	3.3	Upgrading the EVM Firmware	14
1.2	Ordering Information	4	3.4	Automation of Measurements.....	16
2	Setting Up the EVM	5	4	Revision Information	20
2.1	Setting Up the EVM Hardware	5	5	Legal Information.....	21
2.2	Installing the EVM Graphical User Interface	7			
3	Using the EVM Software	8			
3.1	EVM GUI “Histogram Display” Tab	8			

1 Introduction

The Time-of-Flight (hereafter referred to as 'ToF') EVM demonstration kit provides a way to evaluate the latest prototype ToF optical sensor(s) from ams-OSRAM AG. This document is a basic user guide to the setup and operation of the ToF EVM software.

1.1 EVM Kit Content

Below is a checklist of what is included in the ToF EVM kit:

- ToF sensor EVM enclosure and sample glass (some EVMs come without an enclosure)
- USB type A to micro-USB cable(s)
- USB Flash drive with EVM GUI software
- EVM documentation (including this guide)

Figure 1:
Kit Content



1.2 Ordering Information

Ordering Code	Description
TMF8701-EVM	TMF8701 ToF Evaluation Module
TMF8701-DB	TMF8701 ToF Daughter Board
TMF8801-EVM	TMF8801 ToF Evaluation Module
TMF8801-DB	TMF8801 ToF Daughter Board
TMF8805-EVM	TMF8805 ToF Evaluation Module
TMF8805-DB	TMF8805 ToF Daughter Board

2 Setting Up the EVM

This section describes the setup steps necessary to start using the EVM software.

2.1 Setting Up the EVM Hardware


The ToF sensor enclosure is already assembled and ready to plug in to a PC. The EVM with the enclosure exposes only one micro-USB connector:

Figure 2:
EVM with Enclosure




On EVMs without enclosure (or if the enclosure has been removed) plug in the micro-USB connector to the USB connector closer to the center of the Raspberry PI Zero W board (see Figure 3).

Figure 3:
EVM Without Enclosure – Front Side (TMF8701 facing to table)



TMF8701 is shown in the below Figure 4 when placing the Raspberry Pi Zero W on the backside.

Figure 4:
EVM Without Enclosure – Back Side (TMF8701 facing to ceiling)



2.1.1 Install the EVM USB Windows (one-time only)

When the EVM is plugged into the PC, Windows should recognize the EVM as a “Removable Disk”.

Install this necessary USB driver (right-click and choose “Install” from the context menu):

- `ams-raspi-rndis.inf`

This step is only necessary during first-time setup, but will need to be repeated if using the EVM software on a new PC.

2.2 Installing the EVM Graphical User Interface

The ToF EVM GUI software is included on the USB flash drive.

Launch the Windows installer and choose the desired installation options. The EVM graphical user interface executable file is titled `ToF_EVM_GUI.exe`.


3 Using the EVM Software

This section describes the operation and capabilities of the EVM Graphical User Interface.

3.1 EVM GUI “Histogram Display” Tab

The Histogram Display Tab is the primary context of the ToF EVM demo software and it has the most control options available. Here the user can get an overview of object detection as well as histogram graphing. Please refer to Figure 5 for a breakdown of the various components in the Histogram Display Tab.

Figure 5:
Histogram Display Tab TMF8701



The relevant information and control option labels are:


1. View context, consists of:
 - The “Histogram Display” tab for distance and histogram information.
 - The “Distance vs. Time” tab for object tracking over time and responsiveness.
 - “File upload” tab for updating various software files on the EVM demo kit.

2. Distance graph that plots the distance an object is detected vs. the confidence in the detection of an actual object.
3. Histogram plotting area for various histograms.
4. “Control” box for data logging, continuous vs. snapshot data retrieval, calibration trigger and clear, and operating mode selection.
5. “Histogram Display” box for selecting which histogram to display.
 - Distance and proximity show raw histograms directly from the TDCs.
 - Processed shows a histogram, which is already combined of all TDCs and corrected for ambient light effects.
6. “Graph” box for changing graphing options.
7. “Histogram Enable” box for selecting Reference TDC channels.
8. Snapshot feature, serial number, EVM kit software revision, and firmware and hardware revision of the ToF sensor chip in the currently connect EVM kit.
9. Connection status indicators.

3.1.1 EVM GUI “Histogram Display” Tab TMF8801/TMF8805

The GUI from version 2.x.x.x onwards automatically detects if a TMF8701 or TMF8801/TMF8805 is connected. If a TMF8701 is connected, see section 3.1. For TMF8801/ TMF8805 the Histogram display Tab is shown in following figure:

Figure 6:
Histogram Display Tab TMF8801/TMF8805



Additionally to all the controls available for TMF8701, the TMF8801/TMF8805 GUI adds following control (10):

- Mode of operation: High Performance mode, default mode, low power mode. These are predefined settings for iterations and threshold.
- Iterations / threshold:
 - Define the number of iterations for acquisition. An iteration is typically 26.6 ns, so e.g. 900k iterations result in 24 ms acquisition time. Calculation time is approximately 9 ms, so the total ranging time is 33 ms.
 - Threshold: Detection threshold. It is ok to stay at default 0 setting.



Information

To get fastest ranging time, disable all histogram display functions.

3.1.2 Distance vs. Confidence Graph

This is a plot of the detected object's distance vs. the confidence value (range 0 – 63) of the given detection. The X-axis indicates the distance in millimeters and the Y-axis indicates the confidence value.

3.1.3 Histogram Plot

This is a plot of the TDC histogram information based on the selections in the “Data” box and the “Histogram Display” box. The X-axis indicates the “time buckets” in 100 picosecond increments, and the Y-axis indicates the number of photonic triggers/hits at the given time interval.

3.1.4 “Graph” Box

The Graph box controls the display parameters of the histogram plots. You can enable/disable auto scaling of the independent axes or optionally set a fixed range to display. The graphing legend box will show labels for the various histograms as well as precise distance and confidence values in the distance vs confidence graph.

3.1.5 “Control” Box

Logging Data

For logging Data:

1. Click “...” and use the File Explorer to fill out a log file path
2. Select the “Save data to file” option
3. Perform desired data collection
4. De-select “Save data to file” option
5. View the contents of the entered file path to observe the collected data



Attention

Be careful when logging with multiple data options selected over a long period of time. With all histograms enabled and continuous logging, the resulting log file can be almost 1 GB in size in 1 – 2 hours.

Finding Software Version Information

The software versions of the ToF EVM GUI, EVM kit, and ToF firmware are displayed in the lower right hand corner of the ToF EVM GUI as well as logged to the data file selected in section “Logging Data”.

The format of the version information in the log file:

```
#VER;ToF Serial Number;App0 Version Number;GUI Version Number;Host Driver Version Number  
#VER;01-00-80-0b;01.02.04.00;1.0.0.0;01.01.00.00
```

Continuous vs. Snapshot Data Retrieval

Selecting the “Continuous Mode” box will force the EVM GUI to continuously pull data from the EVM demo kit for displaying in real time. If continuous is not selected the data will only be updated each time the user selects the “Start” button.

Operating Mode Selection

This drop-down box shows the available operating modes available to the ToF device. Some examples are “distance + proximity” or “proximity” only. The object detection graph will scale accordingly for the supported distances in the current operating mode.

Trigger/Clear Calibration

The “Clear Calibration” button will clear the current devices factory calibration data and resume measurements with the current EVM GUI parameters. During this short time the device is reset and all graphs will stop updating until the reset is complete. The “Calibrate” button will trigger a factory calibration measurement. Both calibration and clearing the calibration take approximately 1 - 2 seconds to complete.



Attention

When performing factory calibration no object should be within 400 mm of the ToF sensor’s field of view and use low ambient light (avoid high IR content).

3.1.6 “Histogram Display” Box

TMF8701

The Data box indicates which histogram types are displayed in the histogram plotting area.

- Distance measurement histograms (only applicable when “distance” mode is enabled).

- Proximity histograms
- Processed histograms

TMF8801/TMF8805

The Data box indicates which histogram types are displayed in the histogram plotting area.

- Short and long range histograms
These are the raw histograms directly from the TDC channels. See datasheet for description of long / short range.
- Processed histograms
Processed shows a histogram which is already combined of all TDCs and corrected for ambient light effects.

3.1.7 “Histogram Enable” Box

This box allows the user to select the reference TDC channels for display in the histogram plotting area. The GUI will always display TDC channels 1-4 if long range / short range respectively distance or proximity histograms are enabled.

3.1.8 Histogram Snapshot Control

The Histogram Snapshot button allows the user to “freeze frame” the current histogram plot while still plotting the real time histograms concurrently. This gives the ability to examine two histogram plots (one in real time, the other a snapshot) at the same time in the histogram plotting area. Hitting the “Clear” button deletes the saved snapshot histograms.

3.1.9 Connection Status Indicators

Connection status indicators between the EVM GUI software and the ToF EVM software running in the enclosure.

- “Control HID” is the connection status with the enclosure software
 - A RED icon indicates that there is no good connection with the enclosure software
 - A GREEN icon means the connection is good
- “Module HID” is the connection status with the ToF demo software
 - A RED icon indicates that there is a problem communicating with the ToF demo software or an internal software error.
 - A GREEN icon means the ToF software connection is good.


3.2 EVM GUI “Distance vs Time” Tab

The Distance versus Time tab replaces the distance vs. confidence graph and histogram plot with a single display of the object data reported over the previous 3.5 seconds. The control options to the right of the window have the same meaning as the “Histogram Display” tab with some of the histogram displaying options removed.

3.3 Upgrading the EVM Firmware


To upgrade the EVM use following tab:

Figure 7:
Firmware Upgrade GUI 2.x.x.x



Press “Update All Binaries” – see **1** above – and select directory where the new firmware is located. Use “Select Folder” in the directory selection box to start the firmware upgrade. Power cycle the EVM once firmware upgrade is finished (see Figure 8).


Figure 8:
Firmware Upgrade Finished -> Power Cycle EVM



3.4 Automation of Measurements

The EVM firmware allows control through a separate (e.g. customer) program. The communication link is achieved through TCP/IP using TCP port 39999 on the host where the EVM GUI is running.

1. To start the automation mode the automation host needs to open a TCP connection to 127.0.0.1 port 39999.
To use 127.0.0.1 (localhost), the automation host must run on the same machine as the EVM GUI. Once connected the GUI shows following status:




2. After the connection is established, the EVM sends version and calibration information to the automation host.
This will look like the following:
#VER;dc-00-40-14;2.0.30.0;1.6.0.0;4.3.2.25;7;3
#CAL;02;21;37;00;0F;15;80;F9;F0;FF;FC;17;34;00;04
3. To trigger a single measurement the automation host has to send the character "m" to the EVM GUI.
4. To switch the distance measurement algorithm mode send these characters to the EVM GUI from the automation host (only TMF8701)
"d" -> distance mode
"p" -> proximity mode
"b" -> combined mode
5. The EVM GUI sends all histograms the user selects with the checkboxes in the GUI. The default is the "Processed" histogram.
6. The protocol for the measurement data is described in document TMF8XXX_Logfile_Format.docx.

3.4.1 Automation Example Session

To operate the following example, the EVM GUI needs to be started first.


Start the Windows shell “cmd” and connect through Windows program telnet:

Figure 9:
Telnet Command



Immediate response and in the GUI the status ‘Automation On’ is displayed.


Figure 10:
Automation Example



Press “m” executes one measurement and transfer the enabled histograms (in this case only the average histogram).

Executing “m” several times:

Figure 13:
Executing m Several Times



```

Telnet 127.0.0.1
m#OBJ;1539607928504;00001;00063;00107;000050462;000176793
m#OBJ;1539608025517;00001;00063;00119;000049904;000176926
m#OBJ;1539608025907;00001;00063;00116;000050507;000182552
m#OBJ;1539608026308;00001;00010;00076;000050524;000384260
m#OBJ;1539608026812;00001;00063;00127;000050445;000148622
m#OBJ;1539608027154;00001;00063;00150;000049665;000082038
m#OBJ;1539608027385;00001;00063;00158;000050971;000082317
m#OBJ;1539608027578;00001;00063;00164;000049518;000073187
m#OBJ;1539608027763;00001;00063;00171;000049383;000062368
m#OBJ;1539608027945;00001;00063;00166;000049510;000055071
m#OBJ;1539608028114;00001;00063;00151;000050688;000067082
m#OBJ;1539608028285;00001;00063;00139;000050019;000102151
m#OBJ;1539608028464;00001;00063;00130;000050710;000126955
m#OBJ;1539608028651;00001;00063;00113;000050219;000166896
m#OBJ;1539608028830;00001;00063;00097;000051209;000185691
m#OBJ;1539608029024;00001;00010;00083;000051171;000332910
m#OBJ;1539608029232;00001;00010;00070;000051114;000417894
m#OBJ;1539608029412;00001;00010;00069;000051195;000415975
m#OBJ;1539608029618;00001;00010;00091;000050402;000258837
m#OBJ;1539608029819;00001;00063;00111;000049417;000154987
m#OBJ;1539608030018;00001;00063;00128;000050281;000146939
m#OBJ;1539608030239;00001;00063;00135;000049590;000096181
m#OBJ;1539608030477;00001;00063;00139;000050125;000098028
m#OBJ;1539608030692;00001;00063;00144;000051082;000093884
m#OBJ;1539608031180;00001;00063;00134;000049641;000095704
m#OBJ;1539608031646;00001;00063;00126;000049721;000113915

```

Windows telnet can be stopped by using Ctrl-']' and then enter the command quit.

4 Revision Information

Changes from previous version to current revision v6-00	Page
Updated document security class from “Confidential” to “Public”	
Updated title of the document from “TMF8x01” to “TMF8x0x”	

- Page and figure numbers for the previous version may differ from page and figure numbers in the current revision.
- Correction of typographical errors is not explicitly mentioned.

5 Legal Information

Copyrights & Disclaimer

Copyright ams-OSRAM AG, Tobelbader Strasse 30, 8141 Premstaetten, Austria-Europe. Trademarks Registered. All rights reserved. The material herein may not be reproduced, adapted, merged, translated, stored, or used without the prior written consent of the copyright owner.

Demo Kits, Evaluation Kits and Reference Designs are provided to recipient on an "as is" basis for demonstration and evaluation purposes only and are not considered to be finished end-products intended and fit for general consumer use, commercial applications and applications with special requirements such as but not limited to medical equipment or automotive applications. Demo Kits, Evaluation Kits and Reference Designs have not been tested for compliance with electromagnetic compatibility (EMC) standards and directives, unless otherwise specified. Demo Kits, Evaluation Kits and Reference Designs shall be used by qualified personnel only.

ams-OSRAM AG reserves the right to change functionality and price of Demo Kits, Evaluation Kits and Reference Designs at any time and without notice.

Any express or implied warranties, including, but not limited to the implied warranties of merchantability and fitness for a particular purpose are disclaimed. Any claims and demands and any direct, indirect, incidental, special, exemplary or consequential damages arising from the inadequacy of the provided Demo Kits, Evaluation Kits and Reference Designs or incurred losses of any kind (e.g. loss of use, data or profits or business interruption however caused) as a consequence of their use are excluded.

ams-OSRAM AG shall not be liable to recipient or any third party for any damages, including but not limited to personal injury, property damage, loss of profits, loss of use, interruption of business or indirect, special, incidental or consequential damages, of any kind, in connection with or arising out of the furnishing, performance or use of the technical data herein. No obligation or liability to recipient or any third party shall arise or flow out of ams-OSRAM AG rendering of technical or other services.

RoHS Compliant & ams Green Statement

RoHS Compliant: The term RoHS compliant means that ams-OSRAM AG products fully comply with current RoHS directives. Our semiconductor products do not contain any chemicals for all 6 substance categories plus additional 4 substance categories (per amendment EU 2015/863), including the requirement that lead not exceed 0.1% by weight in homogeneous materials. Where designed to be soldered at high temperatures, RoHS compliant products are suitable for use in specified lead-free processes.

ams Green (RoHS compliant and no Sb/Br/Cl): ams Green defines that in addition to RoHS compliance, our products are free of Bromine (Br) and Antimony (Sb) based flame retardants (Br or Sb do not exceed 0.1% by weight in homogeneous material) and do not contain Chlorine (Cl) not exceed 0.1% by weight in homogeneous material).

Important Information: The information provided in this statement represents ams-OSRAM AG knowledge and belief as of the date that it is provided. ams-OSRAM AG bases its knowledge and belief on information provided by third parties, and makes no representation or warranty as to the accuracy of such information. Efforts are underway to better integrate information from third parties. ams-OSRAM AG has taken and continues to take reasonable steps to provide representative and accurate information but may not have conducted destructive testing or chemical analysis on incoming materials and chemicals. ams-OSRAM AG and ams-OSRAM AG suppliers consider certain information to be proprietary, and thus CAS numbers and other limited information may not be available for release.

Headquarters

ams-OSRAM AG
Tobelbader Strasse 30
8141 Premstaetten
Austria, Europe
Tel: +43 (0) 3136 500 0

Please visit our website at www.ams.com

Buy our products or get free samples online at www.ams.com/Products

Technical Support is available at www.ams.com/Technical-Support

Provide feedback about this document at www.ams.com/Document-Feedback

For sales offices, distributors and representatives go to www.ams.com/Contact

For further information and requests, e-mail us at ams_sales@ams.com