

Kit P/N: H-1202

**BOURNS®**

Bourns Part No.	Taper/Shaft	Resistance Value (Ohms)
<a href="#">PDB181-GTR01-254A2</a>	Knurled Shaft/Solder Lugs	250K
<a href="#">PDB181-GTR01-504A2</a>	Knurled Shaft/Solder Lugs	500K
<a href="#">PDB181-GTR02-254A2</a>	Plain Shaft/Solder Lugs	250K
<a href="#">PDB181-GTR02-504A2</a>	Plain Shaft/Solder Lugs	500K
<a href="#">PDB182-GTRB1-254MN</a>	Knurled Shaft/Solder Lugs/Center Detent	250K
<a href="#">PDB182-GTRB1-504MN</a>	Knurled Shaft/Solder Lugs/Center Detent	500K
<a href="#">PDB182-GTRB2-254MN</a>	Plain Shaft/Solder Lugs/Center Detent	250K
<a href="#">PDB182-GTRB2-504MN</a>	Plain Shaft/Solder Lugs/Center Detent	500K
<a href="#">PDB183-GTR01-254A2</a>	Knurled Shaft (18 Tooth) / Solder Lugs	250K
<a href="#">PDB183-GTR01-504A2</a>	Knurled Shaft (18 Tooth) / Solder Lugs	500K
<a href="#">PDB183-GTR02-254A2</a>	Plain Shaft / Solder Lugs	250K
<a href="#">PDB183-GTR02-504A2</a>	Plain Shaft / Solder Lugs	500K