

## **Installation Manual**

Cincon AC adapter type, power supplies  
Model series TR, TRG and TRH

### **⚠ WARNING**

1. Do not open, modify or attempt to repair the adapter. Electric shock and/or fire can result.
2. Output current and wattage must not exceed specified rating.
3. Do not allow objects, including liquids, to penetrate the adapter.
4. Do not place the adapter in or near a wet or high moisture area.
5. Do not place adapter on or near a heat source
6. Use only an approved, compatible AC power cord for adapter requiring an AC power cord.
7. Disconnect adapter from AC power source before cleaning. Only clean with a dry cloth.
8. Consult a local recycler for disposal of adapter.

### **► INSTALLATION**

1. Verify adapter voltage and current rating is appropriate for equipment being powered.
2. Place adapter in a well ventilated and mechanically stable location. Do not hang adapter from either the AC power cord or DC output cable. Do not place objects on the adapter.
3. For adapters requiring an AC power cord, ensure power cord is firmly attached to the adapter before plugging into an AC power source. Avoid twisting or tangling the power cord or placing in a location where it can be stepped on. Do not place objects on the AC power cord.
4. For adapters with replaceable AC plugs, snap plug to adapter body and ensure a positive attachment before plugging into an AC power source.

---