

Series 80 "Mighty Mouse" Jam Nut Spanner and Connector Holding Tools

Spanner Tool for Tightening Series 80 Jam Nuts



Spanner
Tool

Connector Holding Tool for Tightening Backshells and Accessories



1
Plug
Holder



2
Receptacle Holder

Use these tools to tighten Series 80 jam nuts. 1/4" or 3/8" square drive for use with torque wrenches. Heat-treated steel, nickel plated.

Shell Size	Spanner Tool Part Number					
	Series 800	Series 801	Series 803	Series 804 Style 07	Series 804 Style 00	Series 805
5	600-146-01	600-146-02	600-137-02	600-146-03	600-147-5	
6	600-146-02	600-146-03	600-137-03	600-146-04	600-147-6	
7	600-146-03	600-146-05	600-137-05	600-146-06	600-147-7	
8	600-146-04	600-146-05	600-137-05	600-146-06	600-147-7	600-154-08
9	600-146-05	600-146-06	600-137-06	600-146-07	600-147-9	600-154-09
10	600-146-06	600-146-07	600-137-07	600-146-08	600-147-10	600-154-09
11	—	—	—	—	—	600-154-11
12	600-146-08	—	600-137-10	600-146-10	600-147-12	600-154-12
13	—	600-146-10	—	—	—	—
14	600-146-10	—	600-137-13	600-146-12	600-147-14	—
15	600-146-11	—	600-137-14	600-146-13	600-147-15	600-154-15
16	—	600-146-13	—	—	—	—
17	—	600-146-14	—	—	—	—
18	—	—	—	—	—	600-154-18
19	—	—	—	—	—	600-154-19

Use these tools to hold Series 80 connectors while installing thread-on adapters or backshells.

1 Plug tool for holding Series 80 plug connectors.
Heat-treated steel, nickel plated.

2 Receptacle tool for holding Series 80 receptacle connectors. Heat-treated steel, nickel plated.

Shell Size	Holding Tool Part Number (Add P or R)				
	Series 800	Series 801	Series 803	Series 804	Series 805
5	600M005-05 ★	600MM005-05 ◆	600-140-5 ★	600-141-5 ■	—
6	600M005-06 ★	600MM005-06 ◆	600-140-6 ★	600-141-6 ■	—
7	600M005-07 ★	600MM005-07 ◆	600-140-7 ★	600-141-7 ■	—
8	600M005-08 ★	600MM005-08 ◆	600-140-8 ★	600-141-8 ■	600-155-8 ■
9	600M005-09 ★	600MM005-09 ◆	600-140-9 ★	600-141-9 ■	600-155-9 ■
10	600M005-10 ★	600MM005-10 ◆	600-140-10 ★	600-141-10 ■	600-155-10 ■
11	—	—	—	600-141-11 ■	600-155-11 ■
12	600M005-12 ★	—	600-140-12 ★	600-141-12 ■	600-155-12 ■
13	—	600MM005-13 ◆	—	—	—
14	—	—	600-140-14 ★	600-141-14 ■	—
15	—	—	600-140-15 ★	600-141-15 ■	600-155-15 ■
16	—	600MM005-16 ◆	—	—	—
17	—	600MM005-17 ◆	—	—	—
18	—	—	—	—	600-155-18 ■
19	—	—	—	—	600-155-19 ■

★ Add **P** for plug holder or **R** for receptacle holder, followed by polarizing position (**N, X, Y, Z** or **U** for universal keying).

◆ Add **P** for plug holder or **R** for receptacle holder, followed by polarizing position (**A, B, C, D**).

■ Add **P** for plug holder or **R** for receptacle holder.

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Glenair:

[600-155-11P](#) [600-140-10PU](#) [600-140-10RU](#) [600-140-12PU](#) [600-140-12RU](#) [600-140-14PU](#) [600-140-14RU](#) [600-140-15PU](#) [600-140-15RU](#) [600-140-5PU](#) [600-140-5RU](#) [600-140-6PU](#) [600-140-6RU](#) [600-140-8PU](#) [600-140-8RU](#) [600-140-9PU](#) [600-140-9RU](#) [600-155-18P](#) [600-155-8P](#) [600-155-8R](#) [600-155-9P](#) [600-141-6P](#) [600-141-10R](#) [600-141-7P](#) [600-140-6RN](#) [600-140-9PN](#) [600-141-15PA](#) [600-141-12PA](#) [600-140-6PN](#) [600-141-9P](#) [600-141-9R](#) [600MM005-08PB](#) [600-154-21](#) [600-140-7PN](#) [600-141-7R](#) [600-140-9RN](#) [600-141-9PA](#) [600-141-12R](#) [600-141-15PB](#) [600-141-8R](#) [600-141-14R](#) [600-140-8PN](#) [600-140-7RN](#) [600-141-15R](#)