

Flasher-C2000

- ❶ **Install Flasher-C2000** Insert the *JTAGjet-C2000* CD into the drive. The Master Setup dialog box appears, providing access to the complete installation documentation. Select **Flasher-C2000 for JTAGjet**.
- ❷ **Install USB driver** Plug the emulator into the USB port. If prompted by the *Found New Hardware* wizard, point to the **SigUSB.inf** file in the root of the CD. For details, see *USB 2.0 Driver for JTAGjet and ADM51: Installation Instructions* (jtagjet_usb_install.pdf).
- ❸ **Start Flasher-C2000** Click the Windows Start button and select **Flash2800Win** or **Flash2400Win** from the *Signum Systems Flasher-C2000* program group.
- ❹ **Uninstalling** You can uninstall Flasher-C2000 using *Add or Remove Programs* in Windows Control Panel (or equivalent). ■

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

IAR Systems:

[JTAGjet-C2000](#) [JTAGjet-C2000F](#) [JTAGjet-C2000F-ISO](#) [ADA-ISO-TI14](#)