


NOTES:

1. OPERATION

1. GENTLY LIFT LATCH AT SIDE OF CONNECTOR.
2. SWING COVER OFF OF CONTACTS.
3. SLIDE THE FLEX TAPE INTO THE CONNECTOR PLACING THE EDGE OF THE FLEX TAPE UNDER 2 HOLD DOWN TABS.
4. FOLD OVER THE COVER AND PRESS IN PLACE UNTIL THE LATCH IS FULLY ENGAGED.

2. LIMIT CURRENT TO A MAXIMUM OF 5 AMPS.

JKL PART NO.: ZCH-137HD-8J

				<div>METRIC</div> <div></div> <div>THIRD ANGLE PROJECTION</div>	<div>DIMENSIONS ARE IN mm (INCHES)</div> <div>TOLERANCE UNLESS OTHERWISE SPECIFIED</div> <div>1 PL +/- REF.</div> <div>2 PL +/- REF.</div> <div>ANGLE +/-</div>	<div>JKL COMPONENTS CORPORATION</div>				
						TITLE NO SOLDER 8mm FLEX TAPE JOINER CONNECTOR				
A	ADD SIDE VIEW	8/20/15	DRAWN BY L. WENGSTROM	APPV'D BY L.R.	DATE 8/20/15	SIZE A	FSCM NO. 55335	DRAWING NO. ZCH-137HD-8J		
	RELEASE & CANCEL PL-1409-02	10/10/14								
REV. NO.	DESCRIPTION/ECO NUMBER	APPV'D DATE	- CAD DRAWING - MANUAL REVISIONS NOT PERMITTED			SCALE	RELEASED DATE	REVISION DATE	REV. NO.	SHEET
						NONE	10/10/14	8/20/15	A	1 OF 1

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[JKL Components:](#)

[ZCH-137HD-8J](#)