

REMOTE INDICATION, SENSING RESISTORS

| REMOTE INDICATION & METERS | | | |
|---|--|---|--|
| Product | Features | Accessory For | |
| RK-302 Remote Indication and Reset Kit | Panel-mounted remote indication and reset, standard 22 mm mounting with NEMA 4 and NEMA 13 rating. | SE-325 | |
| RK-332 Remote Indication and Reset Kit | Panel-mounted remote indication and reset, standard 22 mm mounting with NEMA 4 and NEMA 13 rating. | SE-330 SE-330AU SE-330HV | |
| PGB-6130 Remote Indication and Reset Assembly | Remote indication of overcurrent, phase unbalance, phase loss, phase sequence, and overtemperature. Remote reset included. | PGR-6130 | |
| PGB-6800 Remote Indication and Reset Assembly | Remote indication of overcurrent, undercurrent, phase unbalance, phase loss, and phase sequence. Remote reset included. | PGR-6800 | |
| PGA-0500 Analog % Current Meter | Panel-mounted analog meter displays ground-fault current as a percentage of the set point. | SE-601 SE-701 PGR-4300 SE-703 PGR-6100 SE-704 | |
| PGA-0510 Analog Ohm Meter | Panel-mounted analog ohmmeter displays insulation resistance from 0 $\boldsymbol{\Omega}$ to infinity. | PGR-3200 PGR-6100 | |
| E2323 & E2324 Megaohmmeter & Kiloohmmeter | Flush-mounted units designed for connection with the T3200 for instrument readings. | T3200 | |
| M8100 Synchroscope | Flush-mounted units provide illuminaated indication of the phase and frequency difference between voltages on two separate AC systems. | T5000 T4500 C6200 FlexGen S6000 Sigma | |

| SENSING RESISTORS | | | |
|--|---|---|------------------------------------|
| Product | | Features | Accessory For |
| ER-600VC (PGE-600V) Sensing Resistor (L) c@us | | Used on systems up to 1 kV. (Continuous duty) | SE-330 SE-325 SE-330AU |
| SE-MRE-600 Enclosure | | Used in outdoor enclosures. (ER-600VC ordered separately) | ER-600VC |
| ER-5KV (PGE-05KV) Sensing Resistor | | Used on systems up to 5 kV. (Continuous duty) | SE-330 SE-325 SE-330AU |
| ER-5WP (PGE-05WV) Sensing Resistor | | Used on systems up to 5 kV, includes weather-protected terminals for use in outdoor enclosures. (Continuous duty) | SE-330 SE-325 SE-330AU |
| ER-15KV (PGE-15KV) Sensing Resistor | | Used on systems up to 15 kV. (Non-continuous duty) | SE-330 SE-325 SE-330HV SE-330AU |
| ER-25KV (PGE-25KV) Sensing Resistor | | Used on systems up to 25 kV. (Non-continuous duty) | SE-330 SE-325 SE-330HV SE-330AU |
| ER-35KV (PGE-35KV) Sensing Resistor | | Used on systems up to 35 kV. (Non-continuous duty) | SE-330 SE-330HV SE-330AU |
| ER-72KV (PGE-72KV) Sensing Resistor | 4 | Used on systems up to 72 kV. (Non-continuous duty) | SE-330HV |

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Littelfuse:

<u>PGE-05KV</u> <u>PGE-600V</u> <u>PGE-15KV</u> <u>PGE-25KV</u> <u>PGE-35KV</u> <u>ER-15KV</u> <u>ER-35KV</u> <u>ER-72KV</u> <u>ER-5KV</u> <u>ER-600VC</u> ER-25KV ER-1000HV SE-MRE-600