

AVR® Functional Safety - Hardware User's Guide

Introduction

This document is the hardware user's guide of AVR[®] Functional Safety board based on ATtiny3217 microcontroller (MCU). It gives details about the overall board design and the hardware function blocks. The AVR Functional Safety board is designed to easily demonstrate and evaluate the safety and reliability peripherals on ATtiny3217 MCU and firmware based safety features, such as:

- Watchdog Timer (WDT)
- Cyclic Redundancy Check (CRC)
- Brown-out Detection (BOD)
- Voltage Level Monitoring (VLM)
- Power-on Reset (POR)
- Timer/Counter Type D (TCD) Fault Detection
- Class B Self Tests



Features

- Core Independent Operation Using Configurable Custom Logic (CCL) and 16-bit Timer/Counter Type A to Create a Heartbeat Signal
- Core Independent Cyclic Redundancy Check Memory Scan (CRCSCAN)
- Core Independent Operation Using 12-bit Timer/Counter Type D (TCD) to Drive a Fan Motor
- Core Independent TCD Fault Handling Using Event System (EVSYS), Analog Comparator (AC) and Digital-to-Analog Converter (DAC)
- Using Charlieplexing Technique to Drive a Large Number of LEDs with a Low Number of Pins, Using 16-bit Timer/Counter Type B (TCB) and Priority Interrupt
- Demonstrating Core Independent Watchdog Timer (WDT) in Window mode
- Demonstrating Real-Time Counter Periodic Interrupt (RTC) (PIT)
- Board Controller with (PTC) Touch Slider to Adjust the Voltage to ATtiny3217, Demonstrating Voltage Level Monitor (VLM) Interrupt, Brown-out Detector (BOD) and Power-on Reset (POR)
- On-board Mini Embedded Debugger (mEDBG) for Programming and Debugging.

Table of Contents

Introduction1			
Fea	atures	S	2
1.	Over 1.1.	rview Block Diagram	4
2.	1.2. Desi	gn Documents and Related Links	6
3.	Quic	k Start	7
4.	Hard 4.1. 4.2. 4.3.	Iware Blocks Target MCU Peripherals Board Controller Peripherals Mini Embedded Debugger Implementation	8 8 11 16
5.	Revi	sion History	19
The	e Micı	rochip Web Site	20
Cu	stome	er Change Notification Service	20
Cu	stome	er Support	20
Microchip Devices Code Protection Feature			
Legal Notice			
Trademarks			
Quality Management System Certified by DNV22			
Wo	Worldwide Sales and Service23		

1. Overview

1.1 Block Diagram

There are three MCUs on this board:

- Target MCU ATtiny3217:
 - The main MCU that demonstrates the safety and reliability functions.
- Board controller ATtiny1617:
 - It simulates external conditions to trigger the target MCU safety and reliability functions.
- Mini Embedded Debugger:
 - On-board debugger and programmer for target MCU and board controller.

Depending on different safety and reliability functions, the hardware design can be divided into the following function blocks:

- Reset Register and Class B status
- Operation Voltage
- Window Watchdog Timer
- Cyclic Redundancy Check
- Fault Detection Using Event System

These function blocks are clearly noted on the top side of the AVR Functional Safety board. Refer to Figure 1-2 for more details.

The block diagram of the AVR Functional Safety board can be seen below.

Figure 1-1. AVR[®] Functional Safety Board Block Diagram



1.2 Board Overview

Here is a brief overview of the AVR Functional Safety board.



Figure 1-2. AVR[®] Functional Safety Board Overview - Top Side

Figure 1-3. AVR[®] Functional Safety Board Overview - Bottom Side



2. Design Documents and Related Links

The design documents and relevant links are available here:

- AVR Functional Safety website: Board information, the latest documents and design files.
- microchipDIRECT: Where to buy this board online.
- ATtiny3217 website: Target MCU information, documentation and development tools, etc.
- ATtiny1617 website: Board controller MCU information, documentation and development tools, etc.

3. Quick Start

The AVR Functional Safety boardis powered by a 5.0V USB voltage. The on-board programming and debugging function relies on the same USB connection. Refer to Mini Embedded Debugger Implementation for more information about programming and debugging.

Steps to start exploring the AVR Functional Safety board:

- 1. Download and install Atmel Studio.
- 2. Launch Atmel Studio.
- 3. Connect a USB cable (Standard-A to Micro-B or Micro-AB) between the PC and the USB port on the board.

When the AVR Functional Safety board is connected to the computer for the first time, the operating system will perform a driver software installation. The drivers for the board are included with Atmel Studio. Once the driver is successfully installed and the board is correctly powered, it will be automatically detected and recognized as a mEDBG tool by Atmel Studio.

Before using the board with default firmware, calibrating the board first is recommended. The calibration steps are listed on the backside of the board as shown in Figure 1-3.

4. Hardware Blocks

In this chapter, the hardware designs are described in detail. There are three MCUs on this board and different hardware peripherals are built around them, so this chapter is further divided into three sections according to the MCU and peripheral connections.

4.1 Target MCU Peripherals

ATtiny3217 is the target MCU on the AVR Functional Safetyboard. All the safety and reliability functions demonstrated on this board are from ATtiny3217 MCU. The hardware peripherals around the target MCU are designed for the user to trigger different abnormal conditions, so that the reaction of each safety and reliability module can be easily observed.

4.1.1 Charlieplexed LEDs

On this board, there are 19 LEDs Charlieplexed and driven by only five I/O pins. On this board, PC0, PC1, PC2, PC3 and PC4 are used to drive these LEDs. Compared with traditional LED connection method, Charlieplexing saves a lot of I/O pins. In theory, five I/O pins can drive up to 20 LEDs. More details about Charlieplexing can be found here: https://en.wikipedia.org/wiki/Charlieplexing.

Below are the names of 19 LEDs and their functions.

LED Description	LED Name	LED Function
LED1	D2	Power-on Reset
LED2	D3	Brown-out Reset
LED3	D5	External Reset
LED4	D6	Watchdog Reset
LED5	D9	Software Reset
LED6	D10	UPDI Reset
LED7	D15	Watchdog Timer Indicator
LED8	D16	Watchdog Timer Indicator
LED9	D7	Watchdog Timer Indicator
LED10	D8	Watchdog Timer Indicator
LED11	D14	Watchdog Timer Indicator
LED12	D11	Watchdog Timer Indicator
LED13	D20	Watchdog Timer Indicator
LED14	D17	Watchdog Timer Indicator
LED15	D12	Watchdog Timer Cleared
LED16	D13	CRCSCAN Error
LED17	D18	TCD Fault Detected

Table 4-1. Charlieplexed LEDs

LED Description	LED Name	LED Function
LED18	D19	Class B Fail
LED19	D21	Class B OK

The schematic of Charlieplexed LEDs is shown below.

Figure 4-1. LED Charlieplexing



4.1.2 Heartbeat LED

There is an LED on this board simulating a heartbeat pattern. It is connected to the Configurable Custom Logical (CCL) output pin, so that the heartbeat pattern is easily generated with the timer/counter and the CCL without the intervention of the CPU. This LED is ON when the connected I/O pin output is low.

Table 4-2. Heartbeat LED

ATtiny3217 Pin	Pin Function	Comment
PB4	Heartbeat LED D4	LUT0-OUT on alternative pin

Figure 4-2. Heartbeat LED



4.1.3 Buttons

There are three mechanical buttons on this board. They are used to trigger different target MCU actions. Their functions are listed below.

Table 4-3. Buttons

ATtiny3217 Pin	Pin Function	Button Function
PB5	SW1	Clear Watchdog (WDT)
PB6	SW2	Start/Stop Fan
PB7	SW3	Modify Flash Memory Bit

The buttons are implemented to be low active. When a button is pressed, a low level can be detected on the connected I/O pin.

Their connection is shown below.

Figure 4-3. Buttons



4.1.4 Fan

A small DC fan is attached on this board. It is driven by a MOSFET via an I/O pin control. The fan motor current is amplified by an op amp MCP6002 and fed back to the ATtiny3217 Analog Comparator (AC) input. If the current is above safety value (For example, the fan motor is forced to stop by putting a finger on it) then the fan control signal will be stopped immediately thanks to a Timer/Counter Type D (TCD)

fault control function. According to different input modes, fault detection puts TCD outputs into a predefined state without CPU intervention.

Please see below the table with details on the fan control pin and on the current detection pin connection. **Table 4-4. FAN Control**

ATtiny3217 Pin	Pin Function	Comment
PA4	Fan MOSFET control	WOA of TCD0
PA7	Fan current detect	AC0 positive input

Below is the fan control schematic.

Figure 4-4. Fan



4.2 Board Controller Peripherals

The purpose of the board controller is to simulate different external conditions to trigger different safety and reliability functions of the target MCU. There are several hardware blocks built around the board controller to make this easier. On this board, an ATtiny1617 is used as the board controller.

4.2.1 Variable Target Voltage

A simple variable voltage circuit is designed to generate the target MCU V_{CC}. Ideally, it varies between 0~5V if the MOSFET on-resistance is considered as 0 Ω . The board controller, ATtiny1617, controls the ON/OFF and output level of this variable voltage. The pin functions are listed below.

Table 4-5. Variable Target Voltage

ATtiny1617 Pin	Pin Function	Comment
PA6	Controls variable voltage level	DAC output
PA7	Controls ON/OFF of voltage	I/O output

The controlled variable voltage circuit is shown below.

Figure 4-5. Variable Target Voltage



4.2.2 Touch Slider

A touch slider is implemented on this board for an easy user input. It is based on the Peripheral Touch Controller (PTC) module in ATtiny1617. On this board, the touch slider is implemented with four selfcapacitance sensors (Y-line). For further information about PTC touch usage, refer to QTouch[®] Modular Library User's Guide and Glossary of Touch Terms. In default firmware, this slider is used to control the output voltage of Variable Target Voltage.

The connection of touch slider is shown below.

Table 4-6. Touch Slider

ATtiny1617 Pin	Pin Function	Comment
PC0	Touch slider sensor 1	PTC Y6
PC1	Touch slider sensor 2	PTC Y7
PC2	Touch slider sensor 3	PTC Y8
PC3	Touch slider sensor 4	PTC Y9

Figure 4-6. Touch Slider



Figure 4-7. Touch Slider PCB Layout Pattern



4.2.3 Status LED

Four LEDs are controlled by a board controller to indicate the target MCU voltage described in Variable Target Voltage. There are four segments of the target MCU voltage. These LEDs are designed to be low active.

Table 4-7. Status LED

ATtiny1617 Pin	Pin Functions	Target MCU Voltage
PB2	D22	Normal voltage
PB3	D23	15% above BOD level

ATtiny1617 Pin	Pin Functions	Target MCU Voltage
PB4	D24	Below BOD level
PB5	D25	Below POR level

The schematic is shown below. Figure 4-8. Status LED



4.2.4 Level Shifter

As the voltage of the target MCU is controlled by the board controller, the voltage between them can be different. Level shifters are used to make sure that the MCUs can talk to each other when they operate under different voltages. The UPDI pin and mEDBG UART pins are also connected via level shifter, thus the target MCU can be programmed and debugged under any working voltage. The following pins are connected via level shifters.

Refer to the table below for more details.

Table 4-8. Pin Connections via Level Shifter

ATtiny1617 Pin	ATtiny3217 Pin	mEDBG Pin	Pin Function
PB0	PB0		I ² C SCL
PB1	PB1		I ² C SDA
PB6	PA6		Target BOD indicator
PB7	PA2		Target VLM indicator
	PB2	PD2	UART Tx
	PB3	PD3	UART Rx
	PA0	PE6	mEDBG UPDI





4.2.5 Reserved Interfaces

The SPI and I²C pins are also reserved on two unmounted headers. The user can use them conveniently if such functions are necessary.

Table 4-9. Reserved Interfaces

ATtiny1617 Pin	Pin Function	Comment
PA1	SPI MOSI	Board controller SPI interface
PA2	SPI MISO	

Hardware Blocks

ATtiny1617 Pin	Pin Function	Comment	
PA3	SPI SCK		
PA4	SPI SS		
PB0	I ² C SCL	Board controller I ² C interface	
PB1	I ² C SDA		

Figure 4-10. Reserved Interface



4.3 Mini Embedded Debugger Implementation

On the AVR Functional Safety board, the Mini Embedded Debugger (mEDBG) is used as an easy way to program and debug the target MCU. It features a virtual COM port for serial communication to a host PC. Atmel Studio can be used as a front end for the mEDBG.

4.3.1 Mini Embedded Debugger

The AVR Functional Safety board contains the Mini Embedded Debugger (mEDBG) for on-board programming. The mEDBG is a composite USB device of two interfaces: a debugger and a virtual COM port.

Together with Atmel Studio, the mEDBG debugger interface can program the ATtiny3217. On AVR Functional Safety board, the UPDI interface is connected between the mEDBG and the ATtiny3217.

The virtual COM port is connected to a UART on the ATtiny3217 and provides an easy way to communicate with the target application through the terminal software. It offers variable baud rate, parity, and Stop bit settings.

Note: The settings on the ATtiny3217 must match the settings given in the terminal software.



Info: The virtual COM port in the mEDBG requires the terminal software to set the Data Terminal Ready (DTR) signal to enable the UART pins connected to the ATtiny3217. If the DTR signal is not enabled, the UART pins on the mEDBG are kept in high-z (tri-state) rendering the COM port unusable. The DTR signal is automatically set by some terminal software, but it may have to be manually enabled in the target terminal.

The mEDBG controls one status LED on the AVR Functional Safety board. The table below shows how the LED is controlled in different operation modes.

Table 4-10. mEDBG LED Control

Operation mode	Status LED
Power-up	LED is briefly lit
Normal operation	LED is not lit
Programming	Activity indicator; the LED flashes when programming/debugging with the mEDBG

4.3.2 UPDI Interface

The Unified Program and Debug Interface (UPDI) uses one pin to communicate with the target. The actual connection of UPDI line between mEDBG and MCU is decided by UPDI Selection.

Table 4-11. UPDI Interface

ATtiny3217	ATtiny1617	Function
PA0 (default connection)	PA0	UPDI/RESET

4.3.2.1 UPDI Selection

On this board, both the target MCU ATtiny3217 and the board controller ATtiny1617 use the same programming and debugging interface (UPDI). It is supported by the on-board program and debug chip mEDBG. An UPDI selection circuit is used to switch the UPDI lines between these two MCUs. By default, the mEDBG UPDI interface is connected to ATtiny3217. To program and debug ATtiny1617, the hardware has to be modified by the user.

Table 4-12. UPDI selection

UPDI Line Target	Hardware Connection	Comment
ATtiny3217	TP29 and TP30 open circuit	Default
ATtiny1617	TP29 and TP30 short circuit	Modified by user

Figure 4-11. UPDI Selection



4.3.3 Virtual COM Port

The Mini Embedded Debugger (mEDBG) acts as a virtual COM port gateway by using the ATtiny3217 UART pins. As the target MCU may work at different voltage with mEDBG, the pins are connected via a Level Shifter.

Table 4-13. Virtual COM Port

ATtiny3217 Pin	Pin Function	mEDBG Pin Function
PB2	UART Tx	mEDBG CDC Rx
PB3	UART Rx	mEDBG CDC Tx

5. Revision History

Doc Rev.	Date	Comments
DS40002013A	2/2018	Initial document release.

The Microchip Web Site

Microchip provides online support via our web site at http://www.microchip.com/. This web site is used as a means to make files and information easily available to customers. Accessible by using your favorite Internet browser, the web site contains the following information:

- Product Support Data sheets and errata, application notes and sample programs, design resources, user's guides and hardware support documents, latest software releases and archived software
- **General Technical Support** Frequently Asked Questions (FAQ), technical support requests, online discussion groups, Microchip consultant program member listing
- Business of Microchip Product selector and ordering guides, latest Microchip press releases, listing of seminars and events, listings of Microchip sales offices, distributors and factory representatives

Customer Change Notification Service

Microchip's customer notification service helps keep customers current on Microchip products. Subscribers will receive e-mail notification whenever there are changes, updates, revisions or errata related to a specified product family or development tool of interest.

To register, access the Microchip web site at http://www.microchip.com/. Under "Support", click on "Customer Change Notification" and follow the registration instructions.

Customer Support

Users of Microchip products can receive assistance through several channels:

- Distributor or Representative
- Local Sales Office
- Field Application Engineer (FAE)
- Technical Support

Customers should contact their distributor, representative or Field Application Engineer (FAE) for support. Local sales offices are also available to help customers. A listing of sales offices and locations is included in the back of this document.

Technical support is available through the web site at: http://www.microchip.com/support

Microchip Devices Code Protection Feature

Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.

• Neither Microchip nor any other semiconductor manufacturer can assure the security of their code. Code protection does not mean that we are assuring the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Legal Notice

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

Trademarks

The Microchip name and logo, the Microchip logo, AnyRate, AVR, AVR logo, AVR Freaks, BeaconThings, BitCloud, CryptoMemory, CryptoRF, dsPIC, FlashFlex, flexPWR, Heldo, JukeBlox, KeeLoq, KeeLoq logo, Kleer, LANCheck, LINK MD, maXStylus, maXTouch, MediaLB, megaAVR, MOST, MOST logo, MPLAB, OptoLyzer, PIC, picoPower, PICSTART, PIC32 logo, Prochip Designer, QTouch, RightTouch, SAM-BA, SpyNIC, SST, SST Logo, SuperFlash, tinyAVR, UNI/O, and XMEGA are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

ClockWorks, The Embedded Control Solutions Company, EtherSynch, Hyper Speed Control, HyperLight Load, IntelliMOS, mTouch, Precision Edge, and Quiet-Wire are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Adjacent Key Suppression, AKS, Analog-for-the-Digital Age, Any Capacitor, AnyIn, AnyOut, BodyCom, chipKIT, chipKIT logo, CodeGuard, CryptoAuthentication, CryptoCompanion, CryptoController, dsPICDEM, dsPICDEM.net, Dynamic Average Matching, DAM, ECAN, EtherGREEN, In-Circuit Serial Programming, ICSP, Inter-Chip Connectivity, JitterBlocker, KleerNet, KleerNet logo, Mindi, MiWi, motorBench, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, MultiTRAK, NetDetach, Omniscient Code Generation, PICDEM, PICDEM.net, PICKit, PICtail, PureSilicon, QMatrix, RightTouch logo, REAL ICE, Ripple Blocker, SAM-ICE, Serial Quad I/O, SMART-I.S., SQI, SuperSwitcher, SuperSwitcher II, Total Endurance, TSHARC, USBCheck, VariSense, ViewSpan, WiperLock, Wireless DNA, and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

Silicon Storage Technology is a registered trademark of Microchip Technology Inc. in other countries.

GestIC is a registered trademark of Microchip Technology Germany II GmbH & Co. KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.

© 2018, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

ISBN: 978-1-5224-2734-6

Quality Management System Certified by DNV

ISO/TS 16949

Microchip received ISO/TS-16949:2009 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC[®] MCUs and dsPIC[®] DSCs, KEELOQ[®] code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.



Worldwide Sales and Service

AMERICAS	ASIA/PACIFIC	ASIA/PACIFIC	EUROPE
Corporate Office	Australia - Sydney	India - Bangalore	Austria - Wels
2355 West Chandler Blvd.	Tel: 61-2-9868-6733	Tel: 91-80-3090-4444	Tel: 43-7242-2244-39
Chandler, AZ 85224-6199	China - Beijing	India - New Delhi	Fax: 43-7242-2244-393
Tel: 480-792-7200	Tel: 86-10-8569-7000	Tel: 91-11-4160-8631	Denmark - Copenhagen
Fax: 480-792-7277	China - Chengdu	India - Pune	Tel: 45-4450-2828
Technical Support:	Tel: 86-28-8665-5511	Tel: 91-20-4121-0141	Fax: 45-4485-2829
http://www.microchip.com/	China - Chongqing	Japan - Osaka	Finland - Espoo
support	Tel: 86-23-8980-9588	Tel: 81-6-6152-7160	Tel: 358-9-4520-820
Web Address:	China - Dongguan	Japan - Tokyo	France - Paris
www.microchip.com	Tel: 86-769-8702-9880	Tel: 81-3-6880- 3770	Tel: 33-1-69-53-63-20
Atlanta	China - Guangzhou	Korea - Daegu	Fax: 33-1-69-30-90-79
Duluth, GA	Tel: 86-20-8755-8029	Tel: 82-53-744-4301	Germany - Garching
Tel: 678-957-9614	China - Hangzhou	Korea - Seoul	Tel: 49-8931-9700
Fax: 678-957-1455	Tel: 86-571-8792-8115	Tel: 82-2-554-7200	Germany - Haan
Austin, TX	China - Hong Kong SAR	Malaysia - Kuala Lumpur	Tel: 49-2129-3766400
Tel: 512-257-3370	Tel: 852-2943-5100	Tel: 60-3-7651-7906	Germany - Heilbronn
Boston	China - Nanjing	Malaysia - Penang	Tel: 49-7131-67-3636
Westborough, MA	Tel: 86-25-8473-2460	Tel: 60-4-227-8870	Germany - Karlsruhe
Tel: 774-760-0087	China - Qingdao	Philippines - Manila	Tel: 49-721-625370
Fax: 774-760-0088	Tel: 86-532-8502-7355	Tel: 63-2-634-9065	Germany - Munich
Chicago	China - Shanghai	Singapore	Tel: 49-89-627-144-0
Itasca, IL	Tel: 86-21-3326-8000	Tel: 65-6334-8870	Fax: 49-89-627-144-44
Tel: 630-285-0071	China - Shenyang	Taiwan - Hsin Chu	Germany - Rosenheim
Fax: 630-285-0075	Tel: 86-24-2334-2829	Tel: 886-3-577-8366	Tel: 49-8031-354-560
Dallas	China - Shenzhen	Taiwan - Kaohsiung	Israel - Ra'anana
Addison, TX	Tel: 86-755-8864-2200	Tel: 886-7-213-7830	Tel: 972-9-744-7705
Tel: 972-818-7423	China - Suzhou	Taiwan - Taipei	Italy - Milan
Fax: 972-818-2924	China - Wuhan	Tel: 886-2-2508-8600	Tel: 39-0331-742611
Detroit	Tel: 86-27-5980-5300	Thailand - Bangkok	Fax: 39-0331-466781
Novi, MI	China - Xian	Tel: 66-2-694-1351	Italy - Padova
Tel: 248-848-4000	Tel: 86-29-8833-7252	Vietnam - Ho Chi Minh	Tel: 39-049-7625286
Houston, TX	China - Xiamen	101. 01 20 0110 2100	Netherlands - Drunen
Tel: 281-894-5983	Tel: 86-592-2388138		Tel: 31-416-690399
Indianapolis	China - Zhubai		Fax: 31-416-690340
Noblesville, IN	Tel: 86-756-3210040		Norway - Trondheim
Tel: 317-773-8323			Tel: 47-7289-7561
Fax: 317-773-5453			Poland - Warsaw
Tel: 317-536-2380			1el: 48-22-3325737
Los Angeles			Romania - Bucharest
Mission Viejo, CA			Tel: 40-21-407-87-50
Tel: 949-462-9523			Spain - Madrid
Fax: 949-462-9608			Tel: 34-91-708-08-90
Tel: 951-273-7800			Fax: 34-91-708-08-91
Raleigh, NC			Sweden - Gothenberg
iei: 919-844-7510			1el: 46-31-704-60-40
NEW YORK, NY			Sweden - Stockholm
			1el: 46-8-5090-4654
San Jose, CA			
Iel: 408-735-9110			Iel: 44-118-921-5800
Iel: 408-436-4270			rax: 44-118-921-5820
Iel: 905-695-1980			

Fax: 905-695-2078

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Microchip: ATAVRFEB-SAFETY