

EVKT-USBSPI-00

USB to SPI

Communication Interface Device

DESCRIPTION

The EVKT-USBSPI-00 is a USB to SPI communication interface device. It is designed to work with MPS's SPI products and SPI GUI tools. The EVKT-USBSPI-00 kit includes one USB to SPI communication device interface.

one USB cable, one 10-pin ribbon cable, one 5-pin ribbon cable, one datasheet, and driver files. Together with MPS's SPI GUI tool, it provides a quick and easy way to evaluate the performance of MPS digital products.

EVKT-USBSPI-00





EVKT-USBSPI-00 CONNECTION





RIBBON CABLE DESCRIPTION

The EVKT-USBSPI-00 supports two kinds of ribbon cable connections between communication interface device and the evaluation board: a 5-pin ribbon cable and a 10pin ribbon cable. Figure 1 shows the bottom view of the 10-pin ribbon cable, and Table 1 shows the pin descriptions.




Figure 1: 10-Pin Ribbon Cable Bottom View

Table 1: 10-Pin Ribbon Cable Pins

Pin #	Description	Pin#	Description
1	SCL	2	GND
3	GND	4	SDI
5	SDA	6	SDO
7	GND	8	SCK
9	NC	10	NCS

© 2023 MPS. All Rights Reserved.





QUICK START GUIDE

- 1. Connect the EVKT-USBSPI-00 to the evaluation board with the 5-pin ribbon cable or the 10-pin ribbon cable. (1)
- 2. Connect the EVKT-USBSPI-00 to the computer with the USB cable. (1)
- 3. Turn on the power supply for the evaluation board.
- 4. Start the SPI GUI software; it should check the connection automatically.

Note:

1) The sequence of steps 1 and 2 must be followed. Otherwise, the communication pins may be damaged during a hot-plug event.





REVISION HISTORY

Revision #	Revision Date	Description	Pages Updated
1.0	6/19/2023	Initial Release	-

Notice: The information in this document is subject to change without notice. Please contact MPS for current specifications. Users should warrant and guarantee that third-party Intellectual Property rights are not infringed upon when integrating MPS products into any application. MPS will not assume any legal responsibility for any said applications.

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Monolithic Power Systems (MPS):

EVKT-USBSPI-00