

TERMINALS APPLIED[illegible]

- △ THIS APPLICATOR HAS BEEN DESIGNED TO APPLY FLRY
TYPE INSULATION. INSULATION RANGE SHOWN IS THAT
OF THE APPLICATOR.

VIEW B ROTATED 180°


AMP 4805 Rev 31MAR2005

Diagram illustrating the terminal support location. The diagram shows a cross-section of a terminal with two support points labeled 8 REF and 34 REF. The distance between the support points is dimensioned as 5.08 ± 0.5 [$.200 \pm .020$]. The text "TERMINAL SUPPORT LOCATION" is centered below the diagram.

[illegible][illegible][illegible]

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[TE Connectivity:](#)

[1528905-2](#)