



# IQS572EV02 Arduino Shield Module Datasheet

Trackpad Arduino Shield PCB using IQS572

## **1** Overview

The IQS572-B000 is a trackpad solution including on-chip gesture recognition, flexible device setup and leading sensitivity management and adjustment. The IQS572EV02 uses an 8x8

diamond sensor pattern to detect user proximity and touch, identify finger position co-ordinates, and generate gesture outputs based on the finger interaction. With effective on-chip sensor co-ordinate filtering, and advanced processing algorithms, the IQS572 provides reliable and stable operational outputs.

The sensor reports these outputs via standard I<sup>2</sup>C protocol to the master (in this case the Arduino), and is also fully configurable and programmable via this interface.

The IQS572-B000 is a standard IQS5xx-B000 product, and thus the complete IQS5xx-B000 product datasheet can be referenced for all IQS572-B000 trackpad information:

http://www.azoteq.com/images/stories/pdf/iqs5xxb000\_trackpad\_datasheet.pdf

## **2 Device Configuration**



Figure 1.1 IQS572EV02 Shield Board

The IQS572EV02 is programmed with the standard B000 trackpad firmware, with the setup parameters pre-configured for this PCB. Some of the important parameter configurations are shown in the table below.

Since this is just an example configuration, all normal IQS572-B000 setup flexibility exists, and the configuration can be modified as required by the user.

Settings parameter	Value	Settings parameter	Value
Total Rx	8	Total Tx	8
Rx mapping	{2, 1, 3, 5, 4, 8, 6, 7,}	Tx mapping	{0, 1, 2, 3, 4, 5, 6, 7,}
ALP channel	Enabled	-	-
ALP Rxs	0x00 0xFF	ALP Txs	0x00 0x55
Prox theshold (TP)	23	Prox threshold (ALP)	8
Touch threshold – set	28	Touch threshold – clear	22
ATI Target (TP)	800	ATI Target (ALP)	500

#### Table 2.1 IQS572EV02 Parameter / Setup Summary



### IQ Switch<sup>®</sup> ProxSense<sup>®</sup> Series



ATI C (TP)	2	ATI C (ALP)	18
Active Mode report rate	13	Idle Touch report rate	50
Idle Mode report rate	75	LP1 report rate	60
LP2 report rate	120	-	-
Active Mode timeout	5	Idle Touch timeout	60
Idle Mode timeout	45	LP1 timeout	30
Total multi-touches	5	X & Y resolution	1024

To obtain the full device configuration, simply connect the trackpad module to a CT210 (or DS100), and run it with the IQS5xx-B000 PC GUI software. At start up all GUI parameters are updated to match the on-chip values, and can therefore easily be read in the GUI.

## 3 Connecting to PC

Although the module is designed to be used as a plug-in shield PCB for the Arduino Uno, it can also be connected to the Azoteq PC software for evaluation, visualisation, configuration and programming.

### 3.1 Hardware connections

To connect the IQS572EV02 to the PC, the following needs to be linked between the CT210/DS100 and the module.

Function	CT210 Pin	IQS572EV02 (AZP691A01) Pin
GND	Pin 1	P1 Pin 6 or 7 or P4 Pin 4
VDDHI	Pin 3	P1 Pin 4
SDA	Pin 7	P4 Pin 2
SCL	Pin 9	P4 Pin 1
RDY	Pin 10	P3 Pin 6

#### Table 3.1 Hardware connections to CT210/DS100







### Figure 3.1 CT210 I<sup>2</sup>C connections

## 3.2 Evaluation in GUI

The features of the IQS572-B000 product can be evaluated and visualised using the following PC GUI software:

http://www.azoteq.com/images/stories/software/azoteq\_iqs5xxb000\_setup.zip

This allows the designer to see the full power and information available from the IQS572 trackpad product. For more information on the GUI itself, including the device setup procedure, please see the following application note:





Figure 3.2 2D preset display examples



Figure 3.3 3D preset display examples

### 3.3 Programming

The IQS5xx-B000 GUI enables a user to modify the configuration of a trackpad and to subsequently program the device with a new hex file containing the new settings.

This is explained further in the AZD087 application note.

## 4 Connecting to Arduino

The main purpose of the module is to be used together with an Arduino Uno mainboard, providing a trackpad input shield module for the popular development environment.

### 4.1 Hardware connections

Simply plug the module into the aligning sockets on the Arduino mainboard.









### 4.2 Arduino source code

An example project is provided to allow for fast integration into the Arduino environment. The example source code communicates with the IQS572EV02 module, handles the I<sup>2</sup>C interaction with the device, and then displays relevant output data on the serial monitor.

The source code for the IQS572EV02 module can be obtained here:

http://www.azoteq.com/images/stories/software/igs572ev02\_arduino\_shield\_v1.0.zip

### 4.3 User guide

The project must be compiled ( ), and the serial COM port must be configured.

3 IQS5xx_Example	e_Code   Arduino 1.6.6		
File Edit Sketch	Tools Help		
IQS5xx_Examp	Auto Format Archive Sketch Fix Encoding & Reload	Ctrl+T	:S5xx.h defs.h
	Serial Monitor	Ctrl+Shift+M	
	Serial Plotter	Ctrl+Shift+L	
/*********	Board: "Arduino/Genuino Un	10" >	****
	Port: "COM6"	;	Serial ports
	Programmer: "AVR ISP"	;	COM1
	Burn Bootloader		COM6
	MMMMM, MMMMM MMMM MMMM MMMMO MMMMM8 =MMMMMM MMMMMMA	MMMMD MMMMM MMMMM MMMMM MMMMM DMMMMM DMMMMM 7MMMMMM MMMMM MMMMM MMMMMM MMMMMM	-       - <t< td=""></t<>

After this the program must be uploaded (), and once this is successful, the serial monitor can be opened (Tools->Serial Monitor) to view the data from the IQS572.

With a successful setup, shortly after opening the serial monitor window, you will see the version number details displayed as follows:

	© COM6
*	
	Product 58 Project 15 Version 1.1





Now when interacting with the trackpad you will see finger position data and gesture outputs displayed on the window, here is an example of such data:

COM6																							
Product 58	Project	15 V	ers	ion 1	.1																		
Gestures:	RelX:	RelY:	Fi	g: X1	: Y:	L: TS1:	TA	1: X2	: Y2:	TS2:	TA	2: X3	: Y3:	TS3:	ТА	3: X4	: Y4:	TS4:	TA	4: X5	: Y5:	TS5:	TA5:
	0	0	1	158	593	728	0	XXX	XXX	0	0												
	0	0	1	157	591	768	1	XXX	XXX	0	0												
	0	0	1	164	583	832	2	XXX	XXX	0	0												
	0	0	1	194	568	900	2	XXX	XXX	0	0												
	0	0	1	272	549	971	3	XXX	XXX	0	0												
	82	-15	1	354	534	1038	3	XXX	XXX	0	0												
	107	-5	1	461	529	1095	3	XXX	XXX	0	0												
	155	3	1	616	532	1131	3	XXX	XXX	0	0												
Swipe X+	149	0	1	765	551	1124	2	XXX	XXX	0	0												
Gestures:	RelX:	RelY:	Fi	g: X1	: Y:	l: TS1:	TA	1: X2	: Y2:	TS2:	TA	2: X3	: Y3:	TS3:	TA	3: X4	: Y4:	TS4:	TA	4: X5	: Y5:	TS5:	TA5:
	0	0	1	765	596	1463	0	XXX	XXX	0	0												
	0	0	1	752	590	1480	1	XXX	XXX	0	0												
	0	0	1	703	584	1494	1	XXX	XXX	0	0												
	0	0	1	602	584	1514	1	XXX	XXX	0	0												
	-106	16	1	496	600	1552	2	XXX	XXX	0	0												
	-105	27	1	391	627	1572	2	XXX	XXX	0	0												
Swipe X-	-126	0	1	265	653	1573	3	XXX	XXX	0	0												
Gestures:	RelX:	RelY:	Fi	g: X1	: Y:	l: TS1:	TA	1: X2	: Y2:	TS2:	TA	2: X3	: Y3:	TS3:	TA	3: X4	: Y4:	TS4:	TA	4: X5	: Y5:	TS5:	TA5:
	0	0	1	278	605	2626	0	XXX	XXX	0	0												
	0	0	1	278	605	2633	2	XXX	XXX	0	0												
	0	0	1	278	605	2642	3	XXX	XXX	0	0												
	0	0	1	277	609	2633	3	XXX	XXX	0	0												
	0	0	1	272	622	2592	3	XXX	XXX	0	0												
Single Tap																							

## **5** Electrical characteristics

For all general electrical characteristics, please refer to the IQS5xx-B000 datasheet.

### 5.1 Current consumption

With the parameters configured for the specific module, some expected current consumption values can be provided. Please note these are bench measured values, and can vary depending on numerous factors. For example in Active mode (during a user touch), the current varies according to the size of the touch due to change in the amount of processing required. The following are simply to provide an estimate of what can be expected.

User Interaction	Mode	I <sup>2</sup> C bytes read	Report Rate	Current	Unit
1 standard 8mm finger	Active Mode	16 bytes	13ms	1.86	mA
2 standard 8mm fingers	Active Mode	16 bytes	13ms	2.26	mA
None	Idle Mode	None	75ms	227	uA
None	LP1	None	60ms	58	uA
None	LP2	None	120ms	30	uA
None	Suspend	None	n/a	<1	uA

### Table 5.1Total Current Consumption





## **6** Contact Information

	USA	Asia	South Africa
Physical Address	6507 Jester Blvd Bldg 5, suite 510G Austin TX 78750 USA	Rm2125, Glittery City Shennan Rd Futian District Shenzhen, 518033 China	109 Main Street Paarl 7646 South Africa
Postal Address	6507 Jester Blvd Bldg 5, suite 510G Austin TX 78750 USA	Rm2125, Glittery City Shennan Rd Futian District Shenzhen, 518033 China	PO Box 3534 Paarl 7620 South Africa
Tel	+1 512 538 1995	+86 755 8303 5294	+27 21 863 0033
Fax	+1 512 672 8442		+27 21 863 1512
Email	info@azoteq.com	info@azoteq.com	info@azoteq.com

Please visit **www.azoteq.com** for a list of distributors and worldwide representation.

The following patents relate to the device or usage of the device: US 6,249,089; US 6,952,084; US 6,984,900; US 7,084,526; US 7,084,531; US 8,395,395; US 8,531,120; US 8,659,306; US 8,823,273; US 9,209,803; US 9,360,510; EP 2,351,220; EP 2,559,164; EP 2,656,189; HK 1,156,120; HK 1,157,080; SA 2001/2151; SA 2006/05363; SA 2014/01541; SA 2015/023634

IQ Switch<sup>®</sup>, SwipeSwitch<sup>™</sup>, ProxSense<sup>®</sup>, LightSense<sup>™</sup>, AirButton<sup>™</sup>, ProxFusion<sup>™</sup>, Crystal Driver<sup>™</sup> and the Uogo are trademarks of Azoteg.

The information in this Datasheet is believed to be accurate at the time of publication. Azoteq uses reasonable effort to maintain the information up-to-date and accurate, but does not warrant the accuracy, completeness or reliability of the information contained herein. All content and information are provided on an "as is" basis only, without any representations or warranties, express or implied, of any kind, including representations about the suitability of these products or information for any purpose. Values in the datasheet is subject to change without notice, please ensure to always use the latest version of this document. Application specific operating conditions should be taken into account during design and verified before mass products and information, including but not limited to all implied warranties and conditions of merchantability, fitness for a particular purpose, title and non-infringement of any third party intellectual property rights. Azoteq assumes no liability for any damages or injury arising from any use of the information or the product or caused by, without limitation, failure of performance, error, omission, interruption, defect, delay in operation or transmission, even if Azoteq has been advised of the possibility of such damages. The applications mentioned herein are used solely for the purpose of illustration and Azoteq makes no warranty or representation that such applications will be suitable without further modification, nor recommends the use of its products for application that may present a risk to human life due to malfunction or otherwise. Azoteq products are not authorized for use as critical components in life support devices or systems. No licenses to patents are granted, implicitly, express or implied, by estoppel or otherwise, under any intellectual property rights. In the event that any of the abovementioned limitations or exclusions does not apply, it is agreed that Azoteq's total liability for all losses, damages and causes of action (in contract, tort (including

#### www.azoteq.com/ip

info@azoteq.com

## **Mouser Electronics**

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Azoteq: IQS572EV02