



**TOOL FOR REMOVING  
BMA FLOATING PLUG****R282.918.000**Series : **TOOLING****INSTRUCTION FOR USING :**

1. Insert the tool into the connector
2. Make sure that the front side of the tool is flush inserted in the connector
3. Maintain with pressure in F direction the tool handle by the body and push by the ball side into the panel
4. The connector is disengage

**Issue : 1135 B**

In the effort to improve our products, we reserve the right to make changes judged to be necessary.

**RADIAL**®

# Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Radial:

R282918000