



Solar Man Robot

Components list
is on PAGE 2.


1




Assemble right arm




Assemble left arm




2



Please note to verify
front and back, the holes
in red rectangle are
for this assembling step.




Install left leg




Install right leg


3



Firstly as picture shown,
assemble the top of leg to
the shaft of back cover.




Then fix motor and
both legs.




Follow the picture, get
the motor wire through
out of the hole

4



As picture shown, install
the right arm to the motor
shaft.




Install the left arm the
same as right arm.


5




Install the front cover.




Fix the front and back covers with screws.




Assemble the front and back covers of head.





Install the solar board.



1. put the heat shrink on the motor wires.
2. connect the motor wires to the solar board.
3. Make the the heat shrink on the connecting part for avoiding circuit short.




Install the solar part as picture shown.



Assembling finished



Components diagram



Components list:

Front cover*1, Back cover*1, Left leg*1, Right leg*1, Left arm*1, Right arm*1, Left shoulder lever*1, Right shoulder lever*1, Front cover of head (black)*1, Back cover of head*1, Solar board*1, Solar board holder*1, Motor*1, Heat shrink*2, Screw*2 (M2.2*6), Screwdriver*1.

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Seeed Studio:](#)

[110990100](#)