

# Quick Start Guide Lighting Development Kit





# **Table of Contents**

1.	Intended Use	3
2.	Cautions and Warnings	3
3.	Abbreviation	4
4.	Short Description of the Kit Contents	5
	Power Board 1780050	
	RGBW Panel and Lens	7
	Horticulture Panel and Lens	8
	Heat Sink	9
	Mounting	9
	LED Panel Connection Lead	9
	Power Supply	9
5.	Initial Start-Up	10
6.	Assembly	11
7.	WEilluminate App Description	12
	Overview	
	System Requirements	12
	Compatible Bluetooth® LE Devices	12
	- Internet Connection	
	Installation	12
	Operation	13
	Starting the Program	13
	Splash Screen	13
	Scan Tab	13
	Channels Tab	14
	Info Tab	14
	Software History	14

## **Intended Use**



### **Description**

The all-in-one Lighting Development Kit provides an easy solution to either mix RGBW color for different lighting situations or amplify the growth of plants with the horticulture panel. The Magl³C Multi Color LED driver can power both panels. With four Magl³C LED Step Down High Current Modules (172946001) as its heart it is possible to control the intensity and color of each of the four LED strings individually to meet the applications needs.

The controlling is done via an app for iOS, which is developed to control the reference design using Bluetooth® LE. The board can be used for horticulture, mixing of different white color temperatures, mixing of RGBW LED combinations (red, green, blue, white) or just to change the intensity of one type of LED.

The board includes an EMI filter in order to comply with the limits of the EN55015 conducted lighting norm and the CISPR32 norm for radiated EMI (tested with 1m output cable length) even while dimming the LED strings.

### **Features**

- 4 Channel LED Driver
- Horticulture panel to grow plants (16 LEDs)
- RGBW panel for lightning solutions (4 LEDs)
- Intensity of each channel can be adjusted individually (dimming 0-100%)
- Dimming via Bluetooth® LE control (2608011024000)
- App "WEilluminate" to perform dimming
- PWM dimming method controlled by PIC16F1527 microcontroller
- Dimming profiles and colors can be stored
- LED Driver: Magl<sup>3</sup>C Power Module 172 946 001
- Conducted and radiated EMI compliant (EN55015 & EN55032)
- Good thermal behavior
- Integrated robust industrial Bluetooth® LE module based on Nordic nRF52832
- The Kit is Bluetooth® LE 4.2 qualified. The QDID is 90212

This Lighting Development Kit is not intended for usage in final applications. This Kit is also not intended for resale.

Hereby, Würth Elektronik declares that the product is in compliance with Directives 2011/65/EU and 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: **www.we-online.com/doc** 

# **Cautions and Warnings**



This product is highly sensitive to electrostatic discharge (ESD). As such, always use proper ESD precaution when handling. Failing to fallow the aforementioned recommendations can result in severe damage to the part.



The heat sink and LED panels can get hot during operation. Please don't touch these surfaces.



Warning against optical radiation: Please avoid direct eye contact with the LEDs whilst using the LED panel at any time. The optical radiation may cause irreversible damage to eyesight.



If the switches S1 – S4 are not in position "OFF" it is possible that the LEDs will flash up for a few milliseconds (typically about 50 ms) due to the initialization of the  $\mu$ C when turning on the power supply!



Before assembling or use of this product please read the attached terms of use. **Note:** To ensure safety the assembly instructions must be followed in the described order!








Abbreviation	Name	Description
Арр	Application	A smart device software programm
BTMAC	Bluetooth® LE Media-Access-Control	Bluetooth® LE conform MAC address of the module used on the RF-Interface
BLE	Bluetooth® LE	According to Bluetooth® LE specification
BT	Bluetooth®	A series of standards introduced by the Bluetooth® LE Special interest Group (BT SiG)
CCT	Correlated Color Temperature	The CCT is used to characterize the spectral distribution of optical radiation emitted by a light source. It is given in Kelvin (K)
EMI	Electromagnetic Interference	EMI is a disturbance generated by an external source that affects an electrical circuit
ESD	Electrostatic Discharge	The sudden flow of electricity between two electrically charged objects by contact
GAP	Generic Access Profile	The GAP provides a basic level of functionality that all the Bluetooth® LE devices must implement
1/0	Input/Output	
LED	Light Emitting Diode	
LPM	Low Power Mode	Mode for efficient power consumption
MAC	Media-Access-Control	Unique 6 byte address of the module
MTU	Maximum Transmission Unit	Maximum packet size of the Bluetooth® LE connection
Payload		The user's message in a UART or radio frame
PCB	Printed Circuit Board	
RF	Radio Frequency	Describes wireless transmission
RGBW	Red, Green, Blue, White	A LED setup of red, green, blue, white LEDs
RSSI	Receive Signal Strength Indicator	The RSSI indicates the strength of the RF signal. Its value is always printed in two's complement notation
RuntimeSettings		Volatile settings to configure the module. This setting are not retained through a reset or VCC loss
SMD	Surface-Mounted Device	Component mounted directly onto the surface of the PCB
UUID	Universally Unique Identifier	A 16 or 128 bit Bluetooth® LE profile identifier
UserSettings		Non-volatile settings to configure the module
UART	Universal Asynchronous Receiver Transmitter	Allows the serial communication with the module
μС	Microcontroller	A compact, energy efficient, performance adopted central processing unit








### Power Board 1780050





Getting startet: Switch S1 – S4 in middle position "OFF"

- Input voltage: 18V-48V
- Output voltage: 0V-V<sub>IN</sub>
- Current capability up to 450 mA
- Switch between V<sub>IN</sub>, OFF and +15V
- VDRM Variable Step Down Regulator Module QFN-41 (171021501)
- 3 PIC16F1527 microcontroller
- Bluetooth® LE 4.2 qualified module (2608011024000)
- Magl<sup>3</sup>C LED Step Down High Current Module (172946001)
- Input and output filter
- Robust screw terminal for V<sub>IN</sub> and V<sub>OUT</sub>
- Ribbon connectors for extended functionality, see DNS005 (not needed for this application)

The power board 1780050 consists of all the components needed for the Bluetooth® LE connection and the four LED control channels. It is meant to control the four LED strings individually or all channels in the same ratio at once. The power supply is connected to J1 and the LED strings at Ch.1 – Ch.4. Every LED channel has three current options (300 mA, 350 mA, 450 mA).

- Right jumper position (J9, J15, J21, J27) is for I<sub>OUT</sub> = 300 mA
- Middle jumper position (J10, J16, J22, J28) for  $I_{OUT} = 350 \, \text{mA}$
- Left jumper position (J11, J17, J23, J28) for  $I_{OUT} = 450 \, \text{mA}$

At any time only one jumper per channel must be connected otherwise the desired way of functioning is not secured!




For further information please visit: https://www.we-online.de/katalog/datasheet/1780050.pdf



### **RGBW Panel**



### **CIE Color Diagram**



### Lens



The LEDiL® PMMA multi-lens was designed, so that every LED on its own gives the optimal light yield. Therefore inside the lens the LED light beam is steered. The angle of radiation is either 30° or 55° for the RGBW panel setup. Via pin by pin adhesive bonding the lense can be fastened to the RGBW panel.

### **RGBW Panel Info**

- R 150353RS74500
- **G** 150353GS74500
- **B** 150353BS74500
- W 158353050
- RGB LEDs with 460 nm, 520 nm and 620 nm
- White LED with 5000 K CCT
- Cover most of the CIE color diagram

### **Description**

- Experiment with different color solution
- Use WEilluminate app to make the color mixtures you need
- Make a color catalog with all the different colors
- Create different entertainment and ambient lights
- Connetct multiple panels in series to increase intensity and LED count

The RGBW panel consists of three WL-SMDC SMD Mono-color Ceramic LEDs with different colors (red, green, blue) and one WL-SWTC SMD White Ceramic LED. The RGBW panel gives the opportunity to experiment with different color solutions. If needed more RGBW panels can be connected in series.



For more information about the 55° lens please visit: www.we-online.com/55degreelens




For more information about the 30° lens please visit: www.we-online.com/30degreelens



### **Horticulture Panel**





The horticulture panel consists of four WL-SMDC SMD White Ceramic LEDs and 12 WL-SMDC SMD Monocolor Ceramic horticulture LEDs with different colors. The horticulture panel can be used to amplify the plant growth in horticulture applications. For the purpose the color ratio mix can be customized, depending on the given plant species.

### Lens



The LEDiL® PMMA multi-lens was designed, so that every LED on its own gives the optimal light yield. Therefore inside the lens the LED light beam is steered. The angle of radiation is 60° for the horticulture panel setup. Using a M3 screw and M3 screw nut to counter the screw the lense can be mounted to the horticulture panel.

### **Horticulture Panel Info**

6 Hyper Red - 150353HS74500

4 Far Red – 150353FS74500

2 Deep Blue - 150353DS74500

4 White - 158353050

### **Standard Distribution**

3:2:1:2 - Hyper Red:Far Red:Deep Blue:White

### Total Output@350mA

- ~ 6W Optical power
- $\sim 30 \,\mu\text{mol/s}$  (calculated from  $400 780 \,\text{nm}$ )

### **Secondary Optic Possibilities**

Viewing angle from 120° down to 30° (current model with 60°)

### **Description**

- Test your own growing recipie
- Adjust blue:red ratio for the plants from 50:50 to 10:90
- Use the WEilluminate app, to adjust, test and store your recepts
- Easily scalable for bigger projects.
- Spectrum and power outputs can be compared to simulation data in REDEXPERT
- Results are strongly dependent on ambience, watering and nutrion



For further information please visit: www.we-online.com/horticulturelens



Try it out:

www.we-online.com/redexpert-horticulture



Develop your own LED panel!

If you wish to design your own LED panel please consider the following Reference Design Notes:









### **Heat Sink**

The heat sink ensures the user safety as well as the protection of the LEDs against damage due to overheating. The heat sink is prepared, so that it is possible to mount either the horticulture panel, one RGBW panel or two RGBW panels in series on it.



# 2.4 8 resp. 10

### Mounting

The M3x8 screws are meant to mount the used LED panel to the heat sink. For mounting the lens on the horticulture panel an extra M3x10 screw is included to the development kit. For every screw a M3 screw nut is given to counter the screw.

### **LED Panel Connection Lead**

For the connection of the power board 1780050 to the LED panel (horticulture panel, RGBW panel) eight 1 m superflexible 0,5 mm<sup>2</sup> connection leads are used. Every connection lead is preassembled with ferrules and can therefore be used without further needed preparations. For LED+ please take the red leads, for LED- the blue leads.




### **Power Supply**

The 48 V/2A power supply is meant to connect to the power board 1780050 (J1). It is an AC/DC power supply and therefore it needs to be connected to 230 V AC on the primary side. The secondary voltage of 48 V falls within the safety extra-low voltage, so that the user safety is ensured. At the output  $V_{\rm IN}$  is marked red, ground is marked black.

# **Initial Start-Up**





### Step-by-Step Manual

- Screw in power supply to power board Don't plug in the primary side to AC mains!
- 2 Ensure that only one jumper for the current limit is set per channel (default: middle = 350 mA)
- 3 Put switches in "OFF" position (switches S1−S4)
- Choose between horticulture panel or RGBW panel and screw connection leads between power board and LED panel
- 5 Mount horticulture panel with lens to heat sink


- 6 Screw connectors between the two RGBW panels
- Ensure that only the last RGBW panel has jumpers on J9 and J10
- 8 Optional: Mount both RGBW panels to heatsink and mount lenses
- 9 Plug in power supply to AC mains (common AC socket) and turn switches to +15 V
- 10 Download the lighting app "WEilluminate"
- Connect board via Bluetooth® LE and set your prefered intensities



Get your App: www.we-online.com/lightingapp

# **Assembly**





# **WEilluminate App Description**



### **Overview**

The WEilluminate app can be used to control the Magl<sup>3</sup>C Multi Color LED Driver reference design via radio. It uses the Bluetooth<sup>®</sup> LE connection of the mobile device to establish a connection to

the Proteus-I (2608011024001) Bluetooth® LE module on the reference design board. Once connected, changes of the LED channel brightness and color distribution can be performed using the sliders in the app.



The WEilluminate app is an evaluation tool that is intended for development purposes only. It is recommended to check regularly for available updates. It does not underly the PCN notification process of Würth Elektronik eiSos.

### **System Requirements**

This app is intended to run on an Apple mobile device, smartphone or tablet, with integrated Bluetooth® LE capabilities. Please make sure your device has installed the most recent iOS updates, security patches and the most recent app version. This app is optimized for portrait mode and was tested with iPad mini 2 and iPhone XS, each with iOS v12.4.1 and iOS 13.3.1.

In order to use the app the user is required to grant the corresponding requested rights, e.g. to use the Bluetooth® LE interface of the smart device.

### Compatible Bluetooth® LE Devices

The WEilluminate app supports connection to the Würth Elektronik eiSos Proteus module implemented in the reference design.

### **Internet Connection**

The WEilluminate app works offline and requires no internet connection to be used. However, the links provided in the info tab require an internet connection to be opened by the system internet browser.

### Installation

The WEilluminate app can be found in the official App Store or on our website.



WEilluminate App www.we-online.com/lightingapp

# **WEilluminate App Description**



### **Operation**

This chapter provides operational instructions for the WEilluminate app.

### Starting the Program

After successful installation, click the WEilluminate app icon on the home screen of your mobile device to start the application.

### Splash Screen

During the application startup phase your mobile device shows the following splash screen and then proceeds to the scan tab of the app.

### Scan Tab

This tab lists all Bluetooth® LE devices supported by this app within range. Currently, only Würth Elektronik eiSos Bluetooth® LE modules of the Proteus family are supported by the app. In addition a demo device is always the topmost entry in the found devices list. This device enables the user to try the app even in case no suiting Bluetooth® LE device is available in radio range.

The list will show the device names of the detected Bluetooth® LE devices, which are specified in the devices itself and only interpreted by the app. The names can not be changed from the app. For the Proteus modules that short device name in the list defaults to either A2621 for Proteus-I or A2623 for Proteus-II.

The user can select a device from the list and initiate the connection process by clicking on it. The Bluetooth® LE connection will be established automatically. The security option of the Proteus module is set to open, which means no pin code has to be entered and anyone can connect to it. If another security option is set the app prompts to enter a pin code to establish the Bluetooth® LE connection. It is not possible to change the security option from within the app. After a successful connection establishment the app switches automatically to the channels tab.

Then swiping back to the scan tab the connected device is indicated with a red check icon as shown in the following screenshot. A gray check icon shows the last connected device but the gray indicates that the connection is not active.



App icon



Splash screen



Scan tab

# **WEilluminate App Description**



### **Channels Tab**

The channel tab allows to control the LED brightness of the reference design. Each of the four channels can be controlled individually and the additional brightness slider works as a global multiplier for all four channels. The % values shown for each channel are the percentages with brightness already calculated in and rounded down. Whereas the brightness % value is representing its slider value.

If the brightness slider is set to 0 % none of the channels will be active. This means for example a value of 50 % for the channel 1 on the reference design can be created by a multitude of slider positions of channel 1 slider value and brightness slider value.

### For example:

- Brightness slider 100 % and channel 1 slider 50 % resulting in channel 1 overall value 50 %
- Brightness slider 50 % and channel 1 slider 100 % resulting in channel 1 overall value 50 %
- Brightness slider 71 % and channel 1 slider 71 % resulting in channel 1 overall value 50 %

This means whenever the brightness slider is set to 0 % any LED channel will be disabled independent of their slider's value. The app is restricted to a certain number of radio frames per second (in BLE terms: connection interval) which means that not any step of a (fast) change will be transmitted on the radio. The value for the responsiveness is chosen so a good user experience is created but can be easily modified.

### Info Tab

Users can slide most left or touch the info tab symbol at the bottom to switch view to the info tab. This tab gives general app version information and allows accessing the privacy policy, contact information and imprint by forwarding a link to the system's default web browser.

### **Software History**

Version 1.0 "Release"

- First released version of the iOS App.
  - Fixes:
  - Icon color and size adjusted for iOS 13



Channels tab



If the brightness slider is set to 0 % none of the channels will be active.



Info tal



# more than you expect

# **Mouser Electronics**

**Authorized Distributor** 

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Wurth Elektronik: