

Complete Single-Conversion Television Tuner

ABSOLUTE MAXIMUM RATINGS

V_{CC} to GND-0.3V, +3.6V
 RFIN, IFIN, IFOUT1_, IFOUT2_, IFAGC, RFAGC,
 VTUNE, LDO, MUX, CP,
 XTAL to GND-0.3V to (V_{CC} + 0.3V)
 SDA, SCL, ADDR2, ADDR1 to GND.....-0.3V to +3.6V
 IFOUT_ Short-Circuit DurationIndefinite
 RF Input Power+10dBm

Continuous Power Dissipation (T_A = +70°C)
 48-Pin fcLGA (derate 25mW/°C above +70°C)1.4W
 Operating Temperature Range-40°C to +85°C
 Junction Temperature+150°C
 Storage Temperature Range-65°C to +165°C
 Lead Temperature (soldering, 10s)+250°C
 Soldering Temperature (reflow)+240°C

Stresses beyond those listed under "Absolute Maximum Ratings" may cause permanent damage to the device. These are stress ratings only, and functional operation of the device at these or any other conditions beyond those indicated in the operational sections of the specifications is not implied. Exposure to absolute maximum rating conditions for extended periods may affect device reliability.



CAUTION! ESD SENSITIVE DEVICE

DC ELECTRICAL CHARACTERISTICS

(MAX3541 EV kit, V_{CC} = +3.1V to +3.5V, T_A = -40°C to +85°C, no RF signals at RF inputs, default register settings, V_{RFAGC} = V_{IFAGC} = +3V (minimum attenuation), unless otherwise noted. Typical values are at V_{CC} = +3.3V, T_A = +25°C, unless otherwise noted.)

| PARAMETER | CONDITIONS | MIN | TYP | MAX | UNITS |
|--|---------------------|-----------------------|------------------------|-----------------------|-------|
| SUPPLY VOLTAGE AND CURRENT | | | | | |
| Supply Voltage | | +3.1 | | +3.5 | V |
| Supply Current | Receive mode | | 230 | 275 | mA |
| | Shutdown mode | | 5 | | |
| RF and IF AGC Input Bias Current | At +0.5V and +3V | -50 | | +50 | μA |
| RF and IF AGC Control Voltage (Note 1) | Minimum attenuation | +3 | | | V |
| | Maximum attenuation | | | +0.5 | |
| Digital Input Logic-Level Low | | | | 0.3 x V _{CC} | V |
| Digital Input Logic-Level High | | 0.7 x V _{CC} | | | V |
| SERIAL INTERFACE | | | | | |
| Input Logic-Level Low | | | | 0.3 x V _{CC} | V |
| Input Logic-Level High | | 0.7 x V _{CC} | | | V |
| Input Hysteresis | | | 0.05 x V _{CC} | | V |
| SDA, SCL Input Current | | -10 | | +10 | μA |
| Output Logic-Level Low | 3mA sink current | | | 0.4 | V |
| Output Logic-Level High | | V _{CC} - 0.5 | | | V |

Complete Single-Conversion Television Tuner

MAX3541

AC ELECTRICAL CHARACTERISTICS

(MAX3541 EV kit, $V_{CC} = +3.1V$ to $+3.5V$, $T_A = -40^{\circ}C$ to $+85^{\circ}C$, 75Ω system impedance, default register settings, $V_{RFAGC} = V_{IFAGC} = +3V$ (minimum attenuation), unless otherwise noted. Typical values are at $V_{CC} = +3.3V$, $T_A = +25^{\circ}C$, unless otherwise noted.)

| PARAMETER | CONDITIONS | MIN | TYP | MAX | UNITS | | |
|--|---|-------------------------------------|------|-----|----------|----|----|
| RF INPUT TO IFOUT1 OUTPUT | | | | | | | |
| Operating Frequency Range (see Table 7) | Gain specification met across these frequency bands | 47 | | 68 | MHz | | |
| | | 174 | | 230 | | | |
| | | 470 | | 862 | | | |
| Output Frequency | Analog channel PIX carrier | | 38.9 | | MHz | | |
| | Digital channel center frequency | | 36 | | | | |
| Voltage Gain | Source impedance = 75Ω , load impedance = 200Ω | Maximum gain ($V_{RAVGC} = 3V$) | | 33 | 41 | 49 | dB |
| | | Minimum gain ($V_{RAVGC} = 0.5V$) | | -10 | | | |
| Input Return Loss | Selected channel | | 10 | | dB | | |
| Noise Figure | Maximum gain ($V_{RFAGC} = 3V$) | | 4.9 | | dB | | |
| Input IP2 (In-Band and Out-of-Band Tones) | Maximum gain ($V_{RFAGC} = 3V$) | | 20 | | dBm | | |
| | At 12.5dB of gain | | 30 | | | | |
| Input IP3 (In-Band and Out-of-Band Tones) | Maximum gain ($V_{RFAGC} = 3V$) | | -10 | | dBm | | |
| | At 12.5dB of gain | 10 | | | | | |
| Input P _{1dB} | Maximum gain ($V_{RFAGC} = 3V$) | | -38 | | dBm | | |
| | At 12.5dB of gain | | -5 | | | | |
| Beats Within Output | 0dBmV PIX carrier level | | -40 | | dBc | | |
| Beats, Converted to Output | VHF input, 140MHz to 500MHz | | -60 | | dBc | | |
| | VHF input, 500MHz to 1400MHz | | -50 | | | | |
| | UHF input, 950MHz to 1400MHz | | -60 | | | | |
| Gain Flatness | 47MHz to 54MHz | | | 2.5 | dBp-p | | |
| Isolation | 5MHz to 50MHz, RF input to IF output, relative to desired channel | | 60 | | dBc | | |
| Port-to-Port Isolation | Isolation between RF input ports at 215MHz | | 27 | | dB | | |
| Image Rejection | Measured at 77.8MHz above desired channel's center frequency | 57 | 70 | | dBc | | |
| Spurious Leakage at RF Input | 5Hz to 65MHz | | -40 | | dBmV | | |
| | 65MHz to 878MHz | | -40 | | | | |
| Phase Noise (Single-Sideband) | 1kHz | | -80 | | dBc/Hz | | |
| | 10kHz offset | | -85 | | | | |
| | 100kHz offset (1.5kHz loop bandwidth) | | -105 | | | | |
| | 1MHz offset (1.5kHz loop bandwidth) | | -125 | | | | |
| Output Return Loss | Balanced 50Ω load | | 20 | | dB | | |
| IF VARIABLE-GAIN AMPLIFIER | | | | | | | |
| Input Impedance | Balanced | | 2000 | | Ω | | |
| Output Impedance | Balanced (Note 1) | | | 300 | Ω | | |

Complete Single-Conversion Television Tuner

AC ELECTRICAL CHARACTERISTICS (continued)

(MAX3541 EV kit, $V_{CC} = +3.1V$ to $+3.5V$, $T_A = -40^{\circ}C$ to $+85^{\circ}C$, 75Ω system impedance, default register settings, $V_{RFAGC} = V_{IFAGC} = +3V$ (minimum attenuation), unless otherwise noted. Typical values are at $V_{CC} = +3.3V$, $T_A = +25^{\circ}C$, unless otherwise noted.)

| PARAMETER | CONDITIONS | MIN | TYP | MAX | UNITS | |
|--|---|--|---------|----------------|-----------------|----|
| Passband Voltage Gain | Source load = $1.1k\Omega$, output load = $1k\Omega$ | Maximum gain setting ($V_{IFAGC} = 3V$) | 54 | 59 | 63 | dB |
| | | Minimum gain setting ($V_{IFAGC} = 0.5V$) | | | 21 | |
| Passband Gain Flatness | 32MHz to 40MHz (Note 1) | | | 1.2 | dB | |
| Output Voltage | $V_{IFAGC} = 3V$ (Note 1) | | | 2.5 | V_{P-P} | |
| AGC Gain Slope | $V_{IFAGC} = 3V$ to $0.5V$ (Note 1) | | | 27 | dB/V | |
| Equivalent Input Voltage Noise Density | At 36MHz, maximum gain ($V_{IFAGC} = 3V$) (Note 1) | | | 7.3 | nV/ \sqrt{Hz} | |
| Noise Figure Change vs. Attenuation | | | < 0.35 | | dB/dB | |
| IM3 | $V_{OUT} = 1V_{P-P}$, 40dB < gain < 60dB (Note 1) | -56 | | | dBc | |
| IF OVERLOAD DETECTOR (See the IF Overload Detector Section) | | | | | | |
| Output Overload Attack Point | | | 0.7 | | V_{P-P} | |
| Attack Point Accuracy | OD REG = 3 | | ± 1 | | dB | |
| Detector Output Voltage Range | Negative polarity, overload reduces V_{DET} (open collector, 0.3mA sink) | 0.5 | | 3.0 | V | |
| Detector Gain | | | 70 | | V/V | |
| FREQUENCY SYNTHESIZER | | | | | | |
| REFERENCE OSCILLATOR | | | | | | |
| Frequency | | | 8 | | MHz | |
| DIVIDERS | | | | | | |
| RF N-Divider Ratio | | 256 | | 32,767 | | |
| RF R-Divider Ratio | | 16 | | 127 | | |
| LO PHASE DETECTOR AND CHARGE PUMP | | | | | | |
| Comparison Frequency | | 63 | | 250 | kHz | |
| Charge-Pump Current | CP = 00 | | 0.5 | | mA | |
| | CP = 01 | | 1 | | | |
| | CP = 10 | | 1.5 | | | |
| | CP = 11 | | 2 | | | |
| Charge-Pump Three-State Current | | | ± 5 | | nA | |
| Charge-Pump Compliance Range | | 0.4 | | $V_{CC} - 0.4$ | V | |
| Charge-Pump Current Matching | | | 5 | | % | |
| LOCAL OSCILLATOR | | | | | | |
| VCO Tuning Range | Tank frequency | 2200 | | 4400 | MHz | |
| VCO Tuning Gain | Tank oscillator gain | | | 500 | MHz/V | |
| 2-WIRE SERIAL INTERFACE | | | | | | |
| Clock Frequency | | | | 400 | kHz | |









Note 1: Guaranteed by design and characterization.

Complete Single-Conversion Television Tuner

Typical Operating Characteristics

(MAX3541EV kit, $V_{CC} = +3.3V$, $V_{IFAGC} = 3.0V$, $V_{RFAGC} = 3.0V$, $T_A = +25^\circ C$, unless otherwise noted.)







MAX3541



Complete Single-Conversion Television Tuner

Typical Operating Characteristics (continued)

(MAX3541EV kit, $V_{CC} = +3.3V$, $V_{IFAGC} = 3.0V$, $V_{RFAGC} = 3.0V$, $T_A = +25^\circ C$, unless otherwise noted.)









Complete Single-Conversion Television Tuner

MAX3541

Typical Operating Characteristics (continued)



(MAX3541EV kit, $V_{CC} = +3.3V$, $V_{IFAGC} = 3.0V$, $V_{RFAGC} = 3.0V$, $T_A = +25^\circ C$, unless otherwise noted.)



Complete Single-Conversion Television Tuner

Typical Operating Characteristics (continued)

(MAX3541EV kit, $V_{CC} = +3.3V$, $V_{IFAGC} = 3.0V$, $V_{RFAGC} = 3.0V$, $T_A = +25^\circ C$, unless otherwise noted.)



Pin Description

| PIN | NAME | DESCRIPTION |
|-----------------------------------|----------|--|
| 1 | SCL | 2-Wire Serial-Clock Interface. Requires a pullup resistor to V_{CC} . |
| 2 | SDA | 2-Wire Serial-Data Interface. Requires a pullup resistor to V_{CC} . |
| 3, 10, 23, 28, 32, 33, 37, 41, 44 | V_{CC} | Power Supply Connections. Bypass each supply pin to ground with a 1000pF capacitor. |
| 4 | UHF_IN | UHF RF Input. Requires a DC-blocking capacitor. |
| 5 | VHF_IN | VHF RF Input. Requires a DC-blocking capacitor. |
| 6 | RFGND2 | RF Ground. Bypass to the PCB's ground plane with a 1000pF capacitor. Do not connect RFGND2 and RFGND3 together. |
| 7 | LEXT | RF VGA Supply Voltage. Connect through a 270nH pullup inductor to V_{CC} . |
| 8 | RFGND3 | RF Ground. Bypass to the PCB's ground plane with a 1000pF capacitor. Do not connect RFGND2 and RFGND3 together. |
| 9 | RFAGC | RF VGA Gain Control Voltage. Accepts a DC voltage from 0.5V (minimum gain) to 3V (maximum gain). |
| 11–22, 27, 31 | GND | Ground. Connect to the PCB's ground plane. |
| 24 | IFOUT2- | Inverting IF VGA Output. Connect to the input of an anti-aliasing filter. Requires a DC-blocking capacitor. |
| 25 | IFOUT2+ | Noninverting IF VGA Output. Connect to the input of an anti-aliasing filter. Requires a DC-blocking capacitor. |
| 26 | IFAGC | IF VGA Gain Control Voltage. Accepts a DC voltage from 0.5V (minimum gain) to 3V (maximum gain). |
| 29 | IFIN- | Inverting IF VGA Input. Connect to the output of an IF-SAW filter. |
| 30 | IFIN+ | Noninverting IF VGA Input. Connect to the output of an IF-SAW filter. |
| 34 | IFOVLD | IF Overload Detector Open-Collector Output. Requires a 10k Ω pullup resistor to V_{CC} . |
| 35 | IFOUT1+ | Noninverting IF LNA Output. Requires a DC-blocking capacitor. |
| 36 | IFOUT1- | Inverting IF LNA Output. Requires a DC-blocking capacitor. |
| 38 | LDO | VCO LDO Bypass. Bypass to ground with a 0.47 μ F capacitor. |

Complete Single-Conversion Television Tuner

Pin Description (continued)

| PIN | NAME | DESCRIPTION |
|-----|----------|---|
| 39 | GND_TUNE | VTUNE Ground Connection. Connect to the PCB ground plane. All loop filter component GNDs must be connected to this pin (see the <i>Typical Application Circuit</i>). |
| 40 | VTUNE | VCO Tuning Input. Connect to the PLL loop filter output. |
| 42 | MUX | Test Output. Leave this pin unconnected during normal operation. |
| 43 | CP | Charge-Pump Output. Connect to PLL loop filter input. |
| 45 | XTALN | Crystal Oscillator Feedback. See the <i>Typical Application Circuit</i> . |
| 46 | XTALP | Crystal Oscillator Feedback. See the <i>Typical Application Circuit</i> . |
| 47 | ADDR1 | 2-Wire Serial-Interface Address Line 1. This pin along with ADDR2 sets the device address for the I2C-compatible serial interface. |
| 48 | ADDR2 | 2-Wire Serial-Interface Address Line 2. This pin along with ADDR1 sets the device address for the I2C-compatible serial interface. |
| — | EP | Exposed Pad. Solder evenly to the PCB ground plane for proper operation. |

MAX3541

Complete Single-Conversion Television Tuner

Detailed Description

Register Descriptions

The MAX3541 includes 11 programmable registers and 2 read-only registers. The 11 programmable registers include two N-divider registers, an R-divider register, a VCO register, an IFOVLD/Charge Pump/Filter Select register, a Control register, a Shutdown register, and

Tracking Filter Control registers. These 11 programmable registers are also readable. The read-only registers include a status register and a ROM table data register.

Recommended default bit settings are provided for user convenience only and are not guaranteed. The user must write all registers after power-up and no earlier than 100 μ s after power-up.

Table 1. Register Configuration

| REGISTER NAME | READ/ WRITE | REGISTER ADDRESS | MSB | | | | | | | | LSB |
|--|-------------|------------------|-----------|-----------|---------|---------|----------|------------|-------|-------|-----|
| | | | DATA BYTE | | | | | | | | |
| | | | D7 | D6 | D5 | D4 | D3 | D2 | D1 | D0 | |
| N-DIV High | Both | 0x00 | 0 | N14 | N13 | N12 | N11 | N10 | N9 | N8 | |
| N-DIV Low | Both | 0x01 | N7 | N6 | N5 | N4 | N3 | N2 | N1 | N0 | |
| R-DIV | Both | 0x02 | 0 | R6 | R5 | R4 | R3 | R2 | R1 | R0 | |
| VCO | Both | 0x03 | VCO4 | VCO3 | VCO2 | VCO1 | VCO0 | LD | VDIV1 | VDIV0 | |
| IFOVLD, Charge Pump, and Filter Select | Both | 0x04 | 0 | IFOVLD2 | IFOVLD1 | IFOVLD0 | CP1 | CP0 | TF | 0 | |
| Control | Both | 0x05 | 0 | 0 | 0 | 0 | SHDN_RF | SHDN_IFVGA | INPT1 | INPT0 | |
| Shutdown | Both | 0x06 | SHDN_MIX1 | SHDN_MIX0 | SHDN_IF | SHDN_OD | SHDN_SYN | 0 | 0 | 0 | |
| Tracking Filter Series Capacitor | Both | 0x07 | TFS7 | TFS6 | TFS5 | TFS4 | TFS3 | TFS2 | TFS1 | TFS0 | |
| Tracking Filter Parallel Capacitor | Both | 0x08 | FLD | 0 | TFP5 | TFP4 | TFP3 | TFP2 | TFP1 | TFP0 | |
| Tracking Filter ROM Address | Both | 0x09 | 0 | 0 | 0 | 0 | TFA3 | TFA2 | TFA1 | TFA0 | |
| Reserved | Both | 0x0A | X | X | X | X | X | X | X | X | |
| ROM Table Data Readback | Read | 0x0B | TFR7 | TFR6 | TFR5 | TFR4 | TFR3 | TFR2 | TFR1 | TFR0 | |
| Status | Read | 0x0C | POR | LD2 | LD1 | LD0 | X | X | X | X | |

Table 2. N-DIV High Register (Address: 0000b)

| BIT NAME | BIT LOCATION (0 = LSB) | RECOMMENDED DEFAULT | FUNCTION |
|----------|------------------------|---------------------|---|
| RESERVED | 7 | 0 | Must be set to 0. |
| N[14:8] | 6-0 | 0000001 | Sets the most significant bits of the PLL integer divider (N). Default integer divider value is N = 4688. N can range from 256 to 32,767. |

Complete Single-Conversion Television Tuner

MAX3541

Table 3. N-DIV Low Register (Address: 0001_b)

| BIT NAME | BIT LOCATION (0 = LSB) | RECOMMENDED DEFAULT | FUNCTION |
|----------|------------------------|---------------------|--|
| N[7:0] | 7-0 | 10101011 | Sets the least significant bits of the PLL integer divider (N). Default integer divider value is N = 4688. N can range from 256 to 32,767. |

Table 4. R-DIV Register (Address: 0010_b)

| BIT NAME | BIT LOCATION (0 = LSB) | RECOMMENDED DEFAULT | FUNCTION |
|----------|------------------------|---------------------|--|
| RESERVED | 7 | 0 | Must be set to 0. |
| R[6:0] | 6-0 | 0010000 | Sets the PLL reference divider (R). Default reference divider value is R = 64. R can range from 16 to 127. |

Table 5. VCO Register (Address: 0011_b)

| BIT NAME | BIT LOCATION (0 = LSB) | RECOMMENDED DEFAULT | FUNCTION |
|-----------|------------------------|---------------------|---|
| VCO[4:3] | 7-6 | 10 | VCO select. Selects one of three possible VCOs. 00 = VCOs shut down 01 = Selects VCO1 10 = Selects VCO2 11 = Selects VCO3 |
| VCO[2:0] | 5-3 | 111 | VCO sub-band select. Selects one of eight possible VCO sub-bands. 000 = Selects SB0 001 = Selects SB1 010 = Selects SB2 011 = Selects SB3 100 = Selects SB4 101 = Selects SB5 110 = Selects SB6 111 = Selects SB7 |
| LD | 2 | 1 | Lock detect enable. 0 = Disabled 1 = Enabled |
| VDIV[1:0] | 1-0 | 10 | VCO divider ratio select. 00 = Sets VCO divider to 4 01 = Sets VCO divider to 8 10 = Sets VCO divider to 16 11 = Sets VCO divider to 32 |

Complete Single-Conversion Television Tuner

Table 6. IFOVLD, Charge Pump, and Filter Select Register (Address: 0100_b)

| BIT NAME | BIT LOCATION (0 = LSB) | RECOMMENDED DEFAULT | FUNCTION |
|-------------|------------------------|---------------------|--|
| RESERVED | 7 | 0 | Must be set to 0. |
| IFOVLD[2:0] | 6-4 | 000 | Write content of ROM register OD[2:0] to this location. |
| CP[1:0] | 3-2 | 00 | Selects the typical charge-pump current. 00 = 0.5mA 01 = 1mA 10 = 1.5mA 11 = 2mA |
| TF | 1 | 0 | Selects the tracking filter band of operation. 0 = VHF 1 = UHF |
| RESERVED | 0 | 0 | Must be set to 0. |

Table 7. Control Register (Address: 0101_b)

| BIT NAME | BIT LOCATION (0 = LSB) | RECOMMENDED DEFAULT | FUNCTION |
|------------|------------------------|---------------------|--|
| RESERVED | 7-4 | 0000 | Must be set to 0000. |
| SHDN_RF | 3 | 0 | RF shutdown. 0 = RF circuitry enabled 1 = RF circuitry disabled |
| SHDN_IFVGA | 2 | 0 | IF VGA shutdown. 0 = IF VGA enabled 1 = IF VGA disabled |
| INPT[1:0] | 1-0 | 01 | Selects the RF input. 00 = Selects VHF_IN, LPF enabled 01 = Selects VHF_IN, LPF disabled 10 = Selects UHF_IN 11 = Factory use only |

Table 8. Shutdown Register (Address: 0110_b)

| BIT NAME | BIT LOCATION (0 = LSB) | RECOMMENDED DEFAULT | FUNCTION |
|----------|------------------------|---------------------|--|
| SHDN_MIX | 7-6 | 00 | Mixer shutdown. 00 = Mixer enabled 01,10 = Factory use only 11 = Mixer disabled |
| SHDN_IF | 5 | 0 | IF shutdown. 0 = IF section enabled 1 = IF section disabled |
| SHDN_OD | 4 | 0 | IFOVLD shutdown. 0 = Power detector enabled 1 = Power detector disabled |
| SHDN_SYN | 3 | 0 | Frequency synthesizer shutdown. 0 = Synthesizer enabled 1 = Synthesizer disabled |
| RESERVED | 2-0 | 000 | Must be set to 000. |

Complete Single-Conversion Television Tuner

MAX3541

Table 9. Tracking Filter Series Capacitor Register (Address: 0111_b)

| BIT NAME | BIT LOCATION (0 = LSB) | RECOMMENDED DEFAULT | FUNCTION |
|----------|------------------------|---------------------|--|
| TFS[7:0] | 7-0 | 00001111* | Programs series capacitor values in the tracking filter. |

*See the *RF Tracking Filter* section.

Table 10. Tracking Filter Parallel Capacitor Register (Address: 1000_b)

| BIT NAME | BIT LOCATION (0 = LSB) | RECOMMENDED DEFAULT | FUNCTION |
|----------|------------------------|---------------------|--|
| FLD | 7 | 0 | Filter load bit. A 0 to 1 transition of this bit forces the loading of the ROM Table Data Readback register. |
| RESERVED | 6 | 0 | Must be set to 0. |
| TFP[5:0] | 5-0 | 001001* | Programs parallel capacitor values in the tracking filter. |

*See the *RF Tracking Filter* section.

Table 11. Tracking Filter ROM Address Register (Address: 1001_b)

| BIT NAME | BIT LOCATION (0 = LSB) | RECOMMENDED DEFAULT | FUNCTION |
|----------|------------------------|---------------------|--|
| RESERVED | 7-4 | 0000 | Must be set to 0000. |
| TFA[3:0] | 3-0 | 0000* | Address bits of the ROM register to be read. |

*See the *RF Tracking Filter* section.

Table 12. Reserved Register (Address: 1010_b)

| BIT NAME | BIT LOCATION (0 = LSB) | RECOMMENDED DEFAULT | FUNCTION |
|----------|------------------------|---------------------|--|
| RESERVED | 7-0 | N/A | Reserved. Do not program these bits during normal operation. |

Table 13. ROM Table Data Readback Register (Address: 1011_b)

| BIT NAME | BIT LOCATION (0 = LSB) | RECOMMENDED DEFAULT | FUNCTION |
|----------|------------------------|---------------------|---|
| TFR[7:0] | 7-0 | 00000000* | Tracking filter data bits read from the device's ROM table. |

*See the *RF Tracking Filter* section.

Table 14. Status Register (Address: 1100_b)

| BIT NAME | BIT LOCATION (0 = LSB) | RECOMMENDED DEFAULT | FUNCTION |
|----------|------------------------|---------------------|---|
| POR | 7 | N/A | Power-on reset. 0 = Status register has been read 1 = Power reset since last status register read |
| LD[2:0] | 6-4 | N/A | VCO tuning voltage indicators. 000 = PLL not in lock, tune to the next lowest sub-band 001–110 = PLL in lock 111 = PLL not in lock, tune to the next higher sub-band |
| RESERVED | 3-0 | N/A | Reserved. |

Complete Single-Conversion Television Tuner

2-Wire Serial Interface

The MAX3541 use a 2-wire I²C-compatible serial interface consisting of a serial-data line (SDA) and a serial-clock line (SCL). SDA and SCL facilitate bidirectional communication between the MAX3541 and the master at clock frequencies up to 400kHz. The master initiates a data transfer on the bus and generates the SCL signal to permit data transfer. The MAX3541 behaves as a slave device that transfers and receives data to and from the master. Pull SDA and SCL high with external pullup resistors (1k Ω or greater) for proper bus operation.

One bit is transferred during each SCL clock cycle. A minimum of nine clock cycles is required to transfer a byte in or out of the MAX3541 (8 data bits and an ACK/NACK). The data on SDA must remain stable during the high period of the SCL clock pulse. Changes in SDA while SCL is high and stable are considered control signals (see the *START and STOP Conditions* section). Both SDA and SCL remain high when the bus is not busy.

START and STOP Conditions

The master initiates a transmission with a START condition (S), which is a high-to-low transition on SDA while SCL is high. The master terminates a transmission with a STOP condition (P), which is a low-to-high transition on SDA while SCL is high.

Acknowledge and Not-Acknowledge Conditions

Data transfers are framed with an acknowledge bit (ACK) or a not-acknowledge bit (NACK). Both the master and the MAX3541 (slave) generate acknowledge bits. To generate an acknowledge, the receiving device must pull SDA low before the rising edge of the acknowledge-related clock pulse (ninth pulse) and keep it low during the high period of the clock pulse.

To generate a not-acknowledge condition, the receiver allows SDA to be pulled high before the rising edge of the acknowledge-related clock pulse, and leaves SDA high during the high period of the clock pulse. Monitoring the acknowledge bits allows for detection of unsuccessful data transfers. An unsuccessful data transfer happens if a receiving device is busy or if a system fault has occurred. In the event of an unsuccessful data transfer, the bus master must reattempt communication at a later time.

Slave Address

The MAX3541 has a 7-bit slave address that must be sent to the device following a START condition to initiate communication. The slave address is determined by the state of the ADDR2 and ADDR1 pins and is equal to 11000[ADDR2][ADDR1]. The eighth bit (R/W) following the 7-bit address determines whether a read or write operation occurs. Table 15 shows the possible address configurations.

The MAX3541 continuously awaits a START condition followed by its slave address. When the device recognizes its slave address, it acknowledges by pulling the SDA line low for one clock period; it is ready to accept or send data depending on the R/W bit (Figure 1).

Table 15. MAX3541 Address Configurations

| ADDR2 | ADDR1 | WRITE ADDRESS | READ ADDRESS |
|-------|-------|---------------|--------------|
| 0 | 0 | 0xC0 | 0xC1 |
| 0 | 1 | 0xC2 | 0xC3 |
| 1 | 0 | 0xC4 | 0xC5 |
| 1 | 1 | 0xC6 | 0xC7 |




Figure 1. MAX3541 Slave Address Byte

Complete Single-Conversion Television Tuner

MAX3541

Write Cycle

When addressed with a write command, the MAX3541 allows the master to write to a single register or to multiple successive registers.

A write cycle begins with the bus master issuing a START condition followed by the seven slave address bits and a write bit ($R/\bar{W} = 0$). The MAX3541 issues an ACK if the slave address byte is successfully received. The bus master must then send to the slave the address of the first register it wishes to write to. If the slave acknowledges the address, the master can then write one byte to the register at the specified address. Data is written beginning with the most significant bit. The MAX3541 again issues an ACK if the data is successfully written to the register. The master can continue to write data to the successive internal registers with the MAX3541 acknowledging each successful transfer, or it can terminate transmission by issuing a STOP condition. The write cycle does not terminate until the master issues a STOP condition.

Figure 2 illustrates an example in which registers 0 through 2 are written with 0x0E, 0xD8, and 0xE1, respectively.

Read Cycle

A read cycle begins with the bus master issuing a START condition followed by the seven slave address bits and a write bit ($R/\bar{W} = 0$). The MAX3541 issues an ACK if the slave address byte is successfully received. The master then sends the 8-bit address of the first register that it wishes to read. The MAX3541 then issues another ACK. Next, the master must issue a START condition followed by the 7 slave address bits and a read bit ($R/\bar{W} = 1$). The MAX3541 issues an ACK if it successfully recognizes its address and begins sending data from the specified register address starting with the most significant bit (MSB). Data is clocked out of the MAX3541 on the rising edge of SCL. On the 9th rising edge of SCL, the master can issue an ACK and continue reading successive registers or it can issue a NACK followed by a STOP condition to terminate transmission. The read cycle does not terminate until the master issues a STOP condition. Figure 3 illustrates an example in which registers 0 and 1 are read back.

| START | WRITE DEVICE ADDRESS | R/\bar{W} | ACK | WRITE REGISTER ADDRESS | ACK | WRITE DATA TO REGISTER 0x00 | ACK | WRITE DATA TO REGISTER 0x01 | ACK | WRITE DATA TO REGISTER 0x02 | ACK | STOP |
|-------|----------------------|-------------|-----|------------------------|-----|-----------------------------|-----|-----------------------------|-----|-----------------------------|-----|------|
| | 11000[ADDR2][ADDR1] | 0 | — | 0x00 | — | 0x0E | — | 0xD8 | — | 0xE1 | — | |

Figure 2. Example: Write Registers 0 Through 2 with 0x0E, 0xD8, and 0xE1, Respectively

| START | WRITE DEVICE ADDRESS | R/\bar{W} | ACK | WRITE 1ST REGISTER ADDRESS | ACK | START | WRITE DEVICE ADDRESS | R/\bar{W} | ACK | READ DATA REG 0 | ACK | READ DATA REG 1 | NACK | STOP |
|-------|----------------------|-------------|-----|----------------------------|-----|-------|----------------------|-------------|-----|-----------------|-----|-----------------|------|------|
| | 110000[ADDR2][ADDR1] | 0 | — | 0x00 | — | | 110000[ADDR2][ADDR1] | 1 | — | D7–D0 | — | D7–D0 | — | |

Figure 3. Example: Read Data from Registers 0 and 1

Complete Single-Conversion Television Tuner

Application Information

RF Inputs

The MAX3541 features separate UHF and VHF inputs that are matched to 75Ω. Both inputs require a DC-blocking capacitor. The active inputs are selected by the input registers. In addition, the input registers enable or disable the lowpass filter, which can be used when the VHF input is selected. For the 47MHz to 68MHz, select the VHF_IN with the LPF filter enabled (INPT = 00). For 174MHz to 230MHz, select VHF_IN with LPF disabled (INPT = 01). For 470MHz to 862MHz, select UHF_IN (INPT = 10).

RF Gain Control

The gain of the RF low-noise amplifier can be adjusted over a typical range of 45dB with the RFAGC pin. The RFAGC input accepts a DC voltage from 0.5V to 3V, with 3V providing maximum gain. This pin can be controlled with the IF power-detector output to form a closed RF gain-control loop. See the *Closed-Loop RF Gain Control* section for more information.

RF Tracking Filter

The MAX3541 includes a programmable tracking filter for each band of operation to optimize rejection of out-of-band interference while minimizing insertion

loss for the desired received signal. The center frequency of each tracking filter is selected by a switched-capacitor array that is programmed by the TFS[7:0] bits in the Tracking Filter Series Capacitor register and the TFP[5:0] bits in the Tracking Filter Parallel Cap register.

Optimal tracking filter settings for each channel varies from part to part due to process variations. To accommodate part-to-part variations, each part is factory calibrated by Maxim. During calibration, the y-intercept and slope for the series and parallel tracking capacitor arrays is calculated and written into an internal ROM table. The user must read the ROM table upon power-up and store the data in local memory (8 bytes total) to calculate the optimal TFS[7:0] and TFP[5:0] settings for each channel. Table 16 shows the address and bits for each ROM table entry. See the *Interpolating Tracking Filter Coefficients* section for more information on how to calculate the required values.

Reading the ROM Table

Each ROM table entry must be read using a two-step process. First, the address of the ROM bits to be read must be programmed into the TFA[3:0] bits in the Tracking Filter ROM Address register (Table 11).

Table 16. ROM Table

| DESCRIPTION | ADDRESS | MSB | | | | | | | | LSB |
|--------------------------|---------|-----------|--------|--------|--------|--------|--------|--------|--------|-----|
| | | DATA BYTE | | | | | | | | |
| | | D7 | D6 | D5 | D4 | D3 | D2 | D1 | D0 | |
| Reserved | 0x0 | OD2 | OD1 | OD0 | X | X | X | X | X | |
| VHF Series Y-Intercept | 0x1 | VS0[7] | VS0[6] | VS0[5] | VS0[4] | VS0[3] | VS0[2] | VS0[1] | VS0[0] | |
| VHF Series Slope | 0x2 | VS1[7] | VS1[6] | VS1[5] | VS1[4] | VS1[3] | VS1[2] | VS1[1] | VS1[0] | |
| VHF Parallel Y-Intercept | 0x3 | VP0[7] | VP0[6] | VP0[5] | VP0[4] | VP0[3] | VP0[2] | VP0[1] | VP0[0] | |
| VHF Parallel Slope | 0x4 | VP1[7] | VP1[6] | VP1[5] | VP1[4] | VP1[3] | VP1[2] | VP1[1] | VP1[0] | |
| UHF Series Y-Intercept | 0x5 | US0[7] | US0[6] | US0[5] | US0[4] | US0[3] | US0[2] | US0[1] | US0[0] | |
| UHF Series Slope | 0x6 | US1[7] | US1[6] | US1[5] | US1[4] | US1[3] | US1[2] | US1[1] | US1[0] | |
| UHF Parallel Y-Intercept | 0x7 | UP0[7] | UP0[6] | UP0[5] | UP0[4] | UP0[3] | UP0[2] | UP0[1] | UP0[0] | |
| UHF Parallel Slope | 0x8 | UP1[7] | UP1[6] | UP1[5] | UP1[4] | UP1[3] | UP1[2] | UP1[1] | UP1[0] | |

Complete Single-Conversion Television Tuner

Once the address has been programmed, the data stored in that address is transferred to the TFR[7:0] bits in the ROM Table Data Readback register (Table 13). The ROM data at the specified address can then be read from the TFR[7:0] bits and stored in the micro-processor's local memory.

Interpolating Tracking Filter Coefficients

The TFS[7:0] and TFP[5:0] bits must be reprogrammed for each channel frequency to optimize performance. The optimal settings for each channel can be calculated from the ROM table data using the equations below:

VHF filter:

$$TFS = \text{INT}[10 \left[\frac{VS0}{256} \times 5 + \left(\frac{VS1}{256} - 1 \right) \times 1.5 \times 10^{-2} \times f_{RF} \right]]$$

$$TFP = \text{INT}[10 \left[\frac{VP0}{256} \times 5 + \left(\frac{VP1}{256} - 1 \right) \times 10^{-2} \times f_{RF} \right]]$$

UHF filter:

$$TFS = \text{INT}[10 \left[\frac{US0}{256} \times 5 + \left(\frac{US1}{256} - 1 \right) \times 5 \times 10^{-3} \times f_{RF} \right]] - 10$$

$$TFP = \text{INT}[10 \left[\frac{UP0}{256} \times 5 + \left(\frac{UP1}{256} - 1 \right) \times 5 \times 10^{-3} \times f_{RF} \right]]$$

where:

f_{RF} = operating frequency in megahertz.

TFS = decimal value of the optimal TFS[7:0] setting (Table 9) for the given operating frequency.

TFP = decimal value of the optimal TFP[5:0] setting (Table 10) for the given operating frequency.

VS0, VS1, VP0, VP1, US0, US1, UP0, and UP1 = the decimal values of the ROM table coefficients (Table 16).

IF Overload Detector

The MAX3541 includes a broadband IF overload detector, which provides an indication of the total power present at the RF input. The overload-detector output voltage is compared to a reference voltage, and the difference is amplified. This error signal drives an open-collector transistor whose collector is connected to the IFOVLD pin, causing the IFOVLD pin to sink current. The nominal full-scale current sunk by the IFOVLD pin is 300 μ A. The IFOVLD pin requires a 10k Ω pullup resistor to VCC.

The IF overload detector is calibrated at the factory to attack at 0.7V_{P-P} at the IFOUT1. Upon power-up, the baseband processor must read OD[2:0] from the ROM table and store it in the IFVOLD register.

Closed-Loop RF Gain Control

Closed-loop RF gain control can be implemented by connecting the IFOVLD output to the RFAGC input. Using a 10k Ω pullup resistor on the IFOVLD pin as shown in the *Typical Application Circuit* results in a nominal control voltage range of 0.5V to 3V.

VCO and VCO Divider Selection

The MAX3541 frequency synthesizer includes three VCOs and eight VCO sub-bands to guarantee a 2200MHz to 4400MHz VCO frequency range. The frequency synthesizer also features an additional VCO frequency divider that must be programmed to either 4, 8, 16, or 32 by the VDIV[1:0] bits in the VCO register based on the channel being received.

To ensure PLL lock, the proper VCO and VCO sub-band for the channel being received must be chosen by iteratively selecting a VCO and VCO sub-band, then reading the LD[2:0] bits to determine if the PLL is locked. Any reading from 001 to 110 indicates the PLL is locked. If LD[2:0] reads 000, the PLL is unlocked and the selected VCO is at the bottom of its tuning range; a lower VCO sub-band must be selected. If LD[2:0] reads 111, the PLL is unlocked and the selected VCO is at the top of its tuning range; a higher VCO sub-band must be selected. The VCO and VCO sub-band settings should be progressively increased or decreased until the LD[2:0] reading falls in the 001 to 110 range.

Due to overlap between VCO sub-band frequencies, it is possible that multiple VCO settings can be used to tune to the same channel frequency. System performance at a given channel should be similar between the various possible VCO settings, so it is sufficient to select the first VCO and VCO sub-band that provides lock.


Layout Considerations

The MAX3541 EV kit can serve as a guide for PCB layout. Keep RF signal lines as short as possible to minimize losses and radiation. Use controlled impedance on all high-frequency traces. The exposed paddle must be soldered evenly to the board's ground plane for proper operation. Use abundant vias beneath the exposed paddle for maximum heat dissipation. Use abundant ground vias between RF traces to minimize undesired coupling.

To minimize coupling between different sections of the IC, the ideal power-supply layout is a star configuration, which has a large decoupling capacitor at the central VCC node. The VCC traces branch out from this node, with each trace going to separate VCC pins of the MAX3541. Each VCC pin must have a bypass capacitor with a low impedance to ground at the frequency of interest. Do not share ground vias among multiple connections to the PCB ground plane.

Complete Single-Conversion Television Tuner

Typical Application Circuit



Package Information

For the latest package outline information and land patterns (footprints), go to www.maxim-ic.com/packages. Note that a "+", "#", or "-" in the package code indicates RoHS status only. Package drawings may show a different suffix character, but the drawing pertains to the package regardless of RoHS status.

| PACKAGE TYPE | PACKAGE CODE | OUTLINE NO. | LAND PATTERN NO. |
|--------------|--------------|-------------------------|-------------------------|
| 48 LGA-EP | L4877F+15 | 21-0152 | 90-0303 |

Complete Single-Conversion Television Tuner

Revision History

| REVISION NUMBER | REVISION DATE | DESCRIPTION | PAGES CHANGED |
|-----------------|---------------|---|---------------|
| 0 | 10/07 | Initial release | — |
| 1 | 12/07 | Correct TOC01 graph and a few errors | 1, 2, 5, 7 |
| 2 | 4/08 | Converted part number in <i>Ordering Information</i> to lead-free | 1 |
| 3 | 2/11 | Corrected soldering temperature and lead temperature in <i>Absolute Maximum Ratings</i> | 2 |

MAX3541

Maxim cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim product. No circuit patent licenses are implied. Maxim reserves the right to change the circuitry and specifications without notice at any time.

Maxim Integrated Products, 120 San Gabriel Drive, Sunnyvale, CA 94086 408-737-7600 _____ 19

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Maxim Integrated:](#)

[MAX3541ELM+T](#) [MAX3541ELM+](#)