

MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

www.mikroe.com

# **CAN FD 3 Click**





PID: MIKROE-3992

**CAN FD 3 Click** is a add-on board based on TLE9251V CAN network transceiver, designed for HS CAN networks up to 5 Mbit/s in automotive and industrial applications. As an interface between the physical bus layer and the CAN protocol controller, the TLE9251V drives the signals to the bus and protects the microcontroller against interferences generated within the network. Given all the features its components offer, the CAN FD Click is best used for for infotainment applications, gateway modules, body control modules (BCM) or engine control units (ECUs).

CAN FD 3 Click board  $^{\text{\tiny TM}}$  is supported by a mikroSDK compliant library, which includes functions that simplify software development. This Click board  $^{\text{\tiny TM}}$  comes as a fully tested product, ready to be used on a system equipped with the mikroBUS  $^{\text{\tiny TM}}$  socket.

#### How does it work?

CAN FD 3 Click features <u>TLE9251V</u>, a High-Speed CAN transceiver operating as an interface between the CAN controller and the physical bus medium, from <u>Infenion</u>. A HS CAN network is a two wire, differential network which allows data transmission rates up to 5 MBit/s. The characteristic for a HS CAN network are the two signal states on the CAN bus: dominant and recessive. The CANH and CANL pins are the interface to the CAN bus and operate as an input and output. The RxD and TxD pins are the interface to the microcontroller. The TxD pin is the serial data input from the CAN controller. The RxD pin is the serial data output to the CAN controller. The HS CAN transceiver TLE9251V includes a receiver and a transmitter unit, allowing the transceiver to send data to the bus medium and monitors the data from the bus medium at the same time.

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.






health and safety management system.



MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com www.mikroe.com



The HS CAN transceiver TLE9251V converts the serial data stream which is available on the transmit data input TxD, into a differential output signal on the CAN bus, provided by the CANH and CANL pins. The receiver stage of the TLE9251V monitors the data on the CAN bus and converts it to a serial, single-ended signal on the RxD output pin. A logical "low" signal on the TxD pin creates a dominant signal on the CAN bus, followed by a logical "low" signal on the RxD pin. The feature, broadcasting data to the CAN bus and listening to the data traffic on the CAN bus simultaneously is essential to support the bit-to-bit arbitration within CAN networks.

The CAN FD 3 Click after powering up, the device enters one out of three operating modes.

Depending on the condition of the transmitter supply voltage VCC and the mode selection pin STB the device can enter every mode of operation after the power-up:

- VCC is available and STB input is set to "low" Normal-operating mode
- VCC is disabled and the STB input is set to "low" Forced-receive-only mode
- STB input is set to "high" Stand-by mode

Based on the high symmetry of the CANH and CANL output signals, the TLE9251V provides a very low level of electromagnetic emission (EME) within a wide frequency range. The TLE9251V fulfills even stringent EMC test limits without additional external circuit, like a common mode choke for example.

In Power On Reset all functions of the TLE9251V are disabled and the device is switched off.

The TLE9251V has an integrated overtemperature detection to protect the TLE9251V against thermal overstress of the transmitter. The overtemperature protection is active in Normaloperating Mode and is disabled in all other Modes. The temperature sensor provides one temperature threshold: TJSD.When the temperature exceeds the threshold TJSD the transmitter is disabled. This overtemperature event will be signaled as logical "low" on the ERR output pin in Normal-operating Mode. After the device has cooled down, the transmitter is re-enabled and NERR returns to logical "high". A hysteresis is implemented within the temperature sensor.

Given all the features its components offer, the CAN FD Click is best used for for infotainment applications, cluster modules, radar applications and HVAC. The onboard SMD jumper labeled as the VIO SEL is used to select which voltage rail will be used as the logic voltage level. It offers voltage selection between 3.3V and 5V so that the click board™ can be interfaced with both the 3.3V and 5V capable MCUs. The two UART wires (RX and TX) can also be connected

Mikroe produces entire development toolchains for all major microcontroller architectures. Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.





MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com

www.mikroe.com

directly through two pins on the left edge of the board.

## **Specifications**

Туре	CAN,CAN FD
Applications	CAN FD Click is best used for for infotainment applications, gateway modules, body control modules (BCM) or engine control units (ECUs).
On-board modules	On-board modules TLE9251V, a transceiver designed for HS CAN networks up to 5 Mbit/s in automotive and industrial applications from Infineon
Key Features	Key Features Very low electromagnetic emission (EME) for chokeless usage, Dual Power Supply Solution
Interface	UART
Feature	No ClickID
Compatibility	mikroBUS™
Click board size	L (57.15 x 25.4 mm)
Input Voltage	3.3V or 5V

## **Pinout diagram**

This table shows how the pinout on CAN FD 3 Click corresponds to the pinout on the  $mikroBUS^{m}$  socket (the latter shown in the two middle columns).

Notes	Pin	mikro™ BUS				Pin	Notes
	NC	1	AN	PWM	16	NC	
	NC	2	RST	INT	15	NC	
Chip Select	CS	3	CS	RX	14	TX	UART Transmit
	NC	4	SCK	TX	13	RX	UART Transmit
	NC	5	MISO	SCL	12	NC	I2C Clock
	NC	6	MOSI	SDA	11	NC	I2C Data
Power Supply	3.3V	7	3.3V	5V	10	5V	Power Supply
Ground	GND	8	GND	GND	9	GND	Ground

## **Onboard settings and indicators**

Label	Name	Default	Description
LD1	PWR	-	Power LED Indicator
J1	-	-	CAN lines solder pads
J2	-	-	UART lines solder pads
JP1	VIO SEL	Left	VIO Voltage select

### **Software Support**

Mikroe produces entire development toolchains for all major microcontroller architectures. Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.







MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918 Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com www.mikroe.com

We provide a library for the CAN FD 3 Click on our LibStock page, as well as a demo application (example), developed using MikroElektronika compilers. The demo can run on all the main MikroElektronika development boards.

#### **Library Description**

Library provides functions for communication via UART module, and a function for controlling cs pin, which sets device mode.

#### Key functions:

- void canfd3 write byte ( uint8 t input ) Writes single byte of data
- uint8 t canfd3 read byte() Reads single byte of data
- uint8 t canfd3 byte ready ( ) Checks if new data ic received
- void canfd3 set cs pin ( uint8 t mode ) Sets state of the CS pin

#### **Examples description**

The application is composed of three sections:

- System Initialization Intializes UART module
- Application Initialization Driver intialization
- Application Task Choose one mode (read or write) of task. If you reading it checks if data is ready to be read and then reads one byte and if you are wiriting send data via UART.

The full application code, and ready to use projects can be found on our <u>LibStock</u> page.

Other mikroE Libraries used in the example:

• UART

#### Additional notes and informations

Depending on the development board you are using, you may need <u>USB UART click</u>, <u>USB UART</u> 2 click or RS232 click to connect to your PC, for development systems with no UART to USB interface available on the board. The terminal available in all MikroElektronika compilers, or any other terminal application of your choice, can be used to read the message.

#### mikroSDK

This Click board™ is supported with mikroSDK - MikroElektronika Software Development Kit. To ensure proper operation of mikroSDK compliant Click board<sup>™</sup> demo applications, mikroSDK should be downloaded from the LibStock and installed for the compiler you are using.

For more information about mikroSDK, visit the official page.

management system.

health and safety management system.

#### Resources

<u>mikroBUS™</u>

**mikroSDK** 









MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918

Phone: + 381 1178 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com www.mikroe.com

Click board™ Catalog

Click Boards™

#### **Downloads**

CAN FD 3 click example on Libstock

**CAN FD 3 click schematic** 

TLE9251V datasheet

CAN FD 3 click 2D and 3D files

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.





## **Mouser Electronics**

**Authorized Distributor** 

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Mikroe:

MIKROE-3992