

MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918 Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com www.mikroe.com

# Stepper 14 Click





PID: MIKROE-4125

The **Stepper 14 Click** is a Click board<sup>™</sup> that features the <u>DRV8847PWPR</u>, a step motor driver, from <u>Texas Instruments</u>. This Click board<sup>™</sup> provides a bipolar step motor controle, It features an H-bridge bipolar step motor driver, which supports full-, half-, quarter-, or eighthstep modes. This click board<sup>™</sup> also carries a port expander so that the communication can be done with a minimal number of pins, through the mikroBUS<sup>™</sup> I2C bus. This click board<sup>™</sup> offers thermal protection, integrated kickback voltage protection, it has a wide range of input voltage, protection against current shoot-through the H-Bridge and high current capability. These features make Stepper 14 click an ideal solution for driving motors in any application that demands a precise and safe step motor driver.

Stepper 14 click is supported by a mikroSDK compliant library, which includes functions that simplify software development. This Click board<sup>™</sup> comes as a fully tested product, ready to be used on a system equipped with the mikroBUS<sup>™</sup> socket.

## How does it work?

This click board<sup>™</sup> is equipped with two integrated circuits. The step motor driver IC is the DRV8847PWPR, a dual full-bridge motor driver from Texas Instruments. This IC internal structure is somewhat symmetrical. It features two MOSFET H-bridges used to drive two coils of a bipolar step motor in both directions. The DRV8847PWPR uses a wide input voltage range from 2.7V to 18V. This is the voltage used to energize the motor coils. A jumper (JP4) is used to select whether to use external power supply or to obtain the power supply from the mikroBUS<sup>™</sup> +3.3V or +5V rail. The DRV8847PWPR has two PHASE inputs which are used to control the direction of current flow through H-bridges and thus, the motor coils. It also allows controlling step motor in both full step and half step modes, by toggling states on MS1 and MS1 Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.



ISO 27001: 2013 certification of informational security management system. ISO 14001: 2015 certification of environmental management system. OHSAS 18001: 2008 certification of occupational health and safety management system.





MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918 Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com www.mikroe.com

pins.



The bipolar step motor coils can be connected to the onboard screw terminals. There are two terminals, used to connect each of the step motor coils. The third connector is used to connect an external voltage, ranging from 2.7V to 18V, depending on the used motor voltage requirements. It should be noted that without a valid external voltage connected to this terminal, the motor will not work. Also, it should be noted that 20V is an absolute maximum voltage allowed as per datasheet, thus the overtemperature protection might be activated when driving heavier loads. The recommended maximum voltage should not exceed 18V, as stated on the silkscreen layer of the PCB.

All of the DRV8847PWPR control lines are routed to the second IC on Stepper 14 board, which is the PCA9538A, a well-known 8bit I/O expander with a serial interface, used on many of the MikroElektronika's designs for its simplicity and reliability. It allows the control lines of the DRV8847PWPR IC to be driven via the I2C and few pins it uses - reducing the required pin count of the Stepper 14 click. This also allows for sending compact I2C messages, instead of toggling several pins at once - which can introduce problems with timing sometimes, especially when those pins belong to different MCU ports. By changing states of the six control pins, it is possible to drive the step motor in full step mode as well as the half step mode. However, provided MikroElektronika libraries contain simple and intuitive functions to fully control the bipolar step motor, connected to Stepper 14 click. Their usage is demonstrated in the included example application, which can be used as a reference for a custom design.

The motor power supply can be connected to the input terminal labeled as VIN and should be within the range of 2.7V to 18V. Stepper motor coils can be connected to the terminals labeled as A1, B2, B1, and A2. The Click board<sup>™</sup> supports an optional external power supply for the motor in order to work.

However, this Click board<sup>™</sup> can be supplied and interfaced with both 3.3V and 5V without the need for any external components. The onboard SMD jumper labeled as VCC SEL allows voltage selection for interfacing with both 3.3V and 5V microcontrollers.

## Specifications



MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918 Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com www.mikroe.com

Applications	Refrigerator damper and ice maker, Washers, dryers and dishwashers, Electronic point-of- sale (ePOS) printers , Stage lighting equipment, Miniature circuit breakers and smart meters etc.
On-board modules	DRV8847PWPR Dual Full-Bridge 18V, 1A, Stepper Motor Driver, from Texas Instruments; PCA9538A 8bit I/O Expander with Serial Interface, from NXP
Key Features	Dual H-bridge motor driver, Single or dual brushed DC motors, One bipolar stepper motor, Solenoid loads, Multiple control interface options.
Interface	GPIO,I2C
Feature	No ClickID
Compatibility	mikroBUS™
Click board size	M (42.9 x 25.4 mm)
Input Voltage	3.3V or 5V

## **Pinout diagram**

This table shows how the pinout on Stepper 14 Click corresponds to the pinout on the mikroBUS<sup>m</sup> socket (the latter shown in the two middle columns).

Notes	Pin	● ● mikro* ● ● ● BUS			TN-	Pin	Notes	
	NC	1	AN	PWM	16	NC		
Reset In	RST	2	RST	INT	15	FLT	Fault	
Enable	EN	3	CS	RX	14	NC		
	NC	4	SCK	TX	13	NC		
	NC	5	MISO	SCL	12	SCL	I2C Clock	
	NC	6	MOSI	SDA	11	SDA	I2C Data	
Power Supply	3.3V	7	3.3V	5V	10	5V	Power Supply	
Ground	GND	8	GND	GND	9	GND	Ground	

## **Onboard settings and indicators**

Label	Name	Default	Description
LD1	PWR	-	Power LED Indicator
JP1	VCC SEL	Left	Power Supply Voltage Selection: Left position 3V3, right position 5V
JP2	ADDR SEL	Left	Slave address selection: Left position 0, right position 1.
JP3	ADDR SEL	Left	Slave address selection: Left position 0, right position 1.

Mikroe produces enrire development rooicnains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.



ISO 27001: 2013 certification of informational security management system. ISO 14001: 2015 certification of environmental management system. OHSAS 18001: 2008 certification of occupational health and safety management system.





MIKROELEKTRONIKA D.O.O, Batajnički drum 23, 11000 Belgrade, Serbia VAT: SR105917343 Registration No. 20490918 Phone: + 381 11 78 57 600 Fax: + 381 11 63 09 644 E-mail: office@mikroe.com www.mikroe.com

JP4	VM SEL	Left	Power select jumper
			for motor power
			supply: left position -
			On-board supply, right
			position - External
			supply.

## **Stepper 14 Click electrical specifications**

Description	Min	Тур	Max	Unit
Input Voltage	2.7	-	18	V
Output current	-	-	1	A

## Software Support

We provide a library for the Stepper 14 Click as well as a demo application (example), developed using MIKROE <u>compilers</u>. The demo can run on all the main MIKROE <u>development</u> <u>boards</u>.

Package can be downloaded/installed directly from NECTO Studio Package Manager (recommended), downloaded from our LibStock<sup>™</sup> or found on MIKROE github account.

#### **Library Description**

This library contains API for Stepper 14 Click driver.

Key functions

- stepper14\_set\_direction This function sets the motor direction to clockwise or counterclockwise in ctx->direction.
- stepper14\_set\_step\_mode This function sets the step mode resolution settings in ctx->step\_mode.
- stepper14\_drive\_motor This function drives the motor for the specific number of steps at the selected speed.

#### **Example Description**

This example demonstrates the use of the Stepper 14 Click by driving the motor in both directions for a desired number of steps.

The full application code, and ready to use projects can be installed directly from NECTO Studio Package Manager (recommended), downloaded from our LibStock<sup>™</sup> or found on MIKROE github account.

Other MIKROE Libraries used in the example:

- MikroSDK.Board
- MikroSDK.Log
- Click.Stepper14

Mikroe produces entire development toolchains for all major microcontroller architectures. Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.



ISO 27001: 2013 certification of informational security management system. ISO 14001: 2015 certification of environmental management system. OHSAS 18001: 2008 certification of occupational health and safety management system.





#### Additional notes and informations

Depending on the development board you are using, you may need <u>USB UART click</u>, <u>USB UART</u> <u>2 Click</u> or <u>RS232 Click</u> to connect to your PC, for development systems with no UART to USB interface available on the board. UART terminal is available in all MIKROE <u>compilers</u>.

## mikroSDK

This Click board<sup> $\mathbb{M}$ </sup> is supported with <u>mikroSDK</u> - MIKROE Software Development Kit. To ensure proper operation of mikroSDK compliant Click board<sup> $\mathbb{M}$ </sup> demo applications, mikroSDK should be downloaded from the <u>LibStock</u> and installed for the compiler you are using.

For more information about mikroSDK, visit the <u>official page</u>.

#### Resources

<u>mikroBUS™</u>

<u>mikroSDK</u>

Click board<sup>™</sup> Catalog

Click Boards™

## **Downloads**

Stepper 14 click 2D and 3D files v100

PCA9538A datasheet

DRV8847 datasheet

Stepper 14 click example on Libstock

Stepper 14 click schematic v100

Mikroe produces entire development toolchains for all major microcontroller architectures.

Committed to excellency, we are dedicated to helping engineers bring the project development up to speed and achieve outstanding results.



ISO 27001: 2013 certification of informational security management system. ISO 14001: 2015 certification of environmental management system. OHSAS 18001: 2008 certification of occupational health and safety management system.



## **Mouser Electronics**

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Mikroe:

MIKROE-4125