



IQS7211AEV02A USER GUIDE

IQ Switch® - ProxFusion® Series








Table of Contents

IQS	IQS7211AEV02A USER GUIDE1					
1	INTRODUCTION	. 3				
2	STAMPS	. 4				
3	TRACKPAD CAREFUL CONSIDERATION	. 6				
4	SETTING UP FOR THE IQS7211A RECTANGLE TRACKPAD	. 7				
5	SETTING UP FOR THE IQS7211A FLOWER TRACKPAD	. 8				
6	REFERENCE DESIGNS	a				






1 Introduction

This user guide describes the operation of the IQS7211AEV02A Evaluation Kit. The EV-Kit consists of five parts:

- IQS7211A Rectangle Trackpad x 1
- IQS7211A Flower Trackpad x 1
- CT210A x 1
- > IQS7211A Stamp x 2
- > IQS721XY IC x 5

To visualise raw data from the EV-Kit, the Trackpad board can be interfaced to any personal computer with USB support, along with the CT210A and the relevant IQS7211A software Graphical User Interface (GUI) available to download from the Azoteq website. The purpose of the IQS7211AEV02A EV-Kit is to help application and development engineers in evaluating this IC's capabilities. A picture of the evaluation kit is shown below.







2 Stamps

To interface the IQS7211A Stamp to a PC we advise using the CT210A. This EV Kit can be setup with the following steps:

- Download & Install GUI from Azoteq website
- Plug the stamp board into the CT210A as shown below










- Connect the CT210A to the PC with a USB cable (use USB data cable only)
- Run the IQS7211A GUI (latest version available from the www.azoteq.com website)
- Click "Start Streaming" button
- GUI should look as follow.








3 Trackpad Careful Consideration

Please note following picture when Flower Trackpad and Rectangle Trackpad modules are plugged into the CT210A.

Take care in ensuring pin alignment is correct as shown in picture below.

The pin on the right must line up directly below the black triangle (shown below as white triangle to clearly indicate) on the CT210A.








4 Setting up for the IQS7211A Rectangle Trackpad

To interface the IQS7211A Rectangle Trackpad to a PC we advise using the CT210A. This EV Kit can be setup with the following steps:

- Download GUI and Header files from Azoteq website
 - azoteq_iqs7211a_setup.zip
 - o iqs7211a_header_files.zip
- Install GUI on PC
- Unzip iqs7211a header files.zip file to obtain header files
- ➢ Plug the Trackpad into the CT210A (Please ensure pin 1 from Trackpad module line-up with black triangle as shown earlier)
- Connect the CT210A to the PC with a USB cable (use USB data cable only)
- > Run the IQS7211A GUI (latest version available from the www.azoteq.com website)
- Click "Start Streaming" button
- ➢ Click "IMPORT H FILE"
- Browse to "IQS7211A Rectangle Trackpad.h" file and click Open
- ➢ Click "ACK RESET"
- Click "TRACKPAD RE-ATI"
- GUI should look as follow.




Trackpad is now active to be evaluated.



5 Setting up for the IQS7211A Flower Trackpad

To interface the IQS7211A Flower Trackpad to a PC we advise using the CT210A. This EV Kit can be setup with the following steps:

- Download GUI and Header files from Azoteq website
 - azoteq iqs7211a setup.zip
 - o iqs7211a_header_files.zip
- Install GUI on PC
- Unzip iqs7211a header files.zip file to obtain header files
- ➢ Plug the Trackpad into the CT210A (Please ensure pin 1 from Trackpad module line-up with black triangle as shown earlier)
- Connect the CT210A to the PC with a USB cable (use USB data cable only)
- > Run the IQS7211A GUI (latest version available from the www.azoteq.com website)
- Click "Start Streaming" button
- Click "IMPORT H FILE"
- Browse to "IQS7211A Flower Trackpad.h" file and click Open
- ➢ Click "ACK RESET"
- Click "TRACKPAD RE-ATI"
- GUI should look as follow.



Trackpad is now active to be evaluated.



6 Reference Designs




Figure 6-1 IQS7211A Rectangle Trackpad Layout






Figure 6-2 IQS7211A Flower Trackpad Layout








Figure 3 IQS7211A QFN20 Stamp Layout





	USA	Asia	South Africa
Physical	11940 Jollyville	Room 501A, Block A,	1 Bergsig Avenue
Address	Suite 120-S	T-Share International Centre,	Paarl 7646
	Austin	Taoyuan Road, Nanshan District,	South Africa
	TX 78750	Shenzhen, Guangdong, PRC	
	USA		
Postal	11940 Jollyville	Room 501A, Block A,	PO Box 3534 Paarl 7620
Address	Suite 120-S	T-Share International Centre,	
	Austin	Taoyuan Road, Nanshan District,	South Africa
	TX 78750	Shenzhen, Guangdong, PRC	
	USA		
Tel	+1 512 538 1995	+86 755 8303 5294	+27 21 863 0033
		ext 808	
Email	info@azoteq.com	info@azoteq.com	info@azoteq.com

Visit www.azoteq.com for a list of distributors and worldwide representation.

Patents as listed on www.azoteq.com/patents-trademarks/ may relate to the device or usage of the device.

Azoteq®, Crystal Driver®, IQ Switch®, ProxSense®, ProxFusion®, LightSense™, SwipeSwitch™, and the logo are trademarks of Azoteq.



The information in this Datasheet is believed to be accurate at the time of publication. Azoteq uses reasonable effort to maintain the information up-to-date and accurate, but does not warrant the accuracy, completeness or reliability of the information contained herein. All content and information are provided on an "as is" basis only, without any representations or warranties, express or implied, of any kind, including representations about the suitability of these products or information for any purpose. Azoteq disclaims all warranties and conditions with regard to these products and information, including but not limited to all implied warranties and conditions of merchantability, fitness for a particular purpose, title conditions with regard to these products and information, including but not limited to all implied warranties and conditions of merchantability, fitness for a particular purpose, title and non-infringement of any third party intellectual property rights. Azoteq assumes no liability for any damages or injury arising from any use of the information or the product or caused by, without limitation, failure of performance, error, omission, interruption, defect, delay in operation or transmission, even if Azoteq has been advised of the possibility of such damages. The applications mentioned herein are used solely for the purpose of illustration and Azoteq makes no warranty or representation that such applications will be suitable without further modification, nor recommends the use of its products for application that may present a risk to human life due to malfunction or otherwise. Azoteq products are not authorized for use as critical components in life support devices or systems. No licenses to patents are granted, implicitly, express or implied, by estoppel or otherwise, under any intellectual property rights. In the event that any of the abovementioned limitations or exclusions does not apply, it is agreed that Azoteq's total liability for all losses, damages and causes of action (in contract, tort (including without limitation, negligence) or otherwise) will not exceed the amount already paid by the customer for the products. Azoteq reserves the right to alter its products, to make corrections, deletions, modifications, enhancements, improvements and other changes to the content and information, its products, programs and services at any time or to move or discontinue any contents, products, programs or services without prior notification. For the most up-to-date information and binding Terms and Conditions please refer to www.azoteq.com.

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Azoteq:

IQS7211AEV02A-S