


# **RF Monolithics, Inc.**

## **XG2510HE Gateway/Manager Hardware and Configuration Guide**

**WirelessHART®**



---

# Contents

## About This Guide

<b>Related Documents</b> .....	iii
<b>Conventions Used</b> .....	iii

## 1 Introduction

<b>What is a SmartMesh Network?</b> .....	1
SmartMesh Network Features .....	2
XG2510HE Gateway/Manager's Role .....	2
<b>XG2510HE Packing List</b> .....	3
<b>XG2510HE Overview</b> .....	3
10/100Base-T Ethernet Interface .....	4
Serial 1 Interface .....	5
Serial 2 Interface .....	6

## 2 Specifications

<b>Detailed Radio Specifications</b> .....	7
<b>Antenna Specifications</b> .....	8
<b>Power Supply</b> .....	8
<b>Mechanical Drawings</b> .....	9
<b>Regulatory and Standards Compliance</b> .....	10
<b>Normal Operating Conditions</b> .....	10

## **3 Installing the XG2510HE**

<b>Ports Used by the XG2510HE .....</b>	<b>11</b>
<b>Connecting the XG2510HE Directly to a Computer .....</b>	<b>12</b>
<b>Installing the XG2510HE on a LAN .....</b>	<b>13</b>

## **A Configuring Serial 1 Operation**

<b>Configuring the Serial 1 Interface .....</b>	<b>15</b>
Using Admin Toolset to Configure Serial 1 .....	15
Using Linux Commands to Configure Serial 1 .....	17

## **B Assembling a 9-pin D-SUB Adapter for Serial 1**

## **C Restoring XG2510HE Factory Default Settings**

# About This Guide

This guide provides an overview of the hardware and software resources of the XG2510HE WirelessHART gateway/network manager. The guide also includes specifications and configuration information.

## Related Documents

This guide is a part of a documentation suite for the XG2510HE gateway/manager. The following documents contain additional information to support software and firmware development for use with an XG2510HE gateway/manager:

- *XG2510HE Gateway/Manager Serial API Guide* - provides information about manager's packet-based API and instructions on configuring the serial port application function.
- *XG2510HE Gateway/Manager XML API Guide* - provides information about manager's hierarchical tag-based XML API.
- *XG2510HE Gateway/Manager CLI Commands Guide* - describes manager's CLI commands, used for debugging and troubleshooting.

## Conventions Used

The following conventions are used in this guide:

- `Computer` type indicates information that you enter, such as specifying a URL.
- **Bold type** indicates buttons, fields, and menu commands.
- *Italic type* is used to introduce a new term.

**Note:** Notes provide more detailed information about concepts.

**Caution:** Cautions advise you about actions that might result in a loss of data.

**Warning!** Warnings advise you about actions that may cause physical harm to the hardware or your person.

WirelessHART® is a registered trademark of the HART Communication Foundation.  
SmartMesh IA-510(H)<sup>TM</sup> is a trademark of DUST Networks, Inc.



# Introduction

RFM's XG2510HE WirelessHART gateway/network manager is based on Dust Networks' SmartMesh IA-510(H)<sup>TM</sup> protocol. The XG2510HE is designed to manage a network of RFM's XDM2510H radio modules that use Dust Networks' low power radio technology. In combination, these products provide carrier class data reliability, low latency, and deterministic power management that is required for the industrial automation market. The XG2510HE acts as both as a gateway and network manager for up to 250 XDM2510H modules (motest), creating a self-configuring, reliable wireless mesh network.

## What is a SmartMesh Network?

SmartMesh networks are reliable, ultra low-power wireless mesh networks that can be used for a wide variety of monitoring applications, including building automation, industrial monitoring, and remote site security. A SmartMesh network consists of a network manager and up to 250 low-power wireless transceivers that have connections for analog, digital, and serial sensors and actuators.




Figure 1 An XG2510HE - XDM2510H Network

- **XG2510HE Gateway/Manager** - a line powered network node that controls and monitors network performance. The XG2510HE coordinates routing, aggregates XDM2510H packets, collects network statistics, and publishes data to a wired network. The XG2510HE can publish data in XML format over the Ethernet port, or in serial format over the serial port.

- **XDM2510H modules** - ultra low-power wireless transceivers that receive serial data from attached sensors and use an onboard radio to send the packets to neighboring modules. These modules pass the packet on to other modules as needed, and, in a series of “hops” deliver the data to the manager. XDM2510H’s run SmartMesh software and are designed as simple-to-integrate wireless modules.

## SmartMesh Network Features

SmartMesh networks provide a simple, reliable way to monitor and control processes and equipment. Using redundant, multi-hop networking and ultra low-power hardware, SmartMesh networks offer unprecedented access to information about the physical world.

XG2510HE-XDM2510H SmartMesh networks are:

- **Easy to Install** - They are self-configuring, battery-powered networks that require no site survey or wireless expertise to install.

*Benefit:* You can deploy a SmartMesh Network within hours, not days.

- **Reliable** - They provide redundant, self-healing routing that approaches the reliability of a wired network.

*Benefit:* You have the reliability of a wired network with the flexibility of wireless.

- **Manageable** - They provide network-wide quality-of-service metrics and control commands that simplify network management.

*Benefit:* You can manage multiple networks from a single PC. No device-level coding or management is needed.

## XG2510HE Gateway/Manager’s Role

The XDM2510E gateway/manager provides configuration, management and gateway functionality for a network of XDM2510H transceiver modules. At its core, the XG2510HE utilizes a SmartMesh IA-510 embedded manager, which includes a wireless transceiver, processor and memory, embedded networking software, and multiple interfaces to host systems, including PPP and Ethernet.

XG2510HE gateway/managers host well defined application interfaces (via both XML API and serial API) that allow programmatic access to network control commands, performance statistics, and connectivity details. In addition, the XG2510HE offers administrative interfaces via its Web-based Admin Toolset utility and text-based command line interface (CLI).



## XG2510HE Packing List

The components shipped with the XG2510HE gateway/manager are listed in Table 1.

**Table 1 Packing List for the XG2510HE Manager**


Component	Amount	Description
XG2510HE	1	Controls and monitors the network.
Power cable	1	Connects the manager to an AC outlet.
International adapter kit	1	The kit includes power adapters for most countries.

## XG2510HE Overview

The XG2510HE provides a 10/100Base-T Ethernet interface and three serial interfaces, a power supply connector, and status LEDs, as shown in Figure 2. The data interfaces are described in detail in the following sections. For power supply specifications, refer to Chapter 2.

The status LEDs provide the following information:

- **Power (Green)** - The Power LED is on when the 12 V power supply provided with the D2511 is connected and functioning properly.
- **Subscription (Yellow)** - Indicates that a client program is subscribed to the manager via Ethernet or the Serial 1 interface.
- **Radio (Yellow)** - Blinks when there is data activity over the radio.



**Figure 2 XG2510HE Features**

## 10/100Base-T Ethernet Interface

The 10/100Base-T Ethernet interface is a standard RJ45 connector which provides users with access to manager's XML-RPC API and the Admin Toolset utility.

**Table 2 Ethernet Port Hardware Specifications**

Port	Description	Signaling
Ethernet	10/100Base-T Ethernet	IEEE 802.3 10/100Base-T

**Note:** The Ethernet interface must be connected *before* the XG2510HE is powered on in order for Linux to recognize the Ethernet port.


### XML-RPC API

The XML-RPC API is an open Extensible Markup Language (XML) interface that lets a client application send Remote Procedure Call (RPC) requests to the gateway/manager and receive responses and other data from the manager via XML-RPC. The API consists of a Control Channel and a Notification Channel. The Control Channel is used to establish connection and exchange commands and information about the SmartMesh Network. The Notification Channel is used to stream data and network events to the client program. The API is documented in the *XG2510HE Gateway/Manager XML API Guide*.

### Admin Toolset

The XG2510HE provides a Web-based administrative tool, called Admin Tool-set (see Figure 3), which can be used to view network statistics and module (mote) and alarm information, configure serial and Ethernet port settings, configure the Real Time Clock or enable the Network Time Protocol (NTP) server, set the network security mode, and execute selective commands. You can also use Admin Toolset to upgrade the software and perform remote software updates on XDM2510H modules in the wireless network. The Admin Toolset utility is described in detail in the *XG2510HE Gateway/Manager Admin Toolset Guide*.

**Figure 3 Admin Toolset**



## Serial 1 Interface

The Serial 1 interface (RJ45 connector) provides programmatic access for configuration, management, and data access to the XG2510HE. The interface can be used for one of two functions:


- To access the manager using Point-to-Point Protocol (PPP)
- To access the serial API associated with the XG2510HE

The following sections describe the Serial 1 functions in greater detail. Instructions for configuring the Serial 1 are provided Appendix A.

**Note:** An adapter is required for the Serial 1 interface if you are connecting to a PC or other control device that uses a 9-pin D-SUB RS232 port. See Appendix B for information on assembling an RJ45 to 9-pin D-SUB adapter.

**Table 3 Serial 1 Interface Hardware Specifications**

Port	Description	Signaling
Serial 1	UART 5-pin	RS232 levels



**Figure 4 RJ45 Connector**

**Table 4 RJ45 Connector Pinout**

Pin	Signal Name	Signal Description
1	RI	Ring Indicator
2	DCD	Carrier Detect
3	DTR	Data Terminal Ready
4	GND	Signal Ground Common
5	RXD	Receive Data
6	TXD	Transmit Data
7	CTS	Clear To Send
8	RTS	Request To Send

### PPP

The manager allows IP connection through the Serial 1 port using Point-to-Point Protocol (PPP). This connection provides access to the same interfaces that are available through the Ethernet interface, such as the XML API and the Admin Toolset utility. The manager acts as a PPP server. Note that the client is responsible for periodically pinging the XG2510HE and re-establishing PPP connection if necessary. Table 5 provides specifications for the PPP interface.

**Table 5 PPP Interface Specifications**

Parameter	Value
Serial port data rate	115 kbps, 8 bits, no parity, 1 stop bit
Authentication required	None
Header compression	PPP header compression
Data compression supported	PPP deflate compression (preferred), BSD compression
IP addresses	Settable during connection
Default XG2510HE (server)	192.168.101.10
Default client	192.168.101.11

### Serial API


The manager provides a packet-based serial API that allows communications over its asynchronous Serial 1 interface. For more information about the Serial API, refer to the *XG2510HE Gateway/Manager Serial API Guide*. See Appendix A in this guide for instructions on configuring the Serial 1 port for the Serial API.

## Serial 2 Interface

The Serial 2 interface (9-pin D-SUB female connector) allows access to manager's command line interface (CLI) through RS232. The CLI can be used to set the configuration of the Serial 1 interface and for troubleshooting with the assistance of RFM technical support. Appendix A provides instructions on using the CLI to set the Serial 1 configuration.

**Table 6 Serial 2 Port Hardware Specifications**

Port	Description	Signaling
Serial 2	UART 9-pin	RS232 levels

**Figure 5 9-pin D-SUB Female Connector**

## Serial 3 Interface

The Serial 3 interface is reserved for future use.

# Specifications

## 2

This chapter provides specifications, mechanical drawings and certification information for the XG2510HE gateway/manager.

## Detailed Radio Specifications

**Table 7 XG2510HE Radio Specifications**

Parameter	Min	Typ	Max	Units	Comments
Operating frequency	2.4000		2.4835	GHz	
Number of channels		15			
Channel separation		5		MHz	
Occupied channel bandwidth		2.7		MHz	At -20 dBc
Frequency accuracy	-40		+40	ppm	
Modulation					IEEE 802.15.4 DSSS
Raw data rate		250		kb/s	
Receiver operating input level		0		dBm	
Receiver sensitivity		-92.5 -90		dBm dBm	At 50% PER, 25 °C At 1% PER, 25 °C, (inferred from 50% PER measurement)
Output power, EIRP PA* enabled PA* disabled		+10 0		dBm dBm	See “Antenna Specifications”
Range** PA* enabled Indoor Outdoor PA* disabled Indoor Outdoor		 100 300  25 200		 m m  m m	25 °C, 50% RH, 1 meter above ground, +2 dBi omni-directional antenna
* PA = power amplifier ** Actual RF range performance is subject to a number of installation-specific variables including, but not restricted to ambient temperature, relative humidity, presence of active interference sources, line-of-sight obstacles, near-presence of objects (for example, trees, walls, signs) that may induce multipath fading. As a result, actual performance varies for each instance.					

## Antenna Specifications


The antenna provided on the XG2510HE gateway/manager meets the specifications in Table 8. For optimum performance, position the antenna vertically when gateway/manager is installed.

**Table 8 XG2510HE Antenna Specifications**

Parameter	Value
Frequency range	2.4-2.4835 GHz
Impedance	50 $\Omega$
Gain	+2 dBi maximum
Pattern	Omni-directional

## Power Supply

A universal power supply is included with each XG2510HE gateway/manager. The output of the transformer is 12 V at 1.1 Amps DC, and it is connected to + (positive) and -(ground) terminals of the connector. However, any DC supply with an output of 9 to 30 V at 0.5 Amps can be connected. A 24 VAC supply can be connected to the two right-most terminals of the connector (see Figure 6). The power supply connector uses a Phoenix PN 1757048 or equivalent mating connector.



**Figure 6 Power Supply Connector**

# Mechanical Drawings




Figure 7 Dimensions of the XG2510HE Manager

# Regulatory and Standards Compliance

## Installation and Operation

The antenna used for the XG2510HE transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operated in conjunction with any other antenna or transmitter. Installers and end-users must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

## FCC Compliance

### *FCC Testing*

The XG2510HE is certified as complying with Part 15.247 of FCC rules and regulations, CFR Title 47, Part 15, Subpart B.

## IC Compliance

### *IC Testing*

The XG2510HE is certified as complying with Industry Canada (IC) RSS-210 Regulations. The XG2510HE also complies with IC ICES-003.

## CE Compliance

### *Declaration of Conformity*

RF Monolithics, Inc., 4441 Sigma Road, Dallas, TX 76012, USA, declares that our product, the XG2510HE, and in combination with our accessories, to which this declaration relates is in conformity with the appropriate standards ETSI EN 300 328, ETSI EN 301 489-17, EN 60950, EN 55022 Class A, EN55024, EN61000-4-3, following the provisions of Radio Equipment and Telecommunication Terminal Equipment Directive 99/5/EC with requirements covering EMC Directive 2004/108/EC, and Low Voltage Directive 2006/95/EC.

### *Restrictions*

Norway prohibits operation in the 2.4000 GHz to 2.4835 GHz spectrum within 20 km of Ny-Alesund in Svalbard. The XG2510HE should not be operated in this region.

# Normal Operating Conditions

**Table 9 XG2510HE Normal Operating Conditions**

Parameter	Min	Typ	Max	Units	Comments
Operating temperature range	0		+70	°C	



# Installing the XG2510HE

## 3

The XG2510HE gateway/manager can be connected directly to a computer or installed on your local area network (LAN). The computer must have the following:

- Windows Internet Explorer 7 (or later) or Firefox 2.0 (or later)
- Java Runtime Environment (JRE) version 6 (or later)

The XG2510HE gateway/manager is preconfigured with network ID 1229. If you are already running another gateway/manager in the same area with the default network ID of 1229, you need to change the network ID of the existing network before installing the XG2510HE. For information on changing the network ID and using the XG2510HE supplied in the XDM2510H Development Kit, refer to the *XDM2510H Module Integration Guide*.

**Note:** The XG2510HE is not recommended for outdoor use because the enclosure is not weatherproof. Exposing the XG2510HE to moisture may cause permanent damage.

## Ports Used by the XG2510HE

The transmission control protocol (TCP) ports listed in Table 10 must be open to allow the Admin Toolset utilities to connect to the XG2510HE gateway/manager. These ports are restricted by default in the Windows XP firewall and some other operating systems. If you have difficulties connecting to the gateway/manager, consider temporarily disabling your Windows XP firewall in the Windows Control Panel.

**Table 10 Ports Used by Data Console and Admin Toolset**


Port #	Type	Description
4445	TCP	XML-RPC control channel.
24112	TCP	XML-RPC notification channel.
80	TCP	Used for http services. (Optional) A script redirects all traffic to the https port (443).
443	TCP	Used for https (secure http for a Web server).

## Connecting the XG2510HE to a Computer

The XG2510HE is preconfigured with the static IP address 192.168.99.100 for direct connection to a computer. You will temporarily set the computer IP address to a static IP address that enables the computer to communicate with the manager. The computer needs to have Windows Internet Explorer 7 (or later) or Firefox 2.0 (or later) installed.


### To connect the manager directly to a computer:

- A Use an Ethernet cross-over cable to connect the manager to your computer.



- B Connect the power cord to the manager and an AC outlet.  
The Power light on the manager turns on after a 20-second delay.
- C Set the computer IP address to a static address that will enable connection to the manager:
- On the **Start** menu, click **Control Panel**.
  - Double-click **Network Connections**.
  - Right-click **Local Area Connection**, and then click **Properties**.
  - Click **Internet Protocol (TCP/IP)**, and then click **Properties**.
  - Click **Use the following IP address**, and enter the following information:
    - **IP Address:** 192.168.99.101
    - **Subnet Mask:** 255.255.255.0

- f. Click **OK** to close the dialog boxes.




**Note:** When you are finished using the manager, you can switch your computer IP address back by selecting “Obtain an IP address automatically” on the General tab in the Internet Protocol (TCP/IP) Properties window.

## Installing the XG2510HE on a LAN

To install the XG2510HE gateway/manager on a LAN, you need to change the XG2510HE’s default static IP address to a LAN IP address. You can either configure the manager to use DHCP to obtain a LAN-assigned IP address, or assign a static LAN IP address to the XG2510HE. If you want to use a static LAN IP address, you will need to obtain this address from the LAN administrator.

### To connect to the manager over the LAN:


- A Use the serial DB9 cable to connect the XG2510HE to your computer.



- B Connect the power cord to the manager and an AC outlet.  
The Power light on the manager turns on after a 20-second delay.

- C Establish a HyperTerminal connection to the gateway/manager using the following settings:
- **Bits per second:** 115200
  - **Data bits:** 8
  - **Parity:** None
  - **Stop bits:** 1
  - **Flow control:** None
- D At the manager login, enter: `dust`
- E At the manager password, enter: `dust`
- F Connect the manager to the LAN using the Ethernet straight-through cable.
- G Configure the manager to use DHCP or assign a static LAN IP address:
- **DHCP** - To configure the manager to use DHCP, enter:  
`sudo ifswitch-to-dhcp`
- Note:** The manager must be connected to the LAN (step 6) before the `sudo ifswitch-to-dhcp` command is issued or an IP address will not be assigned to the manager by the DHCP server.
- **Static LAN IP address** - To configure the manager to use a static LAN IP address provided by your LAN administrator, enter:  
`sudo ifswitch-to-static <New Static IP Address>`  
(IP addresses format - `xxx.xxx.xxx.xxx`)
- H Verify that the manager's IP address has been changed by entering:  
`ifconfig`  
Then manager's new IP address should display.
- I Enter `logout` to close the HyperTerminal window.
- J Disconnect the manager from your computer and from AC power. Then reconnect the manager to AC power.  
The new IP address takes effect when the gateway/manager powers on again.

**Note:** If the gateway/manager is configured to use DHCP, it must always have an Ethernet connection to the LAN when it is powered on or reset or it will not receive a LAN IP address from the DHCP server. If you power on or reset the gateway/manager before connecting it to the LAN, you will need to establish a HyperTerminal connection to the gateway/manager and issue the `sudo ifswitch-to-dhcp` command to prompt the DHCP server to assign the manager a LAN IP address.





# Configuring Serial 1 Operation



The Serial 1 interface on manager can be used for a PPP, gateway/manager serial API, gateway/manager CLI, or Linux shell connection. Refer to the *XG2510HE Gateway/Manager Serial API Guide* for information on how to log into these processes.

This appendix provides instructions for configuring the Serial 1 interface using the Admin Toolset utility on the gateway/manager or with Linux commands.

## Configuring the Serial 1 Interface

To connect the Serial 1 interface to a PC or control device that uses a 9-pin D-SUB RS232 port, an RJ45 to 9-pin D-SUB adapter is required. Appendix B provides instructions for assembling the adapter.

**Note:** The Serial 1 interface is intended for local serial connections only. Because no authentication is performed, use it only in a trusted environment.

### Using Admin Toolset to Configure Serial 1

#### To configure Serial 1 for PPP:


- A Connect your computer to the XG2510HE gateway/manager:
  - If the gateway/manager is installed on the LAN, connect your computer to the LAN.
  - If the gateway/manager is not installed on the LAN, connect your computer directly to the gateway/manager using an Ethernet cross-over cable. The gateway/manager default IP address is 192.168.99.100. You can change your computer IP address to 192.168.99.101 to be compatible. For more information, see “Connecting the Manager Directly to a Computer” in Chapter 3.
- B Open Internet Explorer. In the URL address field, type in the IP address of the gateway/manager.



- C If a security alert displays indicating that there may be a problem with the site

security certificate, take the action required to proceed to the website (the site is secure).

- D Enter “system” as the username and the password.
- E Click the **Interfaces** link.



**Admin Toolset**

**Network**

- Status
- Topology Viewer
- Configuration
- Motes
- Security
- Alarms

**Manager**

- System Settings
- Interfaces
- Redundancy

**Maintenance**

- Commands
- System Software Update
- Mote Software Update

**Network Status**

System Name: Dust

Location: dust

Manager uptime: 6 days, 23:27:40

Manager Hardware Model: D2511

Manager Software Version: 2.1.1.55

Number of Live Motes: 40

Number of Unreachable Motes: 0

Number of Open Alarms: 0

**Network Statistics**

	Lifetime	Last Day	Last 15 minutes
Reliability:	100.00 %	99.99 %	100.00 %
Stability:	73.17 %	74.11 %	70.73 %
Latency:	831 ms	1081 ms	1066 ms

- F In the **Interfaces: Serial Port Settings** area, change the serial port settings (if necessary). If you are setting up a PPP connection, enter the local and remote PPP IP addresses.
- G **Note:** By default, the IP address of the manager over the PPP connection is 192.168.101.10 (local IP address), and the client PC's PPP IP address is 192.168.101.11 (remote IP address).

**Admin Toolset**

**Interfaces: Serial Port Settings**

Warning: If you are connected via PPP, clicking "Apply changes" may require you to reconnect to Admin Toolset using the new PPP settings.

Serial 1: Bits Per Second: 115200 Parity: None Stop Bits: 1 Flow Control: off

Serial 1 Mode: Login

PPP Local IP address: 192.168.101.10

PPP Remote IP address: 192.168.101.11

Apply Changes Clear Changes

**Interfaces: Ethernet**

Warning: Clicking "Apply Changes" may require you to reconnect to this Admin Toolset using the new IP settings.

Type of IP Address: ☒ Static ☐ DHCP

IP Address: 192.168.1.68

Subnet Mask: 255.255.255.0

Default Gateway: 192.168.1.1

Apply Changes Clear Changes



- H Click **Apply Changes**.

## Using Linux Commands to Configure Serial 1

### To configure Serial 1 for PPP using Linux:

- A Connect your computer serial port to the serial 2 port on the gateway/manager.  
or

Connect your computer to the LAN if the gateway/manager is on the LAN.

- B Open a Secure Shell connection to the gateway/manager (an SSH utility such as PuTTY can be used with a PC running Microsoft Windows).

- C At the login prompt, enter `dust` as the username and password.

- D To view the current serial port settings, enter:

```
cat/etc/ttyS1.conf
```

- E Use the following commands to change the port settings (if necessary):

```
sudo set-serial { -d <device> [-b <speed>] [-p <parity>]  
[-s <stopbits>] [-f <flow-control>] }
```

The command options are as follows:

**device:** `ttyS1`

**speed:** 4800, 9600, 19200, 38400, 57600, 115200, or 230400

**parity:** none, even, or odd

**stopbits:** 1 or 2

**flow-control:** on or off

The following are sample commands:

```
sudo set-serial -d ttyS1 -b 38400
```

```
sudo set-serial -d ttyS1 -b 115200
```

```
sudo set-serial -d ttyS1 -b 38400 -f off
```

- F If you are setting up a PPP connection, you can use the following command to change the local and remote PPP addresses:

```
sudo /usr/sbin/config-ppp -l <localAddress> -r <remoteAddress>
```

The following example changes the local PPP IP address to 192.168.101.14 and the remote PPP address to 192.168.101.15:

```
sudo /usr/sbin/config-ppp -l 192.168.101.14 -r 192.168.101.15
```


**Note:** By default, the IP address of the manager over the PPP connection is 192.168.101.10 (local IP address), and the client PC's PPP IP address is 192.168.101.11 (remote IP address).

- G To log out, enter: `logout`




# Assembling a 9-pin D-SUB Adapter for Serial 1

If you are connecting the Serial 1 interface on the gateway/manager to a 9-pin D-SUB RS232 port on a PC or control device, you need to use an RJ45 to 9-pin D-SUB RS232 adapter (see Figure 8).




**Figure 8 RJ45 to 9-pin D-SUB Adapter**

A crossover Ethernet cable is used to connect the Serial 1 interface to the adapter. The adapter in the following example is a female RJ45 to female 9-pin D-SUB. The arrows indicate how to match up the RJ45 and 9-pin D-SUB connector pins described in Table 11.



**Figure 9 Female RJ45 Connector**



**Figure 10 9-pin D-SUB Connector**

**Table 11 Matching Up RJ45 and 9-pin D-SUB Connector Pins**

RJ45 Pinout		9-pin D-SUB Pinout	
Pin	Signal Description	Pin	Signal Description
1	TX out of manager	1	Not connected
2	RTS out of manager	2	RXC
3	RX into manager	3	TXD
4	GND	4	Not connected
5	GND	5	GND
6	CTS into manager	6	Data Set Ready
7	Not connected	7	RTS
8	GND	8	CTS
		9	Not connected



# Restoring XG2510HE Factory Default Settings

C

Use the following procedure if you need to restore the factory default settings on the XG2510HE gateway/manager:

The following factory default settings are restored:

- IP address
- PPP settings
- Serial port settings
- User name and password
- Wireless network and mote configuration settings
- Wireless network ID and common join key
- Access control list (cleared)
- Log files (cleared)
- Mote list (cleared)

## To restore the manager's factory default settings:

- A Insert a jumbo paper clip into the **Mode** hole and gently press and hold down while you press and release the **Power** button. Continue holding the paper clip down for another 20 seconds, and then release.

The gateway/manager's factory default settings are restored.

**Note:** If the XG2510HE is configured for redundancy, you need to repeat step 1 after the gateway/manager restarts in order to fully restore the default settings.



- B To view the default settings, follow these steps to log onto the **Admin Toolset** utility on the XG2510HE:
- a. Open **Internet Explorer** or **Firefox**.
  - b. In the browser's address box, enter the default manager IP address,  
192.168.99.100.  
https://192.168.99.100
  - c. If navigation to the site is blocked due to a certificate error, click to continue on to the Web site (the Web site is safe).
  - d. In the **Connect** dialog box, enter the following username and password:
    - **Username:** system
    - **Password:** system
  - e. In the Admin Toolset window, click the links in the left panel to view the default settings. For example, to see the PPP and serial port settings use the **Interfaces** link.