

# Compact Power Line Shelves

Model: J85480S1



- Only 16.81" wide fits inside equipment that is designed into a 19" rack
- Two DC Outputs may be common or split. Each output bus is rated for 100A with two-hole lug landings for 2 AWG wire (L15 can be 148A at one side with two-hole lug landings for 1 AWG wire)
- Independent IEC-320 AC input for each rectifier

#### Description

The 1U (1.75") high CPL family of shelves mount in 19-inch wide frames and provide up to 11kW of 48V output power per shelf. There are three or four slots for rectifiers, converters (PEMs). With the exception of L23, these rectifier shelves are capable of utilizing the higher power capacity of the CP2725 rectifier.

- Analog, RS485 or dual/redundant I<sup>2</sup>C communications.
- Adjustable mounting ears for flush or set back positions.
- Stackable up to 8 high with 32 paralleled power supplies.
- Isolated output for common output shelves

	Max	#AC	_	DC Output		Fe	eatures	
List	Power	Power Input	AC Input Plug	Bus	Max Rectifier Size	Setpoint	Other	Ordering Codes
4	8kW		IEC-320, C13		CP2000	(±) 54V <sub>dc</sub>	Analog, I²C, RS485	108994538
20		л	(	Common		(±) 54V <sub>dc</sub>		CC109147344
20A	11kW	4	IEC-320, C19		CP2725	(±) 48.8V <sub>dc</sub> <sup>1</sup>	Analog, I²C	1600087352A
21				Split		- 54V <sub>dc</sub>		CC109147328
23	8kW	4	IEC-320, C13	Common	CP2000	(±) 54V <sub>dc</sub>	POE, Analog, I <sup>2</sup> C	CC109150447
PEM Shelves (DC Input, DC Output)								
1:0+				DC Output		<b>Communications Features</b>		
LIST	Capacity	Input	DC Input Plug	Bus	Max PEM Size	Controller	Protocol	Ordening Codes
14	8kW	2	AMP Power-Blade	Split	CP2000	No	Analog, I <sup>2</sup> C	CC109124764
15	8kW	2	AMP Power-Blade	Common	CP2500	No	Analog, I <sup>2</sup> C	1600264406A

#### Notes:

Split shelf L21 V<sub>out</sub> ( - ) is split, however V<sub>out</sub> ( + ) is paralleled among the 4 rectifiers. V<sub>out</sub> ( + ) should be grounded.

All lists, up to 2 shelves can be paralleled for a single  $l^2C$  line. Up to eight shelves may be paralleled for current shared power delivery.

All lists, shelf configured set point ensures inter-operability among all rectifiers from CP1800 to CP2725. Rectifiers will proportionately current share relative to their output power capacity.

All shelves are RoHS 6 compliant. Order should reflect J85480S1LxxZ where xx is the list number and Z indicates compliance to RoHS 6.

 $^1\mbox{L20A}$  must use with CP2725-FB rectifier to get  $48.8V_{dc}$  output.

Consult the factory for product availability



# **Technical Specifications**

### Package Outline



List 4





### Package Outline (continued)



#### **Rear Views**



<sup>2</sup>Input: L20, L20A & L21: IEC 320-C20 sockets L23: IEC 320-C14 sockets



### **AC Input Connections**



Tie\_rap secured AC cables for IEC-320 inputs

### DC Input Connection – L14, L15 shelf

Housing:	AMP 1600798-6 multi-beam XL
Contacts:	AMP 1-1600960-8
Wire:	10 ga stranded – 30A rated capacity

Pins	Color	Signal	Unit
1-2	Black	-48V	_
3-4	Red	RTN	1
5-6	Black	-48V	
7-8	Red	RTN	2



### **DC Output Connections**

- Each Output Bus is rated for 100A and up to 2 gage two- hole lugs. (L15 can be 148A at one side with two-hole luglandings for 1 AWG wire)
- M6 nuts with conical washersprovided.
- Touch-Safe plastic coversaround output buses.





### DC Split Output Bus Option

- Split V<sub>out</sub> ( ) buses on either side of the shelf. V<sub>out</sub> ( + ) is common to both sections.
- +5V bias maintains I<sup>2</sup>C communications even during a feeder fault.
- Multiple shelves may not be paralleled together.



• Lists 4 and 15 ship with a jumper installed on connector J1 pins 21 and 23. This allows the shelf to be powered without a controller.



• Lists 20, L20A & L23 single output shelves, shorting jumper between J1 pins 19 and 20. Lists 21 split output shelf, second shorting jumper between J1 pins 21 and 22.



• Lists 14 requires cc848836107 connector be installed in J1 to allow the shelf to power up without a controller.

#### Notes:

Jumpers to short ENABLE (turn ON) to Logic\_GRD are either in a separate bag or inserted into the J1 signal connector.

Jumper must be removed prior to inserting a mating connector into the J1 housing.

Applications that desire a remote ON/OFF feature should connect ENABLE-A to Logic\_GRD via an external switch. For split shelves ENABLE-A control the two leftmost rectifiers and ENABLE-B controls the two rightmost rectifiers. Page 5



### L14, L15 J1 Mating connector (pin out is standard 40 position like L4)

Туре	Housing	Mating pin	Crimping tool	
Individual wire set	AMP 102387-9 RoHS	20-21 41/6.6-87523-9	91517_1	
	AMP 1658621-9 e/w		01517-1	
40 position Ribbon Cable	499252-1 (strain relief) RoHS	22-20 AWG: 0-81150-8	91517-1	

This connector set is different because it can accept either a ribbon cable or an individual wire mate.

### Communication Signals: J1 Connector (L4, L14, L15)

	Pi	in out		Control Interface Connection (J1 - AMP 499913-9)
Pin	Signal	Pin	Signal	
1	POWER_CAP_4	21	Enable side A	
2	POWER_CAP_3	22	5VA	
3	POWER_CAP_2	23	Logic_GRD	
4	POWER_CAP_1	24	Interrupt_1	11000
5	MOD_PRES_4	25	Reset	1 1 1 1 1 1 North
6	MOD_PRES_3	26	Enable Side B	La state and a state of the sta
7	MOD_PRES_2	27	Spacing	
8	MOD_PRES_1	28	Spacing	
9	PFW_4	29	RS_485_Select	Analog single-
10	PFW_3	30	Shelf_Addr_A	shelf applications
11	PFW_2	31	Shelf_Addr_B	can be
12	PFW_1	32	Shelf_Addr_C	the first 24 pins
13	SCL_0	33	Shelf_Addr_D	of controller require pins 25 through 39 of controller
14	SCL_1	34	Shelf_Addr_E	connector J1.
15	SDA_0	35	Shelf_Addr_F	<del></del>
16	SDA_1	36	Shelf_Addr_G	Pins 1-24
17	OTW	37	Protocol_S	J1 Ribbon Cable Assembly current sharing. It and all serial addressing
18	Margin	38	RS-485+	pins (30-36) are referenced to 48_OUT (-
19	Fault	39	RS_485-	
20	Interrupt 0	40	Ishare	

### Communication Signals: J2 Connector (L4, L15, except split shelf L14)

	P	in out		Multi-shelf Connection (J2 – AMP 499913-8)
Pin	Signal	Pin	Signal	
1	PFW_4	18	Enable Side B	
2	PFW_3	19	Spacing	
3	PFW_2	20	Spacing	
4	PFW_1	21	RS_485_Select	1. I a a a a
5	SCL_0	22	Shelf_Addr_B	
6	SCL_1	23	Shelf_Addr_C	
7	SDA_0	24	Shelf_Addr_D	12 to 11 Ribbon Cable Assembly
8	SDA_1	25	Shelf_Addr_E	848738253
9	OTW	26	Shelf_Addr_F	
10	Margin	27	Shelf_Addr_G	CI Contraction 18 1
11	Fault	28	Shelf_Addr_H	
12	Interrupt_0	29	Protocol_S	
13	Enable side A	30	RS-485+	and the second second
14	5VA	31	RS_485-	J1 Ribbon Cable Assembly
15	Logic_GRD	32	Ishare	848738245
16	Interrupt_1	33	Spare	
17	Reset	34	Spare	



### Communication Signals: J1 Connector (L20, L20A, L21, L23)



### Communication Signals: J2 Connector (L20, L20A, L21,L23)

	I	Pin out		Shelf-to-shelf cable connection (part # CC848848952)
Pin	Signal	Pin	Signal	
1	SCL_0	8	Alert#_1	
2	SCL_1	9	Isolation n/c	
3	SDA_0	10	Isolation n/c	
4	SDA_1	11	Ishare - B	
5	Alert#_0	12	Ishare - A	
6	5VA	13	8V_INT - B	
7	Logic_GRD	14	8V_INT - A	- And

#### Notes:

Shelf addressing, 8V\_INT, and current share are referenced to the most negative power output  $V_{out}(-)$  of the shelf. For paralleled shelves the  $V_{out}(-)$  terminations must be tied together in order to ensure proper operation of these functions. Modules could get damaged if this connection is not made.

For address A2=0, connect a voltage divider between  $8V_{INT_x}$  [149K] and  $V_{out}(-)_x$ [10K]. The midpoint of the two resistors should be connected to Shelf\_Addr\_x. For A2=1, connect Shelf\_Addr\_x to  $V_{out}(-)$ . For all other signals refer to the rectifier data sheet.

#### Signal connector part numbers

(AMP – as specified or equivalent)

Connector	Positions	On shelf	Ribbon cable	Individual wires	Crimping tool
71	20	5102159-7	1658621-7 header	102387-7 header	
JI	30	102320-1 latch	1-499252-2 retainer	6-87756-8 pin <sup>2</sup>	91517-1
10	14	5102159 <b>-</b> 2	1658621-2 header	102387 <b>-</b> 2 header	
JZ	14	102320-1 latch	499252-9 retainer	6-87756-8 pin	91517-1



### Specifications

Parameter	Min	Max	Notes
Input			
		15A	IEC-320, C13 type <sup>3</sup>
AC Input Current, per module		20A	IEC-320, C13 type <sup>4</sup>
DC Input Current, per module		60A	
Output			
Programmable output set point	42V <sub>dc</sub>	58V <sub>dc</sub>	Minimum 44V <sub>dc</sub> via hardware margining
Max Output Current J85480S1		200A	lugs for 2/1 ga wires, 2/1 pairs, 100A/148A max $^5$
Output Terminations			M6 threaded studs on 5/8-inch centers
Environmental		40°C to 1	CF°C for UL recognition and 4F°C for VDF partification
Operating Temperature Range		-40°C to 6	65°C for UL recognition and 45°C for VDE certification
Operating Relative Humidity		0 - 95% (1	non-condensing)
Storage Temperature Range		-40°C to 8	B5°C
EMC		FCC, EN 5	5032, CISPR22, Level A, conducted and radiated
Immunity		FCC and C	CISPR22 (EN55032) Class A2
Safety/Standards Compliance			
Safety Standards		UL1950, E	N62368 (IEC950), CSA*234/950
		Lists 14,15	5,20,20A,21,23: VDE,
		UL Recogr	nized (Canada and U.S.)

Lists 4: VDE,

UL Listed (Canada and U.S.)

Certification Marks

Notes:

 $^{\rm 3}$  IEC320 – C13 plugs are rated for 10A international and 15A in North America

 $^4\,\mathrm{IEC320}$  – C19 plugs are rated for 16A international and 20A in North America

 $^{\rm 5}$  L15 can be 148A at one side output with two-hole lug landings for 1 AWG wire



### Ordering Information

Part number	Description	Ordering Code	Usage
Blank Slot Fille	rs		
	Central Office White	CC848822263	
	Raven Black	CC848781534	All
	Graphite	CC848825233	
Extensions and	I mounting brackets		
	1U high extension bracket kit for 23" cabinets (includes two brackets	CC040044002	
	and mounting hardware)	CC040044003	All
	2U high extension bracket kit for 23" cabinets (includes two brackets	848683009	All
Cables / Conne	ectors for 185480S1 Shelves		
	Ribbon cable for attaching a controller to the power shelf $-10$ ft		
	One end mates into J1 the other end not terminated.	848738245	L4
	Individual wire ser cable for attaching a controller to the power shelf – 6 ft. One end mates into J1 the other end not terminated.	CC848854034	L20, L20A, L21, L23
	Cable set from J1 of the shelf to the CPL Interface Board	CC848848960	L20, L20A, L21, L23
	Inter-shelf connector for daisy-chaining shelves – 9 in between J1 of $2^{nd}$ and J2 of $1^{st}$ shelf	848738253	L4
	Inter-shelf cable set for interconnecting J2 signals between shelves	CC848848952	L20, L20A, L21, L23
	2 AWG DC output cable set – 10 ft (1 RED and 1 BLACK cable)	848748987	All
	1 AWG DC output cable set – 10 ft (1 RED and 1 BLACK cable)	8600279027P	L15
	AC Input cable: High temperature IEC 320 C13 straight over-mold (one end), NEMA5-15P plug (one end), 14 AWG, 10 ft	CC848776105	L4
	AC input cable: IEC 320 C13 plug (one end), other end not terminated, 14 AWG, 14 ft,	847861192	L4, L23
	AC input cable: IEC320 C19 straight plug (one end), other end not terminated	CC848847368	L20, L20A, L21
	AC input cable: IEC320 C19 right angle plug (one end), other end not terminated	848713376	L20, L20A, L21
	DC input cable – 4 ft	CC848794908	L14, L15
	Shorting jumper for J1 connector ENABLE for single output shelf (see locating picture)	AMP 881545-2	L4, L15
	J1 connector ENABLE jumper for split shelf	CC848836107	L14
	M6 screw with conical washer	901377010	L20, L20A, L21, L23
Pulsar Controll	ers for J85480S1 Shelves		
NE843G	1U standalone Controller (Display, DB9 craft port and RJ45 ethernet)	CC109139358	
	······································		
Cables for Puls	ar Controllers		
	NE843G to CP Shelf Cable Kit (Includes 2ft power and communication cable)	CC109144820	
	J4 Output Alarm Cable 50ft – 24ga solid twisted pair	CC848817635	
	J4 Output Alarm Cable 150ft – 24ga solid twisted pair	CC848817643	
	J3 Input Alarm Cable 50ft – 24ga Stranded	CC848817651	
-	J3 Input Alarm Cable 150ft – 24ga Stranded	CC848817668	



### Support Tools

#### **Graphical User Interface**

This program exercises the various commands and functions available via the I<sup>2</sup>C interface of the power supply. Two independent GUIs can demonstrate the two independent I<sup>2</sup>C multiplexed lines. Find out who is in control, take over control.

The GUI has an automated polling feature and records all state changes in a time stamped automated fashion. Monitoring of the power system is therefore trivial for long periods of time.



#### **Interface Board**

This board can be used independently or in combination with the GUI interface LEDs display the status of the analog signals and dip switches change the signal state to the power supply.

In addition, two connectors are provided for interfacing to the two i<sup>2</sup>C lines of the power supplies.



#### **Total Communications Solution**

This is a nuts and bolts complete hardware solution that starts from either the USB or RS232 port of a computer and ends with a cable set that connects into the J1 signal connector of the shelf.

In between is the interface board and a commercially available converter that translates the computer signals into  $I^2C$  and vice versa.

The converter is an MIIC-202 IPort manufactured by Micro Computer Control (mcc-us.com).





### Safety Symbols and Guidelines

Read and understand all instructions before attempting any installation of this product. When installing, operating, or maintaining the J85480S1 Power System, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Such precautions include the following:



This symbol identifies the need to refer to the equipment instructions for important information.

This symbol identifies the presence of hazardous AC or DC voltages or hazardous energy levels. In the context of this product

- The DC output cables contain electrical energy levels capable of causing heating and arcing if shorted to metal objects. Make connections with the power disconnected.
- Hazardous AC voltage and DC electrical energy is contained within the enclosure of the power shelf. No user or field serviceable parts inside



This symbol is used to identify safety earth ground connection points within the equipment.

### **Product Labeling**

Follow all warnings and instructions marked on the product. Some of the safety symbols used with the CP1800 Rectifier and J85480S1 Shelf may include the following. They may also be accompanied by instructions:

#### **Mounting and Installation**

- This product shall be installed in compliance with mounting requirements for the ultimate application.
- This product must be installed, serviced, and operated only by skilled and qualified personnel who have the necessary knowledge and practical experience with electrical equipment and who understand the hazards that can arise when working on this type of equipment. This product is intended for use in a Restricted Access Location.
- This equipment is to be used in controlled environments (an area where the humidity is maintained at levels that cannot cause condensation on the equipment, the contaminating dust is controlled, and the steady-state ambient temperature is within the range specified).
- This equipment has been evaluated for use in a continuous ambient temperature of up to 55°C and the application environment should not exceed 55°C.
- The CE mark if provided on the product is applied to show conformance to the requirements outlined in the European Union's Low Voltage Directive {72/73/EEC} and EMC Directive {89/336/EEC}, as amended by the CE Mark Directive {93/ 68/ EEC}.
- The J85480S1 shelf, when used with the CP1800 rectifiers, has been evaluated for hot swapping.
- A separate protective Earthing terminal is provided at the reach of the shelf
- the building installation shall provide a means for connection to protective earth; and
- the equipment is to be connected to that means; and
- a SERVICE PERSON shall check whether or not the socket-outlet from which the equipment is to be powered provides a connection to the building protective earth. If not, the SERVICE PERSON shall arrange for the installation of a PROTECTIVE EARTHING CONDUCTOR from the separate protective Earthing terminal to the protective earth wire in the building.



#### **Output Connections**

- All field wiring should comply with the U.S. National Electrical Code (NEC) and/or applicable local codes/standards.
- Routing of the DC output cables should guarantee that cables are not in contact with sources of heat and surfaces that may damage the cable insulation.
- The DC output is not provided with a fuse or circuit breaker suitable for branch circuit protection. Therefore, the power shelf should be mounted in the same rack or cabinet as the equipment being powered. Use interconnecting power cables suitable for the application and sized to carry the rated output current. The interconnecting cables should be capable of carrying the overload current and short circuit current without damage or risk of fire.
- The output for the system is SELV and has available power greater than 240VA.
- Insulation on output field-wired conductors should be rated no less than 90°C. Wiring internal to enclosed equipment cabinets should be rated at 105°C (minimum). The provided DC output cords (red and black wires) are rated for 105°C.
- Before opening the insulating cover to gain access to load and ground connections, ensure all power supplies are disconnected from the AC MAINS.

#### **AC Input Connections**

- AC branch circuits to this equipment must be protected with fuses or circuit breakers sized as required by the U.S. National Electric Code (NEC) and/or local codes. Up to four AC mains power cords are required to power the shelf (one for each rectifier). Each power cord should be connected to a separate AC mains branch circuit with an overcurrent protector rated at no more than 20A.
- The power supply mains inlet may be used as the means to provide AC protective earthing.
- An accessible AC disconnect/protection device to remove AC power from the equipment in the event of an emergency must be provided. An accessible socket-outlet/receptacle installed near the equipment is also acceptable as a disconnect.
- The equipment is powered by multiple AC inputs (one per rectifier). Disconnect all AC sources of power before servicing.
- These units are to be used with TN-S power systems only.

#### **German Safety Guidelines**

#### Installationsanleitung

- Alle Ausgänge des Gerätes erfüllen die Anforderungen für SELV nach IEC/EN60950-1.
- Die Ausgänge des Gerätes liegen über den Limits für Energiegefahr nach IEC/EN60950-1 (>240 VA). Das Gerät ist zum Einbau in ein Montage-Rack bestimmt. Siehe Einbaubestimmungen in der Montageanleitung, um eine Gefährdung des Benutzers während der Installation zu vermeiden.

#### ACHTUNG:

#### Hoher Ableitstrom Vor Anschluss an den Versorgungsstromkreis unbedingt Erdungsverbindung herstellen

- Das Produkt ist zum Gebrauch in einer Umgebungstemperatur von max. 55°C bestimmt.
- Die Gerätestecker des Produktes sind dazu bestimmt, eine sichere Erdung des Gerätes herzustellen.
- Das Produkt ist zum Gebrauch in einer Umgebung mit Verschmutzungsgrad 2 nach IEC/EN60950 bestimmt.
- Die Netzteile des Gerätes können während des Betriebes einzeln ausgetauscht werden (Hot Swapping).
- Das Gerät wurde zusammen mit den Anschlussleitungen (ohne Anschlussstecker) geprüft. Die Installation eines Steckers des jeweiligen Landes, sollte nur durch geschultes Service Personal durchgeführt werden. Als alternative könnte eine Vorinstallation des Steckers bereits bei der Herstellung erfolgt sein.



# Change History (excludes grammar & clarifications)

Version	Date	Description of the change
3.3	01/04/2022	Updated as per template and upgraded RoHS standards



**ABB** 601 Shiloh Rd. Plano, TX USA

abbpowerconversion.com

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. ABB does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of ABB.

Copyright© 2021 ABB All rights reserved.

# **Mouser Electronics**

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

OmniOn Power:

J85480S1L21-CCZ