

Other Information

To obtain the most recent and complete documentation for this demonstration board, including:

- User's Guide
- Board Description
- Board Schematics
- Source Code
- Application Examples
- Links to Web Seminars

please refer to the Microchip web site: www.microchip.com

Americas

Atlanta - 678-957-9614
Boston - 774-760-0087
Chicago - 630-285-0071
Dallas - 972-818-7423
Detroit - 248-538-2250
Kokomo - 765-864-8360
Los Angeles - 949-462-9523
Phoenix - 480-792-7200
Santa Clara - 408-961-6444
Toronto - 905-673-0699

Asia/Pacific

Australia - Sydney - 61-2-9868-6733
China - Beijing - 86-10-8528-2100
China - Chengdu - 86-28-8665-5511
China - Hong Kong SAR - 852-2401-1200
China - Nanjing - 86-25-8473-2460
China - Qingdao - 86-532-8502-7355
China - Shanghai - 86-21-5407-5533
China - Shenyang - 86-24-2334-2829
China - Shenzhen - 86-755-8203-2660
China - Wuhan - 86-27-5980-5300
China - Xiamen - 86-592-2388138
China - Xian - 86-29-8833-7252
China - Zhuhai - 86-756-3210040
India - Bangalore - 91-80-4182-8400
India - New Delhi - 91-11-4160-8631
India - Pune - 91-20-2566-1512
Japan - Yokohama - 81-45-471-6166
Korea - Daegu - 82-53-744-4301
Korea - Seoul - 82-2-554-7200
Malaysia - Kuala Lumpur - 60-3-6201-9857
Malaysia - Penang - 60-4-227-8870
Philippines - Manila - 63-2-634-9065
Singapore - 65-6334-8870
Taiwan - Hsin Chu - 886-3-572-9526
Taiwan - Kaohsiung - 886-7-536-4818
Taiwan - Taipei - 886-2-2500-6610
Thailand - Bangkok - 66-2-694-1351

Europe

Austria - Weis - 43-7242-2244-39
Denmark - Copenhagen - 45-4450-2828
France - Paris - 33-1-69-53-63-20
Germany - Munich - 49-89-627-144-0
Italy - Milan - 39-0331-742611
Netherlands - Drunen - 31-416-690399
Spain - Madrid - 34-91-708-08-90
UK - Wokingham - 44-118-921-5869

01/02/08

PIC32 Starter Board PIM Adapter (AC320002)

Overview

The PIC32 Starter Board PIM Adapter is designed to enable the PIC32 Starter Board to work with the Explorer 16 Development Board. This enables users to customize functionality using PICtail™ Plus daughter cards or eliminate the need for external debugging hardware.

With the PIC32 Starter Board plugged into the Explorer 16 Development Board, there are 2 options to connect to MPLAB® Integrated Development Environment (IDE):

1. Use the existing PIC32 Starter Board circuitry. Ensure the PIC32 Starter Board USB cable is connected to the PIC32 Starter Board debug port. Also, connect the +9V DC power supply to the Explorer 16 Development Board.
2. Use a third party JTAG debugger connected to the Explorer 16 Development Board JTAG port.

Getting Started

To get started, attach the PIC32 Starter Board PIM Adapter to the Explorer 16 Development Board (DM240001, DM240002) through the U1A connector of the Explorer 16 board. The PIC32 Starter Board is then connected to the PIM Adapter via J2. After connecting the PIC32 Starter Board, PIM Adapter, and Explorer 16 Development Board, power the Explorer 16 using its +9V DC power supply. Do this before connecting the PIC32 Starter Board debug USB cable to the PC. The PIC32 Starter Board is now powered by the Explorer 16 Development Board rather than by the USB debug connection.

Limitations

The PIM connector does not provide +5V, therefore the PIC32 Starter Board +5V_EXT signal is not connected to the application circuit.

The connector on the PIC32 Starter Board PIM Adapter is not compatible with the MPLAB® REAL ICE™ in-circuit emulator or the MPLAB ICD 3 in-circuit debugger.

Schematics

Schematics for the PIC32 Starter Board PIM Adapter are featured on the next page of this document.




Microchip Technology Inc. • 2355 West Chandler Blvd. • Chandler, AZ 85224-6199
www.microchip.com

The Microchip name and logo and the Microchip logo are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries. PICtail is a trademark of Microchip Technology Incorporated in the U.S.A. and other countries. All other trademarks mentioned herein are property of their respective companies. © 2008, Microchip Technology Incorporated, Printed in the U.S.A. All Rights Reserved. 3/08



PIC32MX Starter Board PIM Adapter (AC320002)

Board Schematic



Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Microchip:](#)

[AC320002](#)