

mikroBoard for ARM 64-pin™

User manual

All MikroElektronika's development systems represent irreplaceable tools for programming and developing microcontroller-based devices. Carefully chosen components and the use of machines of the last generation for mounting and testing thereof are the best guarantee of high reliability of our devices. Due to simple design, a large number of add-on modules and ready to use examples, all our users, regardless of their experience, have the possibility to develop their project in a fast and efficient way.

Development system



SOFTWARE AND HARDWARE SOLUTIONS FOR EMBEDDED WORLD ...making it simple

TO OUR VALUED CUSTOMERS

I want to express my thanks to you for being interested in our products and for having confidence in Mikroelektronika.

The primary aim of our company is to design and produce high quality electronic products and to constantly improve the performance thereof in order to better suit your needs.

A handwritten signature in white ink, appearing to read 'N. Matic', is positioned above the name and title.

Nebojsa Matic
General Manager

TABLE OF CONTENTS

1. General information 4

2. LPC2148 microcontroller 5

3. Programming the microcontroller 8

4. Voltage regulator 13

5. MicroSD connector 14

6. Flash module 15

7. USB communication 16

1. General information

MikroBoard for ARM 64-pin is primarily intended to be connected to the EasyARM v6 development system but can also be used as a stand-alone device. The board features the LPC2148 microcontroller, flash module, USB connectors, microSD connector, JTAG connector, USB UART, voltage regulator and connectors that enable connection with a development system.




Figure 1-1: mikroBoard for ARM 64-pin

2. LPC2148 microcontroller

The LPC2148 microcontroller in 64-pin LQFP package is soldered on the mikroBoard for ARM 64-pin. Some of its key features are:

- 16-bit/32-bit ARM7TDMI-S microcontroller in a tiny LQFP64 package
- 40 kB of on-chip static RAM and 512 kB of on-chip flash memory. 128-bit wide interface/ accelerator enables high-speed 60 MHz operation
- In-System Programming/In-Application Programming (ISP/IAP) via on-chip boot loader software. Single flash sector or full chip erase in 400 ms and programming of 256 B in 1 ms
- USB 2.0 full-speed compliant device controller with 2 kB of endpoint RAM
- Low power Real-Time Clock (RTC) with independent power and 32 kHz clock input




Figure 2-1: LPC2148 microcontroller

The LPC2148 is connected to on-board modules via pins which are also connected to the CN1 and CN2 connectors. These two connectors enable the board to be connected to the EasyARM v6 development system or some other device.




Figure 2-2: LPC2148 microcontroller with oscillators connection schematic

The LPC2148 microcontroller is connected to the X1 and X2 oscillators. The X1 oscillator generates a clock used for the operation of the microcontroller, whereas the X2 oscillator is used for the operation of the RTC module built into the microcontroller. The microcontroller can be cleared by feeding the reset pin with a logic 0, i.e. by pressing the RESET button.




Figure 2-3: LPC2148 microcontroller with connectors connection schematic

3. Programming the microcontroller

The microcontroller can be programmed with a bootloader or the JTAG programmer. The use of bootloader is enabled due to the bootloader code that is loaded into the microcontroller. In order to program the microcontroller with the bootloader, it is necessary to connect the board to a PC via the CN3 connector and USB cable, figure 3-1. A hex code is transferred from the PC to the microcontroller by using some of the bootloader programs, such as Flash Magic.




Figure 3-1: USB connector for programming

The CN3 USB connector is connected to the UART module built into the microcontroller via FTDI module (FT232RL).





Figure 3-2: USB UART module connection schematic

When the mikroBoard for ARM 64-pin operates as a stand-alone device, it is necessary to place jumper J3 on the board. If the board is connected to the EasyARM v6 development system, jumper J3 should be removed.

The following steps explain how to program the microcontroller with bootloader via the Flash Magic application.


STEP 1: Connect the system to a PC




Connect the mikroBoard for ARM 64-pin to available USB port on your PC.

STEP 2: Start Flash Magic

Download the Flash Magic application from <http://www.flashmagictool.com/download.html&d=FlashMagic.exe> and install it on your PC.

When the installation is finished, double click on the Flash Magic icon  Flash Magic

STEP 3: Select MCU



Flash Magic - NON PRODUCTION USE ONLY

File ISP Options Tools Help

Step 1 - Communications Step 2 - Erase

Select Device... LPC2148

Erase block 0 (0x000000-0x000FFF)
Erase block 1 (0x001000-0x001FFF)

Device Database

LPC2132
LPC2134
LPC2136
LPC2138
LPC2141
LPC2142
LPC2144
LPC2146
LPC2148
LPC2157
LPC2158
LPC2194
LPC2212
LPC2214
LPC2210


UART bootloader
500KB (0x0007CFFF) on-chip Flash
RAM blocks: 0x40000000 ->
0x40007FFF
Signature: 67305253 (0x0402FF25)
Flash erased value: 0xFF
Code Read Protection location:
0x000001FC
High speed communications supported

Click on the Select Device button

Select MCU from the list

Click OK

STEP 4: Settings




From the drop-down menu
select COM port on your PC



Set Baud Rate to 19200

Enter 12 in the Oscillator field (if you use different
oscillator enter its value in MHz instead)


Device Manager on your PC contains information on which COM port is used for USB communication with the mikroBoard for ARM 64-pin. In this case the COM4 port is used.




Select the Port Settings
tab from pop-up window



STEP 5: Browse for .hex file



STEP 6: Upload .hex file



page




Figure 3-3: JTAG connector

In order to enable the JTAG programmer to be used, it is necessary to place jumper J4 in the ENABLE position, Figure 3-5. If the JTAG programmer is not used for programming, jumper J4 should be removed from the board, Figure 3-6.




Figure 3-4: JTAG module connection schematic




Figure 3-5: JTAG is enabled




Figure 3-6: JTAG is disabled

4. Voltage regulator

The on-board microcontroller operates at 3.3V power supply voltage. The board is powered with the 5V power supply voltage via the CN3 USB connector.




Figure 4-1: Voltage regulator




Figure 4-2: Voltage regulator connection schematic

If the board is powered by a development system (EasyARM v6), the function of the voltage regulator remains the same. In this case, it is necessary to remove jumper J3 (STANDALONE), Figure 4-3.




Figure 4-3: Standalone mode disabled (development system connection)




Figure 4-4: Standalone mode enabled

5. MicroSD connector

There is a connector CN5 provided on the development system that enables the use of microSD card. When inserted, the microSD card provides additional memory space that the microcontroller can use to store data. Communication between the microSD card and the microcontroller is performed via the Serial Peripheral Interface (SPI).




Figure 5-1: microSD connector




Figure 5-2: microSD connector connection schematic

The pins' designations have the following meaning:

CS - Chip Select
SCK - Clock

Din - Master Out/Slave In (MOSI)
Dout - Master In/Slave Out (MISO)

6. Flash module

Flash module provides additional 8Mbit of flash memory that the microcontroller can use via the Serial Peripheral Interface (SPI).




Figure 6-1: Flash memory




Figure 6-2: Flash module connection schematic

7. USB communication

The USB connector CN7 enables USB devices to access the microcontroller. When connecting USB devices, jumpers J1 and J2 are used to determine whether the UP_LED or soft connect function will be active. When jumpers J1 and J2 are placed in the UP_LED position, a LED marked UP_LED (LD1) will illuminate if the connected USB device is configured. If the connected USB device is not configured, this LED will not illuminate. If jumpers J1 and J2 are placed in the CONNECT position, an external resistor of 1.5K will be automatically controlled by the software, thus enabling the soft connect function.




Figure 7-1: USB connector




Figure 7-2: UP_LED function




Figure 7-3: Soft connect function




Figure 7-4: USB connector connection schematic




Figure 7-5: Dimensions of the mikroBoard for ARM 64-pin

DISCLAIMER

All the products owned by MikroElektronika are protected by copyright law and international copyright treaty. Therefore, this manual is to be treated as any other copyright material. No part of this manual, including product and software described herein, may be reproduced, stored in a retrieval system, translated or transmitted in any form or by any means, without the prior written permission of MikroElektronika. The manual PDF edition can be printed for private or local use, but not for distribution. Any modification of this manual is prohibited.

MikroElektronika provides this manual 'as is' without warranty of any kind, either expressed or implied, including, but not limited to, the implied warranties or conditions of merchantability or fitness for a particular purpose.

MikroElektronika shall assume no responsibility or liability for any errors, omissions and inaccuracies that may appear in this manual. In no event shall MikroElektronika, its directors, officers, employees or distributors be liable for any indirect, specific, incidental or consequential damages (including damages for loss of business profits and business information, business interruption or any other pecuniary loss) arising out of the use of this manual or product, even if MikroElektronika has been advised of the possibility of such damages. MikroElektronika reserves the right to change information contained in this manual at any time without prior notice, if necessary.

HIGH RISK ACTIVITIES

The products of MikroElektronika are not fault – tolerant nor designed, manufactured or intended for use or resale as on – line control equipment in hazardous environments requiring fail – safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life support machines or weapons systems in which the failure of Software could lead directly to death, personal injury or severe physical or environmental damage ('High Risk Activities'). MikroElektronika and its suppliers specifically disclaim any expressed or implied warranty of fitness for High Risk Activities.

TRADEMARKS

The Mikroelektronika name and logo, the Mikroelektronika logo, mikroC, mikroC PRO, mikroBasic, mikro-Basic PRO, mikroPascal, mikroPascal PRO, AVRflash, PICflash, dsPICprog, 18FJprog, PSOCprog, AVR-prog, 8051prog, ARMflash, EasyPIC5, EasyPIC6, BigPIC5, BigPIC6, dsPIC PRO4, Easy8051B, EasyARM, EasyAVR5, EasyAVR6, BigAVR2, EasydsPIC4A, EasyPSoC4, EasyVR Stamp LV18FJ, LV24-33A, LV32MX, PIC32MX4 MultiMedia Board, PICPLC16, PICPLC8 PICPLC4, SmartGSM/GPRS, UNI-DS are trademarks of Mikroelektronika. All other trademarks mentioned herein are property of their respective companies.

All other product and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are only used for identification or explanation and to the owners' benefit, with no intent to infringe.



SOFTWARE AND HARDWARE SOLUTIONS FOR EMBEDDED WORLD ...making it simple

If you want to learn more about our products, please visit our website at www.mikroe.com

If you are experiencing some problems with any of our products or just need additional information, please place your ticket at www.mikroe.com/en/support

If you have any questions, comments or business proposals, do not hesitate to contact us at office@mikroe.com

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Mikroe:

[MIKROE-649](#)