Mesh Network System BR-400AN

User's Manual



Copyright© 2017 silex technology, Inc. All rights reserved. WA104900XG

Index

1. Introduction	
1-1. Introduction	1
Disclaimers	1
Trademarks	1
1-2. Safety Instructions	2
1-3. Product Information and Customer Services	5
Product Information	5
Customer Support Center	5
2. Specifications	7
2-1. What is Mesh Network?	7
2-2. Features	8
2-3. Parts and Functions	10
2-4. Hardware Specification	12
2-5. Software Specification	14
2-6. Optional Utilities	15
What is AMC Manager [®] ?	15
What is Mesh Monitor?	17
2-7. Wireless Interference Information	
Notes of Use	
DFS	20
2-8. Notes on Security	21
2-9. Restrictions	22
Restrictions on DFS Channels	22
3. How to Install BR-400AN	
3-1. How to Install BR-400AN	23
Product Installation and Radio Distance	24
Connecting BR-400AN with Firmware Version 2.0.0 or Lower	25
How to Turn on BR-400AN	26

 3-2. Example of Installation	27 28 29 30 31
Configuring Mesh network using BR-400AN only Connecting BR-400AN to your existing network Dividing the Mesh network for each area Connecting tablet devices or PCs wirelessly 4. How to Configure BR-400AN	28 29 30 31
Connecting BR-400AN to your existing network Dividing the Mesh network for each area Connecting tablet devices or PCs wirelessly 4. How to Configure BR-400AN	29 30 31
Dividing the Mesh network for each area Connecting tablet devices or PCs wirelessly 4. How to Configure BR-400AN	30 31
Connecting tablet devices or PCs wirelessly 4. How to Configure BR-400AN	31
4. How to Configure BR-400AN	
	33
4-1. Configuration via BR-400AN's Web Page	33
Accessing the BR-400AN's Web Page Using Configuration Mode	33
Accessing BR-400AN's Web Page over Network	36
Configuration via BR-400AN's Web Page	38
4-2. Bulk Configuration Using AMC Manager [®]	42
Preparation for Bulk Configuration	42
Starting Bulk Configuration	46
Product Installation	54
4-3. Configuration Change Using Mesh Monitor	56
5. List of Configuration Items	59
5-1. Configuration Items on BR-400AN's Web Page	59
Basic Configuration	60
Access Point Function Configuration Page	68
Access Point Function Extended Configuration Page	74
Option Configuration Page	76
Login Password Configuration Page	78
6. How to Connect Wireless Client Devices	79
6-1. How to Enable Access Point Feature on BR-400AN	79
How to enable the Access Point feature using the Web configuration interface	80
	02
How to enable the Access Point feature using AMC Manager [®]	83
How to enable the Access Point feature using AMC Manager [®] How to enable the Access Point feature using Mesh Monitor	83 91

7. Maintenance Feature95
7-1. Restart
How to restart BR-400AN by unplugging the AC adaptor
How to restart BR-400AN using the Web configuration interface
7-2. Factory Default Configuration99
How to reset BR-400AN to factory defaults using the Push Switch
How to reset BR-400AN to factory defaults using the Web configuration interface101
7-3. Firmware Update103
8. Other Features 109
8-1. Mac Address Filter
Filter Type109
MAC Address List110
MAC Address Filter Setting111
8-2. Saving Log114
BR-400AN's System Log114
Retrieving System Log115
Deleting System Log117
A. Appendix119
A-1. Troubleshooting

1. Introduction

Thank you for purchasing the Mesh Network System BR-400AN (hereinafter the "BR-400AN").

1-1. Introduction

This manual provides information on how to configure and use the BR-400AN. Please read the Safety Instructions carefully before you begin.

Disclaimers

- The unauthorized transfer or copying of the content of this manual, in whole or in part, without prior written consent is expressly prohibited by law.
- The content of this manual is subject to change without notice.
- This manual was prepared to accurately match the content of each OS, but the actual information shown on the computer monitor may differ from the content of this manual due to future OS version upgrades, modifications, and other changes.
- Although every effort was made to prepare this manual with the utmost accuracy, Silex Technology will not be held liable for any damages as a result of errors, setting examples, or other content.

Trademarks

- AMC Manager[®] is a registered trademark of silex technology.
- Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries.
- Wi-Fi, Wi-Fi Protected Setup (WPS), Wi-Fi Protected Access (WPA), WPA2 are trademarks or registered trademarks of Wi-Fi Alliance.
- Other company names and product names contained in this manual are trademarks or registered trademarks of their respective companies.

1-2. Safety Instructions

This page provides the safety instructions for safe use of BR-400AN.

To ensure safe and proper use, please read the following information carefully before using BR-400AN.

< Meaning of the warnings >

Warning	"Warning" indicates the existence of a hazard that could result in death or serious injury if the safety instruction is not observed.
Caution	"Caution" indicates the existence of a hazard that could result in serious injury or material damage if the safety instruction is not observed.

< Meaning of the symbols >

$\mathbf{\Delta}$	This symbol indicates the warning and caution. (Example: "Danger of the electric shock")
\bigcirc	This symbol indicates the prohibited actions. (Example:) "Disassembly is prohibited")
	This symbol indicates the actions users are required to observe. (Example: Remove the AC plug from an outlet")

🕂 Warning

	 In the following cases, turn off the connected devices and unplug the AC plug of this product from a power outlet. Failure to follow these instructions may cause fire or an electrical shock. When this product emits a strange smell, smoke or sound or becomes too hot to touch. When foreign objects (metal, liquid, etc.) gets into this product. When this product is dropped or the case is broken or cracked.
	 Do not disassemble or modify this product. It may cause fire, electrical shock or malfunction. Do not disassemble or modify the AC adaptor that came with this product. It may cause fire, electrical shock or malfunction.
\bigcirc	 Do not cover up the vents on this product. The temperature inside may rise and cause fire or malfunction. Do not place anything on top of this product. Also, do not place this product on top of the other product. Failure to do so may cause fire, electrical shock, malfunction or performance degradation. Do not cover up this product with a cloth such as blanket or table cloth. The heat remains inside and it may cause fire or malfunction. Do not place any objects on top of AC adapter, or do not cover it up with anything. Also, do not use the AC adapter on top of the heat/moisture retaining materials (carpet, sponge, cardboard, styrofoam, etc.). The accumulated heat may result in fire or malfunction. Do not plug or unplug the AC adaptor or any other cables with wet hands. It may cause an electrical shock or malfunction. Do not move this product when the AC adapter is connected to it. The cable of AC adapter may be damaged, and which may result in fire or electric shock. Keep the small parts out of reach of young children. If these are swallowed, consult a doctor immediately.
	 For use of the devices connected to this product, please follow all warnings, cautions and notices given by that manufacturer and carefully use them in a proper manner. Failure to follow these instructions may cause fire, electrical shock or malfunction. Use the correct power voltage. Improper voltage may cause fire or an electrical shock. If a ground wire is supplied with your device to use with, connect it to the ground terminal in order to prevent an electrical shock. Do not connect the ground wire to gas pipe, water pipe, lighting rod or telephone ground wire. It may cause malfunction. Keep the cords and cables away from children. It may cause an electrical shock or serious injury. Make sure that you have a secure scaffold when this product is installed or removed to/from a high place. There is a danger of falling.

🔥 Caution

\bigcirc	 Use the AC adaptor supplied with this product. Other AC adaptors may cause malfunction. Do not place any objects on the cable or bend, twist, or pull it excessively. Do not use or store this product under the following conditions. It may cause malfunction. Locations subject to vibration or shock Shaky, uneven or tilted surfaces Locations exposed to direct sunlight Humid or dusty places Wet places (kitchen, bathroom, etc.) Near a heater or stove Locations subject to extreme changes in temperature Near strong electromagnetic sources (magnet, radio, wireless device, etc.) Poorly ventilated locations (on bookshelf, rack, etc.) Do not step on this product. It may cause injury if the product is broken. Do not wire in a place where many people are walking by. They may trip over the cables and get injured. When installing this product to a high position, make sure that this product is firmly fixed so it does not drop for weight of the cables.
	 This product may become hot when it is in use. Be careful of the heat when moving or removing this product. Do not pull on the cord to disconnect the plug from the power supply. The code may be broken, which could result in fire or an electrical shock. Follow the law of each country when you discard this product. Verify all codes or cables are plugged correctly before using this product.
	 When removing this product, disconnect the AC plugs of both this product and the other devices you are using with it. When this product will not be used for a long time, unplug the power cables of this product and the other devices you are using with it.

1-3. Product Information and Customer Services

Product Information

The services below are available from the Silex Technology website. For details, please visit the Silex Technology website.

	URL
USA / Europe	https://www.silextechnology.com/
	·

- Latest firmware download - Latest software download
- Latest manual download
- Support information (FAQ)

Customer Support Center

Customer Support is available by e-mail or telephone for any problems that you may encounter. If you cannot find the relevant problem in this manual or on our website, or if the corrective procedure does not resolve the problem, please contact Silex Technology Customer Support.

Contact Information		
USA	+1-657-218-5199	support@silexamerica.com
Europe	+49-2154-88967-0	support@silexeurope.com



Visit the Silex Technology website (https://www.silextechnology.com/) for the latest FAQ and product information.

Note



The Mesh network can easily be established using BR-400AN.

As 2.4GHz/5GHz wireless communication bands are supported, the wireless devices can easily be joined to the Mesh network after they are connected to BR-400AN via a wired LAN.

2-1. What is Mesh Network?

In the Mesh network, several Mesh-network compatible devices (hereinafter, "Mesh devices") are connected each other to configure a network without using Access Point. It allows communication in a wider area as the range of radio wave can be expanded by relay.

Also, Mesh devices communicate each other regularly to select a best route for relay. For example, if a device (BR-400AN(3)) has malfunctioned when the route (1) is used, the rest of devices will continue communication by rebuilding the route (2).



2-2. Features

BR-400AN has the following features:

Giving unlimited locations for your non-wireless devices

As you do not have to care wiring conditions in order to establish your environment, choices of location greatly expand in any kinds of scenes such as office, factory, school, commercial facility, etc. where the layout change is frequently required or effective layout of equipment needs to be carefully considered for a work line. Also, since the Mesh network can be created using two or more BR-400AN units, cost reductions could be expected as you will not have to prepare Access Point for each channel.

IEEE 802.11a/b/g/n

BR-400AN supports communications at both 2.4GHz/5GHz bands. Using 5GHz band will help to avoid radio interference with 2.4GHz band which is most commonly used in the market.

Advanced security

The following security features are supported:

- WEP (64bit/128bit)
- WPA-PSK (AUTO/TKIP/AES), WPA2-PSK (AUTO/AES)
- IEEE 802.1X, WPA-Enterprise (AUTO/TKIP/AES), WPA2-Enterprise (AUTO/AES)

Two types of operating mode

< Mesh Point mode (hereinafter, "MP mode") >

- A radio wave is relayed from the other Mesh devices in the Mesh network. Also, the wired devices can be used over the Mesh network via BR-400AN.
- < Mesh Access Point mode (hereinafter, "MAP mode" >
 - In addition to the MP mode function, Access Point function will run. BR-400AN can be used as Access Point to connect wireless client devices.

On-board storage chip with 1GB memory

The operating log data can be stored in the on-board storage chip for a long period of time. This will help you to quickly resolve the troubles that may occur during the use of BR-400AN.

Easy access to the Web configuration interface

Without changing the setting of the PC you use for setup, the Web configuration interface of BR-400AN can easily be accessed.

AMC Manager® (non-free program) / AMC Manager® Free (free program)

BR-400AN supports the total management software, "AMC Manager®". The AMC Manager® provides the useful features as follows:

- Remote device control and monitoring
- Bulk configuration IP address configuration Firmware updates
- Visualization of the Mesh network using Mesh Monitor (option utility)



Note

2-3. Parts and Functions

The parts name and functions are as follows:

(FRONT)



(1)	Push Switch	Start in Configuration Mode	Press and hold this switch for 5 sec while BR-400AN is active.
		Factory default configuration	Press and hold this switch while turning on BR-400AN and release it when the WLAN LED turns from Green to Red.
(2) Status LED	Plink (Orange)	Waits for connection when the Link LED is turned off.	
		Blink (Orange)	Handles data communication when the Link LED is turned on.
(3)	LAN port	Connect a network cable.	
(4)	Link LED	ON	Has connected to a wired LAN.
(5)	AC connector	Connect an AC adaptor.	

2. Specifications



(6)	POWER LED	ON (Green)	Powered on.	
		ON (Red)	Turns on when BR-400AN is started in Configuration Mode.	
		* Turns green for 2 sec after BR-400AN is powered on and then turns off.		
		When the power-on process is completed, it turns green again.		
		* Blinks red together with the STATUS LED if some Mesh devices have a different setting for		
		Route Switching Mo	ode or Transmission Control Function.	
(7)	WLAN LED	ON (Green)	Connected to the Mesh device in MP mode.	
		Blink (Green)	Not connected in MP mode.	
		ON (Orange)	Connected to the Mesh device in MAP mode.	
		Blink (Orange)	Not connected in MAP mode.	
		Blink (Red)	DFS function is in progress.	
		* Turns from Green to	Red during the factory default configuration.	
		* Blinks Green together with the STATUS LED when operating in Configuration Mode.		
(8)	STATUS LED	ON (Green)	Connected to the Mesh device. The link quality is good and	
		ON (Green)	communication with the Mesh device is stable.	
		ON (Orange)	Connected to the Mesh device. The link quality is OK and it is possible	
			to connect to the Mesh device.	
		ON (Red)	Connected to the Mesh device. The link quality is poor and the	
			network environment needs to be improved.	
		Blink (Green)	Data communication is in progress when link quality is good.	
		Blink (Orange)	Data communication is in progress when link quality is OK.	
		Blink (Red)	Data communication is in progress when link quality is poor.	
* Does not blink when co		* Does not blink when	n connection is not established.	
		 * Blinks Green together with the WLAN LED when operating in Configuration Mode. * Blinks red together with the POWER LED if some Mesh devices have a different setting for Route Switching Mode or Transmission Control Function. 		
		MAC Address of the L	AN port on BR-400AN. The last 6-digit number is a serial number.	
(9)	MAC Address	Example) If the MAC	Address is "84:25:3F:00:11:22", it would be noted as "84253F001122"	
		and then the serial nu	umber is "001122".	

2-4. Hardware Specification

	1			
Operating environment	Temperature : 0 degrees to +40 degrees			
	Humidity : 20% to 80	%RH (Non-condensing)		
Storage environment	Temperature : -10 degrees to +50 degrees			
	Humidity : 20% to 90	Humidity : 20% to 90%RH (Non-condensing)		
EMI	VCCI Class-B			
	FCC Part15 SubPart B Class-B			
	ICES-003 Class-B			
	CE EN301489-1/-17 (EN55032 Class-B)		
Wired network interface	10BASE-T/100BASE-T	X/1000BASE-T (Auto-sensing) :1 port		
	Auto MDI/MDIX			
Wireless network interface	IEEE 802.11a/b/g/n			
Channel	(US/CA)	(US/CA)		
	2.4GHz: 1-11ch			
	5GHz: (W52) 36,40,44,48			
	(W53) 52,56,60,64			
	(W56) 100,104,108,112,116,132,136,140 (W58) 149,153,157,161,165 (ELI)			
	2 4GHz· 1-13ch			
	5GHz (W52) 36 40 44 48			
	(W56) 100 104 108 112 116 120 124 128 132 136 140			
Push Switch	1			
LED	Тор	POWER (Green / Red)		
		WLAN (Green / Red / Orange)		
		STATUS (Green / Red / Orange)		
	LAN Port	Status (Orange)		
		Link (Green)		
Compatible devices	Network devices wit	h LAN port (RJ-45)		

FCC / IC Notice



FCCID : N6C-SXPCEAN2 IC : 4908A-SXPCEAN2

Channel Selection For product available in the USA/Canada market, only channel 1~11 can be operated. Selection of other channels is not possible.

Fcc Rules Part 15 FCC CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Rules, Part 15 §15.19(a)(3) / IC RSS Gen §8.4

Below sentences must be indicated on the final product which contains this module inside.

This device complies with Part 15 of FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device.

Le présent appareil est conforme à la partie 15 des règles de la FCC et CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

FCC Rules Part 15 Subpart C §15.247 and Subpart E / IC RSS-102 §2.6

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 20cm or more away from person's body.

Cet équipement est conforme aux limites d'exposition aux rayonnements énoncées pour un environnement non contrôlé et respecte les règles les radioélectriques (RF) de la FCC lignes directrices d'exposition et d'exposition aux fréquences radioélectriques (RF) CNR-102 de l'IC. Cet équipement doit être installé et utilisé en gardant une distance de 20 cm ou plus entre le radiateur et le corps humain.

FCC Rules Part 15 Subpart E §15.407(c)

Compliance with FCC requirement 15.407(c)

Data transmission is always initiated by software, which is the passed down through the MAC, through the digital and analog baseband, and finally to the RF chip. Several special packets are initiated by the MAC. These are the only ways the digital baseband portion will turn on the RF transmitter, which it then turns off at the end of the packet. Therefore, the transmitter will be on only while one of the aforementioned packets is being transmitted.

In other words, this device automatically discontinue transmission in case of either absence of information to transmit or operational failure.

FCC Rules Part 15 Subpart E §15.407(g)

Frequency Tolerance: +/-20 ppm

FCC Rules Part 15 Subpart C §15.247(g) / Subpart E

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

RSS-Gen §8.3

This radio transmitter 4908A-SXPCEAN2 has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Le numéro IC du présent émetteur radio 4908A-SXPCEN2 a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés ci-dessous et avant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué pour ce type, sont strictement interdits pour l'exploitation avec cet appareil.

- Antenna type External printed PCB antenna

- Model H2B1PC1A1C

- Antenna Gain 2.4GHz : +1.8dBi (Peak)

5GHz:+3.9 dBi (Peak)

RSS-210

5150-5250 MHz and 5250-5350 MHz bands are restricted to indoor operations only.

High-power radars are allocated as primary users (i.e. priority users) of the bands 5250-5350 MHz and 5650-5850 MHz and that these radars could cause interference and/or damage to LE-LAN devices.

La bandes 5150-5250 MHz et 5250-5350 MHz ont restreinte à une utilisation à l'intérieur seulement. Les radars de haute puissance sont désignés comme utilisateurs principaux (c'est-à dire utilisateurs prioritaires) pour les bandes 5250-5350 MHz et 5650-5850 MHz, et que ces radars peuvent provoquer du brouillage et/ou des dommages aux dispositifs LAN-EL.

WARNING

The FCC / The Industry Canadaregulations provide that changes or modifications not expressly approved by the party responsible for compliance could void the user'sauthority to operate the equipment.

CE Notice

2-5. Software Specification

Normal Mode

TCP/IP	Network layer	ARP, IP, ICMP, RSTP
	Transport layer	TCP, UDP
	Application layer	HTTP, DNS client, DHCP client, NTP, FLDP, SX-SMP
		* FLDP, SX-SMP are the silex proprietary protocols.

Configuration Mode

TCP/IP	Network layer	ARP, IP
	Transport layer	TCP, UDP
	Application layer	HTTP, DNS(simple reply function only), DHCP (simple server function only),
		NetBIOS over TCP/IP (Name Service only), FLDP
		* FLDP is the silex proprietary protocol.

2-6. Optional Utilities

By using the following optional utilities, the Mesh network can be visualized and the time of device management can be reduced.

- AMC Manager®
- Mesh Monitor

What is AMC Manager®?

AMC Manager[®] is the unified device management utility that provides remote status monitoring and individual/bulk configuration for Silex devices over an IP network. If AMC Manager[®] is used, the BR-400AN's operating status can be shown as a list.

AMC Mar	nager						-		×
<u>File Edit</u> S	itat <u>u</u> s <u>S</u> ettings <u>T</u> o	ols <u>H</u> elp							
C		BBGC	b 🗗 · 🕼 ·	0.6	- 🔊				م
Group		Device Name	Ethernet Address	Host Name	IP Address	Version	Status		
Detect	ed Devices	🔮 BR-400AN	84:25:3F:01:09:E8	SX0109E8	172.25.72.100	1.2.0.1	Active		
		SR-400AN	84:25:3F:01:09:F1	SX0109F1	172.25.72.101	1.2.0.1	Active		
		SR-400AN	84:25:3F:01:09:F2	SX0109F2	172.25.72.102	1.2.0.1	Active		
		SR-400AN	84:25:3F:01:09:F3	SX0109F3	172.25.72.103	1.2.0.1	Active		
		SR-400AN	84:25:3F:01:09:F4	SX0109F4	172.25.72.104	1.2.0.1	Active		
		🕑 BR-400AN	84:25:3F:01:09:F5	SX0109F5	172.25.72.105	1.2.0.1	Active		
		🕑 BR-400AN	84:25:3F:01:09:F6	SX0109F6	172.25.72.106	1.2.0.1	Active		
		🔮 BR-400AN	84:25:3F:01:09:F7	SX0109F7	172.25.72.107	1.2.0.1	Active		
		🔮 BR-400AN	84:25:3F:01:09:F8	SX0109F8	172.25.72.108	1.2.0.1	Active		
		🔮 BR-400AN	84:25:3F:01:09:F9	SX0109F9	172.25.72.109	1.2.0.1	Active		
		🔮 BR-400AN	84:25:3F:01:09:FA	SX0109FA	172.25.72.110	1.2.0.1	Active		
		🔮 BR-400AN	84:25:3F:01:09:FB	SX0109FB	172.25.72.111	1.2.0.1	Active		
		🔮 BR-400AN	84:25:3F:01:09:FC	SX0109FC	172.25.72.112	1.2.0.1	Active		
		🕑 BR-400AN	84:25:3F:01:09:FD	SX0109FD	172.25.72.113	1.2.0.1	Active		
		🛇 BR-400AN	84:25:3F:01:09:FE	SX0109FE	172.25.72.114	1.2.0.1	Active		
		🛇 BR-400AN	84:25:3F:01:09:FF	SX0109FF	172.25.72.110	1.2.0.1	Active		
		🛇 BR-400AN	84:25:3F:01:0A:00	SX010A00	172.25.72.110	1.2.0.1	Active		
	-	<							
Event Log									
Level	Date/Time	Event	Device Name	Ethernet Address	Host Name	C	etails		
🕕 Informa	9/11/2018 8:40:34 A	M Device detecti	BR-400AN	84:25:3F:01:0A:00	SX010A00	C	evice was found.		
lnforma	9/11/2018 8:40:30 A	M Device detecti	BR-400AN	84:25:3F:01:09:FF	SX0109FF	C	Device was found.		
lnforma	9/11/2018 8:40:28 A	M Device detecti	BR-400AN	84:25:3F:14:09:FE	SX0109FE	C	evice was found.		
🕕 Informa 9/11/2018 8:40:25 AM		M Device detecti	BR-400AN	84:25:3F:01:09:FD	SX0109FD	C	evice was found.		
🚺 Informa	9/11/2018 8:40:24 A	M Device detecti	BR-400AN	84:25:3F:14:09:FC	SX0109FC	0	evice was found.		
🚺 Informa	9/11/2018 8:40:22 A	M Device detecti	BR-400AN	84:25:3F:01:09:FB	SX0109FB	0	evice was found.		
item(s) select	ted.								

As shown in the image below, AMC Manager[®] can configure IP address and write the same setting to several units at once.



For AMC Manager[®], there are a free version "AMC Manager[®] Free" and a non-free version "AMC Manager[®]". When a non-free version is used, more devices can be managed and configured at once and the plug-in utilities such as Mesh Monitor, etc. can be used.

Function	AMC Manager® Free (Free version)	AMC Manager® (Non-free version)	
Number of controllable devices	Up to 10 devices	Up to 10,000 devices	
Number of devices that can be controlled at a time	Up to 10 devices	Up to 10,000 devices	
Number of groups that can be created	Up to 2 devices	Up to 100 devices	
Number of devices that can be registered per group	Up to 10 devices	Up to 1,000 devices	
Plug-in utility such as Mesh Monitor	Unavailable	Available	



- To use AMC Manager® (non-free version), the license key needs to be purchased.

- If you are interested in purchasing the license, please contact us. For the contact information, refer to 1-3. User Registration and Customer Services - Customer Support Center.

Display on Mesh Monitor

What is Mesh Monitor?

Mesh Monitor is a non-free plug-in utility of AMC Manager®.

Mesh Monitor can visualize the route setting and operating status to support the Mesh network management.

Actual environment



As shown in the image above, the actual installation environment is simulated on Mesh Monitor. The route information is displayed based on the actual route setting of BR-400AN. It is possible to change some functions of BR-400AN using Mesh Monitor (e.g. enabling/ disabling Access Point function, etc.). Also, a history of Mesh network route and BR-400AN's operating status can be checked and which can be used conveniently for troubleshooting.



- Mesh Monitor does not come with AMC Manager[®].
- Mesh Monitor is a non-free plug-in utility of AMC Manager[®]. To install it, another license key needs to be purchased.
- If you are interested in purchasing the license, please contact us. For the contact information, refer to 1-3. User Registration and Customer Services Customer Support Center.

2-7. Wireless Interference Information

Notes of Use

Do not use BR-400AN near the following devices or places.

- Microwave, pacemaker, etc. of industrial, scientific and medical devices
- Licensed radio station in a factory
- Small power radio station (A non-licensed radio station)

These devices may use the same band. If you use BR-400AN near these devices, the radio waves emitted from BR-400AN may interfere with them.

Do not use BR-400AN near a cellular phone, TV or Radio.

A cellular phone, TV and radio use a different radio band than our products. Generally, if they are used near BR-400AN, it will not cause any problems. However, when they approximate BR-400AN, sound or image noise may occur.

If there is reinforced concrete/metal between wireless devices, they may not connect.

BR-400AN can connect through wood or glass, but may have troubles connecting through reinforced concrete/metal.

BR-400AN complies with the certification of conformance to technical standards. Please pay attention to the following points:

- Please do not disassemble or remodel the product. Such action is prohibited by law.
- Please do not remove the certificate label. Using the product without a label is prohibited.

Wireless devices using 2.4GHz band

The same frequency band of BR-400AN is used for a microwave, industry, science, medical equipment and licensed in room or low power (non-licensed) radio stations.

- Before you use BR-400AN, check that it does not interfere with other devices.
- If interference occurs, stop using BR-400AN or change the wireless band. Please consider to create a wall between these devices to avoid interference. Contact us to for possible solution.

* The meaning of the symbols in the bottom of the unit:



2.4	: Wireless devices using 2.4GHz frequency band
DS/OF	: DS-SS or OFDM is used as modulation.
4	: The range of interference is equal to or lower than 40m.
	: All bands can be used to avoid interference.

Notes on using 5GHz band

Use of 5.2GHz band (W52) and 5.3GHz band (W53) outdoors is prohibited by the radio law. When BR-400AN is used outdoors, use W56 channels only and do not use W52/W53 channels.

DFS

BR-400AN supports DFS (Dynamic Frequency Selection) of the IEEE 802.11h wireless standard. When radar signals are detected, the channel will automatically be switched to avoid interference with radar systems (e.g. weather radar, etc).

One alternative channel can individually be set for W53/W56 channels beforehand, which will be used when radar signals are detected and the channel needs to be switched. When alternative channels are not specified or radar signals are detected even for that channel, the channel is randomly is changed.



- If Use DFS Band is ON, the DFS channels can be used (it is set to OFF by default).
- When BR-400AN is started with a DFS channel, it checks if there are radar signals on that channel. During such a period, BR-400AN is unable to communicate.
- If radar signals are detected during or after BR-400AN is powered on, the channel needs to be changed in order to avoid wireless interference. Therefore, if DFS channels are selected, the channel could be changed automatically.
- The radar signals are monitored for a certain amount of time (*) after it is detected, while wireless communication is disabled on BR-400AN then. Once radar signals are detected, the channel will not be available for 30 mins. (* This time period differs depending on the country.)
- If radar signals are detected when they are monitored, the channel is switched to CH36. If radar signals are not detected by MP/MAP, a scan is handled on CH36. When connectable MP/MAP are found, the channel is switched to CH36. When it is not found, the same channel is used. This operation is processed only when the channel is W53.
- When the channel is switched after radar signals are detected, the destination channel is notified to the adjacent MP/MAP. MP/MAP switches the channel when it receives the notification.

2-8. Notes on Security

Because a wireless LAN uses electromagnetic signals instead of a network cable to establish communication with network devices, it has the advantage of allowing devices to connect to the network easily. However, a disadvantage of this is that within a certain range, the electromagnetic signals can pass through barriers such as walls, and if security countermeasures are not implemented in some way, problems such as the following may occur.

- Communication is intercepted by a third party
- Unauthorized access to the network
- Leakage of personal information (ID and Card information)
- Spoofing and the falsification of intercepted data
- System crashes and data corruption

Nowadays, wireless LAN cards or access points are equipped with security measures that address such security problems, so that you can enable security-related settings for wireless LAN products in order to reduce the likelihood of problems occurring.

We recommend that you make yourself fully acquainted with the possible implications of what might happen if you use a wireless product without enabling security features, and that you configure security-related settings and use wireless products at your own responsibility.

2-9. Restrictions

BR-400AN has the following restrictions.

Restrictions on DFS Channels

- If radar signals are detected again during the radar monitoring period that occurs as a result that radar signals are found when BR-400AN is started or operating (*), BR-400AN may not be able to join the network of adjacent MP/MAP.
- For some wireless environments, even if the destination channel is notified to the adjacent MP/MAP, the channel switch may not perform as the notification is not received correctly.
- If BR-400AN is restarted after it detected radar signals and switched the channel, BR-400AN starts with the pre-configured channel NOT with the channel it switched. If the channel is different from the adjacent MP/MAP, BR-400AN will not be able to join the same network.

(* This time period differs depending on the country.)

3. How to Install BR-400AN

This chapter provides the notes and examples of installation.

3-1. How to Install BR-400AN

The wireless distance, installation method and power-on method are explained.

Product Installation and Radio Distance

BR-400AN radiates radio waves. Make sure that the top surface of BR-400AN (the surface with Silex logo and LEDs) face a target device.

As a wireless communication distance is set to approximately 20m by defaults, place the target device within that range. The height of installation position must be about 2m from the ground.





An actual wireless communication distance may vary depending on wireless signal status on your environment.



 By changing the transmission power setting on BR-400AN, the wireless communication distance can be expanded / shortened. For details, refer to 5-1. Configuration Items on BR-400AN's Web Page - Option Configuration page.

Connecting BR-400AN with Firmware Version 2.0.0 or Lower

Execute one of the followings when BR-400AN is connected to an older version of BR-400AN (Ver.2.0.0 or lower) in the Mesh network.

- Update the older version of BR-400AN to the latest version. Make sure that all BR-400AN units have the same setting for **Route Switching Mode** and **Transmission Control Function**, then.
- For all BR-400AN units with the firmware version 2.0.0 or later, select **Responsive Type** for **Route Switching Mode**.





How to Turn on BR-400AN

Below explains how to turn on BR-400AN and how the LED lights when BR-400AN is operating correctly.

1. Connect the AC adapter to BR-400AN (1) and the AC plug to outlet (2).



2. When BR-400AN is started, the LED turns on or blinks as shown at (1). When the Mesh network is configured, the LED turns on or blinks as shown at (2)(3)(4).





If the POWER LED and the STATUS LED blink red together, some BR-400AN units have a different setting for **Route Switching Mode** or **Transmission Control Function**.



- When BR-400AN is operating in MP mode, the WLAN LED turns or blinks green.
- To improve a link quality, confirm the followings and change the location of installation if necessary.
 - No reinforcing bars, metal and concrete walls or poles are installed in front of the radio emission portion.
 Not too far away from the other BR-400AN units
 - The bottom surface of BR-400AN is not facing a concrete wall.

3-2. Example of Installation

BR-400AN can configure various types of the Mesh network by changing the combination of settings and devices.

In this section, some examples of typical installation are introduced.

See the example that best matches your environment to install BR-400AN.

- When the Mesh network is established using BR-400AN only
- When BR-400AN is connected to your existing network
- When the Mesh network is divided for each area
- When tablet devices or PCs are connected wirelessly

Configuring Mesh network using BR-400AN only

The following is a sample configuration image for the Mesh network using BR-400AN only without using the existing network.





- The sample network above can be configured by default setting.
- If a valid IP address has already been configured to each device and they can communicate among each other, you do not have to install a new DHCP server to congure the Mesh network.
- As long as a valid IP address is configured, PC (A), PC (B) and IP device can communicate with each other.
- As shown in above image, even if an error occurs to BR-400AN (4) and the route (1) becomes unavailable, the devices will continue to communicate through the route (2).
- The communication speed can be improved by selecting **DISABLE** for **Avoid Network Loop** on all BR-400AN units.

Connecting BR-400AN to your existing network

The following is a sample configuration image for the Mesh network when adding multiple BR-400AN units to your existing network.





If the Mesh network meets two conditions below, the **Network Loop Avoidance** setting needs to be set to **ENABLE** on the BR-400AN units that are connected to the existing network via a wired LAN (by default, this setting is **DISABLE**).

- Two or more BR-400AN units are directly connected to the existing network using network cables.
- In the existing network, there is no Ethernet HUB on which RSTP function is turned on.



The sample network above can be configured by default setting.

- If a valid IP address has already been configured to each device and they can communicate among each other, you do not have to install a new DHCP server to congure the Mesh network.
- As long as a valid IP address is configured, PC (A), PC (B) and IP device can communicate with each other.
- As shown in above image, even if an error occurs to BR-400AN (4) and the route (1) becomes unavailable, the devices will continue to communicate through the route (2).
- The communication speed can be improved by selecting **DISABLE** for **Avoid Network Loop** on the BR-400AN units (2)-(4).

Dividing the Mesh network for each area

The Mesh network can be configured separately for each section of the area where BR-400AN units are installed. The following is the example of how to configure the Mesh network for each section. For this, Mesh ID and Mesh encryption key need to be changed for each area.

For details, refer to 5-1. Configuration Items on BR-400AN's Web Page - Basic Configuration page.



If the Mesh network meets two conditions below, the Network Loop Avoidance setting needs to be set to
 ENABLE on the BR-400AN units that are connected to the existing network via a wired LAN (by default, this setting is DISABLE).

- Two or more BR-400AN units are directly connected to the existing network using network cables.
- In the existing network, there is no Ethernet HUB on which RSTP function is turned on.



- If a valid IP address has already been configured to each device and they can communicate among each other, you do not have to install a new DHCP server to congure the Mesh network.
- **Note** As long as a valid IP address is configured, each PC, server and IP device can communicate with each other.
 - As shown in above image, even if an error occurs to BR-400AN (9) and the route (1) becomes unavailable, the devices will continue to communicate through the route (2).
 - The communication speed can be improved by selecting **DISABLE** for **Avoid Network Loop** on the BR-400AN units which are not connected to the Ethernet HUB.
Connecting tablet devices or PCs wirelessly

By using the Access Point function of BR-400AN, wireless client devices (PC, tablet device, etc.) can be connected to the Mesh network.

For details on how to enable the Access Point feature of BR-400AN and connect wireless client devices, refer to **6. How to Connect Wireless Client Devices**.





 If the Mesh network meets two conditions below, the Network Loop Avoidance setting needs to be set to ENABLE on the BR-400AN units that are connected to the existing network via a wired LAN (by default, this setting is DISABLE).

- Two or more BR-400AN units are directly connected to the existing network using network cables.
- In the existing network, there is no Ethernet HUB on which RSTP function is turned on.
- If a valid IP address has already been configured to each device and they can communicate among each other, you do not have to install a new DHCP server to congure the Mesh network.
- **Note** As long as a valid IP address is configured, PC (A), PC (B), tablet device and IP device can communicate with each other.
 - As shown in above image, even if an error occurs to BR-400AN (4) and the route (1) becomes unavailable, the devices will continue to communicate through the route (2).
 - The communication speed can be improved by selecting **DISABLE** for **Avoid Network Loop** on the BR-400AN units (2)-(4).

4 How to Configure BR-400AN

This chapter explains how to configure BR-400AN. The following configuration methods are available:

- 1) Configuration via the BR-400AN's Web page
- 2) Configuration using AMC Manager®
- 3) Configuration using Mesh Monitor

4-1. Configuration via BR-400AN's Web Page

Below explains how to configure BR-400AN via its Web page.

If you know the IP address of BR-400AN, the Web page can be accessed by entering the IP address to the address bar of Web browser. If you do not know the IP address, the Web page can be accessed by starting BR-400AN in configuration mode.

Accessing the BR-400AN's Web Page Using Configuration Mode

How to access the BR-400AN's Web page using the configuration mode is explained.

1. Connect BR-400AN and the PC using a network cable (1) and turn on BR-400AN (2)(3).



2. On top surface of BR-400AN, check that the POWER LED turns green and the WLAN LED turns or blinks orange/green (1). Push and hold the push switch on the front surface (2). When the POWER LED turns red and the WLAN LED and the STATUS LED start to blink green together (3), release the push switch (4) (it may take 20 sec until both LEDs start to blink).

BR-400AN will start to run in a conguration mode and conguration will become available on the PC that has been connected to BR-400AN using the network cable.





When BR-400AN is started, only the POWER LED turns green for 2 sec and then turns off. If the push switch is pushed then, BR-400AN is not started in the configuration mode.

Before you push the push switch, check that the POWER LED turns green and the WLAN LED turns or blinks _ orange/green.

3. Start a Web browser on the PC. When the login password configuration page appears, enter the password to configure for BR-400AN and click **Submit**.

■ Welcome to BR-400AN		2
	Please set a password for this unit. Password Confirm Password 1-15 Character String(Password) Submit	
	Select Language English	



- The login password configuration page is displayed only when BR-400AN is configured for the first time.



I Ne	w tab		× +
\leftarrow	\rightarrow	U	http://silex

4. The login page of BR-400AN is displayed. Enter the password of BR-400AN and click **Login**.

Welcome to BR-400AN	
	Enter the password, and click [Login]. Password Login
	Select Language
	English V

Accessing BR-400AN's Web Page over Network

If you know the IP address of BR-400AN, BR-400AN does not need to be started in the configuration mode. Access the BR-400AN's Web page from your PC and change the configuration from the Web page.

1. Start a Web browser (Edge, Internet Explorer, Google Chrome, etc.) on the PC and enter the IP address of BR-400AN to the address bar of the Web browser.

🚥 New tab		× +
$\leftarrow \ \rightarrow $	\bigcirc	http://192.168.0.1

2. When the login password configuration page appears, enter the password to configure for BR-400AN and click **Submit**.

■ Welcome to BR-400AN		050
	Please set a password for this unit. Password Confirm Password 1-15 Character String(Password) Submit	
	Select Language English	



- The login password configuration page is displayed only when BR-400AN is configured for the first time.

3. The login page of BR-400AN is displayed. Enter the password of BR-400AN and click **Login**.

Uelcome to BR-400AN	
	Enter the password, and click [Login]. Password Login
	Select Language English

Configuration via BR-400AN's Web Page

When the login password authentication is successfully finished, the window below is displayed. When the login password is not set, the login page is skipped and the window below is immediately displayed.



(1) Menu

If clicked, the configuration page is changed.

(2) Tab

The tab is displayed when there are multiple pages for the configuration. If the tab is clicked, the configuration page is changed.

(3) Configuration page

Each setting can be configured.

(4) Link to Help

The Help page is displayed. The Help page provides the detailed explanation of each setting.

(5) Firmware version / MAC address

The firmware version and MAC address of BR-400AN are displayed.

(6) Submit (Save) button

If clicked, the changes you made to the configuration page will be saved. (You may need to scroll-down the screen to find this button.)

(7) Clear button

If clicked, the changes you made to this configuration page will be cleared. (You may need to scroll-down the screen to find this button.)



- Be sure to change the password when BR-400AN is connected to a public network.
- Be sure to use encryption when the Access Point feature of BR-400AN is used.
- The wireless bands of IEEE 802.11b/g and IEEE 802.11n/b/g are often in use by someone as a large number of wireless devices are using that bands. In such a case, you may not be able to procure enough communication bands for your use.
- Follow the radio law of your country when BR-400AN is used outdoors. There are restrictions on the communication bands (channels) that you can use outdoors.
- When W53(52/56/60/64ch) or W56(100/104/108/112/116/120/124/128/132/136/140ch) is selected, you may need to refer to the restrictions at **2. Specifications 2-7. Wireless Interference Information DFS**.

1. Select the configuration page by clicking the menu or tab and enter the necessary settings. Click **Submit** when finished.

silex technology	Basic Configuration		
Select Language English ~	Basic Configuration		
System Configuration Basic Access Point Function Option	 DNS Configuration Name 	Value	,
▼ Maintenance - Login Password - Reboot - Factory Default	DNS Server (Primary) DNS Server (Secondary)	0000	
-Firmware Update -Log	Mesh General Configuration		
▼ Information	Name	Value	
	Wreless Mode Channel Bandwidth Use DFS Band Channel Mesh Group Name Mesh Encryption Key	80211n/b/c > 2/4FE 602/11n/c 80211n/b/c 5944c ::90211n, 90211n/b 20MHz > 0FF v <0FF (Recommended) 11 · > SK-MESH-NET	
	Mesh Route Configuration		
	Name	Value	
	Max Hop Count Route Refresh Function Route Refresh Nethod Route Refresh Interval Route Switching Mode Transmission Control Function Network Loop Avoidance	No Limit ∨ ENABLE ∨ Licht refresh Mode ∨ 3000 Stable Type ∨ ENABLE ∨ DISABLE ∨	
			Submit Re et
silex BR-400AN			
Ver 2.0.1 [84:253f00:11:22]			Capyright (C) 2017 silex technology, Inc.



For details on each configuration item, refer to **5. List of Configuration Items**.

Note

2. The message below is displayed. Repeat **1** to continue the configuration.

Solice So	Basic Configuration	65
Endish V System Configuration Basic Access Point Function Option Usin Function Login Password Bactory Befault Finnware Update Log Unformation	Setting is completed To take effect of this setting please restart.	
- License Information		

3. When the configuration is completed, restart BR-400AN. Click **Reboot** from the menu (1) and Click **Yes** (2).

technology	# Reboot	COT
Select Language English V	Reboot	
System Configuration System Configuration Satisfy Solution Second State Second Second State Second State	This product will be rebooted.	
silex BR-400AN		
Ver 2.0.1 [84:253f00:11:22]		Copyright (C) 2017 silex technology, Inc

4. BR-400AN is restarted.

When the progress bar reaches the right end of the screen, the restart is completed. Finish the Web browser then.

Silex technology Select Language	
English V System Configuration Basic Access Point Function Option	Flesse wait while the device is restarting.
Maintenance Login Password Reboot Reboot Factory Default Firmware Update Log	
- License Information	

4-2. Bulk Configuration Using AMC Manager®

If the unified device management software AMC Manager[®] is used, several BR-400AN units can be configured at once. The bulk configuration method is explained.



- For details on AMC Manager®, refer to the AMC Manager® User's Manual.

Preparation for Bulk Configuration

Create a configuration file for bulk configuration using AMC Manager[®]. To create the configuration file, following items are necessary.

- PC (AMC Manager® needs to be installed)



When the login password is not set to a device, please include that setting to the configuration file. If the login password is not set, the bulk configuration does not perform correctly.

1. Start AMC Manager[®] on the PC.

AMC Ma	nager						- 🗆	\times
<u>File E</u> dit S	Eile Edit Stat <u>us S</u> ettings Iools Help							
CS		G B G (b 📝 • 🚺 •	G G 🕸	- 🔊			٩
Group		Device Name	Ethernet Address	Host Name	IP Address	Version	Status	
🔎 Detect	ed Devices							
		<						>
Event Log								
Level	Date/Time	Event	Device Name	Ethernet Address	Host Name	Details		
0 device(s) fou	ind.							

2. From the toolbar, click the icon Create the configuration file and select Create from Template.





3. Select a template file for BR-400AN (1) and click **OK** (2).





The template to select will vary depending on the firmware version of BR-400AN. When the version is 2.0.0 or higher: Select **BR-400AN Ver.2.0.0**. When the version is 2.0.0 or lower: Select **BR-400AN**. **4.** If a configuration category is clicked on the left side of the screen (1), the corresponding setting is displayed on the right side (2).



5. Check the check boxes of the settings to configure and edit them (1). When finished editing the necessary settings, click **Save** (2).

Create Configuration File - BR-400	AN	>
Edit the file to use for bu	k configuration.	
	0	
System Configuration Network Configuration Wired LAN Configuration Wireless LAN Origination Wireless LAN UF 1 Wireless LAN UF 2 Others	Item Basic Settings P Address P Address Subnet Mask Default Greway DHCP Client DHS Server (Primary)] DHS Server (Secondary) Server Function Local Time Zone NTP Client NTP Server Address	Contents 0.0.0 0.0.0 0.0.0 Enable Disable -9:00 Disable (1)
Display the password		Open Save 💌 Close
		(2)



- If an IP address is specified in the configuration file, such address will be configured to all devices when the same configuration file is used for them. Clear the check box of IP address to avoid it.
- There is a combination of the settings unable to write into BR-400AN units. Below is the example.
 - Wireless mode is set to 802.11n/b/g or 802.11n/a while WEP is enabled.
 - WEP is enabled and incompatible number of characters are used to specify WEP key.
- For other examples, refer to A-1. Troubleshooting.



- The setting whose check box is checked will be configured to BR-400AN. For the setting you do not want to change, clear the check box.
- **Note** It is recommended to set/change the password to protect the setting information.
 - Please be careful not to forget the **Password**, **Mesh Group ID**, **Mesh Encryption Key**, **SSID**, **Security Key** (**WEP Key** or **Pre-Shared key**) to configure.
 - It is possible to configure an IP address to several devices at once using AMC Manager[®].

6. Specify a file name to save the configuration file.

Save Configuration	n File			×
$\leftarrow \rightarrow \checkmark \uparrow$	→ This PC → Desktop → si	lex v Ö Se	arch silex	م
Organize 👻 New	w folder		==	- ?
📌 Quick access	Name	Date	Туре	Size
💻 This PC				
network 🧳				
	<			>
File <u>n</u> ame:	mesh_config01			~
Save as <u>t</u> ype:	Configuration File (*.cfg)			~
∧ Hide Folders			<u>S</u> ave	Cancel

After the configuration is saved, the screen of **4** is displayed again. To create a configuration for each Mesh network group, repeat **4-6**.

When the configuration file is created, the preparation for bulk configuration is completed. Click **Close** then.

Starting Bulk Configuration

Multiple BR-400AN units can be configured at once using the configuration file that you have created at **Preparation for Bulk Configuration**.

For bulk configuration, following items are required.

- PC (AMC Manager® needs to be installed)
- Network cable
- **1.** For the bulk configuration of IP address, the IP address of the PC needs to be changed beforehand. Change the IP address of the PC to the one that can be communicated with BR-400AN units after the bulk configuration.

Sample Setting)

Sample IP address setting for bulk configuration	Sample IP address setting for PC
192.168.0.10 - 192.168.0.30	192.168.0.100
172.25.10.10 - 172.25.10.25	172.25.10.100



- The bulk configuration of IP address can be performed for initial configuration.

When you do not handle the bulk configuration, configure the IP address of the PC as follows. When there is a DHCP server:

Enable the automatic IP setting (check **Obtain an IP address automatically**) on the PC. When there is not a DHCP server:

Set the link local address (169.254.xxx.xxx) to the PC.

2. Turn on all BR-400AN units to configure, and connect a PC to one of them.





- The BR-400AN units to configure should temporarily be placed in a close location to configure the Mesh network.

- Finish the bulk configuration before actual use of BR-400AN.

3. Start AMC Manager[®] on the PC.

BR-400AN units are displayed on the device list when they are active on the Mesh network.



- If the BR-400AN units are not displayed on the device list, click the icon **Refresh**.

- It may take approximately 1 min to show them on the device list depending on your environment. **Note**

4. Select the BR-400AN units to configure at once (1) and click the icon **Configure multiple devices in bulk** (2).



5. Specify the configuration file. Select BR-400AN units to configure (1) and click **Select Config. File** (2).



6. Select the configuration file that you have created beforehand.

🛃 Open Configu	ration File						×
$\leftarrow \ \ \rightarrow \ \ \checkmark \ \Lambda$	> This P	C → Desktop → silex	√ Č	Search sile	x		٩
Organize 🔻	New folder						?
- Ouick accor		Name	Date		Туре		Size
A Quick acces	·>	mesh_config01.cfg	10/9/2018 4:05 P	M	CFG File		
a OneDrive		mesh_config02.cfg	10/9/2018 4:05 P	М	CFG File		
This PC							
network 🥏							
	File <u>n</u> ame	mesh_config01.cfg	~	Configura <u>O</u> per	ition File (*.cf	g) Cancel	~

7. The selected configuration file is displayed under **Configuration File Name**. Repeat **5-6** to specify the configuration file for all BR-400AN units.



8. When the configuration file is specified for all BR-400AN units (1), click **IP Configuration** (2).

Bulk Cont	figuration				×
	Change configuration Specify the configura	n for multiple devices in ition file and click [Start	ı bulk.] to start bulk configurat	tion. (1)	
Configu	ration <u>L</u> ist:			(-/	
ss	Host Name	IP Address	New IP Address	Configuration File Name	Add Device
:8 :D	SX0109E8 SX0109FD	172.25.72.251 172.25.72.87		mesh_config01.cfg mesh_config01.cfg	Delete Device
D7	SX3A8AD7	172.25.72.44		mesh_config02.cfg	<u>E</u> dit Device
					Select Config. <u>F</u> ile
					Ones Carlin File
					IP Configuration
					S <u>h</u> ow Config. List
					Open Bulk Config. File
<				>	Save <u>B</u> ulk Config. File
	ut the device after thi	configuration			
	art the device diter thi	sconiguration			<u>S</u> tart

9. Specify the IP address range to configure for BR-400AN units (1). When the setting is finished, click **OK** (2).

IP Address Configuration							×	
Start IP Address:	172 .	25		72		100		
End IP Address:	172 .	25		72		200		
<u>N</u> umber of Steps:	0.	0		0		1		(1
Subnet <u>M</u> ask:	255 .	255		0		0		
<u>D</u> efault Gateway:	172 .	25		72		254		
	OK)	C	an	cel		
	(2)							



For example, if an IP address is configured to three units with the above setting, the first one will obtain the same address as the **Start IP Address** "172.25.72.100". As the **Number of Steps** is "0.0.0.1", the second one and the subsequent one will obtain "172.25.72.101" and "172.25.72.102" respectively.

10. The IP addresses to configure are pre-assigned and displayed under **New IP Address**.

onfigu	iration <u>L</u> ist:				
	Host Name	IP Address	New IP Address	Configuration File Name	Add Device
)	SX0109E8 SX0109FD	172.25.72.251 172.25.72.87	172.25.72.100 172.25.72.101	mesh_config01.cfg mesh_config01.cfg	<u>D</u> elete Device
7	SX3A8AD7	172.25.72.44	172.25.72.102	mesh_config02.cfg	<u>E</u> dit Device
					Select Config. <u>F</u> ile
					Open <u>C</u> onfig. File
					P Configuration
					Merge Config. File
					S <u>h</u> ow Config. List
					Open Bulk Config. File
				2	Save Bulk Config. File

11.Check the check boxes of BR-400AN units to configure (1) and click **Start** (2).





 Please do not check the check box at **Restart the device after this configuration**. The configuration may fail as it makes all BR-400AN units restart regardless of the Mesh network status when the configuration is completed.



- For changes to take effect, BR-400AN needs to be restarted.
- If the check box at the left of **Device Name** is checked, all check boxes are checked.
- **12.** The progress bar is displayed during the configuration and the result is displayed when the configuration is completed. Click **Close** when the configuration is completed.

lk Configuration	is been configured.		×
Device Name	Ethernet Address 84:25:3F:01:09:E8 84:25:3F:01:09:FD 84:25:3F:3A:8A:D7	Status Completed Completed Completed	
		<u>D</u> etails	Close



If the result status does not say "Completed", modify the setting of the configuration file and try again.

Select File - Exit from the menu to finish AMC Manager®.

Turn off the BR-400AN units. When the BR-400AN units are turned on again at the place where you actually use them, they will start with the new settings.

Product Installation

- **1.** After the bulk configuration is completed, bring one of BR-400AN units to a location of installation. Start the BR-400AN before you fix it to that location.
- Check the STATUS LED of the BR-400AN.
 When it configures the Mesh network, the STATUS LED turns as follows according to a link quality.





- When **Route Refresh Function** is set to **DISABLE**, the link quality is not refreshed unless the number of BR-400AN units increases or decreases in the Mesh network. It is recommended to set **ENABEL** for **Route Refresh Function** until you finish installation.
- When the STATUS LED turns red, adjust the location of the BR-400AN. Refer to **3** for details.
- If the POWER LED and the STATUS LED blink red together, some BR-400AN units have a different setting for **Route Switching Mode** or **Transmission Control Function**.



- The link quality is the average value of communication quality for each route. To check the communication quality value of BR-400AN, Mesh Monitor is required.
- When the communication quality is good, it has a higher transmission rate and stable communication.
 - The refresh interval for the link quality changes according to the value of **Route Refresh Interval**. If the value of **Route Refresh Interval** is set smaller, the refresh interval of the link quality becomes shorter.
 - The STATUS LED blinks when the packets are sent or received.
 - When the BR-400AN is operating in MP mode, the WLAN LED turns green.

- **3.** To improve a link quality, confirm the followings and change the location of installation if necessary.
 - No reinforcing bars, metal and concrete walls or poles are installed in front of the radio emission portion.
 - Not too far away from the other BR-400AN units
 - The bottom surface of BR-400AN is not facing a concrete wall.
- **4.** Repeat **1-3** and adjust the unit location one by one. When the adjustment is finished for all units, fix them to the location.

The product installation is now completed.

4-3. Configuration Change Using Mesh Monitor

Some of the BR-400AN's setting can be changed using Mesh Monitor.

The setting can be changed also by using AMC Manager[®] but if Mesh Monitor is used, you can check the simulated Mesh route to change the setting.



- For details on Mesh Monitor, refer to the Mesh Monitor User's Manual.
- The following settings can be configured using Mesh Monitor. For details on each setting, refer to 5-1.

Note Configuration Items on BR-400AN's Web Page.

- Host name
- Route refresh function
- Route refresh method
- Route refresh interval
- Access Point function
- Network loop avoidance
- **1.** Select a single BR-400AN unit on Mesh Monitor (1) and click the icon **Device configuration** from the toolbar (2).





- The setting can also be changed by following methods.
- Select BR-400AN and click Tools Device Configuration.
- Right-click on BR-400AN and select **Device Configuration** from the context menu.
- When the password is set to BR-400AN, the password authentication dialog is displayed. Enter the password of BR-400AN (1) and click **OK** (2).

	(2)	Concer
	ОК	Cancel
<u>P</u> assword:	•••••	
Ethernet Address	84:25:3F:01:09:E8	
Device Name:	SX010A6C9	
Enter the	assword to connect to the device below.	
Enter Password		×

2. In the device configuration window, change the setting and click **OK**.

Device Configuration - SX0109	E8 (84:25:3F:01:09:E8)	×
Configure the device setting.	restarted after finishing configuration	
The device will automatically be	restanced arter ministing configuration.	
<u>H</u> ost Name :	SX0109E8	
■ Enable <u>R</u> oute Refresh Funct	ion	
Route Refresh Method:	Lite Refresh Mode 🛛 🗸	
Route Refresh <u>I</u> nterval: (1-	86400) 2 • se	ac (1)
✓ Enable <u>A</u> ccess Point Functio	on	
✓ Enable Loop Avoidance		
	OK Cance	el
	(2)	



 When the Access Point feature is enabled, SSID, authentication method and encryption mode also need to be configured. For details on the configuration, refer to 5-1. Configuration Items on BR-400AN's Web Page - Access Point Function Configuration Page.

3. The result of configuration change is displayed Click **OK** to close the window.

Mesh Monitor	×
The device configuration is completed.	
ОК	

5. List of Configuration Items

This chapter explains the BR-400AN's configuration items.

5-1. Configuration Items on BR-400AN's Web Page

In the Web page, following settings can be configured.

Basic Configuration

- Host name
- IP address
- Wireless setting (frequency band, etc.)
- Mesh network setting

Access Point Function

- Access Point function (ENABLE/DISABLE), operating setting (SSID, authentication method, etc)
- MAC address filter

Option Configuration

- TX power
- Wired LAN speed
- Time to switch into the configuration mode
- NTP function

Login Password

- Password

Hereinafter, the configuration items available on each page and the examples of configuration are described.

Basic Configuration

The basic settings (necessary settings to use BR-400AN mainly in MP mode) can be configured.



Basic Configuration - Host Name

Host Name					
Details	Set the host name. Be sure to use a unique name that is not used by other devices.				
Range	Up to 15 characters				
Default Value	SXxxxxxx (xxxxxx is a last 6-digit of the Ethernet Address)				
Note	This host name is displayed on AMC Manager [®] and Mesh Monitor.				

Basic Configuration - IP Address

DHCP	
Details	Enable/Disable the DHCP protocol.
	To assign an IP address using DHCP, the DHCP server must be running in the same network.
Range	ENABLE/DISABLE
Default Value	ENABLE
IP Address	
Details	Configure the IP address.
Range	0.0.0.0 - 255.255.255.255
Default Value	0.0.0
Note	When DHCP is enabled, the IP address obtained from DHCP server will be applied.

Basic Configuration - IP Address

Subnet Mas	Subnet Mask		
Details	Configure the subnet mask.		
Range	0.0.0.0 - 255.255.255.255		
Default Value	0.0.0		
Noto	When DHCP is enabled, the subnet mask obtained from DHCP server will be applied.		
Note	When 0.0.0.0 is set, the subnet mask appropriate for the IP address class will automatically be assigned.		
Default Gat	01//21/		
	eway		
Details	Set the gateway address. If "0.0.0.0" is set, this setting is disabled.		
Range	0.0.0.0 - 255.255.255.255		
Default Value	0.0.0		
Note	When DHCP is enabled, the default gateway obtained from DHCP server will be applied.		

Basic Configuration - DNS Configuration

DNS Server (Primary)		
Details	Set a primary DNS server address.	
Range	0.0.0.0 - 255.255.255	
Default Value	0.0.0	
Note	When DHCP client is enabled, the DNS server address obtained from DHCP server will be applied.	
	(Cacandam)	
DNS Server	(Secondary)	
DNS Server	(Secondary) Set a secondary DNS server address.	
DNS Server Details Range	(Secondary) Set a secondary DNS server address. 0.0.0.0 - 255.255.255	
DNS Server Details Range Default Value	(Secondary) Set a secondary DNS server address. 0.0.0.0 - 255.255.255.255 0.0.0.0	

OFF

Default Value

Basic Configuration - Mesh General Configuration

Wireless Mode		
Details	Select the IEEE 802.11 wireless mode.	
Range	802.11b/g, 802.11n/b/g, 802.11a, 802.11n/a	
Default Value	802.11n/b/g	
	802.11b/g : Uses IEEE802.11b or IEEE802.11g.	
Noto	802.11a : Uses IEEE802.11a.	
Note	802.11n/b/g : Uses IEEE 802.11n, IEEE 802.11b or IEEE 802.11g.	
	802.11n/a : Uses IEEE802.11n or IEEE802.11a.	

Channel Ba	ndwidth	
Details	Set the frequency bandwidth.	
Details	This setting is necessary when using 802.11n/b/g or 802.11n/a.	
Range	20MHz/40MHz	
Default Value	20MHz	
	40MHz (High speed) :	
	Uses double bandwidth.	
	Two neighboring bandwidths are combined together for high speed transmission.	
Next	20MHz (Standard) :	
Note	Uses standard (single) bandwidth.	
	If your network becomes unstable when using 40MHz, change it to 20MHz (Standard).	
	* Do not try to use 20MHz and 40MHz together in the same Mesh network.	
LISE DES Bai		
Details	Select whether to use the DFS band channel as a channel (ON/OFF).	
Range	ON / OFF	

Note If this setting is enabled, the channels of DFS band can be selected for the channel setting.

Basic Configuration - Mesh General Configuration		
Channel		
Details	Set the wireless channel. A channel is the divided frequency bandwidth. In a wireless network, bandwidth is divided up so that more devices can communicate at a time. The selectable channels will differ depending on the wireless mode.	
Range	When the wireless mode is 802.11b/g or 802.11n/b/g : (US) 1-11 (EU) 1-13 When the wireless mode is 802.11a or 802.11n/a : (US) 36/40/44/48/149/153/157/161/165 (EU) 36/40/44/48	
Default Value	11	
Note	 If your network becomes unstable due to interference with other wireless devices, it could be improved by changing the channel. The channel you can use will differ depending on the country. When Use DFS Band is ON, the following channels can be used, however, if the following channels are used and radar signals are detected when BR-400AN is turned on, communication will be lost for a certain amount of time (*1). (US/Canada) 52/56/60/64/100/104/108/112/116(*2)/132/136/140 (EU) 52/56/60/64/100/104/108/112/116/120/124/128/132/136/140 The extended channel setting will depend on the communication channel. *1 This period of time will differ on each country. *2 When Channel Bandwidth is 40MHz, 116ch cannot be used. 	
Extension	Channel	
Details	Set the extended channel when 40MHz is selected for channel bandwidth.	
Range	When the wireless mode is 802.11b/g or 802.11n/b/g: (US) 1-11 (EU) 1-13 When the wireless mode is 802.11a or 802.11n/a: (US) 36/40/44/48/149/153/157/161 (EU) 36/40/44/48	
Default Value	7	
Note	When Use DFS Band is ON, the following channels can be used. (US/Canada) 52/56/60/64/100/104/108/112/132/136 (EU) 52/56/60/64/100/104/108/112/116/120/124/128/132/136	
DFS Prima	ary Channel	
Details	Set the alternative channel to use when radar signals are detected during DFS channels are used. If the alternative channel is not specified or radar signal is detected even for that channel, the channel is randomly switched. For details on DFS channel switch, refer to 2-7. Wireless Interference Information - DFS .	
Range	(US/Canada) NONE/52/56/60/64/100/104/108/112/116/132/136/140 (EU) NONE/52/56/60/64/100/104/108/112/116/120/124/128/132/136/140	
Default Value	NONE	
Note	When radar signals are detected on all channels, BR-400AN will switch the channel again approximately 30 mins, starting from the pre-configured channel.	

Basic Configuration - Mesh General Configuration

Mesh Group Name		
Details	iet a group name of the Mesh network to create or join (up to 32 characters). The Mesh network is identified by the Mesh group name. To join the Mesh network, BR-400AN needs to nave the same Mesh group name as that Mesh network.	
Range	A string of 1-32 alphanumeric characters	
Default Value	SX-MESH-NET	
Mesh Encry	ption Key	
Details	Set the encryption key that BR-400AN uses for the Mesh network communication.	
Range	A string of 1-32 alphanumeric characters	
Default Value	silex technology, Inc.	
Note	The Mesh encryption key must be the same for all Mesh devices to join the Mesh network.	

Basic Configuration - Mesh Route Configuration

Max Hop Co	Max Hop Count		
Details	Set the maximum number of the Mesh devices that BR-400AN can create the Mesh route for. When 6 or more hops are needed, select No Limit . As the number of hops increases, the communication speed decreases.		
Range	1, 2, 3, 4, 5, No Limit		
Default Value	No Limit		
Note	The number of hops represents the number of BR-400AN units to use for a communication relay. This number should exclude the number of source unit (1 hop = 2 devices, 5 hops = 6 devices).		
Route Refre	esh Function		
Details	Enable/Disable the regular optimization for the Mesh route.		
Range	ENABLE / DISABLE		

Default Value ENABLE

Route Refresh Method

Details	Select the Mesh route optimization method from the following options. Light Refresh Mode : Reconstructs the route for direction to BR-400AN. Full Refresh Mode : Reconstructs the route for direction to/from BR-400AN.
Range	Light Refresh Mode / Full Refresh Mode
Default Value	Light Refresh Mode

Basic	Config	uration	- Mesh	Route	Configur	ation
	<u> </u>				5	

Route Refresh Interval			
Details	Set a refresh interval for the Mesh route (sec).		
Range	1-86400		
Default Value	3600		
Route Swi	tching Mode		
Details	Select a method to execute the route refresh.		
	Responsive Type/Stable Type		
Range	Responsive Type: Always performs a route refresh.		
	Stable Type: Performs a route refresh only when communication quality is good.		
Default Value	Stable Type		
	If this setting is set to Stable Type , the communication delay can be improved as the frequency of		
	route change is reduced.		
Note	This setting must be the same for all Mesh devices in the Mesh network. If the setting is different for		
	some Mesh devices, the communication route may not be constructed correctly.		
	When the firmware version is 1.4.1 or lower, BR-400AN operates in Responsive Type .		
Transmiss	ion Control Function		
	Enable/Disable the upper limit on amount of data that can be sent per second.		
Details	When this setting is enabled, amount of data exceeding the upper limit will be discarded.		
Range	ENABLE / DISABLE		
Default Value	ENABLE		
	By enabling the upper limit on amount of data transmission, the bandwidth occupancy of the entire Mesh		
	network can be reduced. The upper limit of data amount is calculated based on the communication		
Note	quality. When the route refresh interval is long, or when the route quality frequently changes in the Mesh		
	network, this may not work effectively. This setting is valid when Stable Type is selected for the route		
	switching mode.		
Network L	oop Avoidance		
Details	Enable/Disable the network loop avoidance. If this setting is enabled, BR-400AN handles a communication regularly to avoid a network loop.		
Range	ENABLE /DISABLE		
Default Value	DISABLE		
	When two conditions below are met, this setting needs to be enabled on the BR-400AN units that are		
	connected to the existing network via a wired LAN.		
Note	- Two or more BR-400AN units are directly connected to the existing network using network cables.		
	- In the existing network, there is no Ethernet HUB on which RSTP function is turned on.		

Sample Setting for Host Name

For the host name, enter a string with 15 or less characters.

Name	Value	Name	Value
Host Name	SX01 09E8	Host Name	MESH-POINTOI

If the host name is changed, you can easily identify that unit on AMC Manager[®] and Mesh Monitor.



Sample Setting for Mesh General Configuration

Configure the setting as follows when you want to use IEEE802.11n/a for **Wireless Mode** and 40ch for **Channel Bandwidth** to configure the Mesh network.

Name	Value
Wireless Mode	802.11n/a ✓ 2.4GHz: 802.11b/g, 802.11n/b/g 5GHz : 802.11a, 802.11n/a
Channel Bandwidth	40MHz 🗸
Use DFS Band	OFF → *OFF (Recommended)
Channel	40 🗸 Extension Channel 36 🗸
Mesh Group Name	SX-MESH-NET
Mesh Encryption Key	••••••
Sample Setting for DFS Channel Use

To use the DFS band channels, select **ON** for **Use DFS Band**.

Name	Value
Wireless Mode	802.11n/a ✓ 2.4GHz: 802.11b/g, 802.11n/b/g 5GHz : 802.11a, 802.11n/a
Channel Bandwidth	40MHz V
Use DFS Band	ON 🗸 *OFF (Recommended)
Channel	100 🗸 Extension Channel 104 🗸 DFS Primary Channel 108 🗸
Mesh Group Name	SX-MESH-NET-11a
Mesh Encryption Key	•••••

Sample Setting for Mesh Route Configuration

By configuring the Mesh route setting, you can set the action of BR-400AN to take when the Mesh route is updated. For example, when you want to set '5' for **Max Hop Count** and reconstruct the Mesh route in both receiving and transmitting direction in every 5 mins, configure the setting as below.

Name	Value
Max Hop Count Route Refresh Function	5 V ENABLE V
Route Refresh Method Route Refresh Interval	Full refresh Mode V
Route Switching Mode	Stable Type V
Transmission Control Function Network Loop Avoidance	ENABLE ~ DISABLE ~

Access Point Function Configuration Page

The Access Point function can be enabled/disabled and the detailed setting can be configured.

	Access Point Function Co	nfiguration
English	Access Point Function Configuration	access Point Function Extended Configuration
System Configuration Basic Access Point Function Option	Configure the parameters for "Access I Enter the values and click "Submit".	Point Function Contiguration".
Maintenance Login Password	The wireless LAN configuration Configuration	is the same as Mesh function. When changing the wireless LAN configuration, please set it from "Basic
- Factory Default	Name	Current Value
- Log	Wireless Mode Channel Bandwidth Channel	80211n/b/¢ 20MHz 11 ch
Ciconde and no den	A serve Daily Davids Davids D	
	Name	Value
	Access Point Function SSID Stealth Mode	ENABLE V SK-KESH-AP DISARLE V
	WPA/WPA2 Configuration	INTRATION V
	Name Encryption Mode Pre-Shared Key Group Key Renew Interval	Valar /AES → €000000000000 (0)
		Submit Reset
silex BR-400AN		
ver 20.1 [84:253r00:11:22]		Capyright (C) 2017 silex technology, B

Access Point Function Configuration - Access Point Function Basic Configuration

Access Poin	t Function
Details	Enable/Disable the Access Point feature. If this setting is enabled, wireless clients (e.g. PC, tablet devices) are allowed to connect to BR-400AN. Once the wireless clients are connected to BR-400AN, they can join the Mesh network.
Range	ENABLE / DISABLE
Default Value	ENABLE
Note	For the wireless mode and channel to use for Access Point function, the settings of Mesh General Configuration will be applied. When the Access Point feature is enabled, up to 100 wireless client devices can be connected. However, depending on the number of Mesh devices used in the Mesh network, the maximum number of connectable devices could be reduced. The maximum number of connectable devices is 100 when 12 Mesh devices are used, but as the number of Mesh devices increases from 12, the maximum number of connectable devices decreases by two.
SSID	
Details	Set an SSID of the wireless LAN for BR-400AN. The SSID is an ID that distinguishes a wireless LAN network from others.
Range	A string of 1-32 alphanumeric characters
Default Value	SX-MESH-AP
Stealth Mod	le
Details	Enable/Disable the stealth mode function.
Range	ENABLE / DISABLE
Default Value	DISABLE
Note	When the stealth mode of BR-400AN is enabled, BR-400AN will not be found by the wireless client devices even when it is searched over the wireless LAN. To connect to BR-400AN, the SSID, authentication method and encryption mode of BR-400AN need to be entered from the wireless client devices.

Access Point Function Configuration - Access Point Function Basic Configuration			
Network Au	Network Authentication		
Details	Select the network authentication mode that will be used to connect to your wireless devices. To ensure a secure network, it is recommended to use WPA/WPA2. When IEEE 802.11n is used, only AES can be used for encryption mode.		
Range	Open, Shared, WPA-PSK, WPA2-PSK, WPA/WPA2-PSK, 802.1X, WPA-Enterprise, WPA2-Enterprise, WPA/WPA2-Enterprise		
Default Value	WPA2-PSK		
	Open (Open System): Allows all access without authentication. For encryption mode, WEP can be used. Shared (Pre-Shared Key): Uses WEP key for encryption and allows access only from those with the same WEP key. For encryption mode, WEP can be used.		
	WPA-PSK: Uses PSK for network authentication. For encryption mode, TKIP/AES/AUTO can be selected. The encryption key will be generated by communicating with your wireless devices using a Pre- Shared key. WEP key setting is not used for this mode.		
	WPA2-PSK: Uses PSK for network authentication. For encryption mode, AES/AUTO can be selected. The encryption key will be generated by communicating with your wireless devices using a Pre- Shared key. WEP key setting is not used for this mode.		
Note	WPA/WPA2-PSK: Uses both WPA-PSK and WPA2-PSK authentication.		
	802.1X: Uses IEEE 802.1X user authentication and WEP encryption.		
	WPA-Enterprise: Uses IEEE 802.1X user authentication and TKIP/AES/AUTO encryption.		
	WPA2-Enterprise: Uses IEEE 802.1X user authentication and AES/AUTO encryption.		
	WPA/WPA2-Enterprise: Uses IEEE 802.1X user authentication and AES/AUTO encryption.		
	When running in IEEE 802.11n, Shared and IEEE 802.1X authentication modes and WEP and TKIP encryption modes cannot be used.		

Access Point Function Configuration - WEP Configuration

WEP		
Details	Enable/Disable WEP encryption. If WEP encryption is used, wireless communication will be encrypted using the settings of WEP Key 1-4 and Key Index .	
Range	OFF / ON	
Default Value	OFF	
Note	If encryption is not enabled, data is not encrypted and is sent as is. To ensure higher security, enabling encryption is recommended.	
Key Index		
Details	Select the number of the WEP key to use for encryption (1-4). This setting must be the same as that of your wireless devices.	
Range	1 - 4	
Default Value	1	
WEP Key1-4		
Details	Set the WEP key for WEP encryption. Up to 4 WEP keys can be set. This setting must be the same as that of your wireless devices. A WEP key must be entered using hexadecimal or alphanumeric characters.	
Range	5 or 13 characters 10 or 26 digit value	
Default Value	(None)	
Note	In most cases, alphanumeric characters are used. Enter 5 characters if the key size is 64bit or 13 characters if the key size is 128bit. For Hexadecimal, a value consists of numbers (0-9) and English letters (A-F). Enter a 10-digit value if the key size is 64bit or a 26-digit value if the key size is 128bit.	

Access Point Function Configuration - WPA/WPA2 Configuration

Encryption Mode		
Details	Select the encryption mode to use for WPA-PSK, WPA2-PSK, WPA/WPA2-PSK, WPA-Enterprise, WPA/PA2-Enterprise authentication.	
Range	TKIP/AES/AUTO	
Default Value	AES	
Note	When the network authentication mode is WPA2-PSK , WPA/WPA2-PSK , WPA2-Enterprise , WPA/WPA2-Enterprise , TKIP cannot be used.	

Access Point Function	Configuration -	WPA/WPA2	Configuration
	configuration		configuration

Pre-Shared	Кеу
Details	Set the Pre-Shared Key to use for TKIP/AES encryption.
	The Pre-Shared Key is a keyword used to create the encryption key. It is also referred to as ' network
	key' or ' password '.
Range	8-63 alphanumeric characters
	64 hexadecimal value
Default Value	PreSharedKey
Note	In most case, alphanumeric characters are used (8-63 characters).
	For Hexadecimal, enter 64-character string that consists of numbers (0-9) and English letters (A-F).
	This value must be the same as that of the wireless device you want to connect.
Group key r	renew interval
Details	Set the refresh interval for Pre-Shared Key (min).
	If 0 is set, this setting is disabled.
Range	0 - 1440
Default Value	60

Access Point Function Configuration - RADIUS Server Configuration			
Server IP	Server IP		
Details	Set the IP Address of RADIUS server. This needs to be set only when the network authentication is 802.1X , WPA-Enterprise , WPA2-Enterprise or WPA/WPA2-Enterprise .		
Range	0.0.0.0 - 255.255.255		
Default Value	0.0.0.0		
Port Number			
Details	Set the port number used to communicate with RADIUS server.		
Range	0 - 65535		
Default Value	1812		
Shared Secret			
Details	Set the secret key used to communicate with RADIUS server.		
Range	Up to 32 characters		
Default Value	(None)		

Sample Setting for Access Point Function

When the Access Point function is enabled, some configuration items (SSID, authentication method, encryption mode, etc.) will become available.

E.g.) To set WEP encryption for Access Point

 Access Point Function Basic Configuration 			
Name	Value		
Access Point Function	ENABLE V		
SSID	SX-MESH-AP		
Stealth Mode	DISABLE V		
Network Authentication	Open 🗸		
WEP Configuration	WEP Configuration		
Name	Value		
WEP	ON V		
Key Index	1 🗸		
WEP Key1	••••		
WEP Key2			
WEP Key3			
WEP Key4			

E.g.) To set WPA2-PSK (authentication method) and AES (encryption mode) for Access Point

Access Point Function Basic Configuration		
Name	Value	
Access Point Function SSID Stealth Mode Network Authentication	ENABLE V SX-MESH-AP DISABLE V WPA2-PSK V	
WPA/WPA2 Configuration		
Name	Value	
Encryption Mode Pre-Shared Key Group Key Rerew Interval	AES ~ 6 0	

E.g.) To establish the IEEE802.1X environment with RADIUS server and wireless client devices

•	Access Point Function Basic Con	figuration	
	Name	Value	
	Access Point Function SSID Stealth Mode Network Authentication	ENABLE ~ MESH-AP001 DISABLE ~ WPA/WPA2-Enterprise ~	
	WPA/WPA2 Configuration		
	Name	Value	
	Encryption Mode Group Key Rerew Interval	AES >	
	RADIUS Server Configuration		
	Name	Value	
	Server IP Port Number Shared Secret	192.168.0.220 1812	

Access Point Function Extended Configuration Page

The filter setting can be configured to allow or deny communication with a specific wireless client device.

	# Access Point Function Configuration	6050
English V	Access Point Function Configuration Access Point Function Extended Configuration	
Control of the second of	Access Pick Function Configuration Mice Value Filter Type Value Mice Address Filter Configuration Value Filter Type IDEALE Configuration Mice Address Filter Configuration Value Filter Type IDEALE Configuration (00000000000) Address	Gabrit Reset
silex BR-400AN		
ver 20.1 [84:253f:00:11:22]		Copyright (C) 2017 silex technology, Inc.

Access Point Function Extended Configuration - MAC Address Filter Configuration			
Filter Type			
Details	Set a security type for MAC address filter to use over a wireless LAN.		
Range	DISABLE/DENY/ALLOW		
Default Value	DISABLE		
MAC Address			
Details	Register the MAC address of the target wireless client device to enable a filter for. By registering the MAC address, access from a wireless LAN can be filtered.		
Range	00:00:00:00:01 - FF:FF:FF:FF:FE		
Default Value	00:00:00:00:00		
Note	If a filter type is DISABLE , access from all devices is allowed. If a filter type is DENY , access from the devices registered to MAC Address filter list is denied. If a filter is ALLOW , only access from the devices registered to MAC Address filter list is allowed. Up to 1024 MAC Addresses can be registered.		

Sample Setting for MAC Address Filter

E.g.) To deny access from the specified wireless client device

Name	Value
Filter Type	DENY V
MAC Address	84:25:3F:11:22:33

E.g.) To allow access from the specified wireless client device only

Name	Value
Filter Type	ALLOW V
MAC Address	84:25:3F:11:22:33

Option Configuration Page

Transmission power, wired LAN, NTP function settings can be configured.

silex technology	Option Configuration		
Select Language	Option Configuration		
System Configuration Basic Access Point Function Option	Configure the parameters for "Option Enter the values and click "Submit".	Configuration".	UP HELF
 Maintenance Lozin Password 	Name	Value	
– Reboot – Factory Default – Firmware Update	Tx Power	50 🗸	
- Los	Wret LAN Configuration		
 Information 	Name	Value	
- License Information	LAN Interface	AUTO	
	 Disk Suitele Coofie entire 		
	Name	Value	
	Time before turning into Configuration Mode (sec)	5	
	NTE Configuration		
	Name	Value	
	NTP Cilent NTP Server Address Local Time Zone	DISABLE ~ +9:00 ~	
			Submit Reset
silex			_
BR-400AN Ver 20.1			Complete (C) 0017 allow to deve laws

Option Configuration - TX Power Configuration

TX Power (%)			
	Set the transmission power for wireless LAN.		
	If a smaller value is set, a wireless distance from BR-400AN is shortened and the scope of search can		
Details	be narrowed down. By narrowing down the scope of search, interference to other network can be		
Details	reduced.		
	If a larger value is set, a wireless distance from BR-400AN is expanded and the scope of search can be		
	broadened. By broadening the scope of search, remote devices can be discovered.		
Range	10, 20, 30, 40, 50, 60, 70, 80, 90, 100		
Default Value	50		

Option Configuration - Wired LAN Configuration

Wired LAN Interface		
Details	Configure the physical network type.	
Range	AUTO/10Base-T-Half/10Base-T-Full/100Base-TX-Half/100Base-TX-Full/1000Base-T-Full	
Default Value	Αυτο	
Noto	Usually, "AUTO" is used. When BR-400AN is powered on and the LINK LED does not turn on the device	
Note	that is connected to BR-400AN, change the network type to that of the device.	

Option Configuration - Push Switch Configuration			
Time before turning into Configuration Mode (sec)			
Details	Specify the period of time until the BR-400AN turns into the Configuration Mode. If the Push Switch is pressed for the period of time specified here, the BR-400AN will turn into the Configuration Mode.		
Range	5-60 (sec)		
Default Value	5		

Option Configuration - NTP Configuration

NTP			
Details	Enable/Disable the NTP protocol.		
Range	ENABLE/DISABLE		
Default Value	DISABLE		
NTP Server			
Details	Set the domain name or IP address of the NTP server.		
Range	In case of the domain name; Alphanumeric character string (0-128 characters) In case of the IP Address; 0.0.0.0 - 255.255.255.255		
Default Value	(None)		
Local Time Zone			
Details	Set the local time zone.		
Range	-12:00 - +12:00		
Default Value	+9:00		

Sample Setting of Transmission Power

By configuring the TX power, the wireless distance of BR-400AN can be changed.

The default value is set to 50(%). When the default value is used, the wireless distance will be about 20m. When the value is changed to 100(%), the wireless distance will be about 35m.



Login Password Configuration Page

The password to login to the Web page can be configured.



Login Password Configuration

New Password		
	Set the login password (up to 16 ASCII characters).	
Details	This password is used for authentication when changing settings from the Web configuration page.	
	The new password needs to be entered again to Confirm New Password .	
Range	Alphanumeric character string (1-15 characters)	
Default Value	(None)	
Note	This password is also used to change configuration using AMC Manager® and Mesh Monitor.	

How to Connect Wireless Client Devices

This chapter explains how to connect wireless client devices (PC, tablet, etc.) to BR-400AN.



When the Access Point feature is enabled, up to 100 wireless client devices can be connected. However, depending on the number of Mesh devices used in the Mesh network, the maximum number of connectable devices could be reduced. The maximum number of connectable devices is 100 when 12 Mesh devices are used, but as the number of Mesh devices increases from 12, the maximum number of connectable devices decreases by two.

6-1. How to Enable Access Point Feature on BR-400AN

To connect the PCs or tablet devices to BR-400AN, the Access Point feature needs to be enabled on BR-400AN. Execute one of the following methods to enable the Access Point feature.

- 1) Use the Web configuration interface to enable the Access Point feature.
- 2) Use AMC Manager[®] to enable the Access Point feature.
- 3) Use Mesh Monitor to enable the Access Point feature.



When the firmware version of BR-400AN is 2.0.0 or newer, the Access Point feature is enabled by defaults.



Note

How to enable the Access Point feature using the Web configuration interface

1. Access the Web configuration interface of BR-400AN using your Web browser, enter the password and click **Login**.

Uelcome to BR-400AN		070
	Enter the password, and olick [Login] Password Login	1
	Select Language	
	English	

- For how to access the Web configuration interface, refer to **4-1.Configuration via BR-400AN's Web Page**.
- \simeq When the password is not set to BR-400AN, the login password configuration page is displayed.
- **2.** When the Web configuration interface is displayed, click **Access Point Function**.

	Basic Configuration	
Select Language	Basic Configuration	
System Configuration	· · · · · ·	
- Access Point Function	Configure the parameters for "Basic O Enter the values and click "Submit".	onfiguration". 📴 HELP
Cation	Host Name	
 Maintenance Login Password 	Name	Value
- Reboot - Factory Default - Firmware Update	Host Name	SX0109FD
- Log	 P Address Configuration 	
 Information License Information 	Name	Value
	DHCP IP Address	ENABLE ~
	Subnet Mask	0.0.0
	Default Gateway	0000
	DNS Configuration	
	Name	Value
	DNS Server (Primary)	0.0.0
	DNS Server (Secondary)	0000
	 Mesh General Configuration 	
	Name	Value
	Wireless Mode	[802:11n/b/ε ∨ 240Hz: 902:11b/ε, 802:11n/b/ε 50Hz: 902:11a, 802:11n/a
	Channel Bandwidth	20MHz V
	Use DFS Band	OFF V *OFF (Recommended)
	Channel	
	Mesh Group Name	SX-MESH-NET
	Mesh Encryption Key	
allau	A second second second	
SIIEX BR-400AN		
Ver 20.1		
[84:253f:00:11:22]	1	Capyright (C) 2017 silex technology,

3. Select ENABLE for Access Point Function.

silex technology	Access Point Function Conf	iguration	Q
Select Language	Access Point Function Configuration Acc	sss Point Function Extended Configuration	
System Configuration Basic Access Poht Function Option	Configure the parameters for "Access Poin Enter the values and click "Submit".	nt Function Configuration".	BY HELP
 Maintenance Login Password 	 Current Wireless LAN Configuration The wireless LAN configuration is the Configuration". 	n the same as Mesh function. When changing the wireless LAN configuration, please set it from "Ba	sic
- Reboot - Factory Default	Name	Current Value	
- Firmware Opdate - Log Information	Wireless Mode Channel Bandwidth	802.11n/b/s 20MHz	
- License Information	Channel	11 ch	
	 Access Point Function Basic Confi Name 	Value	
	Access Point Function	DISABLE V	
		Submit	Reset
silex BR-400AN			
[84:253f:00:11:22]		Copyright (C) 2017 silex te	chnology, inc.

The detailed setting of Access Point feature such as SSID, authentication method, etc. can be configured. For details on the configurable items, refer to 5-1. Configuration Items on BR-400AN's Web Page - Access Point Function Configuration Page. The wireless mode, channel bandwidth and channel cannot be changed in this page. To change these settings, go to the Basic Configuration page.

	Access Point Function Co	onfiguration	
Select Language English V	Access Point Function Configuration	Access Point Function Extended Configuration	
System Configuration Basic Access Point Function Option	Configure the parameters for "Access Enter the values and click "Submit". Current Wireless LAN Configure	Point Function Configuration".	Ba HELP
- Login Password - Reboot - Factory Default	The wireless LAN configuration Configuration". Name	is the same as Mesh function. When changing the wireless LAN Current Value	I configuration, please set it from "Basic
- Firmware Update - Log • Information - License Information	Wireless Mode Channel Bandwidth Channel	802.11n/b/s 2004tz 11.cb	
	 Access Point Function Basic C Name 	onfiguration Value	
	Access Point Function SSID Stealth Mode Network Authentication	ENABLE V SK-ME'SH-AP DISABLE V WPA2-PSK V	⊐ (1)
	 WPA/WPA2 Configuration Name 	Value	
	Encryption Mode Pre-Shared Key Group Key Renew Interval		
			Submit Re
silex BR-400AN			
Ver 2.0.1 [84:25:3f:00:11:22]			Copyright (C) 2017 silex technology, inc.

5. When the configuration is completed, restart BR-400AN.

silex technology	Basic Configuration	3
Select Language English V V System Configuration Basic Access Point Function Ottion	Basic Configuration Setting is completed.	
▼ Maintenance - Login Password - Reboot - Factory Default - Firmware Update - Log	I o take effect of this setting, please restart.	
 ✓ Information – License Information 		



- For details on how to restart BR-400AN, refer to 7-1. Restart.



How to enable the Access Point feature using AMC Manager®

1. Start AMC Manager[®], click the icon Create the configuration file - Create from Template from the toolbar.





When the login password is not set to a device, please include that setting to the configuration file. If the login password is not set, the bulk configuration does not perform correctly.



- If you have the configuration file, it is possible to read the setting from that file. In that case, click the icon **Create the configuration file** - **Edit Existing File**.

2. Select a template file for BR-400AN (1) and click **OK** (2).

Select Template	te file.	×
Device Name AP-500AC AP-511AC AP-5AC	Comments This is the file for AP-500AC. This is the file for AP-511AC. This is the file for AP-5AC.	(1)
BR-400AN BR-400AN Ver.2.0.0	This is the file for BR-400AN. This is the file for BR-400AN Ver.	2.0.0.
DS-600 FBR-100AN	This is the file for DS-600. This is the file for FBR-100AN.	~
	ОК	Cancel



The template to select will vary depending on the firmware version of BR-400AN. When the version is 2.0.0 or higher: Select **BR-400AN Ver.2.0.0**. When the version is 2.0.0 or lower: Select **BR-400AN**. **3.** Select **Wireless LAN I/F 1** from the configuration category on the left (1). The corresponding setting items are displayed on the right (2).



4. Select **Enable** for **Access Point Function** and check the check box.



5. Select **Wireless LAN I/F 2** from the configuration category on the left (1), and configure the SSID, authentication and encryption settings on the right (2).



Note

- Only the setting whose check box is checked will be configured to BR-400AN. Remote a check from the setting that you do not want to change.

6. When the configuration is completed, click **Save**.

	Select All		
ystem Configuration	L Item	Contents	
letwork Configuration	Basic Settings		^
Vired LAN Configuration	SSID	SX-MESH-AP2	
Wireless LAN Configuration Wireless LAN I/F 1	Network Authentication	WPA/WPA2-PSK	
Wireless LAN I/F 2	U WEP	Disable	
Others	WEP Key Index	1	
	WEP Key (1)		
	WEP Key (2)		
	WEP Key (3)		
	WEP Key (4)		
	Encryption Mode	AUTO	
	Pre-Shared Key	******	
	Group Key Renew Interval (min)	60	
	Security Settings		^
	Stealth Mode	Disable	
	EAP Settings		^
	Server IP	0.0.0.0	
	Authentication Port	1812	
	Shared Secret		

7. Specify the file name and click **Save**.

Save Configuratio	n File			×
← → • ↑ 🗌	$\rightarrow~$ This PC $\rightarrow~$ Desktop $\rightarrow~$ silex	✓ Ö Search	silex	<i>م</i>
Organize 👻 Ne	w folder		8== -	?
 > # Quick access > ConeDrive > This PC > # Network 	Name mesh_config01.cfg mesh_config02.cfg	Date 10/9/2018 4:05 PM 10/9/2018 4:05 PM	Type CFG File CFG File	Size
File <u>n</u> ame: Save as <u>t</u> ype:	< mesh_config03.cfg Configuration File (*.cfg)			> ~
∧ Hide Folders			<u>S</u> ave Car	ncel

8. Click Close.

	Select All		
ystem Configuration	🗌 Item	Contents	^
Network Configuration	Basic Settings		- ^
Wired LAN Configuration	SSID	SX-MESH-AP2	
Wireless LAW Conliguration Wireless LAW I/F 1	Network Authentication	WPA/WPA2-PSK	
Wireless LAN I/F 2	WEP	Disable	
Others	WEP Key Index	1	
	WEP Key (1)		
	WEP Key (2)		
	WEP Key (3)		
	WEP Key (4)		
	C Encryption Mode	AUTO	
	Pre-Shared Key	*****	
	Group Key Renew Interval (min)	60	
	Security Settings		^
	Stealth Mode	Disable	
	EAP Settings		^
	Server IP	0.0.0.0	
	Authentication Port	1812	
	Shared Secret		~

9. Select BR-400AN units to configure in bulk (1) and click the icon **Configure multiple** devices in bulk (2).



10. Specify the configuration file to use. Select BR-400AN units to configure (1) and click **Select Config. File** (2).

Bulk Configuration				×
Change configure Specify the config	ation for multiple devices in guration file and click [Start]	bulk. to start bulk configura	ition.	
<u>^</u>				
Device Name	Ethernet Address	Host Name	IP Address	w I <u>A</u> dd Device
🔲 🔒 BR-400AN	84:25:3F:01:09:E8	SX0109E8	172.25.72.251	Delete Device
🗆 强 BR-400AN	84:25:3F:01:09:FD	SX0109FD	172.25.72.87	Delete Device
				Edit Device
	(1)			Select Config. <u>F</u> ile
	(1)			Open Coning, File
				IP Configuration
				Merge Config. File
				S <u>h</u> ow Config. List
				Open Bulk Config. File
<				> Save <u>B</u> ulk Config. File
<u>R</u> estart the device afte	r this configuration			2

11.Select the configuration file that you have created at **7**.

🛃 Open Configuration File	2			×
	his PC → Desktop → silex	✓ Ö Search s	ilex	Q
Organize 🔻 New fold	ler		H 🗸 🔲	?
1 Ouish serves	Name	Date	Туре	Size
Quick access	mesh_config01.cfg	10/9/2018 4:05 PM	CFG File	
a OneDrive	mesh_config02.cfg	10/9/2018 4:05 PM	CFG File	
This PC	mesh_config03.cfg	10/9/2018 4:08 PM	CFG File	
retwork	٢			>
File	name: mesh_config03.cfg	 ✓ Configu Op 	uration File (*.cfg) en Cance	× 1

12.The selected configuration file is displayed under **Configuration File Name**.

Bulk Conf	iguration Change configuration Specify the configura	n for multiple devices in tion file and click [Start]	i bulk.] to start bulk configurat	ion.	×
Configu	ration <u>L</u> ist:				
55	Host Name	IP Address	New IP Address	Configuration File Name	Add Device
:8 :D	SX0109E8 SX0109FD	172.25.72.251 172.25.72.87		mesh_config03.cfg mesh_config03.cfg	Delete Device
					<u>E</u> dit Device
					Select Config. <u>F</u> ile
					Open <u>C</u> onfig. File
					IP Configuration
					Merge Config. File
					S <u>h</u> ow Config. List
					Open Bulk Config. File
<				>	Save <u>B</u> ulk Config. File
<u>R</u> esta	rt the device after thi	s configuration			Start

13.Check the check boxes of BR-400AN units to configure in bulk (1) and click **Start** (2).





- Please do not check the check box at **Restart the device after this configuration**. If it is checked, BR-400AN units will automatically be restarted regardless of the Mesh network status and the bulk configuration may not be completed correctly as the result.



- If the check box on the left of **Device Name** is checked, check boxes of all devices will be checked in the list.

14. When the configuration is in progress, the progress bar is displayed and when the configuration is finished, the result is displayed. Click **Close**.

k Configuration			>
The device ha	as been configured.		
Device Name	Ethernet Address	Status	
🖋 BR-400AN	84:25:3F:01:09:E8	Completed	
🖋 BR-400AN	84:25:3F:01:09:FD	Completed	
		Details	<u>C</u> lose
		<u>D</u> etails	<u>C</u> lose



If the result status does not say "Completed", modify the setting of the configuration file and try again.

15. Restart all BR-400AN units.

For details on how to restart BR-400AN, refer to **7-1. Restart** in this document or **4-9. Restart** in the AMC Manager[®] User's Manual.

BR-400AN units will start with a new setting after restart.

The Access Point feature has been enabled. Click **File** - **Exit** to finish AMC Manager[®]. How to enable the Access Point feature using Mesh Monitor

1. Select a single BR-400AN unit to enable the Access Point feature (1) and click the icon **Device configuration** from the toolbar (2).





- The device configuration window can also be opened by the following methods:
 - Select BR-400AN and click **Tools Device Configuration** from the menu bar.
 - Right-click on BR-400AN and select **Device Configuration** from the context menu.
- When the password is set to BR-400AN, the screen below is displayed. Enter the password (1) and click OK (2).



2. Check the check box at Enable Access Point Function (1) and click OK (2).





 When the Access Point feature is enabled, the SSID, authentication method and encryption mode will also need to be configured. For details on the configuration method, refer to 5-1. Configuration Items on BR-400AN's Web Page - Access Point Function Configuration Page.

3. The result of configuration change is displayed. Click **OK** to close the device configuration window.



6-2. How to Connect PCs or Tablets to BR-400AN

The following explains how to connect your Windows PC to BR-400AN as a wireless client.

1. Click the below icon from the task tray to open the wireless connection window.



2. Select the SSID of BR-400AN from the list of wireless networks (1) and click Connect (2).



- If the check box at **Connect automatically** is checked, the PC is automatically connected to BR-400AN when it is started.

Note

3. Enter the security key of BR-400AN for **Enter the network security key** (1) and click **Next** (2).



4. When the message "Connected" is displayed, the Windows PC has been connected to BR-400AN.



95

7. Maintenance Feature

This chapter explains the maintenance feature of BR-400AN.

7-1. Restart

Execute one of the following methods to restart BR-400AN.

- 1) Restart BR-400AN by unplugging the AC adaptor
- 2) Restart BR-400AN using the Web configuration interface
- 3) Restart BR-400AN using AMC Manager®



- For details on how to restart using AMC Manager[®], see **4-9. Restart** in the AMC Manager[®] User's Manual.

How to restart BR-400AN by unplugging the AC adaptor

1. Unplug the AC adaptor of BR-400AN from the outlet (1) and plug it back into the outlet (2).



2. When the POWER LED turns green and WLAN LED turns or blinks orange/green, the restart is completed. After the restart, the BR-400AN will start in a normal mode.



How to restart BR-400AN using the Web configuration interface

1. Access the Web configuration interface of BR-400AN using your Web browser, enter the password and click **Login**.



- For how to access the Web configuration interface, refer to 4-1.Configuration via BR-400AN's Web Page.
- When the password is not set to BR-400AN, the login password configuration page is displayed. **Note**
- 2. Click Reboot from the menu (1) and click Yes (2).

silex technology	# Reboot			
Belef Larguage English V Y System Configuration - Basis - Data - Option - Option - Option - Configuration - Configur	Reboot This product will be Do you war	rebooted. to reboot this product? (2)	Νο	
silex BR-400AN Ver 20.1 [84:25300:11:22]			Ca	syright (C) 2017 silex technology, Inc.

3. The restart is completed when all LEDs turn off and then the POWER LED turns green and the WLAN LED turns or blinks orange/green. BR-400AN will run in a normal mode then.



7-2. Factory Default Configuration

Execute one of the following methods to initialize BR-400AN.

- 1) Factory default configuration using the push switch of BR-400AN
- 2) Factory default configuration using the Web page of BR-400AN
- 3) Factory default configuration using AMC Manager®



For details on the factory default configuration using AMC Manager®, refer to 4-8. Factory Default Configuration in AMC Manager® User's Manual.

Note

How to reset BR-400AN to factory defaults using the Push Switch

1. Unplug the AC adaptor of BR-400AN from the outlet.



2. Press and hold the push switch on the front (1) while inserting the AC adaptor back into the electrical outlet (2).

When the WLAN LED turns Green then to Red (3), release the push switch (4).

After the factory default configuration is completed, BR-400AN starts in a normal mode.



How to reset BR-400AN to factory defaults using the Web configuration interface

1. Access the Web configuration interface of BR-400AN using your Web browser, enter the password and click **Login**.

Welcome to BR-400AN		0
	Enter the password, and cilck (Login). Peassword Login	
	Select Language English V	

- For how to access the Web configuration interface, refer to 4-1.Configuration via BR-400AN's Web Page.



- When the password is not set to BR-400AN, the login password configuration page is displayed.
- 2. Click Factory Default from the menu (1) and click Yes (2).

Silex technology	Factory Default Configuration
Select Language	Factory Default Configuration
▼ System Configuration - Basic - Access Point Function - Option	Initialize the system configuration of this product and reset it to the factory default settings.
 ✓ Maintenance – Login Password – Factory Default 	Yes No
 Log ✓ Information License Information 	(2)
silex BR-400AN	
Ver 2.0.1 [84:253f:00:11:22]	Copyright (C) 2017 silex technology, Inc.

3. When the factory default configuration is completed, BR-400AN is automatically restarted. When the restart is completed, the POWER LED turns green and the WLAN LED turns or blinks orange/green. BR-400AN will run in a normal mode then.


7-3. Firmware Update

The latest firmware file can be downloaded from our website.



- The current firmware version can be identified at the bottom left of the Web configuration interface.

How to download the firmware file:

1. Access our website below.

	URL
USA / Europe	https://www.silextechnology.com/

2. Go to the support section and download the firmware file.

How to update the firmware:

How to update the firmware of BR-400AN is explained. The firmware can be updated using the Web configuration interface.



Note

- The firmware update procedure is also described on the PDF file that comes with the firmware data.
- The firmware can also be updated using AMC Manager[®]. For details, refer to 4-7. Firmware Update in AMC Manager[®] User's Manual.

1. Access the Web configuration interface of BR-400AN using your Web browser, enter the password and click Login.



For how to access the Web configuration interface, refer to 4-1.Configuration via BR-400AN's Web Page.

Ć - When the password is not set to BR-400AN, the login password configuration page is displayed.

Note

2. Click Firmware Update from the menu.

silex technology	Basic Configuration	
Select Language English V	Basic Configuration	
▼ System Configuration - Basic - Access Point Function - Option	Configure the parameters for "Basic Co Enter the values and click "Submit".	nfeuration". 📭 HELP
V Maintenance	 Host Name 	
- Login Password	Name	Value
- Firmware Update	Host Name	SX0109FD
	P Address Configuration	
 Information License Information 	Name	Value
	DHCP IP Address Subnet Mask Default Gateway	ENABLE ~ 0000 0000 0000
	DNS Configuration	
	Name	Value
	DNS Server (Primary) DNS Server (Secondary)	0000
	 Mesh General Configuration 	
	Name	Value
	Wireless Mode Channel Bandwidth Use DFS Band Channel Meth Group Name	80211n/b/ε √ 249T+: 80211b/ε, 802.11n/b/ε 56Hz : 802.11a, 802.11n/b 20Mtz √ OFF ✓ *0FF (Recommended) 11 √
	Mesh Econotion Key	
	Mean Encrypton Ney	
silex BR-400AN		
Ver 20.1 [84:25/3f/00:11:22]		Copyright (C) 2017 silex technology, Inc

3. When the **Firmware Update** page is displayed, click **Browse**.

silex technology	# Firmware Update	
Select Language	Firmware Update	
English V System Confluention - Access Point Function - Access Point Function - Access Point Function - Rebord - Rebord - Rebord - Rebord - Los V Information - License Information	Firmware Update Specify a firmware, update file to upgrade the firmware. For information on the latest thinware version, visit our homepage(http://www.alex.p/). Citids "Browser" and specify the firmware, update file saved in the PC. After selecting the file. Citids "Update". * It may belies while to colorite the firmware. Please be careful of the following points during the firmware update Do not knowl this product. Do not chose the Web browsere : New firmware :	Browse,
silex BR-400AN Ver 201		
silex BR-400AN Ver 2011 [84:35:00:1122]		Copyright (C) 2017 siles technology.

4. Select the firmware update file of BR-400AN (BR-400AN.bin) and click **Open**.

Open				×
\leftarrow \rightarrow \checkmark \land \square \rightarrow This	s PC > Desktop > silex	✓ Ö Search silex		٩
Organize 🔻 New folder	r		== -	?
- Ouick access	Name	Date	Туре	
	BR-400AN.bin	9/11/2018 7:01 PM	BIN File	
ineDrive 🍊 🗠				
📃 This PC				
i Network				
🖸 Camera				
Photos				
	<			>
File <u>n</u> a	me: BR-400AN.bin	 ✓ All files (*) 		\sim
	L	<u>O</u> pen	Cance	:I

5. Check that the file name is displayed at **New firmware** field (1) and click **Update** (2).

Select Language	E Firmware Update	
English Standardson - Babic - Access Poht Functon - Option - Option - Option - Cost Pohtsword - Rebot - Rebot - Finware Update - Loe - Lo	Specify a firmware update file to upgrade the firmware. For information on the lattert firmware version, visit our homespecifittp://www.slev.jp/). • Click "Browse" and specify the firmware update file saved in the PC. After selective the file. Clock "Update: Please be careful of the following points during the firmware update. Please be careful of the following points during the firmware update. Please be careful of the following points during the firmware update. Please be careful of the following points during the firmware update. Please be careful of the following points during the firmware update. Please be careful of the following points during the firmware update. Please be careful of the following points during the firmware update. Please be careful of the following points during the firmware update. Please be careful of the following points during the firmware update. Please be careful of the reburge calle from this poonts: Please be careful of the reburge calle from this poonts: Please be careful of the reburge calle form this poonts: Please be careful of the reburge calle form this poonts: Please be careful of the reburge calle form this poonts: Please be careful of the reburge calle form this poonts: Please be careful of the reburge calle form this poonts: Please be careful of the reburge calle form this poonts: Please be careful of the reburge calle form the reburge	2)
silex BR-400AN Ver 20.1 [84:253f00:11:22]	Copyright (C) 2017 silex technology, Inc.	

6. Click OK to the confirmation message.



7. The firmware update will begin.

All LEDs on top of BR-400AN turn on while the firmware update is in process.

silex technology	Firmware Update	670
Select Language Endleh V System Configuration - Belic - Access Point Function - Oction V Mainterance - Login Password - Reboot - Factory Default - Firmwer Update - Log V Liformation - License Information	Firmware Update Update Update Update give firmware. This product will autometically reboot itself, after completing the update. Do not turn off this product.	



8. When the firmware update is completed, the login page is displayed. Check the version information at the bottom left of the login page.

Welcome to BR-400AN		010
	Enter the password, and citck [Login]. Password Login	
	Select Laneusee Erglish V	
Ver xxx (\$4253r0109rd]	c	

The firmware update has been completed.

TIP



This chapter explains the other features of BR-400AN.

8-1. Mac Address Filter

The MAC Address filter function of BR-400AN works only when the Access Point feature is enabled. An access from the wireless client device can be filtered.

Filter Type

By registering the MAC Address to a list, access of wireless devices is allowed or denied based on the filter type below.

Name	Description
DISABLE	Does not use MAC Address filter. All devices are allowed to access.
ALLOW	Allows access only from devices with the registered MAC Address.
DENY	Denies access from devices with the registered MAC Address.

MAC Address List

Register the MAC Address of devices to allow/deny access to BR-400AN. Up to 1024 MAC Addresses can be registered.

Example of MAC Address Registration



MAC Address Filter Setting

The following explains how to configure the MAC Address filter.

1. Access the Web configuration interface of BR-400AN using your Web browser, enter the password and click **Login**.

Welcome to BR-400AN		Co Po
	Enter the password, and click [Lopin]. Password Lopin	
	Select Language Erglish V	

For how to access the Web configuration interface, refer to **4-1.Configuration via BR-400AN's Web Page**.

- When the password is not set to BR-400AN, the login password configuration page is displayed.

2. Click Access Point Function from the menu (1) and click the Access Point Function Extended Configuration tab (2).



3. Select the filter setting at **Filter Type** (1). Enter the MAC Address of the wireless client device to filter an access from and click **Add** (2). The entered MAC Address is added to the list.

Point Function Configura	ation Access Point Function Extended Configuration	
		[
MAC Address Filter Co	Infiguration	
Name	Value	
Filter Type		
	<u>^</u>	
		(2)

- To remove the registered MAC Address from the list, select the address and click **Delete**.

Note

4. When the address registration is completed, click **Submit**.

oint Function Configurati	n Access Point Function Extended Configuration	
MAC Address Filter Conf	autation	
Name	Value	
Filter Type MAC Address	ALLOW 84253F112233 84253F112234 84253F112235	
	B4/25/3F11/22/35 Add Delete	

5. Restart BR-400AN.

Select Language	Basic Configuration Eselo Configuration	
V System Configuration Basic Access Point Function Option Viaintenance Login Password Paboot Factory Default Firmware Update	 Setting is completed. To take effect of this setting, please restart. 	
 Log ▼ Information License Information 		

For how to restart BR-400AN, refer to **7-1. Restart**.



8-2. Saving Log

BR-400AN can save the operating log.

Once the log is saved, it can be retrieved or deleted from the Web configuration interface.

BR-400AN's System Log

System Log

The power-on status, operating status, etc. of BR-400AN are saved as a log file.

In case of a network trouble, you can check the operating status by referring the retrieved system logs. The system log can be retrieved or deleted from the log page of Web configuration interface.

Silex technology Belet Language	H Log	0
Postan Contourito Posta - Access Post Function - Option Visitemence - Access Post Function Visitemence - Postan Posta	3 Defendar Fielda Portentuar Fielda wurden son wurden son wurden son	
	Josef Forone	
silex BR-400AN Ver 20.1 [84:253100:11:22]	Copertien (C) 2017 tiller technolog	ay, hc.



- The system log file will remain even after BR-400AN is reset to factory defaults.
- When a size of log file (file name: sys_log.txt) exceeds 10MB, a new file is created. For the existing file, a number will be added to the end of the file name then.
- As the end number of the file name increases one by one when a new log file is created, files with a greater number will be older logs.
- Up to 99 log files can be saved, starting from sys_log.txt.0 to sys_log.txt.98.
- If a new file is created when 99 log files have already been there, the oldest file sys_log.txt.98 will be deleted.
- Up to 1GB log can be saved.

Retrieving System Log

The system log saved on BR-400AN can be accessed from the Web page.

1. Access the Web configuration interface of BR-400AN using your Web browser, enter the password and click **Login**.

Welcome to BR-400AN		64
	Enter the password, and click [Login]. Password Login	
	Select Language English	

For how to access the Web configuration interface, refer to **4-1.Configuration via BR-400AN's Web Page**.

- When the password is not set to BR-400AN, the login password configuration page is displayed.

2. Select Log from the menu to display the syslog page (1). Then, click Save to save the log information (2).

Silex	# Log	0
Select Language	System Lor	
System Configuration System Configuration Access Point Function Option Maintenance Login Password Reboot	System Log File List ws io to to ws jog to to t ws jog to to 1	
-Los		
- License Information		Refer Section
		(2)
silex		
BR-400AN Ver 201		
[B4:253:00:11:22]		Capyright (C) 2017 silex technology, inc



The log files cannot be saved individually.

3. The confirmation message is displayed on which you can specify where the syslog file (sys_log_archive.tgz) should be saved. Click **Save** or **Save as**.

silex BR-400AN					
What do you wan From: 172.25.72.2	t to do with sys_log_archive.tgz (3.87 MB)? 51	Save	Save as	Cancel	×

The system log has been saved.

Deleting System Log

The system log saved on BR-400AN can be deleted from the Web page.

1. Access the Web configuration interface of BR-400AN using your Web browser, enter the password and click **Login**.

Welcome to BR-400AN		
	Enter the password, and click [Login]. Password Login	
	Select Language Erglich	

For how to access the Web configuration interface, refer to 4-1.Configuration via BR-400AN's Web Page.

• When the password is not set to BR-400AN, the login password configuration page is displayed.

2. Select **Log** from the menu to display the syslog page (1). Then, click **Remove** to delete the log information (2).





The system log files cannot be deleted individually.

3. Click **OK** to a confirmation message.





- If **Cancel** is clicked, the system log will not be deleted.

Note

The system log has been deleted.

A. Appendix

A-1. Troubleshooting

This chapter introduces the possible problems you may encounter while installing or using BR-400AN and the troubleshooting methods for those problems.

I don't know what IP address is assigned to BR-400AN.

Solution	Use the unified device management utility "AMC Manager®" or "AMC Manager® Free". They can discover
	BR-400AN units over the network.

The POWER LED is blinking red.

BR-400AN may be connected to Ethernet HUB via wired LAN when it is operating in the configuration mode.		
Solution	Restart BR-400AN.	
	To use BR-400AN in the configuration mode, connect BR-400AN directly to a PC.	

BR-400AN fails to connect to the existing Mesh network.

The wireless setting or Mesh setting of BR-400AN may differ from the setting of that Mesh network.		
Solution	Configure the same wireless setting, Mesh group name and Mesh encryption key to BR-400AN as that of	
	the Mesh network. These settings must be the same between the Mesh network and BR-400AN.	

BR-400AN fails in communication with the target device.

 The communication route to the target device may not have been established.

 Solution
 Use Mesh Monitor to check if the communication route is established for the target device.

Communication speed is too slow.

The communication speed could be improved by changing the configuration of BR-400AN.		
Solution	Change the location or configuration. Example) - Select 802.11n/a for Wireless Mode and 40MHz for Channel Bandwidth .	
	- When BR-400AN is not connected to Ethernet HUB, select DISABLE for Network Loop Avoidance . - Set a greater value for TX Power (e.g. 50% -> 70%). - Install more devices to shorten the interval of devices.	

When BR-400AN is added to the existing network, a communication error occurs in the existing network.

BR-400AN may be connected to the existing network via wired LAN when Network Loop Avoidance is set to DISABLE		
on it.		
	Remove the BR-400AN unit from the network. Set ENABLE for Network Loop Avoidance on the BR-	
Solution	400AN unit and then add it back to the existing network.	
	(By default, Network Loop Avoidance is set to DISABLE.)	

Although the Access Point feature is enabled on BR-400AN, I cannot connect a wireless client device.

The access may be filtered by the MAC Address filter.		
	The MAC Address filter works only when the Access Point feature is enabled on BR-400AN.	
	Login to the Web configuration interface, click Access Point Function and select the Access Point	
Solution	Function Extended Configuration tab. Check if the MAC address filter is enabled. If you do not have a PC	
	to access the Web configuration interface, initialize BR-400AN. For how to initialize, refer to 7-2. Factory	
	Default Configuration - How to reset BR-400AN to factory defaults using the Push Switch.	

Communication is lost.

The route may not be optimized in the Mesh network.	
Solution	When the Route Refresh Function is set to DISABLE , change it to ENABLE .

BR-400AN of a different floor may have been connected to the Mesh network.

BR-400AN of a different floor could be connected if a radio wave is reached from that Mesh network.SolutionTo establish the Mesh network separately for each floor, a different Mesh ID needs to be set for each network.

I cannot connect BR-400AN to the Mesh product of other vendor thought it supports IEEE802.11s.

Solution	BR-400AN does not support other manufacturer's Mesh products.
	The detailed specification differs for each manufacturer.

BR-400AN is found on AMC Manager[®] but when I try to configure it, the message says "Failed to connect to the device" and the configuration fails.

BR-400AN and the PC you are using for configuration may be in a different network segment.		
Solution	If the IP address of BR-400AN is displayed as "169.254.x.x" on AMC Manager®, change the IP address and	
	subnet mask of BR-400AN to the one communicable from the PC. Or otherwise, change the IP address and	
	subnet mask of the PC to the one communicable with the address "169.254.x.x".	

The communication quality is poor as I see it using Mesh Monitor.

One of terminal devices on the Mesh network may keep sending the broadcast packets.		
	If a device continues to send broadcast packets in the Mesh network, it may cause traffic on the bandwidth	
Solution	and interfere with communications of other devices. Remove that device from the Mesh network or	
	change the configuration not to send the broadcast packets.	

BR-400AN falls into the 'undetected' status on Mesh Monitor when BR-400AN is using the DFS channel and the route refresh is executed on Mesh Monitor.

BR-400AN may be in a process of radio wave detection for 1min as it does not find other MP/MAP devices when the			
route refresh is executed.			
Solution	If MP/MAP devices are not found on the Mesh network after the route refresh is executed when BR-400AN		
	is using the DFS channel, BR-400AN tries to see if there are radar signals. During this period, BR-400AN		
	is not able to handle wireless communication and respond to Mesh Monitor for 1 min. To avoid this		
	problem, use the other channel than the DFS channel.		

When I configure BR-400AN using AMC Manager[®], the message says "Invalid value is included" and the configuration fails.

You may try to configure BR-400AN with a combination of incompatible settings.		
	When you configure multiple settings of BR-400AN using AMC Manager®, the configuration can fail due to	
	incorrect combination of settings.	
	For example, the configuration fails when the selected extension channel does not exist on the	
	communication channel, when invalid WEP key or Pre-Shared Key is specified, or when WEP is configured	
	for 802.11n/b/g or 802.11n/a even though these wireless modes do not support WEP.	
	Example of bad combination of settings:	
	- Wireless mode is set to 802.11b/g or 802.11a and channel bandwidth is set to 40MHz.	
	- Wireless mode is set to 802.11n/b/g or 802.11n/a and WEP is set to ENABLE.	
	- Wireless mode is set to 802.11n/a, the communication channel is set to 36, 52, 100, and extension channel	
	is set to Lower .	
	- Wireless mode is set to 802.11n/a, the communication channel is set to 48, 64, 140, and the extension	
Solution	channel is set to Upper .	
	- Wireless mode is set to 802.11n/b/g, the communication channel is set to 1, 2, 3, 4, and the extension	
	channel is set to Lower .	
	- Wireless mode is set to 802.11n/b/g, the communication channel is set to 8, 9, 10, 11 (for US) or 10, 11, 12,	
	13 (for EU), and the extension channel is set to Upper .	
	- WEP is set to ENABLE and values other than below are specified for WEP key.	
	5-10 digit character string	
	13 or 26 digit hexadecimal value	
	- Wireless mode is set to 802.11n/b/g, 802.11n/a or the authentication method that include WPA2 is used,	
	and then TKIP is used for encryption mode.	
	- Pre-Shared Key is specified by 64 characters.	
	Please try to configure BR-400AN again using the correct settings.	

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Silex Technology: BR-400AN-US