

User Guide

External Temperature Sensor

Version 1.1

https://www.lairdconnect.com

Americas: +1-800-492-2320 Europe: +44-1628-858-940 Hong Kong: +852 2923 0610



REVISION HISTORY

Version	Date	Notes	Contributors	Approver
1.0	07 Jan 2019	Initial Release	Robert Gosewehr	Chris Hofmeister
1.1	28 Aug 2019	Reflect new part numbers and modified probe specification	Chris Boorman	Jonathan Kaye

CONTENTS

1		Introd	duct	ion	4
2		Part I	Num	nbers	4
3		Instal	llatio	on	5
	3.	1	Illu	strations	6
		3.1.1		Stainless Steel Temperature Probe with RJ45 Cable Assembly	6
		3.1.2		RJ45 Cable Gland	7
4		Conn	necti	ion Status	8
5		Data	Visu	ualization	9
	5.	1	Sei	ntrius Sensor Mobile App	9
6		Batte	ery C	Consumption1	0
7		Sanit	atio	n and Cleanliness1	0

1 INTRODUCTION

This User Guide explains how to properly install the Laird External Temperature Probe kit for the Sentrius Sensor series and view sampled data using the Sentrius Sensor Mobile App.

This variant of the Sentrius RS1xx series of LoRa / BLE Sensors enables use of an external cabled temperature probe, in place of the integrated temperature sensor. The kit includes an IP67 rated cabled temperature probe that is 200mm in length and 6.35mm in diameter at the stainless-steel probe end. The external temperature probe utilizes a One Wire digital interface and supports a general temperature range of -55° to +125°C (+/-0.9°C). The cabled probe connects into the main body of the Sentrius Sensor via a CAT5 IP67 rated RJ45 connector.

Note: This guide only contains a brief walkthrough. Refer to the RS1xx Guide for further details on sensor functionality and the mobile app capabilities. To access the RS1xx Guide, navigate to the RS1xx product page, click Documentation, and select the Sentrius RS1xx User Guide.



Figure 1: Sentrius sensor with external temperature probe

The external temperature probe is ordered separately from the Sensor body, in single or bulk. See the Laird RS1xx product page for ordering information.

3 INSTALLATION

To install the external temperature sensor, refer to Figure 2 and follow these steps:

- 1. Unscrew the Ethernet cap (1) from the Sentrius Sensor.
- 2. Connect the RJ45 connector from the cable assembly into the external port of the Sentrius Sensor.
- 3. Screw on (by hand) the top portion of the cable gland the screw nut (3) until tight.
- Visually check to ensure the lower portion of the cable gland – the pressing screw (2) – is also tight.



Figure 2: Installing the external temperature sensor

Note: Ensure that references (2) and (3) in Figure 2 are tight when installing the external temperature probe into the Sentrius Sensor. If these areas are not sufficiently tightened, this could lead to a potential leak and cause damage to the sensor's external port connector or to the temperature probe cable assembly.

3.1 Illustrations





Figure 3: Stainless steel temperature probe with RJ45 cable assembly

3.1.2 RJ45 Cable Gland

(DIM in millimeters)



6	SCREW	PRESSING SCREW, NYLON.	BLACK	1
5	SEAL	SANTOPRENE. for cable OD: 3~5mm & 5~8mm.	BLACK	2
4	SCREW NUT	SCREW NUT, NYLON+GF.	BLACK	1
3	SLEEVE	CABLE SLEEVE, NYLON.	BLACK	1
2	GASKET	RUBBER	BLACK	1
1	RJ-45 PLUG	RJ-45 8P8C SHIELDED PLUG.		1

Figure 4: RJ45 cable gland

4 CONNECTION STATUS

When the external probe is connected properly to the sensor, the sensor will operate "normally" once powered up. Normal operation of the sensor is indicated by the left LED will flashing either "orange" or "green" color to indicate the connection status to a network.

A connection problem at power up is indicated by both LEDs on the front panel both being constantly on. This is a visual indicator to the user that there is a communication issue between the sensor and the probe. If the sensor cannot detect the external probe it will not function properly.

To remedy this, follow these steps:

- Retry the steps from the Installation section. Make sure the sensor has the latest firmware installed to ensure the sensor has all the latest capabilities. The firmware can be updated using the mobile app. Reference the RS1xx guide for more details RS1xx product page on this process.
- 2. The time it takes for the sensor to detect a probe depends on the sensor's settings, in particular, the read period and aggregate count. This means that the time to auto detect a probe can fluctuate between 30 seconds or likely much longer.

To speed up the auto detect process of the sensor, press and hold the Bluetooth button on the top of the sensor for five seconds after reconnecting the external probe. This will restart the sensor, and on startup the Sentrius sensor will check for the sensor.

The sensor monitors the status of the external probe on each temperature measurement. If the external probe is damaged or disconnected it will be shown by the LoRa status LED. The LoRa status LED flashes at the heartbeat interval to indicate a network connection. If the external probe becomes disconnected, the LoRa status LED will quickly flash orange three times immediately after the heartbeat indication. When the external probe is reconnected, the heartbeat LED will return to normal operation.

3. If you continue to experience an issue, contact Laird Support. There could be damage to the Sentrius sensor or probe.



Figure 5: Front panel LEDs are lit

5 DATA VISUALIZATION

5.1 Sentrius Sensor Mobile App

The Sentrius mobile application allows a user to configure a device, troubleshoot a device, see real-time sensor data, and update firmware. Search the appropriate app store (Google Play Store, Apple Store, or the Microsoft Store) for the Sentrius Sensor App and install it on your device.

Note: This guide only contains a brief walkthrough. Refer to the RS1xx Guide for further details on sensor functionality and the mobile app capabilities. To access the RS1xx Guide, navigate to the RS1xx product page, click Documentation, and select the **Sentrius RS1xx User Guide**.

The Sentrius sensor mobile app displays real-time sensor data from the external temperature probe and sensor once a good cable connection is established.

To view real-time sensor data, follow these steps:

- 1. Press and hold the BLE button on the front panel of the sensor to start BLE advertising on the device.
- 2. Select the corresponding DEV EUI on the connection screen of the mobile app. The DEV EUI of the sensor can be found on the back label of the sensor.
- 3. Once connected to the mobile app, click the Temperature Reading icon under the Temperature/Humidity section to see real-time sensor data from the temperature probe.

From this screen, the temperature probe can be validated by confirming the temperature measurements are accurate. Place your hand on the probe to fluctuate the temperature.

ATÊT	* ₩E 🐀	ATET	8 ¥8 +9, ,al3	6% 🛚 1:52 PM
😑 🛛 Sentrius De	levice List	SS_TEH		
SS_TEH Dev EUI: 0025ca0a0000	0016a9		DISCONNECT	
		Sensors		
		Temperature/Humic	lity 🔅 🧔	
		BLE Radio		
		Data From BLE Mod	lule	0
		LoRa Radio		
		LoRa Radio Setting	s and Info	
		Device Settings		
		Device Settings		Ø
		Device FW Update		
		Device FW Update		
		Battery Capacity		

Figure 6: Sentrius sensor mobile app displays



Update the sensor settings on the main screen to get a faster reading period if the temperature readings are taking too long to update on the graph. The fastest read period a sensor can have is thirty seconds.

6 BATTERY CONSUMPTION

A RS186 was configured for a read period of 300 seconds with an aggregate of three.

A power analysis was performed for 32 minutes to ensure two LoRa transmit events were captured.



Figure 7: RS186 power consumption

The average current consumption was 72 uA over 32 minutes. The data rate that the RS186 transmitted at was SF7BW125.

7 SANITATION AND CLEANLINESS

Every external temperature probe is cleaned with an alcoholic wipe and placed in an individual bag before leaving the supplier. A label is included with every bag warning the end-user to clean the probe before use. It is up to the end-user to ensure that every temperature probe is cleaned and sanitary for consumer use before using the temperature probes. Laird will not be held liable for any issues pertaining to the cleanliness of the probes.

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Ezurio:

455-00108