

Evaluating the **ADPD188BI** Integrated Optical Module and Smoke Chamber

FEATURES

Supports the detection of universal asynchronous receiver and transmitter (UART)

UDP transfer capability

Full configuration of the **ADPD188BI**

Register level

High level

Graph view

Time graph

Frequency graph

EVALUATION KIT CONTENTS

EVAL-ADPD188BIZ-S2 evaluation board

Ribbon cable

EQUIPMENT NEEDED

PC running Windows 7 or Windows 10 operating system

EVAL-ADPDUZ microcontroller board

EVAL-CHAMBER smoke chamber

DOCUMENTS NEEDED

ADPD188BI data sheet

SOFTWARE NEEDED

Wavetool Evaluation Software package

GENERAL DESCRIPTION

The EVAL-ADPD188BIZ-S2 evaluation board provides users with a simple means of evaluating the **ADPD188BI** optical module along with the **EVAL-CHAMBER** smoke chamber for smoke and aerosol detection applications.

The evaluation system is composed of the EVAL-ADPD188BIZ-S2 evaluation board, the **EVAL-ADPDUZ** microcontroller board, the optional **EVAL-CHAMBER** smoke chamber, and the **Wavetool Evaluation Software** graphical user interface (GUI). The software provides users with both low level and high level configurability, real-time frequency and time domain analysis, and user datagram protocol (UDP) transfer capability so that the evaluation board can easily interface to the user development system.

The EVAL-ADPD188BIZ-S2 is powered through the ribbon cable from the **EVAL-ADPDUZ** microcontroller board (ordered separately).

For full details on the **ADPD188BI**, see the **ADPD188BI** data sheet, which should be consulted in conjunction with this user guide when using these evaluation boards.

EVAL-ADPD188BIZ-S2 EVALUATION BOARD PHOTOGRAPH




Figure 1.

TABLE OF CONTENTS

Features..... 1

Evaluation Kit Contents 1

Equipment Needed..... 1

Documents Needed..... 1

Software Needed..... 1

General Description 1

EVAL-ADPD188BIZ-S2 Evaluation Board Photograph..... 1

Revision History 2

Getting Started.....3

Installing the Wavetool Evaluation Software.....3

Accessing the Online User Guide and Videos.....3

Using the EVAL-CHAMBER Smoke Chamber with the
 EVAL-ADPD188BIZ-S2 Evaluation Board4

Evaluation Board Schematics and Artwork.....7

REVISION HISTORY

- 3/2020—Rev. 0 to Rev. A
- Updated Links to EVAL-ADPDUCZ, EVAL-CHAMBER, and
Wavetool Evaluation Software Throughout
- 10/2019—Revision 0: Initial Version

GETTING STARTED

INSTALLING THE WAVETOOL EVALUATION SOFTWARE

Download the [Wavetool Evaluation Software](#) package from the EVAL-ADPD188BIZ-S2 product page. Navigate to the directory where the software package is downloaded to and double-click the application to install the software.

ACCESSING THE ONLINE USER GUIDE AND VIDEOS

After installing the [Wavetool Evaluation Software](#), download the **AWT Document**, a user manual for the [Wavetool Evaluation Software](#) (see Figure 3), which allows online access to the document as well as the hardware setup. The **AWT Document** contains videos that show the following:

- How to install the correct drivers for the microcontroller board, [EVAL-ADPDUCZ](#)
- How to install the correct firmware
- How to set up the hardware
- Information about the [Wavetool Evaluation Software](#)

To access the **AWT Document**, take the following steps:

1. Open the [Wavetool Evaluation Software](#) application file from the directory where it was installed. Click the **Help** button (see Figure 2) on the software home screen.




Figure 2. *Applications Wavetool - Beta* Home Screen

2. If this is the first time opening the [Wavetool Evaluation Software](#), users are prompted to download the **AWT Document** as shown in Figure 3.




Figure 3. *AWT Document* Download Prompt

3. Depending on the speed of the internet connection, it can take from several seconds to a minute to download the documentation. After the document is downloaded, the prompt shown in Figure 4 appears. Click the **Ok** button to open the documentation in a browser window.




Figure 4. *Document Downloaded* Message

4. Click the **Help** button during subsequent initiations of the software to automatically open the user guide without the need to redownload.

All information required to operate the [Wavetool Evaluation Software](#) is found in the **AWT Document**. Information regarding the [ADPD188BI](#) is found in the [ADPD188BI](#) data sheet.

USING THE EVAL-CHAMBER SMOKE CHAMBER WITH THE EVAL-ADPD188BIZ-S2 EVALUATION BOARD

The EVAL-ADPD188BIZ-S2 evaluation board is designed to be used with the [EVAL-CHAMBER](#) smoke chamber. The smoke chamber helps control the environment around the ADPD188BI module. The [EVAL-CHAMBER](#) smoke chamber is attached to the EVAL-ADPD188BIZ-S2 evaluation board with rivets or self tapping screws. Figure 5 and Figure 6 show the smoke chamber attached to the evaluation board using rivets.




Figure 5. Evaluation Board Attached to Chamber, Top View



Figure 6. Evaluation Board Attached to Chamber, Side View

After initiating the [Wavetool Evaluation Software](#), load the default EVAL-ADPD188BIZ-S2 configuration file (comes with the software installation) and run the software with the chamber securely attached. There is some background response due to the reflection from the smoke chamber.

To have a meaningful blue/infrared (IR) ratio when smoke is present in the chamber, null the background response with the null offset feature in the software. To access the null offset feature, hover the mouse pointer over the raw data plot and right click to open the pull-down menu shown in Figure 7. Select **Offset** and check off **Null** to null the background response to zero (see Figure 7).

After nulling the background response, the ratio appears noisy (see Figure 8). The ratio appears noisy because the ratio is taken with no smoke present and the background response is nulled to approximately zero. As a result, very small numbers are dividing, and this causes large ratios. Users can ignore the ratio at this time.

After smoke is present in the chamber, as shown in Figure 9, the raw data plot shows the individual blue and IR responses to the smoke source. The ratio shows a meaningful blue to IR ratio.

For subsequent smoke tests, clear the chamber with air. If the previous smoke test leaves residue on the chamber, users must then null the background response again prior to starting another smoke test.


Figure 7. Null Background Response with the *Wavetool Evaluation Software*

Figure 8. Raw Data and Ratio After Null of Background Response



Figure 9. Raw Data and Ratio with Smoke Particles Present

22128-009

EVALUATION BOARD SCHEMATICS AND ARTWORK




Figure 10. EVAL-ADPD188BIZ-S2 Schematic






Figure 11. EVAL-ADPD188BIZ-S2 Schematic Page 2



22128-012

Figure 12. EVAL-ADPD188BIZ-S2 Bottom Layer



22128-013

Figure 13. EVAL-ADPD188BIZ-S2 Top Layer




Figure 14. EVAL-ADPD188BIZ-S2 Bottom Layer Silkscreen

01-047686 REV B
() EVAL-ADPD188BIZ-SK




Figure 15. EVAL-ADPD188BIZ-S2 Top Layer Silkscreen

NOTES



ESD Caution

ESD (electrostatic discharge) sensitive device. Charged devices and circuit boards can discharge without detection. Although this product features patented or proprietary protection circuitry, damage may occur on devices subjected to high energy ESD. Therefore, proper ESD precautions should be taken to avoid performance degradation or loss of functionality.

Legal Terms and Conditions

By using the evaluation board discussed herein (together with any tools, components documentation or support materials, the "Evaluation Board"), you are agreeing to be bound by the terms and conditions set forth below ("Agreement") unless you have purchased the Evaluation Board, in which case the Analog Devices Standard Terms and Conditions of Sale shall govern. Do not use the Evaluation Board until you have read and agreed to the Agreement. Your use of the Evaluation Board shall signify your acceptance of the Agreement. This Agreement is made by and between you ("Customer") and Analog Devices, Inc. ("ADI"), with its principal place of business at One Technology Way, Norwood, MA 02062, USA. Subject to the terms and conditions of the Agreement, ADI hereby grants to Customer a free, limited, personal, temporary, non-exclusive, non-sublicensable, non-transferable license to use the Evaluation Board FOR EVALUATION PURPOSES ONLY. Customer understands and agrees that the Evaluation Board is provided for the sole and exclusive purpose referenced above, and agrees not to use the Evaluation Board for any other purpose. Furthermore, the license granted is expressly made subject to the following additional limitations: Customer shall not (i) rent, lease, display, sell, transfer, assign, sublicense, or distribute the Evaluation Board; and (ii) permit any Third Party to access the Evaluation Board. As used herein, the term "Third Party" includes any entity other than ADI, Customer, their employees, affiliates and in-house consultants. The Evaluation Board is NOT sold to Customer; all rights not expressly granted herein, including ownership of the Evaluation Board, are reserved by ADI. CONFIDENTIALITY. This Agreement and the Evaluation Board shall all be considered the confidential and proprietary information of ADI. Customer may not disclose or transfer any portion of the Evaluation Board to any other party for any reason. Upon discontinuation of use of the Evaluation Board or termination of this Agreement, Customer agrees to promptly return the Evaluation Board to ADI. ADDITIONAL RESTRICTIONS. Customer may not disassemble, decompile or reverse engineer chips on the Evaluation Board. Customer shall inform ADI of any occurred damages or any modifications or alterations it makes to the Evaluation Board, including but not limited to soldering or any other activity that affects the material content of the Evaluation Board. Modifications to the Evaluation Board must comply with applicable law, including but not limited to the RoHS Directive. TERMINATION. ADI may terminate this Agreement at any time upon giving written notice to Customer. Customer agrees to return to ADI the Evaluation Board at that time. LIMITATION OF LIABILITY. THE EVALUATION BOARD PROVIDED HEREUNDER IS PROVIDED "AS IS" AND ADI MAKES NO WARRANTIES OR REPRESENTATIONS OF ANY KIND WITH RESPECT TO IT. ADI SPECIFICALLY DISCLAIMS ANY REPRESENTATIONS, ENDORSEMENTS, GUARANTEES, OR WARRANTIES, EXPRESS OR IMPLIED, RELATED TO THE EVALUATION BOARD INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, TITLE, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF INTELLECTUAL PROPERTY RIGHTS. IN NO EVENT WILL ADI AND ITS LICENSORS BE LIABLE FOR ANY INCIDENTAL, SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES RESULTING FROM CUSTOMER'S POSSESSION OR USE OF THE EVALUATION BOARD, INCLUDING BUT NOT LIMITED TO LOST PROFITS, DELAY COSTS, LABOR COSTS OR LOSS OF GOODWILL. ADI'S TOTAL LIABILITY FROM ANY AND ALL CAUSES SHALL BE LIMITED TO THE AMOUNT OF ONE HUNDRED US DOLLARS (\$100.00). EXPORT. Customer agrees that it will not directly or indirectly export the Evaluation Board to another country, and that it will comply with all applicable United States federal laws and regulations relating to exports. GOVERNING LAW. This Agreement shall be governed by and construed in accordance with the substantive laws of the Commonwealth of Massachusetts (excluding conflict of law rules). Any legal action regarding this Agreement will be heard in the state or federal courts having jurisdiction in Suffolk County, Massachusetts, and Customer hereby submits to the personal jurisdiction and venue of such courts. The United Nations Convention on Contracts for the International Sale of Goods shall not apply to this Agreement and is expressly disclaimed.