POTTER CORROSION The Symbol of Protection

SLUDGE KIT 5 YEAR DEPOSIT SLUDGE TEST KIT



This kit is designed to conform to the requirements of NFPA 25, 2002, 13.2.1.2 requiring testing for MIC if slime or tubercles are discovered in an internal inspection. The test involves removing some of the slime, deposit, scale, tubercles, mounds, etc. and sending them to Potter for microbiologically influenced corrosion (MIC) analysis.

Upon receiving the sample, the lab will establish a chain of custody and prepare the sample for bacterium extraction. Five groups of bacteria will be cultured: Heterotrophic Bacterium which determines if the majority of bacterium are anaerobic (without air) or aerobic (with air) in nature; Slime Forming Bacterium (aids in tubercle formation); Iron Related Bacterium (iron-pipe oxidizing and reducing bacterium); Sulfate Reducing Bacterium (causes pit corrosion) and Acid producing Bacterium (causes pit corrosion). The testing will take approximately 9 days to allow for bacteria culture growth. A full written report will be provided approximately 15 business days after testing is started.

Deposit Retrieval/Return Procedure

Note: The sample must be received by Potter within 72 hrs after it is removed from the sprinkler system.

1. Open system to be tested.

2. Remove slime, deposit, scale, tubercles, mounds, etc. with enclosed tongue depressor. If more than one type of deposit is present, try to sample all types.

- 3. Fill 120cc bottle with approximately one-half volume sample collected.
- 4. Cap bottle tightly and tape cap to bottle.
- 5. Complete the sample identification section of this document.

6. Place sample bottle and this completed document into the original shipping container.

Ship to Potter Electric using the enclosed pre-paid UPS Second Day form.
A full report will be issued within 15 business days after testing is started.

Certification

Bacterium testing procedures have been tested against the appropriate A.T.C.C. (American Type Culture Collection) strains for each specific group of bacterium.

Includes:

- 1 ea 120cc sample bottle
- · 1 ea tongue depressor
- Instruction sheet
- Sample identification form
- Prepaid shipping form (U.S. Only)
- Pre-printed return mailing label
- Laboratory analysis of returned deposit samples

Stock number: 1119174

Sample Identification

NOTE: *This section MUST be filled out completely and returned with the sample bottle.*

Person/Firm Requesting Test

Name:		
Company:		
Address:		
	_State:Zip:	
Phone #:		
Email:		
(If you would like report sent via email)		
Facili	ty Tested	
Facili Name:	·	
Name: Bldg #:	Riser #:	
Name: Bldg #: Address:		

System Information

System (circle one): Wet/Dry	FPS Age:_	Total # of Risers:
Facility Sq. Ft. (approx.):		# of Floors:
Facility Type:		

Type of Pipe (circle): TW/Sch 40/Black/Galv/Threaded/Grooved/ CPVC

Previous System Treatment:

Water Sample Information

Date sample collected:	Time:
Location in system where obtained:	
Sample collected by:	
Company:	
Address:	

Sample description/remarks:

Potter Electric Signal Company, LLC • St. Louis, MO • Phone: 866-956-0988/Canada 888-882-1833 • www.pottersignal.com

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

AMSECO: 1119174