



## ■ Terminal Attachment

Terminal attachment to facilitate two or more terminal connections to power supply output is prepared in PAA, UAW, UAF, MAX and ACE series.

Type	Mating Model	Contents
B-PAA600-1	PAA300 PAA600 UAW500 UAF500	Terminal attachment to facilitate two or more terminal connections to power supply output
B-MX-1	PBA600F MAX1600F MAX1600T MAX3200T	Terminal attachment to facilitate terminal connections to power supply output
B-MX-9	MAX1600F MAX1600T MAX3200T	Terminal attachment for series operation as output modules



★ It is necessary to install the attachments on opposite direction to avoid short-circuit between + and - in terminal block.




- ★ It is necessary to install B-MX-1 on opposite direction to avoid short-circuit between + and terminal block.
- ★ Please note the direction of the installation to prevent the short-circuit between the outputs when using B-MX-1 and B-MX-9 at the same time.
- ★ The cover of terminal block does not be attached to B-MX-1 with installation screw and solderless terminal occasionally.



Type	Mating Model	Contents
B-ACE-7	ACE series	Terminal attachment to facilitate faston terminal output modules
B-ACE-8	ACE series	Terminal attachment to facilitate wiring
B-ACE-9	ACE series	Terminal attachment for series opration as output modules

<sup>★</sup>These attachments cannot be used for module code S, T, U, Y, W, Z, 9, Q, and V.



★ B-ACE-7: Recommended faston terminal #250. Quantity is 1 piece.

 $\bigstar$  B-ACE-8: Please be carefull with that B-ACE-8 is not stressd in wiring. Quantity is a couple.

