

Enabling Energy's Future™



BMOD0006

Mounting sketch for stacking of BMOD0006

Laurent Gisler

21.11.2012


Stacking of 3 BMOD0006



Note: this arrangement has not been “Shock & vib.” tested


Stacking of 3 BMOD0006

- **Mounting plate with 12 threaded studs**



Stacking of 3 BMOD0006

- Place the module onto the studs and place to the spacers




- Repeat the operation for the 2nd and 3rd modules

Stacking of 3 BMOD0006

- On the top, place the spacers (shorter spacer), washers and nuts to tight the assembly





Sectional view of the stacking



Support of the module

- Important thing about the spacer



The "spacer" must support on both plastic housing and metal insert.
The minimum diameter of the support is 16 mm