Smart Dupline® Smoke Detector Type BSG-SMOx-U





- Smoke detector using Tyndall effect
- Detection of smouldering fires and flaming fires with smoke development
- Without radioactive sources
- Detection of areas up to 60 m²
- Transmission of alarms and Alive signals via Dupline®
- Operating voltage supplied by Dupline[®] bus
- Optional use of the smoke detector as alarm device for other detections such as gas, water and burglary via Dupline[®]
- Battery backup if the Dupline® connection is interrupted
- Acoustic alarm > 85 dB
- Constant monitoring of sensor sensitivity via Dupline®
- For ceiling mounting

Product Description

BSG-SMOx-U is a detector for home/building applications which transmits the alarm event to the smarthouse controller. It is part of the smart-house concept and it can be used in all the functions where alarm signals are needed.

Ordering Key	BSGSMOAU
Decentral — Smoke Detector — No battery back-up — Smart Dupling®	

Type Selection

Battery back-up	Supply by Dupline®	
YES	BSG-SMO-U	
NO	BSG-SMOA-U	

Input Specifications

Detector	Optical (Tyndall effect)

Dupline® Output Specifications

Voltage	8.2 V
Maximum Dupline® voltage	10 V
Minimum Dupline® voltage	5.5 V
Maximum Dupline® current When the alarm is active	10 mA

Supply Specifications

Power supply	Supplied by Dupline®	
Current consumption typ.	2.5 mA	
Battery current consumption	20 μA, BSG-SMO-U only	
Supply voltage	9 VDC, BSG-SMO-U only	



General Specifications

Address assignments / channel programming	If it is used with the SH2WEB24 the address assignment is automatic: the controller recognises the module through the SIN (Specific Identification Number) that has to be inserted	Indication	Red LED. Short flash once every 42 sec. (alive signal): the smoke detector is OK. Short flash every 0.5 sec.: Alarm. Red flash (42 sec.) and asynchronous beep = Dirty
	in the SH tool. If it is used with the BH8-CTRLX-230, the channels	BSG-SMO-U only	Red flash (42 sec.) and simultaneous beep = Low battery voltage.
have to be programmed by the BGP-COD-BAT Channel assignment	Environment Degree of protection Operating temperature	IP 43 -0° to +50°C	
I/O number 1	Alarm signal.	Storage temperature	-5° to +85°C
I/O number 2	The status of the signal can be programmed (see below). Monitoring of sensor (tamper/presence). The signal can be programmed.	Connection Screwless detachable D+ D-	0.2 to 1.5 mm ² Signal GND
I/O number 3	(tamper/presence). The sig- nal is always active if OK, otherwise inactive. Monitoring of battery voltage. The signal is active if the	Housing Dimensions Material Colour	For installation on ceilings Ø 100 x 51 mm ABS White
	voltage is low.	Weight	160 g
	Only BSG-SMO-U	Sound level	> 85 dB(A) / 3 m (10 ft)
I/O number 4	Monitoring of sensor sensitivity.	Battery	IEC 6LR 61
	The signal is active if the sensor becomes dirty.	Average life, battery	2 years
I/O number 5	Forced alarm.	Alarm signalling	Acoustic and optical
	The smoke sensor can be	CE Marking	Yes
	used as an alarm device for e.g. water, gas and burglar alarms.	EMC Immunity - Electrostatic discharge	EN 61000-6-2 EN 61000-4-2
Fail-Safe mode BSG-SMO-U BSG-SMOA-U	If the Dupline® connection is interrupted, the smoke sensor will still work, but as a normal individual smoke detector. If the Dupline® connection is interrupted, the smoke sensor will also be interrupted.	 Radiated radiofrequency Burst immunity Surge Conducted radio frequency Power frequency magnetic fields Voltage dips, variations, interruptions Emission Conducted and radiated emissions Conducted emissions Radiated emissions 	EN 61000-4-3 EN 61000-4-4 EN 61000-4-5 EN 61000-4-6 EN 61000-4-8 EN 61000-6-3 CISPR 22 (EN55022), cl. B CISPR 16-2-1 (EN55016-2-1) CISPR 16-2-3 (EN55016-2-3)

Mode of Operation

BSG-SMOx-U connected to the SH2WEB24 Coding/Addressing

If the device module is connected to the SH2WEB24 controller, no addressing is needed since the module is provided with a specific identification number (SIN): the user has only to insert the SIN in

the SH tool when creating the system configuration.
Used channels: 4 input channels, 1 output channel.

BSG-SMOx-U connected to BH8-CTRLX-230 Coding/Addressing

If the input module is connected to the BH8-CTRLX-

230 controller, the user has to program the channels using the BGP-COD-BAT: this module has:

- 4 input channels (I/O 1-4)
- 1 output channel (I/O 5)

The alarm signal can be programmed to be active

when the alarm is ON or when the alarm is OFF.

Fail/safe bit = 0 Signal active when the alarm is ON.

Fail/safe bit = 1
Signal active when the alarm is not active.



Mode of Operation

Mounting

SMOx-U,

To achieve minimum protection, one BSG-SMOx-U should be installed in front of each sleeping area or each floor. Higher protection will be achieved if one smoke detector is present in every room (except for the kitchen and the bath - here, false alarms may occur due to steam development). When using the BSG-

the following issues must be observed: • Rooms may have a floor

area of up to 60 m² and a

height of up to 6 m

- Hallways and narrow corridors may have a width of up to 3 m (10 ft) and a length of up to 15 m (50 ft)
- The mounting location must be as close as possible to the centre of the room A minimum distance of 0.5 m
- (1.5 ft) must be maintained from walls and furniture The BSG-SMO-U must NOT

be mounted in the following locations:

- Near ventilation ducts or strong draughts
- · Directly in the apex of

pitched roofs (a minimum distance of 30 cm (1 ft) from the apex must be maintained)

• In rooms which are usually very steam-, dustor smoke-filled (for example in workshops, bathrooms and laundry rooms)


Connection of multiple smoke alarms

It is possible to interconnect several smoke alarms so that the alarm signalfrom one alarm is transmitted to all other connected alarms.

The smoke alarms are connected in parallel using a 2wire cable.

Note: Make sure that the total power consumption does not exceed the Dupline® controller's output when interconnecting the smoke alarms. Use a back-up battery to avoid voltage drop in Dupline® bus when using interconnection.

Wiring Layout and Description




BSG-SMOx-U

Info: Please, when installing the smoke alarm (changing the battery), pay attention to the following:

- Make sure that the PCB is connected correctly to the multiple plug and that the two pole connector is connected to the PCB.
- Test the smoke alarm (by pushing the test button) when it has been placed in its retaining ring on the ceiling.

Dimensions



Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Carlo Gavazzi: