

EV3437-RP-00A

High Efficiency, Fully-Integrated Synchronous Boost Converter EV Board

DESCRIPTION

EV3437-RP-00A Evaluation Board is designed to demonstrate the capability of MP3437. It is a 600kHz fixed frequency, wide input range, highly integrated boost converter. It starts from an input voltage as low as 2.7V, and supports up to 20W load power from 1-cell battery.

MP3437 adopts constant-off-time (COT) control topology providing fast transient response. QFN package has MODE pin which can support mode selection of PSM, FCCM and USM in light load condition. And the integrated low-side and high-side MOSFET simplify the design and save BOM cost.

The MP3437 supports auto-pass-through mode when V_{IN} is higher than $V_{\text{OUT-SET}}$ in PSM mode. It also features with programmable input undervoltage lockout (UVLO) and over temperature protection.

The MP3437 is available in QFN-10 (2mmx2.5mm) and TSOT23-8 package. This board is available in QFN-10 package.

ELECTRICAL SPECIFICATION

| Parameter | Symbol | Value | Units |
|----------------|------------------|--------|-------|
| Input Voltage | V _{IN} | 2.7-16 | V |
| Output Voltage | V _{OUT} | 8 | V |
| Output Current | Іоит | 2.5 | Α |

FEATURES

- 2.7V-to-16V Startup Voltage⁽¹⁾
- 0.8V-to-16V Operation Voltage
- Up to 16V Output Voltage
- Support 20W Power Load from 3.3V
- 9.5A Internal Switch Current Limit
- Integrated 14mΩ & 21mΩ Power MOSFET
- >90% Efficiency for 3.3V VIN to 8V/2.5A
- Auto Pass-Through Function in PSM Mode
- 600kHz Fixed Switching Frequency
- Adaptive COT for Fast Transient Response
- Internal Soft Start and Compensation
- Programmable UVLO and Hysteresis
- 150°C Over Temperature Protection
- Over Voltage Protection
- QFN-10 Package on This Board

APPLICATIONS

- Notebook
- Al Speaker
- Bluetooth Speaker
- · Portable POS System

All MPS parts are lead-free, halogen free, and adhere to the RoHS directive. For MPS green status, please visit MPS website under Quality Assurance. "MPS" and "The Future of Analog IC Technology" are Registered Trademarks of Monolithic Power Systems, Inc.

Note:


(1) During input power on, the inrush current through high-side MOSFET body diode should be limited less than 30A. And the continuous current should be avoided to flow through high-side MOSFET body diode. Refer to "Input Power-up Inrush Current Control" section in MP3437 datasheet for detail.

EV3437-RP-00A EVALUATION BOARD




(L x W x H) 6.4cm x 6.4cm x 0.6cm

| Board Number | MPS IC Number | |
|---------------|---------------|--|
| EV3437-RP-00A | MP3437GRP | |





EVALUATION BOARD SCHEMATIC






EV3437-RP-00A BILL OF MATERIALS

| Qty | Ref | Value | Description | Package | Manufacturer | Manufacturer P/N |
|-----|----------------------------|--------|-----------------------------------|---------|--------------|------------------------|
| 5 | C1A,C1B C2A,C2B, C2C | 22µF | Ceramic Cap.,25V,X7R | 1210 | Murata | GRM32ER71E226KE 20L |
| 1 | C2D | 100nF | Ceramic Cap.,25V,X7R | 0805 | Murata | GRM21BR71E104KA 01L |
| 1 | C3 | 4.7μF | Ceramic Cap.,16V,X7R | 0603 | Murata | GRM188Z71C475KE 21D |
| 1 | C4 | 100nF | Ceramic Cap.,25V,X7R | 0402 | Murata | GRM155R71E104KA 88D |
| 1 | R1 | 750K | Film Res,1% | 0603 | YAGEO | RC0603FR-07750KL |
| 1 | R2 | 107K | Film Res,1% | 0603 | YAGEO | RC0603FR-07107KL |
| 1 | R3 | 0R | Film Res,1% | 0603 | YAGEO | RC0603FR-070RL |
| 1 | R4 | 30K | Film Res,1% | 0603 | YAGEO | RC0603FR-0730KL |
| 0 | R5, R6, C5 | NS | | | | |
| 1 | L1 | 1.5µH | Inductor, RDC=8.6mOhm, Isat=14.5A | SMD | Wruth | 74437349015 |
| 1 | J1 | JUMPER | Jumper,1*3Pins | DIP | WE | 60900213421 |
| 1 | U1 | MP3437 | 16V/9.5A Boost | QFN-10 | MPS | MP3437GRP |



EVB TEST RESULTS

 V_{IN} = 3.3V, V_{OUT} = 8V, L=1.5 μ H, I_{OUT} = 2.5A, PSM, T_A = 25°C, unless otherwise noted.






Bode Plot

EVB TEST RESULTS (continued)

 $V_{IN} = 3.3V$, $V_{OUT} = 8V$, L=1.5 μ H, $I_{OUT} = 2.5$ Å, PSM, $T_A = 25$ °C, unless otherwise noted.

60 180 40 120 00 00 **PHASE (deg)** 20 **GAIN** (dB) 0 -20 -40 -120 Gain Phase -60 -180 10000 100000 1000 FREQUENCY (Hz)




LOAD CURRENT (A)



EVB TEST RESULTS (continued)


 V_{IN} = 3.3V, V_{OUT} = 8V, L=1.5 μ H, I_{OUT} = 2.5A, PSM, T_A = 25°C, unless otherwise noted.





EVB TEST RESULTS (continued)


V_{IN} = 3.3V, V_{OUT}= 8V, L=1.5µH, I_{OUT}= 2.5A, PSM, T_A = 25°C, unless otherwise noted.





EVB TEST RESULTS (continued)

V_{IN} = 3.3V, V_{OUT}= 8V, L=1.5µH, I_{OUT}= 2.5A, PSM, T_A = 25°C, unless otherwise noted.





PRINTED CIRCUIT BOARD LAYOUT




Figure 1: Top Silk




Figure 3: Bottom Silk




Figure 2: Top Layer




Figure 4: Bottom Layer



QUICK START GUIDE

The output voltage of this board is set to 8V. The board layout accommodates most commonly used components. Following blew steps to quick start EV3437-RP-00A.

- 1. Preset Power Supply to $2.7V \le VIN \le 16V$.
- 2. Turn Power Supply off.
- 3. Connect Power Supply terminals to:
 - a. Positive (+): VIN
 - b. Negative (-): GND
- 4. Connect Load to:
 - a. Positive (+): VOUT
 - b. Negative (-): GND
- 5. Turn Power Supply on after making connections. The inrush current through high-side MOSFET body diode should be limited less than 30A. Refer to "Input Power-up Inrush Current Control" section in MP3437 datasheet for detail.
- 6. The MP3437 is enabled on the evaluation board once VIN is applied.
- 7. The output voltage VOUT can be changed by varying R2. Calculate the new value using the formula:

$$V_{OUT} = V_{FB} \times (1 + \frac{R1}{R2})$$

Where V_{FB} = 1V and R1=750k Ω . If $V_{OUT-SET}$ >15V, the RC snubber on SW to GND is recommended, such as R6=1Ω, C5=2.2nF.

- 8. If USM and FCCM is needed, following below steps:
 - a. Turn Power Supply off.
 - b. Change J1 connection. Connect 1 to 2 for FCCM, connect 2 to 3 for USM, and float 2 for PSM.
 - c. Turn the power on. IC will work with the mode which is set by step b.
- 9. If the auto pass-through function is needed, following below steps:
 - a. Set J1 to make MP3437 working in PSM.
 - b. Increasing input voltage much higher than V_{OUT-SET}, MP3437 will enter auto pass-through automatically.

NOTICE: The information in this document is subject to change without notice. Please contact MPS for current specifications. Users should warrant and guarantee that third party Intellectual Property rights are not infringed upon when integrating MPS products into any application. MPS will not assume any legal responsibility for any said applications.

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Monolithic Power Systems (MPS):

EV3437-RP-00A