





PRODUCT OVERVIEW

DMS01-CL-RS12-C is a robust digital panel meter that provides precise measurement and display of current loop process signals on a highly visible red 1" (25mm) tall, 4 1/2 digit seven-segment LED display with adjustable brightness. It provides selectable 4-20 mA or 0-20 mA current range, up to 32 display ranges and choice of user calibration or factory calibration modes. An external 12VDC power source provides power to the meter. An internal DC-DC converter accommodates a +/-48V common-mode measurement range with respect to the power supply input, simplifying a wide range of measurement applications and an internal digital filter enhances performance in electrically noisy environments making this digital panel meter is ideal for laboratory instrumentation, factory automation, and any application requiring precision measurement.


Features

- Measures 4-20mA or 0-20mA current loop process signals
- 32 user-selectable span (display) ranges
- Bright 1" red LED display, readable at distance of 80 feet (~24 m)
- Adjustable display brightness
- Wide common-mode input range (±48V)
- Digital filter for optimizing measurements in electrically noisy environments
- Operates from an external 12VDC power supply
- Mounts with adhesive strips (supplied) or screws
- 0.1% typical accuracy

ORDERING INFORMATION:

DMS01-CL-RS12-C

Digital Current Loop Process Meter, 1" Red Display, 12VDC Power







For full details go to www.murata-ps.com/rohs

Parameter	Min	Тур	Max	Units	
Supply Voltage (Operating)	11	12	13	V	
Absolute Maximum Supply Voltage	-1		+14	V	
Supply Current ¹ (Operating at maximum intensity)			100	mA	
(Operating at minimum intensity)			60	mA	
Digits (Displayed)	3.5 - 4.5	depending on disp	lay range		
Digit Height		1 (25.4)	-	inch (mm)	
Display Update Rate		3.5		Sa/s	
Decimal Selection	Manual, (fixed a				
Display Color					
Over-range indication					
Measurement range (0-20mA range)	0		20	mA	
Display Span Range (unipolar mode)	200	0 to 20,000, 32 co	des		
(bipolar mode)		-9500 to +9500			
Accuracy		0.1%	1%		
Zero-Offset (0-20mA range)	-2		+2	count	
nput Impedance		50		Ω	
Offset Trim Range	±5% of span	±5% of span range, see span range selection table			
Gain Trim Range	variable, s				
Temperature Drift (0 to +50°C)		0.8		count/°C	
Absolute Maximum Input Current (-IIN to +IIN)	-40		+40	mA	
Common-Mode Input Range (-VIN) to (-VS)	-48		+48	V	

¹ based on a display value of "1.888"

PHYSICAL/ENVIRONMENTAL				
Parameter	Min	Тур	Max	Units
Operating Temperature	0		+50	°C
Storage Temperature	-40		+75	°C
Humidity (Non-condensing)			85	%RH
Weight		6.14 (174)		oz (g)


User Controls					
Brightness single-turn potentiometer					
Offset and Gain Adjustment	QTY 2 12-turn trim potentiometers				
Dipswitch configuration setting for: - Input current range - Digital filter enable - Span (display) range - Unipolar / Bipolar mode - Trim enable	QTY 2 6-position Dipswitches (S1 & S2)				
Overall Dimensions	5.86 (149) L x 3.36 (86) W x 1.43 (37) H inch (mm)				

Terminal Blocks	Min	Тур	Max	Units
Wire Size	24		14	AWG
Insulation Strip Length		0.25 (6)		inch (mm)
Screw Tightening torque		56.6 (0.4)		oz-in (N-m)

MEASUREMENT TYPE AND CAPABILITIES:

- Measures 4-20 or 0-20 mADC current loop process signals with 32 user-selectable span ranges (via S1, S2), displaying 3-1/2 to 4 1/2 digits of resolution.
- Two user-selectable modes of operation: unipolar (supporting only positive readings) or bipolar (supports negative output readings).
- The meter's measurement terminals are electrically isolated from the power terminals through a DC-DC converter, providing a high common-mode input range (+/-48V) for the input (relative to the power terminals), simplifying a wide range of measurement applications.
- > Meter requires an external 12VDC power supply (not included).

REAR PANEL LAYOUT: SCREW TERMINAL CONNECTIONS & CONTROLS



Terminal Block									
Terminal # Name Function									
1	-VS	Power Cumply Terminals (+19VDC)							
2	+VS	Power Supply Terminals (+12VDC)							
3	-IN	Magaurament Input Tarminala							
4	+IN	Measurement Input Terminals							


Brightness Adjust – This single-turn potentiometer supports adjustment of the meter's LED display brightness for maximum readability. Turning the pot clockwise increases brightness, while turning it counterclockwise decreases brightness.

Offset Adjust – This 12-turn potentiometer supports the offset adjustments of the span ranges. See the span range selection table for the maximum allowed offset for each span range. Turning the pot clockwise will give a negative offset, while turning it counterclockwise gives a positive offset.

Gain Scale Adjust – This 12-turn potentiometer supports gain adjustments of the span ranges. This allows the user to select values between each of the span ranges, between 1780 to 20300 (unipolar mode) and -9785 to 9785 (bipolar mode). See the span range selection table for the maximum allowed gain for each span range. Turning the pot clockwise decreases (-) the gain, while turning it counterclockwise increases (+) the gain (see Span Ranges below).

S1 & S2 – 6-position dipswitches provided for configuration the meter's various options. See Meter Configuration below for details.

CONNECTION EXAMPLES:



This example illustrates an application where the Current sensor is connected to terminals 3 and 4, where terminal 3 is the negative input terminal (-IN) and terminal 4 is the positive input terminal (+IN).

The 12V power supply (not included) connects to terminals 1 and 2, where terminal 1 is the negative power supply terminal (-VS) and terminal 2 is the positive power supply terminal (+VS) and the sensor is powered from a separate external power supply. Note: it is possible to power both the sensor and the meter from the same power supply provided the sensor can operate from +12VDC.



METER CONFIGURATION

This Meter is configured through two 6 position dipswitches S1 and S2 on the back of the meter. Each switch position is identified by SW#. For example SW1 is switch 1 on S1, and controls the input range, while SW1 on S2 selects of one the span ranges. The following illustrate the

example, SW1 possible config		S1, and contro	ols the input	range, while	SW1 on S2 s	selects of one	e the span ra	nges. The following	g illustrate the	
Input Range S	election									
Input Ran	ge	SW1	Dipsw	itch S1	Description	n				
4-20mA	1	OFF	ON	4 5 6		SW1 on S1 controls the meter's inpu				
0-20mA		ON	ON 1 2 3	1	input range is 4-20 mA, while in the ON position the meter's range is 20 mA.					
Digital Filter 0	n/Off Slection									
Digital Filt	ter	SW2	Dipsw	itch S1	Description	n				
0FF		OFF	ON SW2 on S1 controls the meter's digital filter. In the (mum speed. In the					
ON		ON	ON 1 2 3	4 5 6		erage filter, v		in more stable rea		
Unipolar/Bipol	ar Mode Select	tion								
Mode		SW2	Dipsw	itch S2	Description	n				
Unipolar		OFF	ON	4 5 6	Bipolar mode allows the user to display negative values. the meter is set to 0-20 mA input, span of 6000 and set mode, then 0 mA input results in a count of 0 on the disp mA input results in a count of 6000 on the display. If the bipolar mode with the same settings, 0 mA input results					
Bipolar		ON	ON	4 5 6	display. SV mode. Uni depending between -	N2 on S2 cor polar mode c on the span 9500 to +950 ge is not offe	ntrols whethe an display va range settin 00 dependin	esults in a count of er the meter is in ur alues between 0 to g. Bipolar mode ca g on the span rango ±9500 because of	nipolar or bipolar +20000 n display values e setting. The	
Span Range S										
Span Range	Gain Adjustment	Offset Adjustment	S2 SW1	SW3	SW4	S1 SW5	SW6	Dipswitch S2	Dipswitch S1	
Input Current (mA)	N/A	N/A	0FF	0FF	0FF	0FF	0FF	ON 1 2 3 4 5 6	ON	
2000	220 ±2	100 ±2	0FF	ON	OFF OF		OFF	ON 1 2 3 4 5 6	ON	
2500	288 ±2	125 ± 1	OFF	0FF	ON	OFF	OFF	ON	ON	
3000	255 ±2	150 ±2	0FF	ON	ON	OFF	OFF	ON	ON	
3500	263 ±2	175 ±2	OFF	OFF	OFF	ON	OFF	ON ON ON O	ON DE DE	





Span Range	election contin Gain	Offset	S2			S1		Dipswitch S2	Dipswitch S1
Span nange	Adjustment	Adjustment	SW1	SW3	SW4	SW5	SW6		
4000	260 ±2	200 ±2	0FF	ON	OFF	ON	0FF	ON 1 2 3 4 5 6	ON 1 2 3 4 5 6
4500	270 ±2	225 ±2	0FF	0FF	ON	ON	OFF	ON 1 2 3 4 5 6	ON
5000	250 ±2	250 ±2	0FF	ON	ON	ON	OFF	ON 1 2 3 4 5 6	ON
5500	275 ±2	275 ±2	0FF	0FF	0FF	0FF	ON	ON 1 2 3 4 5 6	ON
6000	270 ±2	300 ±2	OFF	ON	0FF	0FF	ON	ON 1 2 3 4 5 6	ON
6500	260 ±2	325 ±2	OFF	0FF	ON	0FF	ON	ON 1 2 3 4 5 6	ON
7000	280 ±2	350 ±2	0FF	ON	ON	0FF	ON	ON 1 2 3 4 5 6	ON
7500	263 ±2	375 ±2	0FF	0FF	0FF	ON	ON	ON 1 2 3 4 5 6	ON
8000	280 ±2	400 ±2	0FF	ON	0FF	ON	ON	ON 1 2 3 4 5 6	ON
8500	298 ±2	425 ±2	OFF	0FF	ON	ON	ON	ON 1 2 3 4 5 6	ON 1 2 3 4 5 6
9000	270 ±2	450 ±2	0FF	ON	ON	ON	ON	ON 1 2 3 4 5 6	ON
9500	285 ±2	475 ±2	ON	0FF	0FF	0FF	OFF	ON 1 2 3 4 5 6	ON
10000	250 ±2	500 ±2	ON	ON	0FF	0FF	OFF	ON 1 2 3 4 5 6	ON
10500	263 ±2	525 ±2	ON	0FF	ON	0FF	OFF	ON 1 2 3 4 5 6	ON 1 2 3 4 5 6
11000	275 ±2	550 ±2	ON	ON	ON	0FF	OFF	ON 1 2 3 4 5 6	ON
11500	288 ±2	575 ±2	ON	0FF	0FF	ON	OFF	ON	ON
12000	300 ±2	600 ±2	ON	ON	0FF	ON	OFF	ON	ON
12500	250 ±2	625 ±2	ON	0FF	ON	ON	OFF	ON 1 2 3 4 5 6	ON
13000	260 ±2	650 ±2	ON	ON	ON	ON	OFF	ON	ON 1 2 3 4 5 6





	election contin Gain	Offset	S2			S 1					
Span Range		Adjustment		SW3	SW4	SW5	SW6	Dipswitch S2	Dipswitch S1		
13500	270 ±2	675 ±2	ON	OFF	OFF	OFF	ON	ON 1 2 3 4 5 6	ON		
14000	280 ±2	700 ±2	ON	ON	OFF	OFF	ON	ON F	ON		
15000	750 ±2	750 ±2	ON	0FF	ON	OFF	ON	ON 1 2 3 4 5 6	ON		
16000	320 ±2	800 ±2	ON	ON	ON	OFF	ON	ON 1 2 3 4 5 6	ON		
17000	765 ±2	850 ±2	ON	OFF	OFF	ON	ON	ON 1 2 3 4 5 6	ON		
18000	270 ±2	900 ±2	ON	ON	OFF	ON	ON	ON 1 2 3 4 5 6	ON		
19000	760 ±2	950 ±2	ON	OFF	ON	ON	ON	ON 1 2 3 4 5 6	ON		
20000	300 ±2	1000 ±2	ON	ON	ON	ON	ON	ON 1 2 3 4 5 6	ON		
Decimal Point	Selection										
Decimal Placement	SW3	SW4	SW5		itch S2						
0000	OFF	OFF	OFF	ON 1 2 3	1	When moss	ring the phy	nysical current the decimal placement			
0.000	ON	OFF	0FF	ON 	4 5 6	is fixed at 00 turned ON th).00. When a ne decimal po	ny of the span rango int placement has t	e switches are to be manually		
00.00	0FF	ON	OFF	ON	4 5 6		-	N5 on S2 control the work in the table.	e decimal point		
000.0	OFF	OFF	ON	ON	4 5 6						
Trim Enable S											
Trim E	nable	SW6			itch S2			for adjusting gain			
OF	F	OFF		ON	4 5 6	enabled by SW6 on S2. disabled and the meter ranges. In the "ON" posit to vary the gain and c		runs from factory ion the trim is enab iffset of the span	/ calibrated spa lled, allowing use range. The gai		
0	N	ON		ON	1	adjustment allows the user to adjust the span of the many number between 1780 and 20300 (unipolar mode 9785 to +9785 (bipolar mode) with the span range (see span range table above). If the meter is out of call the operator can use the gain or offset adjustme correction only when one of the span range settings is swhen displaying the physical input voltage.					



TECHNICAL NOTES



1. Calibration

This meter is calibrated at the factory at the time of manufacture. If the meter is out of calibration, the operator can use the gain or offset adjustment (Trim Enable) for correction, only when one of the span range settings is set, not when displaying the physical input voltage. However, calibration may no long be within datasheet specifications.

2. Protection and Fusing

This meter contains an internal PTC fuse as well as other protective elements that are intended for protection against brief electrical transients and misconnect conditions. Additional external protective components such as fuses and transient suppressors may be required depending on the application in which the meter is deployed.

3. Noisy Power Supplies


In systems with noisy power supplies, connecting an external, non-polarized capacitor across the +VS and -VS inputs can help reduce measurement errors. In certain situations, the use of twisted pair or shield wiring may be required.

4. Installation

IMPORTANT! To ensure safe and reliable operation, this meter must be installed and serviced by qualified technical personnel. Contact Murata Power Solutions if there is any doubt regarding their installation or operation.

5. Over-range Limit


The meter will flash on and off when the meter exceeds its minimum or maximum input current. For example, if the meter is set in the 0-20 mA range, any input current below 0 mA or above 20 mA will cause the display to flash on and off.



Note: When mounting panel meter with hardware, a four hole pattern (four outermost holes) or the six hole pattern may be used at the customer's option.

DMS01-CL Series

Large Format Digital Current-Loop Process Meter



Murata Power Solutions. Inc. 129 Flanders Rd. Westborough, Ma 01581, USA. ISO 9001 and 14001 REGISTERED



This product is subject to the following operating requirements and the Life and Safety Critical Application Sales Policy:

Refer to: http://www.murata-ps.com/requirements/

Murata Power Solutions, Inc. makes no representation that the use of its products in the circuits described herein, or the use of other technical information contained herein, will not infringe upon existing or future patent rights. The descriptions contained herein do not imply the granting of licenses to make, use, or sell equipment constructed in accordance therewith. Specifications are subject to change without notice.

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Murata:

DMS01-CL-RS12-C