


## **Test Procedure for the CS5171/CS5173 Evaluation Board**



### Figure 1: Test Setup

The following steps describe the test procedure for all these boards:

#### **Suggested Equipment:**

#### **Test Procedure:**

- 1. Connect the test setup as shown in Figure 1.
- 2. Apply an input voltage,  $V_{IN} = 12 \text{ Vdc}$
- 3. Apply Iout(load) = 0 A
- 4. Check that  $VOUT = 200V \pm 5\% Vdc$
- 5. Set Iout to desired level 0 mA- 20 mA and measure voltage and current. The efficiency should be similar to that shown in Figure 3 and 4.
- 6. Check that  $V_{OUT} = 200V \pm 5\%$  Vdc under desired operating condition
- 7. Turn off the load
- 8. Turn off  $V_{IN}$
- 9. End of the test




Figure 2: CS5171 12V to 200V Efficiency




Figure 3: CS5171 12V to 200V Load Regulation

# **Mouser Electronics**

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

onsemi: CS5171HVBSTGEVB