
Test Procedure for NCV8715 XDFN6 LDO Demoboard



Test procedure:

1.Check the Voltage Version (It is mentioned next to OUTPUT terminal on the demoboard.)

- 2. Connect the test setup as shown Figure above
- 3. Appy an input voltage Vin = 6.0 V
- 4. Appy Iout = 0mA load.

5. Check that Vout is:

1.2 V +/-2% for 1.2 V voltage version
1.5 V +/-2% for 1.5 V voltage version
1.8 V +/-2% for 1.8 V voltage version
2.5 V +/-2% for 2.5 V voltage version
3.0 V +/-2% for 3.0 V voltage version
3.3 V +/-2% for 3.3 V voltage version
5.0 V +/-2% for 5.0 V voltage version

6. Increase lout up to 50 mA

7. Check that Vout is :

1.2 V +/-2% for 1.2 V voltage version 1.5 V +/-2% for 1.5 V voltage version 1.8 V +/-2% for 1.8 V voltage version 2.5 V +/-2% for 2.5 V voltage version 3.0 V +/-2% for 3.0 V voltage version 3.3 V +/-2% for 3.3 V voltage version 5.0 V +/-2% for 5.0 V voltage version

8. Increase Vin up to **24.0 V** and decrease the load in accordance with **Safe Operation Area**

9. Power down the Load10. Power down the Vcc11. End of test

•

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

onsemi: NCV8715MXTBGEVB