

AMP 1756 REV 3-92 Ψ 28-FEB-06 08:57:28 us024474 \bigtriangleup 8 4 6 5 З

								/home/us02447	4/tecm	od
									73	
	1	1	1	1	1	1	1528111 1338705-3	PRINT, APPLICATOR LOG SHEET DOCUMENTATION PACKAGE	72 71	
	1			1					70	
									69 68	
	1	1	1	1	1	1	461264-5	PLATE, IDENTIFICATION	67	\vdash
	2	2	2	2	2	2	21017-2	SCR,DRIVE(#2x.19)ID PLATE	66	
									65 64	
	1	1	1	1	1	1	3-18031-0	SCR, SKT SET (M6X6) RAM	63	-
							1 10004 5		62	_
	2	2	2	2	2	2	1-18024-5 18024-7	SCR, BHC (M5X25) DRAG SCR, BHC (M4X10) ANVIL	61 60	-
	1	1	1	1	1	1	5-18022-2	SCR, HEX(M4X8)FEED FINGER	59	
									58 57	-
	1	1	1	1	1	1	1338685-1	PAWL, FEED	56	
	4	4	4	4	4	4	18024-8	SCR,BHC(M4×12)SHEAR HOLDER	55 54	-
	4	4	4	4	4	4	10024-0	JCR, DHC (H4X12) JHEAR HOLDER	53	-
	1	1	1	1	1	1	18030-1	NUT, HEX (M3) HOLD DOWN	52	_
	1	1	1	1	1	1	811242-5 690753-2	BUMPER, HOLDDOWN Spacer, Tonker	51 50	-
	1	1	1	1	1	1	18024-3	SCR, BHC (M3X10) CAM	49	
_	_	1	—	—	1	—	1338675-1	CAM, PRE FEED 30 & 40 mm ST	48]
_	1		1	1		1	1338676-1	CAM, POST FEED 30 & 40 mm ST	47	_
	1	1	1	1	1	1	1320999-3 690191-1	APPLICATOR BASIC SUBASSY	46	-
	1	1	1	1	1	1	1338660-3	PLUG, NYLON Ram	45	-
									43	С
	1	1	1	1	1	1	2-18024-6	SCR,BHC(M8X25)RAM	42	-
	1	1	1	1			2-10024-0	JUR, DHU (MOAZJ) KAM	40	-
									39	
	1	1	1	1	1	1	469367-7	SPACER, FINE ADJUST	38	-
							879103-3	FINE ADJUST HEAD SUBASSY	37 36	-
									35	1
	1	1	1	1	1	1	1320934-3	SUPPORT, TERMINAL	34	
	2	2	2	2	2	2	1-18024-0	SCR, BHC (M4X20) STRIP GUIDE	33	- ~
	3	3	3	3	3	3	18027-2	WASHER, FLAT(M4) SCR,SKT CAP(M4X12)MOUNT BLOCK	32 31	
	1	1	1	1	1	1	1320908-9	SPACER, STRIP GUIDE	30	-
	1	1	1	1	1	1	1633073-1	STRIP GUIDE PLATE ASSY	29	
	1	1	1	1	1	1	1-455888-0	SPACER, FRONT SHEAR DEP	28	_
	2	2	2	2	2	2	1-22284-0 356835-1	SPRING, DRAG Lever, drag release	27 26	-
	1	1	1	1	1	1	240792-1	DRAG, TERMINAL	25	1
	1	1	1	1	1	1	1320928-1	PLATE, STRIP GUIDE	24	-
	1	1	1	1	1	1	980371-4	SCR, SHC SHLD	23	_
	1	- 1	1	1	-	1	690472-2 1-18023-1	STRIPPER SCR, SHC (M4X10) STRIPPER	22 21	В
	4	4	4	4	4	4	18025-2	WASHER, LOCK (M4) STRIPPER	20	
	_	1	_	_	1	_	690472-1	STRIPPER	19	
	1			1			1220004 1		18	_
		_	_			_	1338684-1	HOLDER, SHEAR, FRONT (NO-CUT)	17	-
									15]
									14	_
	1	1	1	1	1	1	5-22280-0	SPRING, SHEAR	13	-
	1	1	1	1	1	1	356885-4	STOP, SHEAR	11	-
	_	1	1	_	1	1	1320921-1	HOLDER, SHEAR, FRONT (CUT)	10	<u> </u>
	1	1	1	1	1	1	462006-1	SHEAR, FLOAT (FRONT)	9	-
	2	2	2				2-1333225-2	ANVIL	8	-
									6	
_	1	1	1	1	1	1	2-455889-0	DEPRESSOR, SHEAR (FRONT)	5	_
	1	1	1	1	1	1	2-238011-0 9-683453-6	SPACER, BLOCK CRIMPER CRIMPER, INSULATION	4	-
	<u> </u>	2 1	2 1	1	1	1	455888-1	SPACER, CRIMPER	2	-
	2	2	2	1	1	1	568176-9	CRIMPER, WIRE	1]
7	-76	-72	-71	-6	-2	-1	PART NO	DESCRIPTION	I TEM NO	<u> </u>
		QTY	REQD	PER AS	SY			SSY NO (WHEN BLANK, USE DWG REVIS Parts list	ION)	
		IMENS	IONS:	mm EIN	NCHES]	MATL	_ HT TR	_ FIN _		1
	Т	OLERAN	SCALE NCES U	NLESS		DR				-
_	1 PLC DEC ±- L.LOFTHOUSE F.BACKHURST AMP Incorporal 2 PLC DEC ±- CHK - REL 09JUL02 AMP Incorporal							Harrisburg, PA 17105-3	3608	
ANGLES + -						DUSE		-		
F	5	urf te	EXTURE		\int	SCALE		FU HU-I APPL HD-I A	PPL ev	-
_	DATE S		BURRS	, BRE/ Ro.38		_	- D DWG NO		С	
		cage c 007		CUS	STOP	MER	AND ASSEMBL	Y DRAWING -	UI U]

RK

APP

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

TE Connectivity: 1528111-6