QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 801 INVERTING DC/DC CONVERTER

LT3483ES6

DESCRIPTION

Demonstration circuit 801 is a general purpose positive to negative converter featuring the LT®3483ES6. The demo board demonstrates two separate DC/DC converters. One converter generates a -8V at 20mA to 30mA from a 2.7V-4.2V input using a step up inverting charge pump topology. The other uses a dual coupled inductor in an inverting flyback topology to generate a -15V at 8mA to 40mA from a 2.7-12V input. This topology is useful to generate output voltages of lower, equal or higher magnitude than the input. For example, for a -12V supply just change the

value of R2 to 1.21M and for a -5V, change R2 to 511K. Both circuits demonstrate low component count and are intended for space-conscious applications such as LCD bias, Handheld Computers, Battery Backup, Digital Cameras and OLED Bias.

Design files for this circuit board are available. Call the LTC factory.

LTC is a registered trademark of Linear Technology Corporation

Table 1. Performance Summary $(T_A = 25^{\circ}C)$

PARAMETERS FOR -8V INVERTER	CONDITION	VALUE
Minimum Input Voltage		2.7V
Maximum Input Voltage		4.2V
Output Voltage V _{OUT}	Vin = 2.5V to 4.2V, lout = 20mA to 30mA	-8V ±3%
Typical efficiency	V _{IN} =3.3V, lout =25mA	67%
Typical Output Ripple	V _{IN} = 3.3V, I _{OUT} = 25mA	60mV _{P-P}
PARAMETERS FOR -15V INVERTER		VALUE
Minimum Input Voltage		2.7V
Maximum Input Voltage		12V
Output Voltage V _{OUT}	V _{IN} = 2.7V to 12V, I _{OUT} = 8mA to 40mA	-15V ±3%
Typical efficiency	V _{IN} = 6V, I _{OUT} = 20mA	75%
Typical Output Ripple V _{OUT}	V _{IN} = 6V, I _{OUT} = 20mA	80mV _{P-P}

QUICK START PROCEDURE

Demonstration circuit 801 is easy to set up to evaluate the performance of the LT3483ES6. Refer to Figure 1 for proper measurement equipment setup and follow the procedure below:

NOTE: When measuring the input or output voltage ripple, care must be taken to avoid a long ground lead

on the oscilloscope probe. Measure the input or output voltage ripple by touching the probe tip directly across the Vin or Vout and GND terminals. See Figure 2 for proper scope probe technique.

1. Place jumper in the following positions for testing of -15V inverter:



JP1 On

- 2. With power off, connect the input power supply to Vin and GND.
- 3. Turn on the power at the input.
- 4. Check for the proper output voltages.

NOTE: If there is no output, temporarily disconnect the load to make sure that the load is not set too high.

- 5. Once the proper output voltages are established, adjust the loads within the operating range and observe the output voltage regulation, ripple voltage, efficiency and other parameters.
- **6.** For testing of -8V Inverter repeat steps 1-5 placing **JP2** in the **ON** position.




Figure 1. Proper Measurement Equipment Setup







Figure 2. Measuring Input or Output Ripple



QUICK START GUIDE FOR DEMONSTRATION CIRCUIT 801 INVERTING DC/DC CONVERTER





Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Analog Devices Inc.: