

## CSU1300AP Series

### 1300 Watts Distributed Power System

**Total Power:** 1300 Watts High line  
1000 Watts low line  
**Input Voltage:** 90 - 264 Vac  
180 - 300 Vdc  
**# of Outputs:** Main and Standby

### Special Features

- 1300W output power
- High power and short form factor
- 1U power supply
- High density design: 39W/in<sup>3</sup>
- Active Power Factor Correction
- EN61000-3-2 Harmonic compliance
- Inrush current control
- 80 PLUS® Platinum efficiency
- N+M redundant N+M ≤ 4
- Active current sharing
- Hot-pluggable
- Full digital control
- PMBus™ compliant
- EN61000-4-5 surge level 1kV/2kV DM/CM
- Black box
- Boot loader
- Compatible with Artesyn's Universal PMBus GUI

### Safety

UL/cUL  
UL+CB Report  
CE Mark  
CCC  
BSMI  
KC  
TUV



## Product Descriptions

The CSU1300AP series power supply features a wide AC and DC input voltage range. It employs active power factor correction when the input is AC to minimize input harmonic current distortion and to ensure compliance with the international EN61000-3-2 standard. The power factor is at >0.96 starting at 20% load, and increase to >0.99 when the load is at 100%.

The CSU1300AP series can deliver up to 108.3 A from its main 12.2Vdc main output, and up to 3 A from its 12Vdc auxiliary output. The form factor is 1U and can be used in single or in redundant configurations.

CSU1300AP series compliant with 80PLUS® Platinum efficiency.

## Model Numbers

| Standard        | Output Voltage | Minimum Load | Maximum Load | Standby Supply | Air Flow Direction                 |
|-----------------|----------------|--------------|--------------|----------------|------------------------------------|
| CSU1300AP-3-600 | 12.2Vdc        | 1A           | 108.33A      | 12.0Vdc@3A     | Normal<br>(DC connector to Handle) |

## Options

None

## Electrical Specifications

### Absolute Maximum Ratings

Stress in excess of those listed in the “Absolute Maximum Ratings” may cause permanent damage to the power supply. These are stress ratings only and functional operation of the unit is not implied at these or any other conditions above those given in the operational sections of this TRN. Exposure to any absolute maximum rated condition for extended periods may adversely affect the power supply’s reliability.

Table 1. Absolute Maximum Ratings:

| Parameter                     | Model      | Symbol      | Min | Typ | Max              | Unit   |
|-------------------------------|------------|-------------|-----|-----|------------------|--------|
| Input Voltage                 |            |             |     |     |                  |        |
| AC continuous operation       | All models | $V_{IN,AC}$ | 90  | -   | 264              | Vac    |
| DC continuous operation       | All models | $V_{IN,DC}$ | 180 | -   | 300              | Vdc    |
| Maximum Output Power          |            |             |     |     |                  |        |
| $V_{IN,AC} \leq 180V_{ac}$    | All models | $P_{O,max}$ | -   | -   | 1000             | W      |
| $V_{IN,AC} > 180V_{ac}$       | All models |             | -   | -   | 1300             | W      |
| Isolation Voltage             |            |             |     |     |                  |        |
| Input to output               | All models |             | -   | -   | 4242             | Vdc    |
| Input to safety ground        | All models |             | -   | -   | 2121             | Vdc    |
| Ambient Operating Temperature | All models | $T_A$       | 0   | -   | +55 <sup>1</sup> | °C     |
| Storage Temperature           | All models | $T_{STG}$   | -40 | -   | +85              | °C     |
| Humidity (non-condensing)     |            |             |     |     |                  |        |
| Operating                     | All models |             | 5   | -   | 90               | %      |
| Non-operating                 | All models |             | 5   | -   | 95               | %      |
| Acoustic <sup>2</sup>         | All models |             | -   | -   | 66               | dBA    |
| Altitude <sup>3</sup>         |            |             |     |     |                  |        |
| Operating                     | All models |             | -   | -   | 3050             | Meters |
| MTBF <sup>4</sup>             | All models |             | 250 | -   | -                | KHrs   |
| Operating Life <sup>5</sup>   | All models |             | 5   | -   | -                | Years  |
| Fan L10 Life <sup>6</sup>     | All models |             | 75  | -   | -                | KHrs   |

Note 1 - The PSU must operate to an altitude of 5000 meters above sea level, the maximum operating temperature(55°C) is to be de-rated by 1°C per 200m above 2000m.

Note 2 - 50% load at 40°C, fan noise as measured from one meter distance from the power supply can meet the limits defined 66dBA.

Note 3 - Safety creepage/clearance rated for 5,000m altitude for CCC.

Note 4 - It is calculated under 40°C ambient temperature and 100%  $I_{O,max}$ .

Note 5 - It is calculated under 50°C ambient temperature and 100%  $I_{O,max}$ .

Note 6 - It is calculated under 35°C ambient temperature.

## Input Specifications

Table 2. Input Specifications:

| Parameter  | Condition   | Symbol           | Min                          | Typ                        | Max                           | Unit |
|--|---|------------------|------------------------------|----------------------------|-------------------------------|------|
| Operating Input Voltage, AC  |   | $V_{IN,AC}$      | 90                           | 115/230                    | 264                           | Vac  |
| Operating Input Voltage, DC  |   | $V_{IN,DC}$      | 180                          | 240                        | 300                           | Vdc  |
| Input AC Frequency   |   | $f_{IN,AC}$      | 47                           | 50/60                      | 63                            | Hz   |
| Maximum Input Current<br>( $I_O = I_{O,max}$ , $I_{SB} = I_{SB,max}$ ) | $V_{IN,AC} = 100Vac$<br>$V_{IN,AC} = 180Vac$  | $I_{IN,max}$     | -<br>-                       | -<br>-                     | 12.5<br>8.5                   | A    |
| No Load Input Current<br>( $V_O = On$ , $I_O = 0A$ , $I_{SB} = 0A$ )   | All   | $I_{IN,no-load}$ | -                            | -                          | 250                           | mA   |
| No Load Input Power<br>( $V_O = On$ , $I_O = 0A$ , $I_{SB} = 0A$ )     | All   | $P_{IN,no-load}$ | -                            | -                          | 4.5                           | W    |
| Standby Input Current<br>( $V_O = Off$ , $I_{SB} = 0A$ )               | All   | $I_{IN,Standby}$ | -                            | -                          | 250                           | mA   |
| Standby Input Power<br>( $V_O = Off$ , $I_{SB} = 0A$ )                 | All   | $P_{IN,Standby}$ | -                            | -                          | 5.5                           | W    |
| Input iTHD <sup>1</sup>  | $V_{IN,AC} = 230Vac$<br>$5 < I_O \leq 10\%I_{O,max}$<br>$10 < I_O \leq 20\%I_{O,max}$<br>$I_O \geq 20\%I_{O,max}$<br>$I_O \geq 40\%I_{O,max}$<br>$I_O \geq 50\%I_{O,max}$<br>$I_O = 100\%I_{O,max}$ | iTHD             | -<br>-<br>-<br>-<br>-<br>-   | -<br>-<br>-<br>-<br>-<br>- | 25<br>15<br>10<br>8<br>5<br>4 | %    |
| Power Factor   | $V_{IN,AC} = 230Vac$<br>$I_O = 10\%I_{O,max}$<br>$I_O = 20\%I_{O,max}$<br>$I_O = 50\%I_{O,max}$<br>$I_O = 100\%I_{O,max}$   | PF               | 0.90<br>0.96<br>0.98<br>0.99 | -<br>-<br>-<br>-           | -<br>-<br>-<br>-              |      |
| Startup Surge Current (Inrush) <sup>2</sup><br>@ 25°C                  | $V_{IN,AC} = 264Vac$  | $I_{IN,surge}$   | -                            | -                          | 25                            | Apk  |
| Input Fuse   | Internal, L<br>5x20mm, Fast Acting<br>20A, 500Vdc   |                  | -                            | -                          | 20                            | A    |
| Leakage Current to earth ground  | $V_{IN,AC} = 264Vac$<br>$f_{IN,AC} = 50Hz$  |                  | -                            | -                          | 1.75                          | mA   |

Note 1 - Individual harmonic contribution, up to 44<sup>th</sup> harmonic, should comply with IEC61000-3-2 starting at 10% load.

Note 2 - The input peak current will not exceed 35A peak when the power supply input is cycled between on and off states at 240Vac, where the off state is not more than one full AC cycle. The AC input can return at any phase. Any peak beyond 35A must not exceed 65A and have a duration of less than 200uS.

## Input Specifications

Table 2. Input Specifications con't:

| Parameter                                | Condition              | Symbol      | Min | Typ | Max | Unit |
|--|------------------------|-------------|-----|-----|-----|------|
| Turn-on Voltage                          | AC Low Line            | $V_{IN,AC}$ | 79  | -   | 89  | Vac  |
| Minimum of 5V hysteresis                 | DC Input               | $V_{IN,DC}$ | 171 | 175 | 179 | Vdc  |
| Turn-off Voltage                         | AC Low Line            | $V_{IN,AC}$ | 75  | -   | 84  | Vac  |
| Minimum of 5V hysteresis                 | DC Input               | $V_{IN,DC}$ | 164 | 169 | 174 | Vdc  |
| Operating Efficiency @ 25°C <sup>1</sup> | $V_{IN,AC} = 230Vac$   | $\eta$      |     |     |     |      |
|  | $f_{IN,AC} = 50Hz$     |             |     |     |     |      |
|  | $I_O = 10\%I_{O,max}$  |             | 88  | -   | -   | %    |
|  | $I_O = 20\%I_{O,max}$  |             | 91  | -   | -   | %    |
|  | $I_O = 50\%I_{O,max}$  |             | 94  | -   | -   | %    |
|  | $I_O = 100\%I_{O,max}$ |             | 91  | -   | -   | %    |
| System Stability                         |                        |             |     |     |     |      |
| Gain Margin                              |                        |             | -6  | -   | -   | dB   |

Note 1 - 90% when fan power is excluded.

## Output Specifications

Table 3. Output Specifications:

| Parameter   | Condition   | Symbol   | Min  | Typ  | Max   | Unit                |
|---|---|----------|------|------|-------|---------------------|
| Factory Set Voltage                                   | All   | $V_O$    | 12.0 | 12.2 | 12.5  | Vdc                 |
|   |   | $V_{SB}$ | 11.8 | 12.0 | 12.6  |                     |
| Output Regulation                                     | Static load   | $V_O$    | 11.8 | -    | 12.6  | Vdc                 |
|   | Dynamic load  | $V_O$    | 11.8 | -    | 12.6  |                     |
|   | All   | $V_{SB}$ | 11.4 | -    | 12.6  |                     |
| Output Ripple, pk-pk                                  | Measure with a 0.1 $\mu$ F ceramic capacitor in parallel with a 10 $\mu$ F tantalum capacitor, 0 to 20MHz bandwidth | $V_O$    | -    | -    | 120   | mV <sub>PK-PK</sub> |
|   |   | $V_{SB}$ | -    | -    | 120   |                     |
| Output Current  | High line   | $I_O$    | 1    | -    | 108.3 | A                   |
|   | Low line  | $I_O$    | 1    | -    | 83.33 |                     |
|   | All   | $I_{SB}$ | 0    | -    | 3     |                     |
| Minimum Current Share Load                            |   | % $I_O$  | 10   | -    | -     | %                   |
| $V_O$ Current Share Accuracy                          | 10% to 20% $I_{O, max}$   | % $I_O$  | -    | -    | 10    | %                   |
|   | 20% to 100% $I_{O, max}$  |          | -    | -    | 5     |                     |
| Number of Parallel Units                              | Main output current share connected   |          | -    | -    | 4     | Units               |
| Load Capacitance                                      | Start up  | $C_O$    | 2200 | -    | 22000 | $\mu$ F/A           |
|   |   | $C_{SB}$ | 100  | -    | 3100  |                     |
| $V_O$ Dynamic Response <sup>1</sup><br>Peak Deviation | 60% load change, slew rate = 0.5A/ $\mu$ s  | $V_O$    | 11.6 | -    | 12.8  | Vdc                 |
|   | 1A load change, slew rate = 0.5A/ $\mu$ s   | $V_{SB}$ | 11.4 | -    | 12.6  | Vdc                 |

Note 1 - The minimum load is 1A, the capacitive load for the main output is 2200 $\mu$ F, the capacitive load for standby output is 1000 $\mu$ F.

## System Timing Specifications


Table 4. System Timing Specifications:

| Label | Parameter   | Min | Typ | Max  | Unit |
|-------|---|-----|-----|------|------|
| T1    | Delay from AC being applied to $V_{SB}$ being within regulation.                                    | -   | -   | 1500 | mSec |
| T2    | Delay from AC being applied to all output voltages being within regulation.                         | -   | -   | 3000 | mSec |
| T3    | $V_O$ rise time, 10% to $V_O$ within regulation limits.   | -   | -   | 25   | mSec |
| T4    | $V_{SB}$ rise time, 10% to $V_{SB}$ within regulation limits.                                       | -   | -   | 70   | mSec |
| T5    | Delay from output voltages within regulation limits to PWOK asserted high at turn on.               | 100 | -   | 500  | mSec |
| T6    | Delay from loss of AC to de-assertion of PWOK.  | 10  | -   | -    | mSec |
| T7    | Delay from PWOK de-asserted to output voltages dropping out of regulation limits.                   | 1   | -   | -    | mSec |
| T8    | Hold up time - time output voltages stay within regulation after loss of AC.                        | 11  | -   | -    | mSec |
| T9    | Delay from standby voltage in regulation to output voltage in regulation at AC turn on.             | 50  | -   | 1000 | mSec |
| T10   | Duration of PWOK being in the de-asserted state during an off/on cycle using AC or the PSON signal. | 100 | -   | -    | mSec |
| T11   | Delay from PSON active to output voltages within regulation limits.                                 | 5   | -   | 400  | mSec |
| T12   | Delay from PSON de-active to PWOK de-asserted low.  | -   | -   | 5    | mSec |
| T13   | Hold up time - time standby voltages stay within regulation after loss of AC.                       | 70  | -   | -    | mSec |
| T14   | Delay from PSON de-active to output out of regulation.  | -   | -   | 5    | mSec |









## System Timing Specifications

System Timing Diagram:





## CSU1300AP-3 Performance Curves



## CSU1300AP-3 Performance Curves




Figure 7: CSU1300AP-3 Turn Off Characteristic via PS ON  
Full Load:  $I_O = 108.33A$ ,  $I_{SB} = 3A$   
Ch 1: PS ON Ch 2:  $V_O$  Ch 3: PWOK




Figure 8: CSU1300AP-3 Transient Response -  $V_O$  Deviation (low to high)  
40% to 100% load change,  $0.5A/\mu S$  slew rate,  $V_{IN} = 230Vac$   
Ch 1:  $V_O$  Ch 2:  $I_O$




Figure 9: CSU1300AP-3 Transient Response -  $V_O$  Deviation (high to low)  
100% to 40% load change,  $0.5A/\mu S$  slew rate,  $V_{IN} = 230Vac$   
Ch 1:  $V_O$  Ch 2:  $I_O$




Figure 10: CSU1300AP-3 Ripple and Noise Measurement -  $V_{IN} = 115Vac$   
Full Load:  $I_O = 83.33A$ ,  $I_{SB} = 3A$   
Ch 1:  $V_O$




Figure 11: CSU1300AP-3 Ripple and Noise Measurement -  $V_{IN} = 230Vac$   
Full Load:  $I_O = 108.33A$ ,  $I_{SB} = 3A$   
Ch 1:  $V_O$




Figure 12: CSU1300AP-3 Efficiency Curves @ 25 degC  
----- 230 Vac ----- 264 Vac  
Loading:  $V_O = 10V$  increment to 108.33A,  $V_{SB} = 3A$  (5V)

## CSU1300AP-3 Performance Curves




Figure 13: CSU1300AP-3 Efficiency Curves @ 25 degC

----- 90 Vac      ----- 115 Vac

Loading: Vo = 10% increment to 83.33A, VSB = 3A (5V)

## Protection Function Specification

### Input Fusing

CSU1300AP series power supply is equipped with an internal non user serviceable 20A Fast Acting 500Vdc fuse for fault protection on L line input.

### Input Over Voltage

The input is a signal phase AC with below characteristics, the power supply can meet all DC output specifications for any input voltage specified in the table below. When the power supply detects input over voltage, it would shut down the main output, but the VSB should keep on. If the input voltage continues to increase, the power supply should subjected to a permanent damage and shut off VSB.

| Parameter                  | Min | Nom | Max | Unit |
|----------------------------|-----|-----|-----|------|
| Input Overvoltage          | 268 | 272 | /   | Vac  |
| Input Overvoltage Recovery | /   | 266 | 270 | Vac  |
| Input Overvoltage          | 310 | /   | 320 | V    |
| Input Overvoltage Recovery | 300 | /   | 310 | V    |

### Over Voltage Protection (OVP)

The power supply latches off during output overvoltage with the AC line recycled or PSON to reset the latch. +12V V<sub>SB</sub> overvoltage protection is also latch mode.

| Parameter                          | Min  | Nom | Max | Unit |
|------------------------------------|------|-----|-----|------|
| V <sub>O</sub> Output Overvoltage  | 13.5 | /   | 15  | V    |
| V <sub>SB</sub> Output Overvoltage | 13.5 | /   | 15  | V    |

## Over Current Protection (OCP)

CSU1300AP series includes internal current limit circuitry to prevent damage in the event of overload or short circuit. It has over current protection (OCP), over current warning (OCW), and over power protection (OPP) limits as defined in table below. When OCP trips, it will shutdown and latch off the PSU. The latched PSU is cleared by a AC power cycle or PSON recycle. The power supply can not be damaged from repeated power cycling in this condition. 12VSB is auto- recovered after removing OCP limit.

The Vo OCP limit at different loading.

| 12V OCP/OPP | Min Load | Normal Load | Max load | SMB Alert | Fault Delay time |
|-------------|----------|-------------|----------|-----------|------------------|
| <b>OCW</b>  | 110%     | 115%        | 120%     | ≥20.1Sec  | NA               |
| <b>OCP</b>  | 120%     | 130%        | 140%     | 10-20mSec | ≥10mSec          |
| <b>OPP</b>  | 140%     | 150%        | 160%     | <20uSec   | ≥100uSec         |

The 12VSB OCP limit at different loading.

| 12VSB      | Min | Nom | Max | Unit |
|------------|-----|-----|-----|------|
| <b>OCP</b> | 4.0 | /   | 5.0 | A    |

## Short Circuit Protection (SCP)

The power supply withstands a continuous short circuit, without permanent damage, when the short is applied to the outputs while up or running.



## Over Temperature Protection (OTP)

The power supply is internally protected against over temperature conditions. When the OTP limit is reached, all outputs, except standby, will shutdown and remain off until the over-temperature condition no longer exists. The OTP circuit have a sufficient hysteresis so that the power supply can not oscillate on and off due to temperature recovering condition. The OTP trip level have a minimum of 4°C of ambient temperature margin.




## Mechanical Specifications

### Mechanical Outlines (Unit: mm)





TOP



BOTTOM



## Mechanical Outlines (Unit: mm)






## Connector Definitions


### AC Input Connector

|       |   |              |
|-------|---|--------------|
| Pin 1 | - | Line         |
| Pin 2 | - | Neutral      |
| Pin 3 | - | Earth Ground |



### Output Connector - Power Blades

|         |   |                    |
|---------|---|--------------------|
| A1-A9   | - | POWER GND          |
| A10-A18 | - | + Main Output (Vo) |
| B1-B9   | - | POWER GND          |
| B10-B18 | - | + Main Output (Vo) |



### Output Connector - Control Signals

|     |   |           |
|-----|---|-----------|
| A19 | - | SDA       |
| A20 | - | SCL       |
| A21 | - | PSON      |
| A22 | - | SMBAlert# |
| A23 | - | - VSENSE  |
| A24 | - | + VSENSE  |
| A25 | - | PWOK      |
| B19 | - | A0        |
| B20 | - | A1        |
| B21 | - | 12VSB     |
| B22 | - | CR_BUS#   |
| B23 | - | ISHARE    |
| B24 | - | Present   |
| B25 | - | VIN_GOOD  |


View from power supply output connector end

## Power / Signal Mating Connectors and Pin Types

Table 5. Mating Connectors for CSU1300AP series:

| Reference          | On Power Supply | Mating Connector or Equivalent   |
|--------------------|-----------------|--|
| AC Input Connector | IEC320-C14      | IEC320-C13   |
| Output Connector   | Card-edge       | <p>Right Angle<br/>2x25 pin configuration of the FCI power card connector 10035388-102LF or any approved equivalent</p> <p>Vertical<br/>FCI Amphenol HPG36P14SVP011T P2P<br/>FCI Amphenol 10147875-111LF</p> |

## LED Indicator Definition



One bi-color (green/amber) LED at the power supply front provides status signal. The status LED conditions are shown on the below table.

Status LED

| Condition   | LED Status          |
|---|---------------------|
| Output ON and OK.   | Green               |
| No AC power to all power supplies.  | Off                 |
| PSU standby state AC present / Only 12 V <sub>SB</sub> on (PS off). / Cold standby state or always standby state as defined in the Cold Redundancy section.   | 1Hz Blinking Green  |
| AC cord unplugged or AC power lost; with a second power supply in parallel still with AC input power.<br>Power supply critical event causing a shutdown; failure, over current, short circuit, over voltage, fan failure, over temperature. | Amber               |
| Power supply warning events where the power supply continues to operate; high temp, high power, high current, slow fan.   | 1 Hz Blinking Amber |
| Power supply FW updating.   | 2 Hz Blinking Green |

### **Weight**

The CSU1300AP series power supply weight is 1000g/2.205 lbs.

## Environmental Specifications

### EMC Immunity

CSU1300AP series power supply is designed to meet the following EMC immunity specifications

Table 6. Environmental Specifications:

| Document          | Description  |
|-------------------|--|
| EN55032           | Conducted and Radiated EMI Limits  |
| EN 61000-3-2:2014 | Harmonics  |
| EN 61000-3-3:2013 | Voltage Fluctuations   |
| EN 61000-4-2      | Electromagnetic Compatibility (EMC) - Testing and measurement techniques - Electrostatic discharge immunity test. 15KV air, 8KV contact discharge, performance criteria B  |
| EN 61000-4-3      | Electromagnetic Compatibility (EMC) - Testing and measurement techniques - Radiated, radio-frequency, electromagnetic field immunity test 10V/m. performance criterion: A  |
| EN 61000-4-4      | Electromagnetic Compatibility (EMC) - Testing and measurement techniques - Electrical Fast Transient/Burst Immunity Test. +/-2KV for AC power port, performance Criteria B   |
| EN 61000-4-5      | Electromagnetic Compatibility (EMC) - Testing and measurement techniques - Surge Test. 2KV common mode and 1KV differential mode for AC ports, performance criteria B  |
| EN 61000-4-6      | Electromagnetic Compatibility (EMC) - Testing and measurement techniques - Conducted Immunity 10Vrms, performance criteria A.  |
| EN 61000-4-11     | Electromagnetic Compatibility (EMC) - Testing and measurement techniques - Voltage Dips and Interruptions: Criteria A: >95% reduction for 10ms, Criteria B: 30% reduction for 500mS, or Criteria C (self-recoverable only): >95% reduction for 5000mS. |
| EN55035/EN55024   | Electromagnetic Compatibility (EMC) - Testing and measurement techniques - Power frequency magnetic field immunity, performance criterion A  |

Notes: Performance Criteria as defined by EN55024.

Performance Criteria A: The apparatus shall continue to operate as intended after the test. No degradation of performance or loss of function is allowed below specified performance level during intended use of operation.

Performance Criteria B: The apparatus shall continue to operate as intended after the test. No degradation of performance or loss of function is allowed below specified performance level during intended use of operation. Degradation of performance is allowed during the exposure to an electromagnetic phenomenon but no change of actual operating state is allowed.

Performance Criteria C: Temporary loss of function is allowed, provided the function is self-recoverable or can be restored by the operation of the controls.

### **Safety Certifications**

The CSU1300AP series power supply is intended for inclusion in other equipment and the installer must ensure that it is in compliance with all the requirements of the end application. This product is only for inclusion by professional installers within other equipment and must not be operated as a stand alone product.

Table 7. Safety Certifications for CSU1300AP series power supply:


| Document                             | Description                |
|--------------------------------------|----------------------------|
| UL62368-1, CAN/CSA C22.2 No. 62368-1 | US and Canada Requirements |
| IEC60950, IEC/EN62368-1              | European Requirements      |
| CB Certificate and Report            | All CENELEC Countries      |
| CCC                                  | China Requirements         |
| KC                                   | Korea Certification        |
| EAC                                  | Russia Requirements        |
| BIS                                  | India Requirements         |
| FCC                                  | EMC                        |
| BSMI                                 | Taiwan Requirements        |
| CE                                   | LVD, ROHS, EMC             |

## EMI Emissions

The CSU1300AP series power supply has been designed to comply with the Class A limits of EMI requirements of FCC CFR 47 Part 15 Subpart B and EN55032 for emissions and relevant sections of EN55032: 2015 for immunity. The unit is tested at 1300W using resistive load with cooling fan.

## Conducted Emissions

The applicable standard for conducted emissions is EN55032 (FCC Part 15). Conducted noise can appear as both differential mode and common mode noise currents. Differential mode noise is measured between the two input lines, with the major components occurring at the supply fundamental switching frequency and its harmonics. Common mode noise, a contributor to both radiated emissions and input conducted emissions, is measured between the input lines and system ground and can be broadband in nature.



The CSU1300AP series power supply has internal EMI filters to ensure the converter's conducted EMI levels comply with EN55032 (FCC Part 15) Class A limits. The EMI measurements are performed with resistive loads at maximum rated loading.

Sample of EN55032 Conducted EMI Measurement at 230Vac input.

Note: Red Line refers to Quasi Peak margin, which is 6dB below the CISPR international limit.  
Green Line refers to the Average margin, which is 6dB below the CISPR international limit.

Conducted EMI emission specifications of the CSU1300AP series power supply:

| Parameter                  | Model | Symbol | Min | Typ | Max | Unit |
|----------------------------|-------|--------|-----|-----|-----|------|
| FCC Part 15, class A       | All   | Margin | 6   | -   | -   | dB   |
| CISPR 32 (EN55032) class A | All   | Margin | 6   | -   | -   | dB   |



### Radiated Emissions

Unlike conducted EMI, radiated EMI performance in a system environment may differ drastically from that in a stand-alone power supply. The shielding effect provided by the system enclosure may bring the EMI level from Class A to Class B. It is thus recommended that radiated EMI be evaluated in a system environment. The applicable standard is EN55032 (FCC Part 15). Testing ac-dc converters as a stand-alone component to the exact requirements of EN55032 can be difficult, because the standard calls for 1m leads to be attached to the input, and any auxiliary output cables aligned such as to maximize the disturbance. In such a set-up, it is possible to form a perfect dipole antenna that very few ac-dc convertors could pass. However, the standard also states that an attempt should be made to maximize the disturbance consistent with the typical application by varying the configuration of the test sample.

### **Operating Temperature**

The CSU1300AP series power supply starts and operates with full rated power at an ambient temperature from 0 °C to 55 °C. Allowable up to 55 °C at de-rated power.

### **Forced Air Cooling**

The CSU1300AP series power supply includes internal cooling fans as part of the power supply assembly to provide forced air-cooling to maintain and control temperature of devices and ambient temperature in the power supply to appropriate levels. The standard direction of airflow is from the DC connector end to the AC connector end of the power supply.

## Storage and Shipping Temperature / Humidity

The CSU1300AP series power supply can be stored or shipped at temperatures between -40 °C to +85 °C and relative humidity from 5% to 95% non-condensing.

## Altitude

The CSU1300AP series power supply can operate within specifications at altitudes up to 5,000 meters above sea level.

## Humidity

The CSU1300AP series power supply can operate within specifications when subjected to a relative humidity from 5% to 90% non-condensing. The power supply can be stored in a relative humidity from 5% to 95% non-condensing.

## Vibration

The CSU1300AP power supply passes the following vibration specifications:

### Non-Operating Random Vibration

|                 |                                 |  |
|-----------------|---------------------------------|--|
| Acceleration    | 1.87                            | gRMS   |
| Frequency Range | 10-500                          | Hz   |
| Duration        | 30                              | Mins/axis                                    |
| Direction       | X,Y,Z                           |  |
| Profile         | <b><u>FREQ</u></b><br><b>Hz</b> | <b><u>SLOPE</u></b><br><b>dB/oct</b>         |
|                 | 10-200                          | ---  |
|                 | 500                             | ---  |
|                 |                                 | <b><u>PSD</u></b><br><b>g<sup>2</sup>/Hz</b> |
|                 |                                 | 0.01   |
|                 |                                 | 0.003  |

### Operating Random Vibration

|                 |                                 |  |
|-----------------|---------------------------------|--|
| Acceleration    | 2.4                             | gRMS   |
| Frequency Range | 10-500                          | Hz   |
| Duration        | 30                              | Mins/axis                                    |
| Direction       | X,Y,Z                           |  |
| PSD Profile     | <b><u>FREQ</u></b><br><b>Hz</b> | <b><u>SLOPE</u></b><br><b>dB/oct</b>         |
|                 | 10                              | ---  |
|                 | 30-200                          | ---  |
|                 | 500                             | ---  |
|                 |                                 | <b><u>PSD</u></b><br><b>g<sup>2</sup>/Hz</b> |
|                 |                                 | 0.001  |
|                 |                                 | 0.02   |
|                 |                                 | 0.002  |

### **Shock**

The CSU1300AP series power supply passes the following vibration specifications:

#### **Non-Operating Half-Sine Shock**

|              |                                 |      |
|--------------|---------------------------------|------|
| Acceleration | 30                              | G    |
| Duration     | 11                              | mSec |
| Pulse        | Half-Sine                       |      |
| No. of Shock | 3 shock in each of 6 directions |      |

#### **Operating Half-Sine Shock**

|              |                            |      |
|--------------|----------------------------|------|
| Acceleration | 30                         | G    |
| Duration     | 11                         | mSec |
| Pulse        | Half-Sine                  |      |
| No. of Shock | 3 shocks in each of 3 axis |      |

# Power and Control Signal Descriptions

## **AC Input Connector**

This connector supplies the AC Mains to the CSU1300AP series power supply.

- Pin 1 - L
- Pin 2 - N
- Pin 3 - Earth Ground

## **Output Connector - Power Blades**

These pins provide the main output for the CSU1300AP series power supply. The + 12V ( $V_O$ ) and the POWER GND pins are the positive and negative rails, respectively, of the  $V_O$  main output of the CSU1300AP series power supply. The +12V ( $V_O$ ) is electrically isolated from the power supply chassis.

- A1 - A9 - Main Output Return
- A10 - A18 - + Main Output ( $V_O$ )
- B1 - B9 - Main Output Return
- B10 - B18 - + Main Output ( $V_O$ )

## **Output Connector - Control Signals**


The CSU1300AP series power supply contains a 14 pins control signal header providing an analogue control interface, standby power and I<sup>2</sup>C interface signal connections.

### **SDA, SCL (I<sup>2</sup>C Data and Clock Signals) - (Pins A19, A20)**

Please refer to “Communication Bus Descriptions” section.


## PSON - (Pin A21)

This signal input pin controls the normal turn on and off of the main output of the CSU1300AP series power supply. The power supply main output ( $V_O$ ) will be enabled when this signal is pulled low below 1V. The power supply output (except  $V_{SB}$  output) is disabled when this input is driven higher than 2.0V. This signal can be pulled high to 3.46V maximum. The PSU has a 10K internal pull-up resistor, hence no additional pull-up resistor required by system. The source current is 4mA maximum when  $V_{pson}$  is low.



## SMBALERT# - (Pin A22)

SMBALERT# is an active low signal used to send an interrupt to the system that a warning or critical event in the PSU occurred. The pin is normally high. It is asserted (goes low) when a warning or fault occurred, such as OTW/OTP/OCV/OPP/OCW. This signal may also indicate the power supply reaches its end of life or operates in an environment exceeding the specified limits.




## + VSENSE & - VSENSE - (Pins A23, A24)

+ VSENSE and -VSENSE are the remote sense signals for 12V main output voltage.

## PWOK - (Pin A25)

The PWOK is an output signal driven high above 2.4V by the power supply to indicate that all outputs are valid. If any of the power supply outputs fails below its regulation limits or AC power removed for a time sufficiently long so that power supply operation is no longer guaranteed, this signal will be driven low below 0.4V. The sink current is 400uA maximum when the signal is low and is 2mA maximum when the signal is high. The rise time and fall time of the signal is 100uSec maximum.



## CR\_BUS# - (Pin B22)

There is an additional signal defined supporting Cold Redundancy. This is connected to a bus shared between the power supplies: CR\_BUS#. This is a tri-state output signal of the power supply used to communicate a fault or Vout under voltage level has occurred in one of the power supplies. This is used to power on all the power supplies in the system via the CR\_BUS#. When the signal is pulled high it allows all power supplies in cold standby mode to go into cold standby state when the load share voltage is below the VCR\_ON level. When the signal is left open on all power supplies it forces all cold standby power supplies into the ON. The Cold Redundancy section showing the logic state of the CR\_BUS# signal depending upon the programmed configuration of the power supply in D0h, the operating state of the power supply, and the power supply fault status.

Refer cold redundancy part for details.



## ISHARE - (Pin B23)


ISHARE is a single wire bus signal used to help equalize the output current from two or more power supplies connected to a common load. The current share signal is a DC signal that represents the load current that a power supply is providing. This voltage increases proportionately with the output load and the 12V load share transients during hot insertion or removal would not cause the supply output go out of regulation. The expected voltage levels are stated as below table.

| Load (per power supply unit) | Min | Typ | Max | Unit |
|------------------------------|-----|-----|-----|------|
| 100% $I_{O,max}$             | 7.6 | 8.0 | 8.4 | Vdc  |
| 50% $I_{O,max}$              | 3.8 | 4.0 | 4.2 | Vdc  |
| 25% $I_{O,max}$              | 1.9 | 2.0 | 2.1 | Vdc  |

## PRESENT - (Pin B24)

This signal used to indicate to the system that a power supply is inserted in the power bay. This pin is grounded inside the power supply.

- Low - PS is present
- High - PS is removed from system



## VIN\_GOOD - (Pin B25)


The VIN\_GOOD is a fast acting signal that indicate the state of the input voltage. During an initial start-up, and at any line condition, VIN\_GOOD should assert ( GO HIGH) whenever the input voltage is within the operation range.

The VIN\_GOOD signal should also assert within 8mS of an input recovery right after a missing cycle.

| Signal Type                             |              |            |
|---|--------------|------------|
| VIN_GOOD = High                         | Input OK     |            |
| VIN_GOOD = Low                          | Input not OK |            |
|   | MIN          | MAX        |
| Logic level low voltage, Isink=400uA    | 0V           | 0.4V       |
| Logic level high voltage, Isource=200uA | 2.4V         | 3.46V      |
| Sink current, PWOK = low                |              | 400uA      |
| Sink current, PWOK = high               |              | 2mA        |
| VIN_GOOD delay: (Input to assertion)    |              | 2000mS max |
| Input Loss to VIN_GOOD De-assertion     |              | 4mS max    |

Power supply side

Customer system side



## Communication Bus Descriptions

### I<sup>2</sup>C Bus Signals

CSU1300AP series power supply contains enhanced monitor and control functions implemented via the I<sup>2</sup>C bus. The CSU1300AP series I<sup>2</sup>C functionality (PMBus™ and FRU data) can be accessed via the output connector control signals. The communication bus is powered either by the internal 3.3V supply or from an external power source connected to the Standby Output (i.e. accessing an unpowered power supply as long as the Standby Output of another power supply connected in parallel is on).

If units are connected in parallel or in redundant mode, the Standby Output must be connected together in the system. Otherwise, the I<sup>2</sup>C bus will not work properly when a unit is inserted into the system without the DC source connected.

Note: PMBus™ functionality can be accessed only when the PSU is powered-up.  
Guaranteed communication I<sup>2</sup>C speed is 100K Hz.

### **A0, A1 (I<sup>2</sup>C Address Signals) - (Pins B19, B20)**

These input pins are the address lines A0 and A1 to indicate the slot position the power supply occupies in the power bay and define the power supply addresses for FRU data and PMBus™ data communication. This allows the system to assign different addresses for each power supply. During I<sup>2</sup>C communication between system and power supplies, the system will be the master and power supplies will be slave.

### **SDA, SCL (I<sup>2</sup>C Data and Clock Signals) - (Pins A19, A20)**

I<sup>2</sup>C serial data and clock bus - these pins must be pulled-up by a 10K ohm resistor to 3.3V at the system side.


### **I<sup>2</sup>C Bus Communication Interval**

The interval between two consecutive I<sup>2</sup>C communications to the power supply should be at least 15ms to ensure proper monitoring functionality.

### **I<sup>2</sup>C Bus Signal Integrity**

The noise on the I<sup>2</sup>C bus (SDA, SCL lines) due to the power supply will be less than 300mV peak-to-peak. This noise measurement should be made with an oscilloscope bandwidth limited to 100MHz. Measurements should be made at the power supply output connector with 10K ohm resistors pulled up to Standby Output and 47pF ceramic capacitors to Standby Output Return.

## I<sup>2</sup>C Bus Internal Implementation, Pull-ups and Bus Capacitances



### I<sup>2</sup>C Bus - Recommended external pull-ups:

Electrical and Interface specifications of I<sup>2</sup>C signals (referenced to StandBy Output Return pin, unless otherwise indicated):

| Parameter                             | Condition  | Symbol    | Min | T.Yp | Max | Unit |
|---------------------------------------|------------|-----------|-----|------|-----|------|
| SDA, SCL internal pull-up resistor    |            | $R_{int}$ | -   | 10   | -   | Kohm |
| SDA, SCL internal bus capacitance     |            | $C_{int}$ | -   | 47   | -   | pF   |
| Recommended external pull-up resistor | 1 to 4 PSU | $R_{ext}$ | -   | 2.2  | -   | Kohm |

## Logic Levels


CSU1300AP series power supply I<sup>2</sup>C Communication Bus will respond to logic levels as per below:

Logic High: 3.3V Nominal (Specs is 2.1V to 5.5V)\*\*

Logic Low: 500mV nominal (Specs is 800mV max)\*\*

\*\*Note: Artesyn 73-769-001 I<sup>2</sup>C adapter was used.

## Timings



| Parameter  | Symbol       | Standard-Mode Specs |      | Actual Measured |             | Unit    |
|--|--------------|---------------------|------|-----------------|-------------|---------|
|  |              | Min                 | Max  |                 |             |         |
| SCL Clock Frequency                              | $f_{SCL}$    | 0                   | 100  | 98              |             | KHz     |
| Hold time (repeated) START condition             | $t_{HD;STA}$ | 4.0                 | -    | 5               |             | $\mu S$ |
| LOW period of SCL clock                          | $t_{LOW}$    | 4.7                 | -    | 5.2             |             | $\mu S$ |
| HIGH period of SCL clock                         | $t_{HIGH}$   | 4.0                 | -    | 4.8             |             | $\mu S$ |
| Setup time for repeated START condition          | $t_{SU;STA}$ | 4.7                 | -    | 5.4             |             | $\mu S$ |
| Data hold time                                   | $t_{HD;DAT}$ | 0                   | 3.65 | 0.6             |             | $\mu S$ |
| Data setup time                                  | $t_{SU;DAT}$ | 250                 | -    | 4200            |             | nS      |
| Rise time  | $t_r$        | -                   | 1000 | SCL = 669.6     | SDA = 710.4 | nS      |
| Fall time  | $t_f$        | -                   | 300  | SCL = 156.8     | SDA = 146   | nS      |
| Setup time for STOP condition                    | $t_{SU;STO}$ | 4.0                 | -    | 5.02            |             | $\mu S$ |
| Bus free time between a STOP and START condition | $t_{BUF}$    | 4.7                 | -    | 95***           |             | $\mu S$ |

\*\*\* Note Artesyn 73-769-001 I<sup>2</sup>C adapter (USB-to-I<sup>2</sup>C) and Universal PMBus™ GUI software was used

## Device Addressing

The CSU1300AP series power supply responds to supported commands on the I<sup>2</sup>C bus that are addressed according to pins A1 and A0 pins of output connector.


Address pins are held high by default via pulled up to internal 3.3V supply. To set the address as “0”, the corresponding address line should be pulled down to logic ground level. Below table shows the address of the power supply with A0 and A1 pins set to either “0” or “1”.

| PSU Slot | Slot ID Bits |    | PMBus™ Address | EEPROM (FRU) Address |
|----------|--------------|----|----------------|----------------------|
|          | A1           | A0 |                |                      |
| 1        | 0            | 0  | 0xB0           | 0xA0                 |
| 2        | 0            | 1  | 0xB2           | 0xA2                 |
| 3        | 1            | 0  | 0xB4           | 0xA4                 |
| 4        | 1            | 1  | 0xB6           | 0xA6                 |

## I<sup>2</sup>C Clock Synchronization

The CSU1300AP series power supply applies clock stretching. An addressed slave power supply hold the clock line (SCL) low after receiving (or sending) a byte, indicating that it is not yet ready to process more data. The system master that is communicating with the power supply will attempt to raise the clock to transfer the next bit, but must verify that the clock line was actually raised. If the power supply is clock stretching, the clock line will still be low (because the connections are open-drain).

The maximum time out condition for clock stretching for CSU1300AP series power supply is 30mS.





## Cold Redundancy

The CSU1300AP series power supply supports capabilities for Cold Redundancy. This capability helps improve the efficiency of the power subsystem when more than one power supply is used in a system. Cold Redundancy uses the PMBus manufacturer specific command area to define commands for the system to configure the power supplies for Cold Redundancy.

### Overview

A system in 1+1, or 2+1 or 3+1 or 2+2 redundant mode configuration may not be operating at the optimum efficiency especially when the load is <50% of each power supply's capacity. The Cold Redundancy mode addresses this condition, where certain power supplies in a system can go into "cold standby" mode, thereby consuming the least amount of power and still be redundant.

Each power supply in this system will have a preprogrammed threshold for output current by which that power supply may determine whether to be actively providing power to the system, or be in cold standby state. A CR\_BUS# signal that connects all power supplies in the system, also indicates whether it is safe for power supplies in cold redundant mode to enter into cold standby state. The CR\_BUS# signal prevents power supplies from going into cold standby mode whenever there isn't any active power supply.

The following table shows the state of the power supplies programmed for Cold Standby mode based on the condition of the CR\_BUS# signal and the Load Share bus voltage.

Logic Matrix for Cold Standby Power Supplies:

| CR_BUS# | Load share | Cold Standby Power Supply State(s) |
|---------|------------|------------------------------------|
| High    | < VCR_ON   | Cold Standby                       |
| Low     | < VCR_ON   | Active                             |
| High    | > VCR_ON   | Active                             |
| Low     | > VCR_ON   | Active                             |

Note: VCR\_ON is the voltage threshold set inside the power supplies configured for Cold Standby which tells them to power down into Cold Standby state when the load share voltage is less than VCR\_ON.

When CR\_BUS# is asserted (or goes low), all power supplies in the system should go active and immediately provide power to the system.

### SMBus Commands for Cold Redundancy

Configuring Cold Redundancy with Cold\_Redundancy\_Config (D0h)

The PMBus™ manufacturer specific command MFR\_SPECIFIC\_00 is used to configure the operating state of the power supply related to cold redundancy. This command for Cold\_Redundancy\_Config is D0h. The table below shows the configuration of the power supply based on the value in the Cold\_Redundancy\_Config register. PEC is used for read/writes of this register.

## Cold Redundancy Configuration Table


| Cold_Redundancy_Config (D0h) |   |   |
|------------------------------|---|---|
| Value                        | State   | Description   |
| 00h                          | Standard Redundancy<br>(default power on state) | Turns the power supply into standard redundant load sharing mode. The power supply's CR_BUS# signal shall be OPEN but still pull the bus low if a fault occurs. |
| 55h                          | Cold Redundant Active                           | Defines this power supply to be the one that is always ON in a cold redundancy configuration.   |
| 02h                          | Cold Standby 1                                  | Defines the power supply that is first to turn on in a cold redundant configuration as the load increases.  |
| 03h                          | Cold Standby 2                                  | Defines the power supply that is second to turn on in a cold redundant configuration as the load increases.   |
| 04h                          | Cold Standby 3                                  | Defines the power supply that is third to turn on in a cold redundant configuration as the load increases.  |
| 05h                          | Always Cold Standby                             | Defines this power supply to be always in cold redundant configuration no matter what the load condition.   |
| 06h -- FFh                   | Reserved  |   |

When the CR\_BUS# transitions from a high to a low state; each PSU programmed to be in Cold Standby state shall be put into Standard Redundancy mode (Cold\_redundancy\_Config = 00h). For the power supplies to enter Cold Redundancy mode the system must re-program the power supplies using the Cold\_Redundancy\_Config command.

## Cold Redundancy State Table

| Cold Redundant Config | Operating State | Power Supply Fault Status | CR_Bus# |
|-----------------------|-----------------|---------------------------|---------|
| Active                | On              | OK                        | High    |
| Cold Standby 1,2,3    | On              | OK                        | Open    |
| Cold Standby 1,2,3    | Cold Standby    | OK                        | Open    |
| Active                | Off             | Fault                     | Low     |
| Cold Standby 1,2,3    | On              | Fault                     | Low     |
| Cold Standby 1,2,3    | Cold Standby    | Fault                     | Low     |

The CR\_Status input is based on both the Cold\_Redundancy\_Config register as well as the fault state of the power supply. The resulting output is a tri-state output. The output is Low when there is a Fault in any power supply or when Cold Redundancy is disabled. The output is High only when a power supply is programmed for the Cold Redundancy Active mode and it is functioning OK. The output is Open only when the power supply is programmed for Cold Redundant Standby mode and is functioning OK. This mean that there needs to be one good power supply programmed for Active Cold Redundant mode to allow power supply to function in cold standby mode; otherwise, all power supplies will power ON and come out of cold redundant mode.



## CR\_BUS# Signal Characteristic

| Signal Type                         | Active: Tri-state output Cold Standby: Input signal |             |
|-------------------------------------|---|-------------|
|                                     | Min   | Max         |
| Logic level low (power supply ON)   | 0 V   | 0.4 V       |
| Logic level high (power supply OFF) | 2.4 V   | 3.46 V      |
| Source current, Cold Red = high     | 2 mA  |             |
| Sink current, Cold_Red = low        | 400 $\mu$ A   |             |
| Cold_Red fault delay                |   | 10 $\mu$ s  |
| Cold_Red turn on delay              |   | 100 $\mu$ s |

### BMC Requirements

The BMC uses the Cold\_Redundancy\_Config command to configure the power supply's roll in cold redundancy and to enabled / disable cold redundancy. It is recommended that the BMC schedule a rolling change for which PSU is the Active, Cold Stby1, Cold Stby 2, and Cold Stby 3 power supply. This allows for equal loading across power supply over their life.

Events that trigger a re-configuration of the power supplies using the Cold\_Redundancy\_config command.

- AC Power ON
- PSON power ON
- Power supply Failure
- Power supply inserted into system
- Power supply removed from the system

### **Black Box**

The power supply will store PMBus and other data into non-volatile memory upon a critical failure that caused the power supply to shutdown. The data can be accessed via the PMBus interface by applying power to the 12VSB pins. No AC power needs to be applied to the power supply.

Data is saved to the Black Box for the following fault events:

- General fault
- Over voltage on output
- Over current on output
- Loss of AC input
- Input voltage fault
- Fan failure
- Over temperature

Black Box Process:

- 1) System writes system tracking data to the power supply RAM at power ON
- 2) System writes the real time clock data to the PSU RAM once every ~5 minutes
- 3) Power supply tracks number of PSON and AC power cycles in FLASH
- 4) Power supply tracks ON time in FLASH
- 5) Power supply loads warning and fault event counter data from FLASH into RAM
- 6) Upon a warning event; the PSU shall increment the associated counter in RAM.
- 7) Upon and fault event the PSU shall increment the associated counter in RAM
- 8) Upon a fault event that causes the PSU to shutdown all event data in the PSU's RAM is saved to event data location N in the power supply's FLASH. This data includes the real time clock, number of AC & PSON power cycles, PSU ON time, warning event counters and fault event counters.

## Commands:

Name: MFR\_BLACKBOX

Format: Read Block with PEC (238 bytes)

Code: DCh

|                             | Item   | Number of Bytes | Description   |
|-----------------------------|--|-----------------|---|
| System Tracking Data        | System top assembly number                                 | 10              | The system will write its Intel part number for the system top assembly to the power supply when it is powered ON. This is 9 ASCII characters.  |
|                             | System serial number                                       | 10              | The system shall write the system serial number to the power supply when it is powered ON. This include the serial number and date code.  |
|                             | Motherboard assembly number                                | 10              | The system will write the motherboard Intel part number for the assembly to the power supply when it is powered ON. This is 9 ASCII characters.   |
|                             | Motherboard serial number                                  | 10              | The system shall write the motherboard's serial number to the power supply when it is powered ON. This includes the serial number and date code.  |
|                             | Present total PSU ON time                                  | 3               | Total on time of the power supply with PSON asserted in minutes. LSB = 1 minute..   |
|                             | Present number of AC power cycles                          | 2               | Total number of times the power supply powered OFF then back ON due to loss of AC power. This is only counted when the power supply's PSON# signal is asserted. This counter shall stay at FFFFh once the max is reached.   |
|                             | Present number of PSON power cycles                        | 2               | Total number of times the power supply is powered OFF then back ON due to the PSON# signal de-asserting. This is only counted when AC power is present to the power supply. This counter shall stay at FFFFh once the max is reached.   |
| Power supply event data (N) |  | 38              | Most recent occurrence of saved black box data  |
| Time Stamp                  |  |                 | The power supply shall track these time and power cycle counters in RAM. When the a black box event occurs the data is saved into the Black Box.  |
|                             | Power supply total power on time                           | 3               | Total on time of the power supply in minutes. LSB = 1 minute.   |
|                             | Real Time Clock Data from System (reserved for future use) | 4               | This time stamp does not need to generated by the power supply. The system rights a real time clock value periodically to the power supply using the MFR_REAL_TIME command. Format is based on IPMI 2.0. Time is an unsigned 32-bit value representing the local time as the number of seconds from 00:00:00, January 1, 1970. This format is sufficient to maintain time stamping with 1-second resolution past the year 2100. This is based on a long standing UNIX-based standard for time keeping, which represents time as the number of seconds from 00:00:00, January 1, 1970 GMT. Similar time formats are used in ANSI C |
|                             | Number of AC power cycles                                  | 2               | Number of times the power supply powered OFF then back ON due to loss of AC power at the time of the event. This is only counted when the power supply's PSON# signal is asserted.  |
|                             | Number of PSON power cycles                                | 2               | Number of times the power supply is powered OFF then back ON due to the PSON# signal deasserting at the time of the event. This is only counted when AC power is present to the power supply.   |

|                               | Item  | Number of Bytes | Description   |
|-------------------------------|---|-----------------|---|
| PMBus                         |   |                 | The power supply shall save these PMBus values into the Black Box when a black box event occurs. Fast events may be missed due to the filtering effects of the PMBus sensors  |
|                               | STATUS_WORD                                   | 2               |   |
|                               | STATUS_IOUT                                   | 1               |   |
|                               | STATUS_INPUT                                  | 1               |   |
|                               | STATUS_TEMPERTATURE                           | 1               |   |
|                               | STATUS_FAN_1_2                                | 1               |   |
|                               | READ_VIN                                      | 2               |   |
|                               | READ_IIN                                      | 2               |   |
|                               | READ_IOUT                                     | 2               |   |
|                               | READ_TEMPERATURE_1                            | 2               |   |
|                               | READ_TEMPERATURE_2                            | 2               |   |
|                               | READ_FAN_SPEED_1                              | 2               |   |
|                               | READ_PIN                                      | 2               |   |
|                               | READ_VOUT                                     | 2               |   |
| Event Counters                |   |                 | The power supply shall track the total number for each of the following events. These value shall be saved to the black box when a black box event occurs. Once a value has reached 15, it shall stay at 15 and not reset.  |
|                               | AC shutdown due to under voltage on input     | Lower 1/2       | The power supply shall save a count of these critical events to nonvolatile memory each time they occur. The counters will increment each time the associated STATUS bit is asserted.   |
|                               | Thermal shutdown                              | Upper 1/2       |   |
|                               | Over current or over power shutdown on output | Lower 1/2       |   |
|                               | General failure shutdown                      | Upper 1/2       |   |
|                               | Fan failure shutdown                          | Lower 1/2       |   |
|                               | Shutdown due to over voltage on output        | Upper 1/2       |   |
|                               | Input voltage warning; no shutdown            | Lower 1/2       | The power supply shall save into RAM a count of these warning events. Events are count only at the initial assertion of the event/bit. If the event persists without clearing the bit the counter will not be incremented. When the power supply shuts down it shall save these warning event counters to non-volatile memory. The counters will increment each time the associated STATUS bit is asserted. |
|                               | Thermal warning; no shutdown                  | Upper 1/2       |   |
|                               | Output current power warning; no shutdown     | Lower 1/2       |   |
|                               | Fan slow warning; no shutdown                 | Upper 1/2       |   |
| Power supply event data (N-1) |   | 38              |   |
| Power supply event data (N-2) |   | 38              |   |
| Power supply event data (N-3) |   | 38              |   |
| Power supply event data (N-4) |   | 38              |   |



Name: MFR\_REAL\_TIME\_BLACK\_BOX  
Format: Write/Read Block with PEC (4 bytes)  
Code: DDh

The system shall use this command to periodically write the real time clock data to the power supply.

Format is based on IPMI 2.0. Time is an unsigned 32-bit value representing the local time as the number of seconds from 00:00:00, January 1, 1970. This format is sufficient to maintain time stamping with 1-second resolution past the year 2100.

This is based on a long standing UNIX based standard for time keeping, which represents time as the number of seconds from 00:00:00, January 1, 1970 GMT. Similar time formats are used in ANSI C.

Name: MFR\_SYSTEM\_BLACK\_BOX  
Format: Write/Read Block with PEC (40 bytes). Low byte first.  
Code: DEh

The system uses this command to write the following data to the PSU.

| Item                        | Bytes |            |
|-----------------------------|-------|------------|
| System top assembly number  | 1-10  | Low bytes  |
| System serial number        | 11-20 |            |
| Motherboard assembly number | 21-30 |            |
| Motherboard serial number   | 31-40 | High bytes |

Name: MFR\_BLACKBOX\_CONFIG  
Format: Read/Write Byte with PEC  
Code: DFh

| Bit | Value   | Description   |
|-----|---|---|
| 0   | 0 = disable black box function<br>1 = enable black box function | Writing a 1 enables the power supply with black box function.<br>Writing a 0 disables the power supply black box function.<br>The state of MFR_BLACKBOX_CONFIG shall be saved in non-volatile memory so that it is not lost during power cycling.<br>Intel shall receive the power supply with the black box function enabled; bit 0 = '1'. |

Name: MFR\_CLEAR\_BLACKBOX  
Format: Send Byte with PEC  
Code: E0h

The MFR\_CLEAR\_BLACKBOX command is used to clear all black box records simultaneously. This command is write only. There is no data byte for this command.

## FRU (EEPROM) Data

The FRU (Field Replaceable Unit) data format is compliant with the Intel IPMI v1.0 specification.

The CSU1300AP series uses 1 page of EEPROM for FRU purpose. A page of EEPROM contains up to 256 byte-sized data locations. A physical EEPROM device is used in this model.

Where:      OFFSET      - The OFFSET denotes the address in decimal format of a particular data byte within CSU1300AP series EEPROM.

VALUE              - The VALUE details data written to a particular memory location of the EEPROM.

DEFINITION      - The contents DEFINITION refers to the definition of a particular data byte.

CSU1300AP series FRU (EEPROM) Data:

| OFFSET                                    |       | DEFINITION  | SPEC VALUE |       |
|---|-------|---|------------|-------|
| (DEC)                                     | (HEX) | (REMARKS)   | (DEC)      | (HEX) |
| <b>COMMON HEADER, 8 BYTES</b>             |       |   |            |       |
| 0   | 00    | <b>FORMAT VERSION NUMBER</b> (Common Header)<br>7:4 - Reserved, write as 0000b<br>3:0 - Format Version Number = 1h for this specification     | 1          | 01    |
| 1   | 01    | <b>INTERNAL USE AREA OFFSET</b> (Not required, do not reserve)  | 0          | 00    |
| 2   | 02    | <b>CHASSIS INFO AREA OFFSET</b> (Not required, do not reserve)  | 0          | 00    |
| 3   | 03    | <b>BOARD INFO AREA OFFSET</b> (Not required, do not reserve)  | 0          | 00    |
| 4   | 04    | <b>PRODUCT INFO AREA OFFSET</b>   | 1          | 01    |
| 5   | 05    | <b>MULTI RECORD AREA OFFSET</b>   | 10         | 0A    |
| 6   | 06    | <b>PAD</b> (Not required, do not reserve)   | 0          | 00    |
| 7   | 07    | <b>ZERO CHECK SUM</b> (256 - (Sum of bytes 0 to 6))   | 244        | F4    |
| <b>PRODUCT INFORMATION AREA, 72 BYTES</b> |       |   |            |       |
| 8   | 08    | <b>FORMAT VERSION NUMBER</b> (Product Info Area)<br>7:4 - Reserved, write as 0000b<br>3:0 - Format Version Number = 1h for this specification | 1          | 01    |
| 9   | 09    | <b>PRODUCT INFO AREA LENGTH</b> (In multiples of 8 bytes)   | 9          | 09    |
| 10  | 0A    | <b>Language</b> (English)   | 25         | 19    |
| 11  | 0B    | <b>MANUFACTURE NAME TYPE / LENGTH</b> (C7H)<br>7:6 – (11)b, 8-Bit ASCII + Latin 1,<br>5:0 – (000111)b, 7-Byte Allocation                      | 199        | C7    |
| 12  | 0C    | MANUFACTURE'S NAME 7 byte sequence<br>"A" = 41h   | 65         | 41    |
| 13  | 0D    | "R" = 52h   | 82         | 52    |
| 14  | 0E    | "T" = 54h   | 84         | 54    |
| 15  | 0F    | "E" = 45h   | 69         | 45    |
| 16  | 10    | "S" = 53h   | 83         | 53    |
| 17  | 11    | "Y" = 59h   | 89         | 59    |
| 18  | 12    | "N" = 4Eh   | 78         | 4E    |
| 19  | 13    | <b>PRODUCT NAME</b> Type / Length (D0H)<br>Type = "ASCII+LANTIN" = (11)b Length = 16 Bytes = (010000)b  | 208        | D0    |
| 20  | 14    | <b>PRODUCT NAME BYTES</b> (16 Byte sequence)<br>"C" = 43h   | 67         | 43    |
| 21  | 15    | "R" = 52h   | 82         | 52    |
| 22  | 16    | "P" = 50h   | 80         | 50    |
| 23  | 17    | "S" = 53h   | 83         | 53    |
| 24  | 18    | "1" = 31h   | 49         | 31    |
| 25  | 19    | "3" = 33h   | 51         | 33    |
| 26  | 1A    | "0" = 30h   | 48         | 30    |
| 27  | 1B    | "0" = 30h   | 48         | 30    |
| 28  | 1C    | "W" = 57h   | 87         | 57    |
| 29  | 1D    | " " = 20h   | 32         | 20    |
| 30  | 1E    | " " = 20h   | 32         | 20    |
| 31  | 1F    | " " = 20h   | 32         | 20    |

# Technical Reference Note

Rev.06.20.20\_#1.0  
CSU1300AP Series  
Page 46

CSU1300AP series FRU (EEPROM) Data:

| OFFSET |       | DEFINITION  | SPEC VALUE |       |
|--------|-------|---|------------|-------|
| (DEC)  | (HEX) | (REMARKS)   | (DEC)      | (HEX) |
| 32     | 20    | " " = 20h   | 32         | 20    |
| 33     | 21    | " " = 20h   | 32         | 20    |
| 34     | 22    | " " = 20h   | 32         | 20    |
| 35     | 23    | " " = 20h   | 32         | 20    |
| 36     | 24    | <b>PRODUCT PART/MODEL NUMBER</b> Type/Length (CFH)<br>Type = "ASCII + LATIN1" = (11)b Length = 15 Bytes = (001111)b | 207        | CF    |
|        |       | <b>PRODUCT PART/MODEL NUMBER BYTES</b>  |            |       |
| 37     | 25    | "C" = 43h   | 67         | 43    |
| 38     | 26    | "S" = 52h   | 83         | 53    |
| 39     | 27    | "U" = 50h   | 85         | 55    |
| 40     | 28    | "1" = 31h   | 49         | 31    |
| 41     | 29    | "3" = 33h   | 51         | 33    |
| 42     | 2A    | "0" = 30h   | 48         | 30    |
| 43     | 2B    | "0" = 30h   | 48         | 30    |
| 44     | 2C    | "A" = 57h   | 65         | 41    |
| 45     | 2D    | "P" = 31h   | 80         | 50    |
| 46     | 2E    | "-" = 33h   | 45         | 2D    |
| 47     | 2F    | "3" = 30h   | 51         | 33    |
| 48     | 30    | "-" = 30h   | 45         | 2D    |
| 49     | 31    | "6" = 57h   | 54         | 36    |
| 50     | 32    | "0" = 30h   | 48         | 30    |
| 51     | 33    | "0" = 30h   | 48         | 30    |
| 52     | 34    | <b>PRODUCT VERSION NUMBER</b> Type/Length (C2H)<br>Type = "ASCII+LATIN1" = (11)b Length = 2 bytes = (000010)b       | 194        | C2    |
|        |       | <b>PRODUCT VERSION NUMBER BYTES</b>   |            |       |
| 53     | 35    |   |            |       |
| 54     | 36    |   |            |       |
| 55     | 37    | <b>PRODUCT SERIAL NUMBER</b> Type/Length<br>Type = "ASCII+LATIN1" = (11)b Length = 13 bytes = (001101)b             | 205        | CD    |
|        |       | <b>PRODUCT SERIAL NUMBER BYTES</b><br>See Latest Model S/N in PSU Tag   |            |       |
| 56     | 38    |   |            |       |
| 57     | 39    |   |            |       |
| 58     | 3A    |   |            |       |
| 59     | 3B    |   |            |       |
| 60     | 3C    |   |            |       |
| 61     | 3D    |   |            |       |
| 62     | 3E    |   |            |       |
| 63     | 3F    |   |            |       |
| 64     | 40    |   |            |       |
| 65     | 41    |   |            |       |
| 66     | 42    |   |            |       |
| 67     | 43    |   |            |       |
| 68     | 44    |   |            |       |
| 69     | 45    | <b>Asset Tag</b> Type/Length<br>Type = "ASCII+LATIN1" = (11)b Length = 0 bytes = (000000)b                          | 192        | C0    |
| 70     | 46    | <b>FRU File ID</b> Type/Length<br>Type = "ASCII+LATIN1" = (11)b Length = 0 bytes = (000000)b                        | 192        | C0    |
| 71     | 47    | C1h (type/length byte encoded to indicate no more info fields)  | 193        | C1    |
| 72     | 48    | 00h - any remaining unused space  | 0          | 00    |
| 73     | 49    | 00h - any remaining unused space  | 0          | 00    |
| 74     | 4A    | 00h - any remaining unused space  | 0          | 00    |
| 75     | 4B    | 00h - any remaining unused space  | 0          | 00    |
| 76     | 4C    | 00h - any remaining unused space  | 0          | 00    |
| 77     | 4D    | 00h - any remaining unused space  | 0          | 00    |
| 78     | 4E    | 00h - any remaining unused space  | 0          | 00    |

# Technical Reference Note

Rev.06.20.20\_#1.0  
CSU1300AP Series  
Page 47

CSU1300AP series FRU (EEPROM) Data:

| OFFSET                             |       | DEFINITION   | SPEC VALUE |          |
|------------------------------------|-------|--|------------|----------|
| (DEC)                              | (HEX) | (REMARKS)  | (DEC)      | (HEX)    |
| 79                                 | 4F    | <b>ZERO CHECK SUM</b> (256-(sum of bytes 8 to 78)) Per Unit<br>Zero Check Sum: Should follow check sum calculation as per IPMI V1.3 specs  |            |          |
| <b>Multi record Area, 72 Bytes</b> |       |  |            |          |
| 80                                 | 50    | <b>Power Supply Record Header</b><br>Record type = 00 for Power supply   | 0          | 0        |
| 81                                 | 51    | End of List/Record Format Version Number   | 2          | 2        |
| 82                                 | 52    | Record Length of Power Supply Record   | 24         | 18       |
| 83                                 | 53    | Record CHECKSUM of Power Supply Record (256-(sum of bytes 85 to 108))  |            |          |
| 84                                 | 54    | Header CHECKSUM of Power Supply Record Header (256-(sum of bytes 80 to 83))  |            |          |
| <b>Power Supply Record</b>         |       |  |            |          |
| 85                                 | 55    | <b>Over Capacity of the Power Supply</b><br>2 Bytes Sequence CSU1300AP-3 = 1300W   | 20         | 14       |
| 86                                 | 56    | 1300W = 0514h(LSB First)   | 5          | 05       |
| 87                                 | 57    | <b>Peak VA, 2200VA = 0898H</b><br>2 Bytes Sequence   | 152        | 98       |
| 88                                 | 58    |  | 8          | 08       |
| 89                                 | 59    | <b>Inrush Current, 35A</b><br>In Decimal = 35 In Hex = 23H   | 35         | 23       |
| 90                                 | 5A    | <b>Inrush Interval, 10mS</b><br>In Decimal = 10 In Hex = 0AH   | 10         | 0A       |
| 91                                 | 5B    | <b>Low End Input Voltage Range 1(10mV),</b> (90V / 10mV) 9000 = 2328H<br>2 Bytes Sequence  | 40         | 28       |
| 92                                 | 5C    | In Decimal = 40 In Hex = 28H   | 35         | 23       |
|                                    |       | In Decimal = 35 In Hex = 23H   |            |          |
| 93                                 | 5D    | <b>High End Input Voltage Range 1(10mV),</b> (264V/10mV) 26400 = 6720H<br>2 Bytes Sequence   | 32         | 20       |
| 94                                 | 5E    | In Decimal = 32 In Hex = 20H   | 103        | 67       |
|                                    |       | In Decimal = 103 In Hex = 67H  |            |          |
| 95                                 | 5F    | <b>Low End Input Voltage Range 2(10mV),</b><br>(Zero if single range) (signed)   | 0          | 00       |
| 96                                 | 60    |  | 0          | 00       |
| 97                                 | 61    | <b>High End Input Voltage Range 2(10mV),</b><br>(Zero if single range) (signed)  | 0          | 00       |
| 98                                 | 62    |  | 0          | 00       |
| 99                                 | 63    | <b>Low End Input Frequency Range, 47Hz = 2FH</b>   | 47         | 2F       |
| 100                                | 64    | <b>Low End Input Frequency Range, 63Hz = 3FH</b>   | 63         | 3F       |
| 101                                | 65    | <b>AC Dropout Tolerance in ms, 10mS= 0AH</b>   | 10         | 0A       |
| 102                                | 66    | <b>Binary Flags: For each of the following binary flags No = 0, Yes = 1;</b><br>Bits 7-5: RESERVED,<br>WRITE AS 000B<br>Bit4: Tachometer Pulses Per Rotation / Predictive Fail Polarity<br>BIT = 0<br>Bit3: Hot Swap / Redundancy Support<br>BIT = 1<br>Bit2: Auto switch Support<br>BIT = 1<br>Bit1: Power Factor Correction Support<br>BIT = 1<br>Bit0: Predictive Fail Support<br>BIT = 0 | 14         | 0E       |
| 103                                | 67    | <b>Peak Wattage and sustained Time, (Set for 1500Watts/15Sec)</b><br>15:12 – Hold up time in seconds   |            |          |
| 104                                | 68    | 11:0 – Peak capacity (watts) (LSB First) [FFFh = unspecified]<br>In Decimal = 220 In Hex = DCH (LSB First)<br>In Decimal = 245 In Hex = F5H  | 220<br>245 | DC<br>F5 |

# Technical Reference Note

Rev.06.20.20\_#1.0  
CSU1300AP Series  
Page 48

CSU1300AP series FRU (EEPROM) Data:

| OFFSET                      |       | DEFINITION  | SPEC VALUE |       |
|-----------------------------|-------|---|------------|-------|
| (DEC)                       | (HEX) | (REMARKS)   | (DEC)      | (HEX) |
| 105                         | 69    | <b>Combined Wattage,</b><br>No combined voltages for power supply   | 0          | 00    |
| 106                         | 6A    |   | 0          | 00    |
| 107                         | 6B    |   | 0          | 00    |
| 108                         | 6C    | <b>Predictive Fail Tachometer Lower Threshold</b> , Not Applicable.<br>Predictive Failure is not Supported.   | 0          | 0     |
| 12V DC OUTPUT RECORD HEADER |       |   |            |       |
| 109                         | 6D    | Record type = 09 for DC Output Record   | 9          | 09    |
| 110                         | 6E    | End of List /Record Format Version Number for 12V DC Output Record  | 2          | 02    |
| 111                         | 6F    | Record Length of 12V DC Output Record   | 13         | 0D    |
| 112                         | 70    | Record CHECKSUM of 12V DC Output Record (256-(sum of bytes 114 to 126 ))  |            |       |
| 113                         | 71    | Header CHECKSUM of 12V DC Output Record Header (256-(sum of bytes 109 to 112 ))   |            |       |
| 12.00V OUTPUT RECORD        |       |   |            |       |
| 114                         | 72    | <b>Output Information</b> , 001 = 01H<br>Bit 7: Standby Information = 0B<br>Bits 6-5: Reserved, Write as 00B<br>Bits 4: Current units, 0b = 10mA,<br>Bits 3-0: Output Number 1 = 001B | 1          | 1     |
| 115                         | 73    | <b>Nominal Voltage (10mV)</b> , (12.20V / 10mV => 1220 = 04C4H)<br>2 Bytes Sequence<br>In Decimal = 196 In Hex = C4H<br>In Decimal = 4 In Hex = 04H                                   | 196        | C4    |
| 116                         | 74    |   | 4          | 04    |
| 117                         | 75    | <b>Maximum Negative Voltage Deviation (10mV)</b> ,<br>(11.80V/10mV=>1180 = 049CH)<br>2 Bytes Sequence<br>In Decimal = 156 In Hex = 9CH<br>In Decimal = 4 In Hex = 04H                 | 156        | 9C    |
| 118                         | 76    |   | 4          | 04    |
| 119                         | 77    | <b>Maximum Positive Voltage Deviation (10mV)</b> , (12.60V/10mV=>1260 =04ECH)<br>2 Bytes Sequence<br>In Decimal = 236 In Hex = ECH<br>In Decimal = 4 In Hex = 04H                     | 236        | EC    |
| 120                         | 78    |   | 4          | 04    |
| 121                         | 79    | <b>Ripple and Noise pk-pk (mV)</b> , 120 = 78H<br>2 Bytes Sequence<br>In Decimal = 120 In Hex = 78H<br>In Decimal = 0 In Hex = 00H  | 120        | 78    |
| 122                         | 7A    |   | 0          | 00    |
| 123                         | 7B    | <b>Minimum Current Draw (10mA)</b> , 0mA = 00H<br>2 Bytes Sequence<br>In Decimal = 0 In Hex = 00H<br>In Decimal = 0 In Hex = 00H  | 0          | 00    |
| 124                         | 7C    |   | 0          | 00    |
| 125                         | 7D    | <b>Maximum Current Draw (10mA)</b> , (108.3A/ 10mA=>10830 = 2A4EH)<br>2 Bytes Sequence<br>In Decimal =78 In Hex = 4EH<br>In Decimal =42 In Hex = 2AH                                  | 78         | 4E    |
| 126                         | 7E    |   | 42         | 2A    |
| 12VSB OUTPUT RECORD HEADER  |       |   |            |       |
| 127                         | 7F    | Record type = 01 for DC Output Record   | 1          | 1     |
| 128                         | 80    | End of List /Record Format Version Number for 12VSB Output Record   | 130        | 82    |
| 129                         | 81    | Record Length of 12VSB Output Record  | 13         | 0D    |
| 130                         | 82    | Record CHECKSUM of 12VSB Output Record (256-(sum of bytes 132 to 144))  |            |       |
| 131                         | 83    | Header CHECKSUM of 12VSB Output Record Header (256-(sum of bytes 127 to 130))   |            |       |
| SB OUTPUT RECORD            |       |   |            |       |
| 132                         | 84    | <b>Output Information</b> , 130 = 82H<br>Bit 7: Standby Information = 1B<br>Bits 6-4: Reserved, Write as 000B<br>Bits 3-0: Output Number 2 = 0010B                                    | 130        | 82    |

# Technical Reference Note

Rev.06.20.20\_#1.0  
CSU1300AP Series  
Page 49

CSU1300AP series FRU (EEPROM) Data:

| OFFSET |       | DEFINITION   | SPEC VALUE |       |
|--------|-------|--|------------|-------|
| (DEC)  | (HEX) | (REMARKS)  | (DEC)      | (HEX) |
| 133    | 85    | <b>Nominal Voltage (10mV)</b> , (12.00V / 10mV => 1200 = 04B0H)<br>2 Bytes Sequence<br>In Decimal = 176 In Hex = B0H<br>In Decimal = 4 In Hex = 04H                | 176        | B0    |
| 134    | 86    |  | 4          | 4     |
| 135    | 87    | <b>Maximum Negative Voltage Deviation (10mV)</b> , (11.40V/10mV=>1140 = 0474H)<br>2 Bytes Sequence<br>In Decimal = 116 In Hex = 74H<br>In Decimal = 4 In Hex = 04H | 116        | 74    |
| 136    | 88    |  | 4          | 4     |
| 137    | 89    | <b>Maximum Positive Voltage Deviation (10mV)</b> , (12.60V/10mV=>1260 =04ECH)<br>2 Bytes Sequence<br>In Decimal = 236 In Hex = ECH<br>In Decimal = 4 In Hex = 04H  | 236        | EC    |
| 138    | 8A    |  | 4          | 4     |
| 139    | 8B    | <b>Ripple and Noise pk-pk (mV)</b> , 120 = 78H<br>2 Bytes Sequence<br>In Decimal = 120 In Hex = 78H<br>In Decimal = 0 In Hex = 00H                                 | 120        | 78    |
| 140    | 8C    |  | 0          | 0     |
| 141    | 8D    | <b>Minimum Current Draw (mA)</b> , 0mA = 00H<br>2 Bytes Sequence<br>In Decimal = 0 In Hex = 00H<br>In Decimal = 0 In Hex = 00H                                     | 0          | 0     |
| 142    | 8E    |  | 0          | 0     |
| 143    | 8F    | <b>Maximum Current Draw (mA)</b> , (3A/ mA => 3000 = 0BB8H)<br>2 Bytes Sequence<br>In Decimal = 184 In Hex = B8H<br>In Decimal = 11 In Hex = 0BH                   | 184        | B8    |
| 144    | 90    |  | 11         | 0B    |
| 145    | 91    | Reserved, Default value is 0.<br>(98h-FFh is Reserved, Default value is 0.)  | 0          | 0     |
| 146    | 92    |  | 0          | 0     |
| 147    | 93    |  | 0          | 0     |
| 148    | 94    |  | 0          | 0     |
| 149    | 95    |  | 0          | 0     |
| 150    | 96    |  | 0          | 0     |
| 151    | 97    |  | 0          | 0     |
| 152    | 98    |  | 0          | 0     |
| 153    | 99    |  | 0          | 0     |
| 154    | 9A    |  | 0          | 0     |
| 155    | 9B    |  | 0          | 0     |
| 156    | 9C    |  | 0          | 0     |
| 157    | 9D    |  | 0          | 0     |
| 158    | 9E    |  | 0          | 0     |
| 159    | 9F    |  | 0          | 0     |
| 160    | A0    |  | 0          | 0     |
| 161    | A1    |  | 0          | 0     |
| 162    | A2    |  | 0          | 0     |
| 163    | A3    |  | 0          | 0     |
| 164    | A4    |  | 0          | 0     |
| 165    | A5    |  | 0          | 0     |
| 166    | A6    |  | 0          | 0     |
| 167    | A7    |  | 0          | 0     |
| 168    | A8    |  | 0          | 0     |
| 169    | A9    |  | 0          | 0     |
| 170    | AA    |  | 0          | 0     |
| 171    | AB    |  | 0          | 0     |
| 172    | AC    |  | 0          | 0     |
| 173    | AD    |  | 0          | 0     |
| 174    | AE    |  | 0          | 0     |
| 175    | AF    |  | 0          | 0     |
| 176    | B0    |  | 0          | 0     |
| 177    | B1    |  | 0          | 0     |
| 178    | B2    |  | 0          | 0     |
| 179    | B3    |  | 0          | 0     |



# Technical Reference Note

Rev.06.20.20\_#1.0  
CSU1300AP Series  
Page 50

CSU1300AP series FRU (EEPROM) Data:

| OFFSET |       | DEFINITION | SPEC VALUE |       |
|--------|-------|------------|------------|-------|
| (DEC)  | (HEX) | (REMARKS)  | (DEC)      | (HEX) |
| 180    | B4    |            | 0          | 0     |
| 181    | B5    |            | 0          | 0     |
| 182    | B6    |            | 0          | 0     |
| 183    | B7    |            | 0          | 0     |
| 184    | B8    |            | 0          | 0     |
| 185    | B9    |            | 0          | 0     |
| 186    | BA    |            | 0          | 0     |
| 187    | BB    |            | 0          | 0     |
| 188    | BC    |            | 0          | 0     |
| 189    | BD    |            | 0          | 0     |
| 190    | BE    |            | 0          | 0     |
| 191    | BF    |            | 0          | 0     |
| 192    | C0    |            | 0          | 0     |
| 193    | C1    |            | 0          | 0     |
| 194    | C2    |            | 0          | 0     |
| 195    | C3    |            | 0          | 0     |
| 196    | C4    |            | 0          | 0     |
| 197    | C5    |            | 0          | 0     |
| 198    | C6    |            | 0          | 0     |
| 199    | C7    |            | 0          | 0     |
| 200    | C8    |            | 0          | 0     |
| 201    | C9    |            | 0          | 0     |
| 202    | CA    |            | 0          | 0     |
| 203    | CB    |            | 0          | 0     |
| 204    | CC    |            | 0          | 0     |
| 205    | CD    |            | 0          | 0     |
| 206    | CE    |            | 0          | 0     |
| 207    | CF    |            | 0          | 0     |
| 208    | D0    |            | 0          | 0     |
| 209    | D1    |            | 0          | 0     |
| 210    | D2    |            | 0          | 0     |
| 211    | D3    |            | 0          | 0     |
| 212    | D4    |            | 0          | 0     |
| 213    | D5    |            | 0          | 0     |
| 214    | D6    |            | 0          | 0     |
| 215    | D7    |            | 0          | 0     |
| 216    | D8    |            | 0          | 0     |
| 217    | D9    |            | 0          | 0     |
| 218    | DA    |            | 0          | 0     |
| 219    | DB    |            | 0          | 0     |
| 220    | DC    |            | 0          | 0     |
| 221    | DD    |            | 0          | 0     |
| 222    | DE    |            | 0          | 0     |
| 223    | DF    |            | 0          | 0     |
| 224    | E0    |            | 0          | 0     |
| 225    | E1    |            | 0          | 0     |
| 226    | E2    |            | 0          | 0     |
| 227    | E3    |            | 0          | 0     |
| 228    | E4    |            | 0          | 0     |
| 229    | E5    |            | 0          | 0     |
| 230    | E6    |            | 0          | 0     |
| 231    | E7    |            | 0          | 0     |
| 232    | E8    |            | 0          | 0     |
| 233    | E9    |            | 0          | 0     |
| 234    | EA    |            | 0          | 0     |
| 235    | EB    |            | 0          | 0     |
| 236    | EC    |            | 0          | 0     |
| 237    | ED    |            | 0          | 0     |
| 238    | EE    |            | 0          | 0     |
| 239    | EF    |            | 0          | 0     |
| 240    | FF    |            | 0          | 0     |



## Technical Reference Note

Rev.06.20.20\_#1.0  
CSU1300AP Series  
Page 51

CSU1300AP series FRU (EEPROM) Data:

| OFFSET |       | DEFINITION<br>(REMARKS) | SPEC VALUE |       |
|--------|-------|-------------------------|------------|-------|
| (DEC)  | (HEX) |                         | (DEC)      | (HEX) |
| 241    | F1    |                         | 0          | 0     |
| 242    | F2    |                         | 0          | 0     |
| 243    | F3    |                         | 0          | 0     |
| 244    | F4    |                         | 0          | 0     |
| 245    | F5    |                         | 0          | 0     |
| 246    | F6    |                         | 0          | 0     |
| 247    | F7    |                         | 0          | 0     |
| 248    | F8    |                         | 0          | 0     |
| 249    | F9    |                         | 0          | 0     |
| 250    | FA    |                         | 0          | 0     |
| 251    | FB    |                         | 0          | 0     |
| 252    | FC    |                         | 0          | 0     |
| 253    | FD    |                         | 0          | 0     |
| 254    | FE    |                         | 0          | 0     |
| 255    | FF    |                         | 0          | 0     |


## PMBus™ Interface Support

The CSU1300AP series is compliant with the industry standard PMBus™ protocol for monitoring and control of the power supply via the I<sup>2</sup>C interface port.

### CSU1300AP Series PMBus™ General Instructions

#### Equipment Setup

The following is typical I<sup>2</sup>C communication setup:



## CSU1300AP Series Support PMBus™ Command List

The CSU1300AP series power supply is compliant with the industry standard PMBus™ protocol for monitoring and controlling the power supply via the I<sup>2</sup>C interface port.

CSU1300AP Series Supported PMBus™ Command List:

| Command Code | Command Name               | Default Value | Access Type | Data Bytes | Data Format | Description   |
|--------------|----------------------------|---------------|-------------|------------|-------------|---|
| 00h          | Page                       | 00            | R/W         | 1          | Hex         | Valid input: 00h  |
| 01h          | OPERATION                  | 80            | R           | 1          | Hex         | Used to turn the unit ON/OFF in conjunction with the input PSON pin   |
| 02h          | ON_OFF_CONFIG              | 1D            | R           | 1          | Bitmapped   | Unit needs CONTROL pin and OPERATION to power-up, where the CONTROL pin and OPERATION has to be asserted for start-up. There will be a minimum of 1mS delay time when the power supply is turned of remotely. |
| 03h          | CLEAR_FAULTS               | 00            | S           |            | N/A         |   |
| 05h          | PAGE_PLUS_WRITE            |               | BW          |            | N/A         |   |
| 06h          | PAGE_PLUS_READ             |               | BR          |            | N/A         |   |
| 19h          | CAPABILITY                 | 90            | R           | 1          | Bitmapped   | Provides a way for the hosts system to determine some key capabilities of a PMBus™ device.  |
|              | b7 - Packet Error Checking | 1             |             |            |             | 0 - PEC not supported<br>1 - PEC supported  |
|              | b6:5 - Maximum Bus Speed   | 00            |             |            |             | 00 - Maximum supported bus speed, 100KHz<br>01 - Maximum supported bus speed, 400KHz<br>10 - Maximum supported bus speed, 1MHz<br>11 - Reserved   |
|              | b4 - SMBALERT#             | 1             |             |            |             | 0 - SMBus Alert Pin not supported<br>1 - SMBus Alert Pin supported  |
|              | b3 - Numeric Format        | 0             |             |            |             | 0 - Linear11, Ulinear16, Slinear16, or Direct<br>1 - IEEE Half Precision Floating Point Format  |
|              | b2 - AVSBus                | 0             |             |            |             | 0 - AVSBus not supported<br>1 - AVSBus supported  |
|              | b1:0                       | 00            |             |            |             | Reserved  |
| 1Ah          | QUERY                      | -             | BR/BW       |            | N/A         | Used to determine if the PSU supports a specific command; It should return the proper information about any commands listed.  |
| 1Bh          | SMBALERT_MASK              | -             | BR/BW       |            | N/A         | Used with STATUS_INPUT, STATUS_TEMPERATURE, STATUS_IOUT   |
| 20h          | VOUT_MODE                  | 17            | R           | 1          | Bitmapped   | Specifies the mode and parameters of Output Voltage related Data Formats  |
| 30h          | COEFFICIENTS               |               | BW/BR       | 5          | Hex         | Use to retrieve the m, b and R coefficients, needed for DIRECT data format  |
|              | byte 5                     | 00            |             |            |             | R byte  |
|              | byte 4:3                   | 0000          |             |            |             | b low Byte, b high byte   |
|              | byte 2:1                   | 0000          |             |            |             | m low Byte, m high byte   |
| 3Ah          | FAN_CONFIG_1_2             | 90            | R           | 1          | Bitmapped   |   |
|              | b7                         | 1             |             |            |             | 0 - No fan is installed in position 1<br>1 - Fan is installed in position 1   |
|              | b6                         | 0             |             |            |             | 0 - Fan is commanded in DC<br>1 - Fan is commanded is RPM   |
|              | b5:4                       | 01            |             |            |             | 00 - 1 pulse per revolution<br>01 - 2 pulse per revolution<br>10 - 3 pulse per revolution<br>11 - 4 pulse per revolution  |
|              | b3:0                       | 0000          |             |            |             | Reserved  |

## CSU1300AP Series Supported PMBus™ Command List:

| Command Code | Command Name                        | Default Value | Access Type | Data Bytes | Data Format | Description  |
|--------------|-------------------------------------|---------------|-------------|------------|-------------|--|
| 3Bh          | FAN_COMMAND_1                       | 00            | R/W         | 2          | Linear      | Adjusts the operation of the Fans in DC. The device may override the command, if it requires higher value to maintain proper device temperature. 0x14 means 20% duty. And the fan speed is adjust by the PMW duty. The range is 20% ~100%. |
| 4Ah          | IOUT_OC_WARN_LIMIT                  | 125           | R/W         | 2          | Linear      | Sets the Over Current Warning Threshold in Amps. (125.00A)   |
| 51h          | OT_WARN_LIMIT                       | 115           | R/W         | 2          | Linear      | Secondary ambient temperature warning threshold, in degree C. Operating limit (115degC)  |
| 79h          | STATUS_WORD                         | -             | R           | 2          | Bitmapped   | Summary of units Fault and warning status.   |
|              | b15 - VOUT                          |               |             |            |             | An output voltage fault or warning has occurred  |
|              | b14 - IOUT/Pout                     |               |             |            |             | An Output current or power fault or warning has occurred.  |
|              | b13 - INPUT                         |               |             |            |             | An input voltage, current or power fault or warning as occurred.   |
|              | b12 - MFR_SPECIFIC                  |               |             |            |             |  |
|              | b11 - POWER_GOOD#                   |               |             |            |             | The POWER_GOOD signal is de-asserted   |
|              | b10 - FANS                          |               |             |            |             | A fan or airflow fault or warning has occurred.  |
|              | b9 - OTHER                          |               |             |            |             |  |
|              | b8 - UNKNOWN                        |               |             |            |             |  |
|              | b7 - BUSY                           |               |             |            |             | Not supported  |
|              | b6 - OFF                            |               |             |            |             | Unit is OFF  |
|              | b5 - VOUT_OV_FAULT                  |               |             |            |             | Not supported  |
|              | b4 - IOUT_OC_FAULT                  |               |             |            |             | Output over-current fault has occurred.  |
|              | b3 - VIN_UV_FAULT                   |               |             |            |             | An input under-voltage fault has occurred.   |
|              | b2 - TEMPERATURE                    |               |             |            |             | A temperature fault or warning has occurred.   |
|              | b1 - CML                            |               |             |            |             | A communication, memory or logic fault has occurred.   |
|              | b0 - NONE OF THE ABOVE              |               |             |            |             |  |
| 7Ah          | STATUS_VOUT                         | -             | R           | 1          | Bitmapped   |  |
|              | b7 - VOUT Over-Voltage Fault        | -             |             |            |             | VOUT Over-Voltage Fault  |
|              | b4 - VOUT Under-Voltage Fault       | -             |             |            |             | VOUT Under-Voltage Fault   |
| 7Bh          | STATUS_IOUT                         |               | R           | 1          | Bitmapped   |  |
|              | b7 - IOUT Overcurrent Fault         |               |             |            |             | IOUT Overcurrent Fault   |
|              | b5 - IOUT Overcurrent Warning       |               |             |            |             | IOUT Overcurrent Warning   |
|              | b1 - POUT_OP_FAULT                  |               |             |            |             | POUT_OP_FAULT  |
|              | b0 - POUT_OP_WARNING                |               |             |            |             | POUT_OP_WARNING  |
| 7Ch          | STATUS_INPUT                        |               | R           | 1          | Bitmapped   | Input related faults and warnings  |
|              | b7 - VIN_OV_FAULT                   |               |             |            |             | VIN Over voltage Fault   |
|              | b5 - VIN_UV_WARNING                 |               |             |            |             | VIN Under voltage Warning  |
|              | b4 - VIN_UV_FAULT                   |               |             |            |             | VIN Under voltage Fault  |
|              | b3 - Unit Off For Low Input Voltage |               |             |            |             | Unit is OFF for insufficient Input Voltage.  |
|              | b1 - IIN_OC_WARNING                 |               |             |            |             | IIN Overcurrent Warning  |
|              | b0 - PIN_OP_WARNING                 |               |             |            |             | PIN Overpower Warning  |

# Technical Reference Note

Rev.06.20.20\_#1.0  
CSU1300AP Series  
Page 55

## CSU1300AP Series Supported PMBus™ Command List:

| Command Code | Command Name                  | Default Value   | Access Type | Data Bytes | Data Format | Description  |
|--------------|-------------------------------|---|-------------|------------|-------------|--|
| 7Dh          | STATUS_TEMPERATURE            |   | R           | 1          | Bitmapped   | Temperature related faults and warnings  |
|              | b7 - Over temperature Fault   |   |             |            |             | Over temperature Fault   |
|              | b6 - Over temperature Warning |   |             |            |             | Over temperature Warning   |
| 80h          | STATUS_MFR_SPECIFIC           |   | R           | 1          | Hex         | 00h - no input<br>01h - AC input<br>02h - DC input                               |
| 81h          | STATUS_FANS_1_2               |   | R           | 1          | Bitmapped   |  |
|              | b7 - Fan1 Fault               |   |             |            |             | Fan1 Fault   |
|              | b5 - Fan1 Warning             |   |             |            |             | Fan1 Warning   |
|              | b3 - Fan1 Speed Overridden    |   |             |            |             | Fan1 Speed Overridden  |
| 86h          | READ_EIN                      |   | BR          | 6          | Direct      | Returns the accumulated input power over time.                                   |
| 87h          | READ_EOUT                     |   | BR          | 6          | Direct      | Returns the accumulated output power over time.                                  |
| 88h          | READ_VIN                      |   | R           | 2          | Linear      | Returns input Voltage in Volts ac.   |
| 89h          | READ_IIN                      |   | R           | 2          | Linear      | Returns input Current in Amperes.  |
| 8Bh          | READ_VOUT                     |   | R           | 2          | Linear      | Returns the actual, measured voltage in Volts.                                   |
| 8Ch          | READ_IOUT                     |   | R           | 2          | Linear      | Returns the output current in amperes.   |
| 8Dh          | READ_TEMPERATURE_1            |   | R           | 2          | Linear      | Returns the ambient temperature in degree Celsius.                               |
| 8Eh          | READ_TEMPERATURE_2            |   | R           | 2          | Linear      | Returns the hot pot temperature in degree Celsius.                               |
| 8Fh          | READ_TEMPERATURE_2            |   | R           | 2          | Linear      | Returns the hot pot temperature in degree Celsius.                               |
| 90h          | READ_FAN_SPEED_1              |   | R           | 2          | Linear      | Speed of Fan 1   |
| 96h          | READ_POUT                     |   | R           | 2          | Linear      | Returns the output power, in Watts.  |
| 97h          | READ_PIN                      |   | R           | 2          | Linear      | Returns the input power, in Watts.   |
| 98h          | PMBUS_REVISION                | 22  | R           | 1          | Bitmapped   | Reads the PMBus revision number  |
|              | b7:5                          | 0001  |             |            |             | Part 1 Revision<br>0000 - Revision 1.0<br>0001 - Revision 1.1                    |
|              | b4:0                          | 0001  |             |            |             | Part 2 Revision<br>0000 - Revision 1.0<br>0001 - Revision 1.1                    |
| 99h          | MFR_ID                        | ARTESYN###<br>##### (0x41<br>52 54 45 53 59<br>4E 23 23 23<br>23 23 23 23<br>23 ) | BR          | 15         | ASCII       | Abbrev or symbol of manufacturers name, ASCII format.                            |
| 9Ah          | MFR_MODEL                     | CSU1K3AP-3-600  | BR          | 14         | ASCII       | Manufacturers Model number, ASCII format   |
| 9Bh          | MFR_REVISION                  | NA  | BR          | 2          | ASCII       | "xx", where x is an alphanumeric character that represents the hardware revision |
| 9Ch          | MFR_LOCATION                  |   | BR          |            | ASCII       | Manufacturers facility, ASCII format   |
| 9Eh          | MFR_SERIAL                    |   | BR          | 14         | ASCII       | Unit serial number, ASCII format.  |
| 9Fh          | APP_PROFILE_SUPPORT           |   | RB          |            |             |  |
| A6h          | MFR_IOUT_MAX                  | 108   | RW          | 2          | Linear      | Maximum Output Current (108A)  |
| A7h          | MFR_POUT_MAX                  | 1300  | RW          | 2          | Linear      | Maximum Output Power (1300W)   |
| A8h          | MFR_TAMBIENT_MAX              |   | R           |            |             |  |

## CSU1300AP Series Supported PMBus™ Command List:

| Command Code | Command Name           | Default Value | Access Type | Data Bytes | Data Format | Description   |
|--------------|------------------------|---------------|-------------|------------|-------------|---|
| A9h          | MFR_TAMBIENT_MAX       |               | R           |            |             |   |
| C0h          | MFR_MAX_TEMP_1         | 78            | RW          | 2          | Linear      | Maximum ambient temperature (78degC)  |
| C1h          | MFR_MAX_TEMP_2         | 120           | RW          | 2          | Linear      | Maximum hot spot temperature (120degC)  |
| D0h          | Cold_Redundancy_Config | 00            | RW          |            |             | 00 - Normal<br>01 - Active<br>02 - Cold Standby 1<br>03 - Cold Standby 2<br>04 - Cold Standby 3<br>05 - Always Cold Standby |
| D4h          | MFR_HW_COMPATIBILITY   | 0             | BR/W        |            |             |   |
| D6h          | MFR_FWUPLOAD_MODE      |               | R/W         |            |             |   |
| D7h          | MFR_FWUPLOAD           |               | BW          |            |             |   |
| D8h          | MFR_FWUPLOAD_STATUS    |               | R           | 2          |             |   |
| D9h          | MFR_FW_REVISION        | varies        | BR          | 3          | Hex         | (MSB) = major revision; mid byte secondary revision, (LSB) = primary revision   |
| DCh          | MFR_BLACKBOX           |               | BR          | 230        |             |   |

## CSU1300AP Series Firmware Upload Command List:

The power supply uses the following command during the boatload process.


| Command Code | Command Name            | Default Value | Access Type | Data Bytes | Description   |
|--------------|-------------------------|---------------|-------------|------------|---|
| D4h          | MFR_HW_COMPATIBILITY    | -             | R           | -          | This is a COMPATIBILITY value used to tell if there are any changes in the FW that create an incompatibility with the FW. This value only changes when the PSU HW is changed creating an incompatibility with older versions of FW  |
| D5h          | MFR_FWUPLOAD_CAPABILITY | -             | R           | -          | The system can read the power supply's FW upload mode capability using this command. For any given power supply; more than one FW upload mode may be supported. The supported FW upload mode(s) must support updating all available FW in the power supply.<br>This power supply supports FW uploading in standby mode only.<br>Bit 0: "1" FW uploading in standby mode only<br>All other bits configurations are not supported   |
| D6h          | MFR_FWUPLOAD_MODE       | -             | R/W         | -          | Writing a 1 puts the power supply into firmware upload mode and gets it ready to receive the first image block via the MFR_FW_UPLOAD command. The system can use this command at any time to restart sending the FW image. Writing a 0 puts the power supply back into normal operating mode.<br>Writing a 1 restart<br>This command will put the PSU into standby mode if the PSU supports FW update in standby mode only.<br>If the power supply image passed to the PSU is corrupt the power supply shall stay in firmware upload mode even if the system requested the PSU to exit the FW upload mode.<br>Value:<br>0 = exit firmware upload mode<br>1 = firmware upload mode |
| D7h          | MFR_FWUPLOAD            |               | BW          |            | Command used to send each block of the FW image.  |
| D8h          | MFR_FWUPLOAD_STATUS     |               | R           | 2          | At any time during or after the firmware image upload the system can read this command to determine status of the firmware upload process.<br>All bits get reset to 0 when the power supply enters FW upload mode.<br>Bit 0: "1" full image received<br>Bit 1: "1" full image not received. This remains asserted until the full image is received<br>Bit 2: "1" bad or corrupt image received<br>Bit 3: For future use<br>Bit 4: "1" FW image is not supported and not received<br>Bit 5-15: Reserved  |
| D9h          | MFR_FW_REVISION         | NA            | BR          | 3          | Describes revisions of the FW<br>Block Read with PEC (3 bytes)<br>Byte 0: 0-255 Minor revision, secondary<br>Byte 1: 0-255 Minor revision, primary<br>Byte 3: 0-255<br>Bit 7: "1" Down grading of PSU FW has to be avoided; "0" no restriction in downgrading the PSU FW<br>Bit 0-6: Major revision   |

Noted: While the PSU FW image is being updated the PSU will blink the green LED at a 2 Hz rate.



## Firmware Update Process

BMC uses these commands to determine if FW needs updating:  
MFR\_FW\_REVISION  
MFR\_MODEL  
MFR\_FW\_UPLOAD\_MODE  
MFR\_FW\_COMPATIBILITY  
MFR\_FW\_UPLOAD\_CAPABILITY




### IMPORTANT!

- PSU may be in standby mode or ON mode during FW update process
- If the FW update process is interrupted at any point during the process; the PSU must always be able to return to the boot loader code.
- The PSU must always check that the application program is not corrupted before starting to run from the application program
- During the FW upload process the PSU must always respond to any communication on the bus; acknowledging its address and the supporting commands without holding the bus. For unsupported boot loader commands the PSU may respond with Not Acknowledge or 00h.
- BMC must configure correct addresses into ME at BMC startup to avoid bad PSU address config if AC power is lost or BMC is reset while the PSU update is in progress

## Application Notes


### Current Sharing

The CSU1300AP series' main output  $V_O$  is equipped with current sharing capability. This will allow up to 4 power supplies to be connected in parallel for higher power application. Current share accuracy is typically 5% when the load is larger than 20%.



### Output Ripple and Noise Measurement

The setup outlined in the diagram below has been used for output voltage ripple and noise measurements on the CSU1300AP Series. When measuring output ripple and noise, a scope jack in parallel with a  $0.1\mu\text{F}$  ceramic chip capacitor, and a  $10\mu\text{F}$  aluminum electrolytic capacitor should be used. Oscilloscope should be set to 20MHz bandwidth for this measurement.



## Record of Revision and Changes

| Issue | Date       | Description | Originators |
|-------|------------|-------------|-------------|
| 1.0   | 06.20.2020 | First Issue | K.Ma        |

### WORLDWIDE OFFICES

#### Americas

2900 South Diablo Way  
Suite B100  
Tempe, AZ 85282  
USA  
+1 888 412 7832

#### Europe (UK)

Ground Floor Offices  
Barberry House, 4 Harbour Buildings  
Waterfront West, Brierley Hill  
West Midlands, DY5 1LN, UK  
+44 (0) 1384 842 211

#### Asia (HK)

14/F, Lu Plaza  
2 Wing Yip Street  
Kwun Tong, Kowloon  
Hong Kong  
+852 2176 3333

**ARTESYN**<sup>TM</sup>  
An Advanced Energy Company  
[www.artesyn.com](http://www.artesyn.com)

Artesyn Embedded Technologies, Artesyn Embedded Power, Artesyn, and all Artesyn related logos are trademarks and service marks of Artesyn Embedded Technologies, Inc. All other names and logos referred to are trade names, trademarks, or registered trademarks of their respective owners. Specifications are subject to change without notice. © 2019 Artesyn Embedded Technologies, Inc. All rights reserved. For full legal terms and conditions, please visit [www.artesyn.com/legal](http://www.artesyn.com/legal).

For more information: [www.artesyn.com](http://www.artesyn.com)  
For support: [productsupport.ep@artesyn.com](mailto:productsupport.ep@artesyn.com)

# Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Artesyn Embedded Technologies:](#)

[CSU1300AP-3-600](#)