






THIS IS ISSUED IN STRICT CONFIDENCE  
THAT IT IS NOT USED AS A BASIS FOR  
MANUFACTURE OR SALE AND THAT IT IS  
NOT COPIED, REPRINTED OR  
DISCLOSED TO A THIRD PARTY EITHER  
WHOLLY OR IN PART WITHOUT THE  
PRIOR WRITTEN CONSENT OF CAL TEST  
ELECTRONICS, INC.

ASSEMBLY INSTRUCTIONS:

1. SLIDE CRIMP SLEEVE ONTO CABLE JACKET
2. STRIP COAXIAL CABLE END 
3. INSERT CENTER CONDUCTOR INTO PIN HOLE DIAMETER
4. CRIMP OR SOLDER PIN TO CENTER CONDUCTOR
5. FLARE THE OUTER CONDUCTOR BRAID
6. INSERT CONTACT PIN FIRMLY INTO POSITION IN THE BNC CONNECTOR
7. ENSURE THE OUTER CONDUCTOR BRAID SEATS PROPERLY AND UNIFORMLY AROUND THE OUTER SURFACE OF THE BNC CRIMP POST
8. SLIDE SLEEVE OVER BRAID AND POST
9. CRIMP SLEEVE TO THE BNC CRIMP POST USING THE APPROPRIATE CRIMPING TOOL



|        |           |           |            |       |           |          |        |
|--------|-----------|-----------|------------|-------|-----------|----------|--------|
| METRIC | APPROVALS |           | DATE       | SIZE  | CAGE CODE | DWG. NO. | REV.   |
|        | DRAWN     | GSG       | 10/25/2023 | B     | 43F45     | CT4506   | A      |
|        | CHECKER   | B. HANSEN | 10/25/2023 | SCALE | 2:1       | SHEET    | 2 OF 2 |

# Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Cal Test Electronics:](#)

[CT4506](#)