# QS18AFF40 Mechanically Adjustable Foreground Suppression Sensor (15-40mm)




### **Features**


Compact sensors featuring precise adjustment of cutoff distance and foreground suppression mode

- · Short-range models for precise adjustment of cutoff distance
- Exceptional optical performance; 15 mm to 40 mm adjustable range in compact QS18 housing
- Foreground suppression models for reliable detection when a fixed background is present and the object color or shape varies
- · Objects detected to the face of the sensor (no dead zone)
- · Simple multi-turn screw adjustment of cutoff distance
- · Enhanced immunity to fluorescent lights
- · Crosstalk immunity algorithm allows two sensors to be used in close proximity
- Visible red emitter



#### WARNING:





This device does not include the self-checking redundant circuitry necessary to allow its use in personnel safety applications. A device failure or malfunction can cause either an energized (on) or de-energized (off) output condition.

# Models

Models	Supply Voltage	Sensing Range	Output Type
QS18VN6AFF40		15 to 40 mm adjustable range	NPN
QS18VP6AFF40	10 to 30 V DC		PNP
QS18AB6AFF40			Bipolar (1 NPN and 1 PNP)

Only standard 2 m (6.5 ft) cable models are listed.

- To order 9 m (30 ft) cable models: add suffix "W/30" to the model number (for example, QS18VN6AFF40 W/30)
- To order 150 mm (6 in) pigtail with a 4-pin M8 models: add suffix "Q" to the model number (for example, QS18VN6AFF40Q); accessory mating cordset required, see "Quick-Disconnect (QD) Cordsets "on page 7.
- To order 150 mm (6 in) pigtail with a 4-pin M12 models: add suffix "Q5" to the model number (for example, QS18VN6AFF40Q5);
  accessory mating cordset required, see " Quick-Disconnect (QD) Cordsets " on page 7.


### Overview

- 1. Green: Power Indicator
- 2. Amber: Light Sensed Indicator (Flashes for Marginal Conditions)
- 3. Cutoff Point Adjustment Screw

The WORLD-BEAM QS18AFF40 Adjustable Field Sensor with Foreground Suppression detects the light reflected from the background. The output changes when the light from the background is blocked.

In general, if the background is fixed and the color or shape of the objects in the foreground varies, foreground suppression mode will provide reliable detection. A foreground suppression sensor uses the background in the same way a retroreflective sensor would use a reflector. The sensor output changes when an object passes between the sensor and the background.

The short-range models offer precise cutoff capability for short-range applications. With an adjustable cutoff distance of 15 to 40 mm, thinner objects closer to the background can be detected with even sharper background suppression.




# Installation Instructions

### Sensor Orientation

To ensure reliable detection, orient the sensor as shown in relation to the target to be detected.




Optimal Orientation of Target to Sensor



# Wiring

Cabled wiring diagrams are shown. Quick disconnect wiring diagrams are functionally identical.



In dark operate (DO) mode, the output is ON when the target returns less light to the sensor than the configured target and OFF when the sensor detects more light than the configured/taught target.

In light operate (LO) mode, the output is ON when the target returns the same or more light to the sensor and OFF when the sensor detects less light than the configured/taught target.

In adjustable field sensing modes, light operate is active when the target is present and dark operate is active when the target is absent.


### Configure the QS18AF with Foreground Suppression (FGS)

X: Distance to Background

Y: Minimum Separation Between Object and Background

Foreground Suppression Mode (also called Background Detection): The light reflected off the background is detected. The output changes when the light from the background is blocked. In general, if the background is fixed and the color or shape of the objects in the foreground vary, foreground suppression mode will provide reliable detection. A foreground suppression sensor uses the background in the same way a retroreflective sensor would use a reflector. The sensor output will change whenever an object passes between itself and the background.

To ensure reliable foreground suppression, a minimum separation distance between the object and the background is necessary. See to determine the minimum separation distance.




- 1. Mount the sensor within 30 mm mm of the fixed background.
- 2. Turn the adjustment potentiometer clockwise until it clicks (5 turns).
- 3. Turn the adjustment potentiometer **counter-clockwise** until the yellow indicator turns **on**. This places the cutoff distance in front of the fixed background.
- 4. Place the application's darkest object into the sensor's field of view at the maximum sensor to the object distance and verify that the yellow indicator turns **off**. The sensor is optimized for detecting thin objects close to the fixed background and is ready for operation. For maximum sensing reliability in applications with variations in background position or color (for example, conveyor belts with flutter), follow these additional steps.
  - a. Turn the adjustment potentiometer counter-clockwise, counting the revolutions, until the yellow indicator turns on.
  - b. Turn the adjustment potentiometer **clockwise** half the number of revolutions from the previous step. This places the cutoff distance midway between the object and the background. The sensor is optimized for reliable detection in applications with thick objects and modest variation in background.

The sensor is ready for operation.

# Example QS18AF FGS Configuration

Foreground Suppression Mode application example



- 1. Object
- 2. Background (Conveyor)
- X: Distance to Background = 30 mm
- Y: Minimum Separation Between Object and Background > 0.7 mm

The sensor is positioned above a black conveyor belt at a distance of 30 mm. The objects on the conveyor are boxes of varying colors. According to the *Minimum Separation Distance* figure in , the box height must be greater than 0.7 mm for reliable detection against a black background. In this application, reliable detection will be achieved when set up according to the procedure outlined in .

### **Output States**

Foreground Suppression Mode				
Sensor Model Type	Output	Object Between Sensor Face and Cutoff Distance	No Object Between Sensor Face and Fixed Background	
All Models	Yellow Indicator Light	OFF	ON	
O. and an artist Martit	Black Wire (Pin 4)	OFF	ON	
Complementary Models	White Wire (Pin 2)	ON	OFF	
Disales Madela	Black Wire (Pin 4)	OFF	ON	
Bipolar Models	White Wire (Pin 2)	OFF	ON	

# Specifications

### Supply Voltage

10 V DC to 30 V DC (10% maximum ripple within specified limits) at less than 16 mA, exclusive of load

#### Sensing Beam

Visible red LED, 630 nm

#### **Supply Protection Circuitry**

Protected against reverse polarity and transient voltages

#### **Output Configuration**

Solid-state complementary: NPN or PNP (current sinking or sourcing), or bipolar (both sinking and sourcing) depending on model;

Rating: 100 mA total output current

Off-state leakage current: < 50 µA at 30 V dc

**ON-state saturation voltage:** < 1.5 V at 10 mA; < 3.0 V at 100

nΑ

Protected against false pulse on power-up and continuous overload or short circuit of outputs

#### **Application Notes**

For mirror-like objects, minimize the sensor-to-object mounting distance and tilt the sensor so reflected light is directed away from the sensor when the object is present.

#### Construction

ABS housing, acrylic lens cover; PVC cable, nickel-plated brass connector, metal adjustment pot

#### **Output Response**

2.8 millisecond ON/OFF

**Note:** 200-millisecond delay on power-up; outputs do not conduct during this time

#### **Adjustments**

Five-turn adjustment screw sets cutoff distance between min. and max. positions clutched at both ends of travel

#### Repeatability

250 µs

#### **Indicators**

Two LED indicators on sensor top:

Green solid: Power on Amber solid: Light sensed

Amber flashing: Marginal sensing condition

### **Environmental Rating**

IEC IP67; NEMA 6; UL Type 1

#### Connections

2 m (6.5 ft) 4-wire PVC cable, 9 m (30 ft) PVC cable, or 4-pin M8 or M12 150 mm (6 in) cable quick-disconnect connector, depending on model

#### **Operating Conditions**

Relative Humidity: 95% relative humidity at 50 °C (non-

condensing)

Temperature: -20 °C to 55 °C (-4 °F to 131 °F)

#### Certifications



Banner Engineering BV Park Lane, Culliganlaan 2F bus 3 1831 Diegem, BELGIUM



Turck Banner LTD Blenheim House Blenheim Court Wickford, Essex SS11 8YT GREAT BRITAIN



#### **Required Overcurrent Protection**



**WARNING:** Electrical connections must be made by qualified personnel in accordance with local and national electrical codes and regulations.

Overcurrent protection is required to be provided by end product application per the supplied table.

Overcurrent protection may be provided with external fusing or via Current Limiting, Class 2 Power Supply.

Supply wiring leads < 24 AWG shall not be spliced.

For additional product support, go to www.bannerengineering.com.

Supply Wiring (AWG)	Required Overcurrent Protection (A)	Supply Wiring (AWG)	Required Overcurrent Protection (A)
20	5.0	26	1.0
22	3.0	28	0.8
24	2.0	30	0.5

### FCC Part 15 Class A for Unintentional Radiators

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

(Part 15.21) Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.


# Industry Canada ICES-003(A)

This device complies with CAN ICES-3 (A)NMB-3(A). Operation is subject to the following two conditions: 1) This device may not cause harmful interference; and 2) This device must accept any interference received, including interference that may cause undesired operation.


Cet appareil est conforme à la norme NMB-3(A). Le fonctionnement est soumis aux deux conditions suivantes : (1) ce dispositif ne peut pas occasionner d'interférences, et (2) il doit tolérer toute interférence, y compris celles susceptibles de provoquer un fonctionnement non souhaité du dispositif.

### **Dimensions**


All measurements are listed in millimeters [inches], unless noted otherwise. The measurements provided are subject to change.




# **Performance Curves**




Minimum Separation Distance Between Object and Background








X: Distance to Background (mm)

Y: Minimum Separation Between Object and Background (mm)











### Accessories

# Quick-Disconnect (QD) Cordsets

Use the M8 cordsets with QS18 with Q suffix; use the M12 cordsets with QS18 with Q5 suffix.

4-Pin Single-Ended Snap-on M8 Female Cordsets					
Model	Length	Style	Dimensions	Pinout (Female)	
PKG4-2	2.03 m (6.66 ft)	Straight	32 Typ. — 1 4 9.0	4 2 1 = Brown 2 = White 3 = Blue 4 = Black	






# **Mounting Brackets**

All measurements are listed in millimeters, unless noted otherwise. The measurements provided are subject to change.

#### SMBQS18A

- · Wrap-around protection bracket
- Die-cast bracket
- Base fits 18 mm threaded hole
- · Metal hex nut, lock washer and grommet included
- · Mounting holes specially designed for QS18AF sensors


**Hole size:** A = Ø 15.3



#### SMBQS18AF

- · Right-angle mounting bracket
- 14-ga. 304 stainless steel

Hole center spacing: A to B = 20.3 Hole size: A =  $4.3 \times 9.4$ , B =  $\emptyset 4.3$ 



# **Product Support and Maintenance**

### Clean Sensor with Compressed Air Then Isopropyl Alcohol

Handle the sensor with care during installation and operation. Sensor windows soiled by fingerprints, dust, water, oil, etc. create stray light that may degrade the peak performance of the sensor.

Blow dust from the sensor using filtered, compressed air. If the sensor is still dirty, gently wipe the sensor with a dry optical cloth. If the dry optical cloth does not remove all residue, use 70% isopropyl alcohol on a clean optical cloth, then dry with a clean dry optical cloth and blow with filtered, compressed air. Do not use any other chemicals for cleaning.

### Contact Us

Banner Engineering Corp. | 9714 Tenth Avenue North | Plymouth, MN 55441, USA | Phone: + 1 888 373 6767

For worldwide locations and local representatives, visit www.bannerengineering.com.

### Banner Engineering Corp Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to:

For patent information, see www.bannerengineering.com/patents.